




Allen-Bradley

9/PC CNC Lathe

Operation and Programming Manual



Important User Information

Because of the variety of uses for the products described in this publication, those responsible for the application and use of this control equipment must satisfy themselves that all necessary steps have been taken to assure that each application and use meets all performance and safety requirements, including any applicable laws, regulations, codes and standards.

The illustrations, charts, sample programs and layout examples shown in this guide are intended solely for purposes of example. Since there are many variables and requirements associated with any particular installation, Allen-Bradley does not assume responsibility or liability (to include intellectual property liability) for actual use based upon the examples shown in this publication.

Allen-Bradley publication SGI-1.1, *Safety Guidelines for the Application, Installation, and Maintenance of Solid-State Control* (available from your local Allen-Bradley office), describes some important differences between solid-state equipment and electromechanical devices that should be taken into consideration when applying products such as those described in this publication.

Reproduction of the contents of this copyrighted publication, in whole or in part, without written permission of Allen-Bradley Company, Inc., is prohibited.

Throughout this manual we use notes to make you aware of safety considerations:



ATTENTION: Identifies information about practices or circumstances that can lead to personal injury or death, property damage or economic loss.

Attention statements help you to:

- identify a hazard
- avoid the hazard
- recognize the consequences

Important: Identifies information that is critical for successful application and understanding of the product.

9/Series and 9/PC are trademarks of Allen-Bradley Company, Inc.
Windows NT, Visual Basic Pro, Word for Windows, Excel, and DDE are trademarks of Microsoft Inc.
Procom is a trademark of Datastorm Technologies Inc.
IBM is a trademark of the International Business Machine Co.
RSLink, RSData, RSJunctionBox, RSTools, and AdvanceDDE are trademarks of Rockwell Software
Etherlink III is a trademark of 3Comm inc

Summary of Changes

New Information

The following is a list of the larger changes made to this manual since its last printing. Other less significant changes were also made throughout.

- Capability of using two 1394 drives
- Addition of 1394-related error messages

Revision Bars

We use revision bars to call your attention to new or revised information. A revision bar appears as a thick black line on the outside edge of the page.



Chapter 1 Using this Manual

Overview	1-1
Audience	1-1
Manual Design	1-1
Attentions and Important Information	1-3
Reading this Manual	1-3
Terms and Conventions	1-4
Additional Publications	1-5
Technical Support	1-5
When You Call	1-6

Chapter 2 Basic Control Operation

Chapter Overview	2-1
Proper Startup and Shutdown of the 9/PC CNC	2-1
Starting the 9/PC	2-1
Stopping the 9/PC	2-2
Stopping the 9/PC Using the Configuration Manager	2-2
Stopping the 9/PC Using Windows NT	2-2
Uncontrolled Shutdowns	2-2
What is the Basic Display Set (BDS)?	2-3
Launching the Basic Display Set (BDS)	2-3
A Tour of the Basic Display Set	2-5
Power Up Conditions	2-6
Pulldown Menus	2-6
File Menu	2-7
Options Menu	2-7
Using the Softkeys	2-8
Inputting Text	2-10
Performing CNC Functions from the PC Keyboard	2-11
Reset Operations	2-11
Block Reset	2-11
Control Reset	2-11
Calculator Function	2-12
Paramacro Variables in CALC Operations	2-15
Navigating through the Display	2-16
The Push-button MTB Panel	2-16
Power Procedures	2-18
Starting the Basic Display Set	2-18
Stopping the Basic Display Set	2-20
Control Conditions at Power-Up	2-20
Emergency Stop Operations	2-21
Emergency Stop Reset	2-22
Access Control	2-23
Assigning Access Levels and Passwords	2-23
Password-protectable Functions	2-26
Entering Passwords	2-28

Changing Operating Modes	2-29
Manual Mode	2-29
MDI Mode	2-30
Automatic Mode	2-31
Displaying System and Machine Messages	2-31
Clearing Active Messages {CLEAR ACTIVE}	2-33
{REFORM MEMORY}	2-34
Removing an Axis (Axis Detach)	2-35
Time Parts Count Display Feature	2-35
Time Part Screen Field Definitions	2-37
Part Program Storage	2-39
Choosing a Part Program Directory	2-40
Copying Part Programs Between Drives	2-40
Part Program Sizes	2-42
Cycling Power	2-42

Chapter 3 Offset Tables and Setup

Chapter Overview	3-1
Tool Offset Tables {TOOL GEOMET} and {TOOL WEAR}	3-1
Tool Offset Numbers	3-2
Tool Dimensional Parameters	3-3
Tool Length (Tool Geometry Table)	3-3
Tool Tip Radius - TTR (Tool Geometry Table)	3-4
Tool Length (Wear Table)	3-5
Tool Tip Radius Compensation - TTRC (Wear Table)	3-5
Tool Orientation Parameters	3-5
Setting Tool Offset Tables	3-8
Setting Offset Data Using {MEASURE}	3-11
Tool Offset Range Verification	3-12
When Does Verification Occur?	3-13
Verify for Maximum Value	3-13
Verify for Maximum Change	3-14
Changing the Active Tool Offset {ACTIVE OFFSET}	3-14
Work Coordinate System Offset Table {WORK CO-ORD}	3-15
Zero Point Parameters	3-15
External Offset	3-15
Setting Work Coordinate System Data	3-16
Backing Up Offset Tables	3-18
Programmable Zone Table	3-20

Chapter 4 Manual/MDI Operation Modes

Chapter Overview	4-1
Manual Operating Mode	4-1
Jogging an Axis	4-2
Continuous Jog	4-3
Incremental Jog	4-3
Jog Offset	4-4
Resetting Overtravels	4-5

Mechanical Handle Feed (Servo Off)	4-6
Removing an Axis (Axis Detach)	4-6
Manual Machine Homing	4-7
MDI Mode	4-9
MDI Basic Operation	4-10

Chapter 5 Editing Programs Online

Chapter Overview	5-1
Creating a Part Program	5-2
Subprograms and Paramacros	5-2
Using Layered Softkeys	5-3
Using Online Help	5-3
Selecting the Program To Edit	5-4
Editing a Part Program	5-5
Using Cut & Paste	5-6
Including a Part Program	5-7
Saving and Exiting	5-8
Using the Line Editor	5-8
Line Editor Dimensions	5-8
Navigating through the Line Editor	5-8
Entering Blocks	5-10
Creating a New Line	5-10
Creating a Blank Line	5-10
Deleting Lines	5-11
Recovering Lines	5-11
Numbering Lines	5-11
Using the Search Softkey	5-12
Configuring the Cycle Editor	5-13
Using the Cycle Editor (Quick View)	5-15
Displaying the Cycle Prompts	5-15
Available Cycles	5-18
Modifying an Existing Cycle Block	5-19
Deleting a Program {DELETE}	5-19
Renaming Programs {RENAME}	5-20
Displaying a Program {DISPLY PRGRAM}	5-21
Displaying Comments {PRGRAM COMENT}	5-21
Copying Programs {COPY PRGRAM}	5-23
Selecting the Protectable Part Program Directory	5-24

Chapter 6 Editing Programs Offline

Chapter Overview	6-1
Selecting the Part Program Application	6-2
Editing Part Programs Offline	6-2
Downloading Part Programs from ODS	6-5
UPLOAD Part Programs to ODS	6-9

Chapter 7 Running a Program

Chapter Overview	7-1
Selecting Special Running Conditions	7-1
Block Delete	7-1
Miscellaneous Function Lock	7-1
Sequence Stop {SEQ STOP}	7-2
Single Block	7-3
Selecting a Part Program Input Device	7-4
Selecting a Part Program	7-5
Deselecting a Part Program	7-7
Program Search {SEARCH}	7-8
Search with Recall {MID ST PROGRAM}	7-10
Basic Program Execution	7-14
(1) Pressing <CYCLE STOP>	7-15
(2) Execution of an M00 or M01 in a Part Program	7-15
(3) Entering a Sequence Stop Number	7-15
(4) Feedhold Status	7-15
QuickCheck	7-16
Axis Inhibit Mode	7-17
Dry Run Mode	7-18
Part Production/Automatic Mode	7-19
Programmable Block Execution	7-21
Synchronous Mode (G60)	7-22
Asynchronous Mode (G60.1)	7-22
Autosynchronous Mode (G60.2)	7-23
Interrupted Program Recover {RESTRT PRGRAM}	7-24
Jog Retract	7-27
Block Retrace	7-30

Chapter 8 Data Display

Chapter Overview	8-1
Selection of Axis Position Data Display	8-1
{PROGRAM}	8-3
{PROGRAM} (Large Display)	8-3
{ABS}	8-4
{ABS} (Large Display)	8-4
{Target}	8-5
{Target} (Large Display)	8-5
{DTG}	8-6
{DTG} (Large Display)	8-6
{AXIS SELECT}	8-7
{M CODE STATUS}	8-7
{PROGRAM DTG}	8-8
{ALL}	8-9
{G CODE STATUS}	8-10
Changing Languages	8-10
Power Turn-on Screen	8-11
Editing the System Integrator Message Lines	8-11

Chapter 9 Introduction to Programming

Chapter Overview	9-1
Program Configuration	9-1
Program Names	9-3
Entering Program Names	9-3
Sequence Numbers	9-4
Comment Blocks	9-4
Block Delete and Multilevel Delete	9-5
End of Block Statement	9-6
Using Subprograms	9-6
Subprogram Call (M98)	9-7
Main and Subprogram Return	9-8
Using M99 in a Main Program	9-8
Using M99 in a Subprogram	9-8
Subprogram Nesting	9-9
Word Formats and Functions	9-10
Leading Zero and Trailing Zero Suppression	9-11
Using LZS and TZS with G-codes	9-12
Programming without Numeric Values	9-13
Word Descriptions and Ranges	9-13
Minimum and Maximum Axis Motion (Programming Resolution)	9-15
Word Descriptions	9-15
Axis Names	9-15
A_L_R_C (QuickPathPlus Words)	9-15
F-Words (Feedrates)	9-16
G-Codes (Preparatory Functions)	9-17
I J K Integrand Words	9-22
M-Codes (Miscellaneous Functions)	9-22
(1) Program Stop (M00)	9-24
(2) Optional Program Stop (M01)	9-24
(3) End of Program (M02)	9-24
(4) End of Program, Tape Rewind (M30)	9-24
(5) Overrides Enabled (M48)	9-24
(6) Overrides Disabled (M49)	9-25
(7) Constant Surface Speed Mode Disabled (M58)	9-25
(8) Constant Surface Speed Mode Disabled (M59)	9-25
(9) Subprogram Call (M98)	9-25
(10) End of Subprogram or Main Program Auto Start (M99)	9-25
2nd Miscellaneous Function (B-Word)	9-26
N-Words (Sequence Numbers)	9-27
O-Words (Program Names)	9-27
P, L Words (Main Program Jumps and Subprogram Calls)	9-27
S-Words (Spindle Speed)	9-28
T-Words (Tool Selection and Tool Length Offset)	9-29

Chapter 10 Basic Control Operation

Chapter Overview	10-1
Machine (Absolute) Coordinate System	10-1
Motion in the Machine Coordinate System (G53)	10-2
Preset Work Coordinate System (G54 - 59.3)	10-4
Altering Work Coordinate System (G10L2)	10-7
Incremental/Absolute Mode and the G10L2 Command	10-8
Work Coordinate System External Offset	10-9
Altering External Offset (G10L2)	10-10
Offsetting the Work Coordinate Systems	10-12
Coordinate Offset Using Tool Position (G92)	10-12
Offsetting Coordinate Zero Points (G52)	10-15
Set Zero Offset	10-16
Jog Offset	10-17
Canceling Coordinate System Offsets (G92.1)	10-18
Canceling Selected Coordinate System Offsets (G92.2)	10-20
Logic Offsets	10-20

Chapter 11 Overtravels and Programmable Zones

Chapter Overview	11-1
Hardware Overtravels	11-2
Software Overtravels	11-3
Programmable Zone 2	11-5
Programmable Zone 3	11-7
Programming Zone 3 Values (3 or fewer axes)	11-9
Programming Zone 3 Values (4 or more axes)	11-10
Resetting Overtravels	11-12

Chapter 12 Coordinate Control

Chapter Overview	12-1
Plane Selection (G17, G18, G19)	12-1
Absolute/Incremental Modes (G90, G91)	12-2
Lathe G-code, System A	12-3
Inch/Metric Modes (G70, G71)	12-4
Radius/Diameter Modes (G07, G08)	12-4
Scaling	12-6
Scaling Axis Position Display Screens	12-9
Scaling Magnification Data Screen	12-9
Scaling Restrictions	12-11

Chapter 13 Axis Motion

Chapter Overview	13-1
Positioning Axes	13-1
Rapid Positioning Mode (G00)	13-1
Linear Interpolation Mode (G01)	13-3
Circulate Interpolation Mode (G02, G03)	13-4
Positioning Rotary Axes	13-8
Programming in absolute or incremental	13-9
Determining Rotary axis feedrates	13-10
Logic Axis Mover	13-11
Automatic Motion to and from Machine Home	13-11
Automatic Machine Homing (G28)	13-11
Automatic Machine Homing (G28) with Distance Coded Markers	13-12
Automatic Return to Machine Home (G28)	13-13
Automatic Return from Machine Home (G29)	13-15
Machine Home Return Check (G27)	13-16
Move to Alternate Home (G30)	13-17
Dwell (G04)	13-18
Dwell - Seconds	13-18
Dwell - Number of Spindle Revolutions	13-18
Mirror Image (G50.1, G51.1)	13-19
Programmable Mirror Image (G50.1, G51.1)	13-19
Manual Mirror Image	13-21
Axis Clamp	13-22

Chapter 14 Using QuickPath Plus

Chapter Overview	14-1
Programming QuickPath Plus	14-1
Linear QuickPath Plus	14-2
No End Coordinate Known (L)	14-4
No Intersection Known	14-5
Circular QuickPath Plus (G13, G13.1)	14-6
Linear to Circular blocks	14-7
Circular to Linear blocks	14-8
Circular to Circular blocks	14-9

Chapter 15 Chamfering and Corner Radius

Chapter Overview	15-1
Chamfering	15-2
Corner Radius	15-3
Considerations with Chamfering and Corner Radius	15-5

Chapter 16 Spindles

Chapter Overview	16-1
Spindle Speed Control	16-1
Spindle Speed (S-word)	16-2
Constant Surface Speed (G96)	16-3
Notes on Constant Surface Speed	16-6
RPM Spindle Speed Mode (G97)	16-7
Controlling Spindles (G12.1, G12.2)	16-8
Spindle Orientation (M19, M19.2)	16-9
Spindle Direction (M03, M04, M05)	16-11
Virtual C Axis	16-11
Virtual C Programming Restrictions	16-12
Virtual C Axis, Cylindrical Interpolation	16-13
Cylindrical Interpolation Block Format	16-14
Cylindrical Interpolation Operation	16-16
Virtual C Axis, End Face Milling	16-18
End Face Milling Block Format	16-19
End Face Milling Operation	16-20
Synchronized Spindles	16-21
Spindle Configuration	16-21
Selecting the Controlling Spindle	16-22
Using the Spindle Synchronization Feature	16-22
Activate Spindle Positional Synchronization (G46)	16-22
Activate Spindle Speed Synchronization (G46.1)	16-24
Deactivate Spindle Synchronization (G45)	16-24
Special Considerations for Spindle Synchronization	16-25

Chapter 17 Programming Feedrates

Chapter Overview	17-1
Feedrates	17-1
Feedrates Applied During TTRC	17-2
Feed Per Minute Mode (G94)	17-3
Feed Per Revolution Mode (G95)	17-4
Rapid Feedrate	17-5
Feedrate Overrides	17-6
<RAPID FEEDRATE OVERRIDE>	17-6
Feedrate override switches disable	17-7
Feedhold	17-7
Feedrate Limits (Clamp)	17-7
Special AMP-assigned Feedrates	17-8
External Deceleration Feedrate Switch	17-8
Automatic Acceleration/Deceleration	17-9
Exponential Acc/Dec	17-10
Linear Acc/Dec	17-11
S-Curve Acc/Dec	17-12
Programmable Acc/Dec	17-13
Selecting Linear Acc/Dec Modes (G47.x -- modal)	17-14
Selecting Linear Acc/Dec Values (G48.n -- nonmodal)	17-14

Precautions on Corner Cutting	17-15
Exact Stop (G09 -- nonmodal)	17-16
Exact Stop Mode (G61 -- modal)	17-16
Cutting Mode (G64 -- modal)	17-16
Tapping Mode (G63 -- modal)	17-17
Automatic Corner Override (G62 -- modal)	17-17
Spindle Acceleration (Ramp)	17-18
Short Block Acc/Dec Check (G36, G36.1)	17-18

Chapter 18 Dual Axis Operation

Overview	18-1
Parking a Dual Axis	18-3
Homing a Dual Axis	18-4
Homing Axes Individually	18-4
Homing Axes Simultaneously	18-5
Programming a Dual Axis	18-5
Invalid Operations on a Dual Axis	18-6
Offset Management for a Dual Axis	18-7
Preset Work Coordinate Systems (G54-G59.3)	18-7
G52 Offsets	18-7
G92 Offsets	18-7
Set Zero	18-8
Cutter Compensation	18-8
Tool Length Offsets	18-8

Chapter 19 Tool Control Functions

Chapter Overview	19-1
T-words and Tool Length Offsets	19-1
Programming a T-word and Tool Offsets	19-2
Activating Tool Length Offsets	19-4
Entering Tool Offset Data Using (G10L10, G10L11)	19-5
Random Tool	19-7
Manually Entering Random Tool Data	19-7
Programming Random Tool Data	19-9
Clearing the Random Tool Table	19-9
Format for Programming Random Tool Table	19-10
Backup Random Tool Table	19-10
Starting a Program with a Tool Already Active	19-11
Automatic Tool Life Management	19-12
Tool Directory Data	19-13
Assigning Tool Numbers to Groups	19-13
Tool Life Measurement Type	19-14
Tool Life Threshold Percentage	19-14
Entering Tool Group Data	19-15
Assigning Detailed Tool Data	19-17
Tool Length and Diameter/Radius Offset Number	19-17
Expected Tool Life	19-17
Entering Specific Tool Data	19-18

Programming Data and Backing Up Tool Management Tables (G10L3, G11)	19-20
Backing Up Tool Management Tables	19-23
Programming a T-word Using Tool Management	19-23

Chapter 20

Tool Tip Radius Compensation (TTRC) Function

Chapter Overview	20-1
Programming TTRC	20-4
TTRC Generation Blocks G39, G39.1	20-7
TTRC Tool Paths (Type A)	20-9
TTRC Type A Entry Moves	20-9
TTRC Type A Exit Moves	20-13
TTRC Tool Paths (Type B)	20-18
TTRC Type B Entry Moves	20-19
TTRC Type B Exit Moves	20-23
Tool Path During TTRC	20-29
TTRC Special Cases	20-34
Changing TTRC Direction	20-34
Too Many Nonmotion Blocks	20-38
Corner Movement After Generated Blocks	20-39
Changing Cutter Radius During Compensation	20-41
Change in Cutter Radius During Jog Retract.	20-43
MDI or Manual Motion During TTRC	20-45
Moving to/from Machine Home	20-47
Changing or Offsetting Work Coordinate System in TTRC	20-48
Block Look-ahead	20-49
Error Detection	20-49
Backwards Motion Detection	20-50
Circular Departure Too Small	20-50
Interference	20-51
Disabling Error Detection	20-51

Chapter 21

Single-pass Turning Cycles

Chapter Overview	21-1
Single-pass O.D. and I.D. Roughing Cycle (G20)	21-2
G20 Straight O.D. and I.D. Roughing	21-3
G20 Taper O.D. and I.D. Roughing	21-4
Single-pass Rough Facing Cycle (G24)	21-7
G24 Straight Facing	21-8
G24 Tapered Facing	21-10

Chapter 22

Grooving/Cutoff Cycles

Chapter Overview	22-1
Face Grooving Cycle (G76)	22-3
O.D. & I.D. Grooving Cycle (G77)	22-6

Chapter 23 Compound Turning Routines

Chapter Overview	23-1
O.D. and I.D. Roughing Routine (G73)	23-2
Case 1:	23-3
Case 2:	23-3
G73 Tool Paths, Case 1	23-8
G73 Tool Paths, Case 2	23-10
Rough Facing Routine (G74)	23-14
Case 1:	23-15
Case 2:	23-16
G74 Tool Paths, Case 1	23-21
G74 Tool Paths, Case 2	23-24
Casting/Forging Roughing Routine (G75)	23-27
O.D. and I.D. Finishing Routine (G72)	23-34

Chapter 24 Thread Cutting

Chapter Overview	24-1
Considerations for Thread Cutting	24-2
Chamfering Your Threads	24-4
Using Thread Retract	24-5
Thread Chamfer and Thread Retract Parameters	24-5
Single Pass Threading Mode (G33)	24-6
Single Pass Variable Lead Thread Cutting (G34)	24-12
Single Pass Threading Cycle (G21)	24-15
Straight Thread Cutting	24-16
Taper Thread Cutting	24-18
O.D. & I.D. Multipass Threading Routine (G78)	24-20
Programming Multipass Thread Cutting	24-20
Tool Infeed	24-22

Chapter 25 Drilling Cycles

Chapter Overview	25-1
Drilling Cycles	25-1
Positioning and Hole Machining Axes	25-4
Parameters	25-7
Drilling Cycle Operations	25-8
(G80): Cancel or End Fixed Cycles	25-8
(G81): Drilling Cycle, No Dwell/Rapid Out	25-8
(G82): Drill Cycle, Dwell/Rapid Out	25-10
(G83): Deep Hole Drilling Cycle	25-11
(G83.1): Deep Hole Peck Drilling Cycle with Dwell	25-13
(G84): Right-Hand Tapping Cycle	25-14
(G84.1): Left-Hand Tapping Cycle	25-17
(G84.2): Right-Hand Solid-Tapping Cycle	25-19
(G84.3): Left-Hand Solid-Tapping Cycle	25-22
(G85): Boring Cycle, No Dwell/Feed Out	25-24
(G86): Boring Cycle, Spindle Stop/Rapid Out	25-26

(G86.1): Boring Cycle, Tool Shift	25-27
Method I	25-29
Method II	25-29
(G87): Back Boring Cycle	25-30
Method I	25-31
Method II	25-31
(G88): Boring Cycle, Spindle Stop/Manual Out	25-32
(G89): Boring Cycle, Dwell/Feed Out	25-34
Altering Drilling Cycle Parameters	25-35
Examples of Drilling Cycles	25-37

Chapter 26 Skip and Gauge Probing Cycles

Chapter Overview	26-1
External Skip Functions (G31 codes)	26-2
Skip Function Application Example	26-3
Tool Gauging External Skip Functions (G37 codes)	26-3
Tool Gauging Application Example	26-5

Chapter 27 Paramacros

Chapter Overview	27-1
Parametric Expressions	27-2
Basic Mathematical Operators	27-2
Mathematical Function Commands	27-3
Parametric Expressions as G- or M-codes	27-5
Transfer of Control Commands	27-6
Conditional Operators	27-7
GOTO and IF-GOTO Commands	27-8
Unconditional GOTO	27-8
Conditional IF-GOTO	27-8
DO-END and WHILE-DO-END Commands	27-9
Unconditional DO-END	27-9
Conditional WHILE-DO-END	27-10
Parameter Assignments	27-11
Local Parameter Assignments	27-11
Considerations for Local Parameters	27-12
Common Parameters	27-14
System Parameters	27-14
#2001 to 8801 Tool Offset Tables	27-16
#3000 Program Stop With Message (Logic)	27-16
#3001 System Timer (Logic)	27-17
#3002 System Clock	27-17
#3003 Block Execution Control 1	27-17
#3004 Block Execution Control 2	27-18
#3006 Program Stop With Message	27-18
#3007 Mirror Image	27-19
#4001 to 4120 Modal Information	27-19
#5001 to 5008 Coordinates of End Point	27-20
#5021 to 5028 Coordinates of Commanded Position	27-20

#5041 to 5048 Machine Coordinate Position	27-20
#5061 to 5068 Skip Signal Position Work Coordinate Position	27-21
#5071 to 5078 Skip Signal Position Machine Coordinate System	27-21
#5081 to 5088 Active Tool Length Offsets	27-21
#5095 to 5096 Probe stylus Length and Radius	27-22
#5101 to 5108 Current Following Error	27-22
#5201 to 5208 External Offset Amount	27-22
#5221 to 5386 Work Coordinate Table Value	27-23
#5630 S-Curve Time per Block	27-24
#5631 to 5638 Acceleration Ramps for Linear Acc/Dec Mode	27-24
#5651 to 5658 Deceleration Ramps for Linear Acc/Dec Mode	27-24
#5671 to 5678 Acceleration Ramps for S-Curve Acc/Dec Mode	27-25
#5691 to 5698 Deceleration Ramps for S-Curve Acc/Dec Mode	27-25
#5711 to 5718 Jerk	27-25
Logic Parameters	27-26
Input Flags:	27-26
Output Flags:	27-27
Assigning Parameter Values	27-28
Assigning Parameters Using Arguments	27-28
Direct Assignment Through Programming	27-30
Direct Assignment Through Tables	27-31
Addressing Assigned Parameters	27-34
Backing Up Parameter Values	27-34
Macro Call Commands	27-35
Nonmodal Paramacro Call (G65)	27-36
Modal Paramacro Call (G66)	27-37
Modal Paramacro Call (G66.1)	27-39
AMP-defined G-code Macro Call	27-41
AMP-defined M-code Macro Call	27-42
AMP-defined T-, S-, and B-code Macro Call	27-42
Nesting Macros	27-43

Appendix A Softkey Tree

Appendix Overview	A-1
Understanding Softkeys	A-1
Describing Level 1 Softkeys	A-2
Using the Softkey Tree	A-3

Appendix B Error and System Messages

Overview	B-1
----------------	-----

Appendix C G-code Tables

Appendix Overview	C-1
G-code Tables	C-1

Using this Manual

Overview

This chapter describes how to use this manual. Major topics include:

- how the manual is organized and what information can be found in it.
- how this manual is written and what fundamentals are presumed to be understood by reader.
- definitions for certain key terms.

Audience

We created this manual for Allen-Bradley 9/PC CNC programmers and/or operators. We assume that you are familiar with the following:

- operating and programming a CNC
- 9/PC standard front panel
- operating a personal computer
- AMP programming
- the Offline Development System (ODS)

Manual Design

We organized this manual in as follows:

For information about:	Refer to:
how to locate control features	chapter 2
how to operate the control	chapters 3 - 9
how to program the control	chapters 10 - 27
softkeys	appendix A
error and operator messages in alphabetical order	appendix B
standard G-codes used to program the control	appendix C

We placed section headings in the left margin of each page, and included illustrations and examples as aids in programming and operating the control.

Table 1.A provides a summary of each chapter.

**Table 1.A
Manual Organization**

Chapter	Title	Summary
1	Manual Overview	Manual overview, intended audience, definition of key terms, how to proceed.
2	Basic Control Operation	A brief description of the control's basic operation including power up, MTB panel, operator panel, access control, and E-Stop.
3	Offset Tables and Setup	Basic setup of the offset table, other initial operating parameters.
4	Manual and MDI Operation	How to use the manual operate mode including, homing the machine, jog hand-wheel, jog continuous, and jog increment. Also covered are the basics for MDI operation.
5	Editing Programs On Line	How to create, edit, and save a part program on line.
6	Editing Part Program Off Line	How to create, edit, and save a part programs from ODS off line.
7	Running a Program	How to select and execute a program automatically. This covers program checking as well as part production. Also details on special running conditions.
8	Data Display	How to access and interpret the different position displays. How to use the Quick Check and Active Program graphics features.
9	Introduction to Programming	Structure and format of the programming language for the control.
10	Basic Control Operation	Machine coordinate system, Preset Work coordinate systems, logic offsets, and external offsets
11	Overtravels and Programmable Zones (G22, G23)	Hardware and software overtravels, programmable zone 2 (G22, G23), programmable zone 3 (G22.1, G23.1), and resetting overtravels
12	Coordinate Control	Describes absolute/incremental modes, inch/metric modes, radius/diameter modes, and scaling
13	Axis Motion	G-words define how the tool is positioned to the endpoint of a move. Also sections on automatic machine home, dwell, mirroring, and axis clamp
14	Using QuickPath Plus	Describes QuickPath Plus programming
15	Chamfering and Corner Radius	Describes the ,C- and ,R-words programmed for chamfering and corner radius
16	Spindles	Describes spindle speed control, spindle orientation, spindle direction, and Virtual C axis
17	Programming Feedrates	Describes acc/dec, AMP-assigned feedrates, feedrate control, short block acc/dec
18	Dual Axis Operation	Describes parking, homing, programming, offset management for a dual axis
19	Tool Control Functions	Selecting a tool. Activating and deactivating tool length offsets. Also tool control features such as Random Tool and Tool Life Management.
20	Tool Tip Radius Compensation (TTRC) Function	Describes the Tool Tip Radius Compensation feature (TTRC) that offsets for different tool diameters.
21	Single-pass Turning Cycles	Describes and use of fixed cycles (canned cycles) for turning operations, and the G-codes and parameters used to define them.
22	Grooving/Cutoff Cycles	
23	Compound Turning Routines	
24	Thread Cutting	
25	Drilling Cycles	
26	Skip and Gauge Probing Cycles	Describes the 9/PC Probing features. Includes the tool measuring gauge feature.
27	Paramacros	Describes paramacros including calling, arithmetic functions, looping, decision making
Appendix A	Softkeys	Describes softkeys and their functions for softkey levels 1 and 2. Also the softkey tree displaying all levels of softkeys and their location is shown.
Appendix B	Error and Operator Messages	An alphabetical listing of 9/Series and 9/PC system messages with brief descriptions.
Appendix C	G and M Code Tables	Lists the G-codes used to program the control.

Attentions and Important Information

We indicate information that is especially important by the following:



ATTENTION: indicates circumstances or practices that can lead to personal injury as well as to damage to the control, the machine, or other equipment.

Important: indicates information that is necessary for successful application of the control.

Reading this Manual

To make this manual easier to understand, we included these explanations of terms and symbols:

- All explanations, illustrations, and charts presented are based on standard CNC functions. Operations may differ from the basic information provided in this manual depending on the configuration of the machine tool. For details, refer to the manuals prepared and supplied by the system installer.
- Some of the softkey functions may be purchased as optional features. This manual assumes that all of the optional features have been purchased.
- Explanations and illustrations are presented based on the movement of the cutting tool on a fixed workpiece.
- 9/PC allows the use of any alphabetic character for expressing a numerically controlled axis. This manual uses X, Y, and Z for the first, second, and third axes on the basic coordinate system respectively. I, J, and K represent the integrand words for the axes.
- The term AMP is an abbreviation for Adjustable Machine Parameters. These parameters are used to configure the 9/PC. Setting of AMP is usually done by the system installer.
- Key names designated between the [] symbols are found on your computer's keyboard.
- Key names designated between the { } symbols are softkeys found on the Basic Display Set.
- Switch and button names on the DeviceNet MTB panel are designated between the < > symbols.
- The term "logic" refers to the SoftLogix 5™ logic engine that processes signals to the 9/PC. It is usually programmed by the system installer.
- System Characteristics:
 - Metric
 - Absolute
 - IPM

Terms and Conventions

In this manual, we use acronyms and shortened product names and features. Shortened terms used in this manual include:

- 9/PC — A CNC PCI card that provides a full-featured open 9/Series motion control solution.
- AMP — Adjustable Machine Parameters
- API — Application Programming Interface
- BDS — Basic Display Set. This software provides the user interface between your PC and CNC by emulating 9/Series standard screens. The software allows you to control, program, position, and monitor your 9/PC.
- CNC — Computerized Numerical Control
- Control — The 9/PC CNC
- CPU — Central processing unit
- DDE — Dynamic data exchange. This allows two applications to share data.
- Device — Any DeviceNet-compatible device
- DRAM — Dynamic random access memory
- E-Stop — Emergency stop
- Flash Memory — Nonvolatile, programmable memory that resides on the CPU board. This memory backs up such things as paramacro tool offsets and work coordinates, and AMP and retains information even after a power failure.
- Hard drive — Any storage location defined by your system installer. In this manual, hard drive refers to the storage space located on the PC.
- HMI — Human-machine interface
- Host Computer — The PC housing your 9/PC card.
- I/O — Input/output
- Layered softkeys — The row of keys located on the bottom of the line and cycle editor screens
- OCI — Open Control Interface. Originating as a 9/Series product, OCI provides an open HMI for existing CNCs.
- ODS — Offline Development Software. This is application software used to create, download, and upload configuration for your 9/PC CNC.
- OLE — Object-linked embedding. This standard provides the ability to link/embed objects created with one application to another application.
- OPC — OLE for process control. This is a means of data exchange between applications.
- Logic — The Logic engine the SoftLogix 5 engine
- PC — Personal Computer

- PCI — Peripheral component interconnect. This is a means of connecting peripheral devices to your PC.
- PCIDS — Peripheral component interconnect device scanner
- PELV — Protected Extra Low Voltage
- Project — A directory that stores configuration, interface, and motion control files for a particular control or application.
- RAM — Random access memory
- SELV — Safety Extra Low Voltage
- SERCOS — Serial Real-time Communication System
- Softkey — A row of keys located directly below the operator panel screen on the BDS.
- System installer — The company or contractor responsible for installing your 9/PC control.
- Topic Name — The name designated to your 9/PC CNC that is entered in the Common tab of the Configuration Manager. This topic name is shared by the API, AMP, and Logic.
- UPS — Uninterruptable Power Supply

Additional Publications

The following publications are available from Allen-Bradley and can be helpful when using your 9/PC system.

Pub. No.	Document Name
MCD-5.1	9/Series CNC Offline Development System (ODS) User's Manual
8520-1.9	9/PC CNC Product Profile
8520-6.6	9/Series CNC API Developer's Guide
8520-9.1	9/PC CNC Installation and Integration Manual
8520-9.2	9/PC CNC Logic Reference Manual
8520-9.3	9/PC CNC AMP Reference Manual
8520-9.4	9/PC CNC Lathe Operation and Programming Manual
8520-9.5	9/PC CNC Mill Operation and Programming Manual

Technical Support

Before you contact technical support, try to find the answer to your question in your 9/PC-related documentation (refer to the table on page 1-5). If you can not find the answer to your question, technical support is available on the World Wide Web and by phone:

- World Wide Web: <http://SUPPORTBBS.RA.ROCKWELL.COM>
- Telephone Technical Support: 1 (440) 646-6800, available 8:00 AM to 5:00 PM EST, Monday through Friday (with the exception of holidays)

When You Call

When you call, make sure you are at the computer running the 9/PC CNC. Be prepared to provide the following information:

Information	Location
9/PC Processor card serial number	Label on 9/PC processor card or via the <i>9/PC Configuration Manager</i> screen. In the latter case, click the Windows NT Start button. Select Programs ⇒ Rockwell Automation ⇒ 9pc ⇒ Configuration Manager . If the 9/PC is running, press {Stop 9/PC} . Important: The CNC must be in E-Stop. Select the 9/PC Configuration tab. Click {Edit CNC} and read the serial number from the opposite field. Click {OK} , select the 9/PC Operation tab, and click {Start 9/PC} to restart your 9/PC.
SoftLogix 5 serial number	SoftLogix 5 activation disk label or from the the Registration field on the SoftLogix 5 Status Monitor screen, which appears when you click on the SoftLogix 5 LED status in the Windows NT system tray.
9/PC Executive software revision number	Press the {SYSTEM SUPPORT} softkey on the BDS screen, the {→} softkey, and then the {PTOM SI/OEM} softkey. Alternatively, you can also read the 9/PC software version from the 9/PC Installation disk's label.
9/PC PC software revision number	Click the {Version Information} button on the 9/PC Configuration Manager screen. To view this screen, click the Windows NT Start button ⇒ Programs ⇒ Rockwell Automation ⇒ 9pc ⇒ Configuration Manager .
SoftLogix 5 software revision number	Go to the SoftLogix 5 Status Monitor screen by clicking on the SoftLogix 5 LED status in the Windows NT system tray. Select {Config} . This takes you to the SoftLogix 5 Configuration Manager screen. Click on the {Version Info} button. Alternatively, you can also read SoftLogix 5 version number from the SoftLogix 5 Installation disk's label.
ODS software revision number	Start ODS. Press the [F1] key. Select "About" with the arrow cursor keys, and press [Enter] .
Miscellaneous <ul style="list-style-type: none"> • A description of what was happening with the system when the problem occurred • A description of how you tried to solve the problem • The exact wording of any messages that appear on the screen, the CNC Error Log, and Windows NT Event Log • The hardware you are using (i.e., PC make and model, type of I/O) 	

END OF CHAPTER

Basic Control Operation

Chapter Overview

This chapter describes how to operate the Allen-Bradley 9/PC control, including:

Topic:	On page:
Starting and Stopping the 9/PC	2-1
The Basic Display Set	2-3
Input Cursor	2-10
MTB Panel	2-16
Power-up	2-18
Emergency Stops	2-21
Access Control	2-23
Changing Modes	2-29
Display System and Messages	2-31
{REFORM MEMORY}	2-34
Removing an Axis	2-35
Time Part Count	2-35

We also tell you about the control conditions automatically assumed at power up.

Proper Startup and Shutdown of the 9/PC CNC

Prior to starting the Basic Display Set, you must start your 9/PC via the 9/PC Configuration Manager.

Starting the 9/PC

To properly start your 9/PC CNC:

1. Click the **Windows NT Start** button and select **Programs**.
2. Click on **Rockwell Automation** to choose the **9pc** option.
3. Select **Configuration Manager** to start the 9/PC Configuration Manager.
4. Select the **{start 9/PC}** button.

The **{start 9/PC}** button becomes ghosted when 9/PC is running.

Important: After initially loading the 9/PC executive and the 9/PC card, on the 9/PC Configuration Manager, **{Start 9/PC}** and **{Stop 9/PC}** appear ghosted and NOT CONFIGURED appears in the **Serial Number** dialog box. Once you make the association between the CNC and the serial number, **{Start 9/PC}** becomes available (unghosted). Refer to your *9/PC Installation and Integration Manual* (8520-9.1) for more information.

Stopping the 9/PC

There are two preferred methods through which your 9/PC can be shut down: via the Configuration Manager or via Windows.

Stopping the 9/PC Using the Configuration Manager

1. Select the Windows NT **Start** button and select **Programs**.
2. Click on **Rockwell Automation** to choose the **9pc** option. Select **Configuration Manager** to start the 9/PC Configuration Manager.
3. Select the **{Stop 9/PC}** button.

Stopping the 9/PC Using Windows NT

1. Select the Windows NT **Start** button.
2. Click on the **Shut Down...** option.



ATTENTION: Improper and uncontrolled shutdowns will cause loss of BBU data. If your 9/PC is not shut down via one of the user-controlled methods described on page 2-2, the system uses the last known BBU data profile (i.e., tool offsets, paramacs, axis calibration, work coordinates, tool management, error log, and AMP data). Any lost data will have to be regenerated by the user.

Uncontrolled Shutdowns

Although the 9/PC does not require the use of battery backup memory, we recommend that you use an uninterruptible power supply (UPS) to protect your CNC data from uncontrolled shutdown sequences (e.g., power loss).

The UPS is an external device that is able to keep your PC running for a prescribed amount of time after the main power is shut down, while ensuring that no vital CNC data is lost after a system power off. For information about restoring data after an uncontrolled shutdown, refer to your UPS documentation. For more information about UPS devices with relation to your 9/PC, refer to your *9/PC Integration and Installation Manual* (8520-9.1).

In the event of a power loss or an improper shutdown, the message “BBU SAVE FAILED, USING LAST VALID DATA” indicates lost BBU data. You may also review the **Windows NT Event Log**. If the Event Log indicates that your system was improperly shut down, the BBU data that you use will have the last known profile that your system stored. Any lost data will have to be regenerated by the user.

What is the Basic Display Set (BDS)?

The Basic Display Set is a compiled executable Visual Basic™ program written to provide a 9/Series compliant operator interface on the PC. With BDS, you can create, edit, and save part programs on your PC. The editor has a new interface and functions differently than the 9/Series standard front panel version. Refer to page 5-9 for more information about navigating through the editor.

Important: If you want to configure the displays for your specific applications, the Visual Basic source code is available. See your system installer for details.

Use the Basic Display Set in the Windows NT™ operating environment to provide a graphical interface to your CNC. The following is a list of enhanced features:

- Updated editor graphics and editing capabilities
- Extended part program storage on the PC
- AMP development
- Optional application program interface (API package) customized user displays and graphics can be created

Launching the Basic Display Set (BDS)

Basic Display Set screens are installed on your personal computer as part of the 9/PC CNC software installation.

Your application may have additional screens created by your system integrator that are not a part of BDS. This manual describes only those screens that are a part of BDS.

Important: Although you may operate BDS without having any other software activated, you should complete the recommended software installations (including configuration) to use BDS with your 9/PC system. Refer to the *9/PC Installation and Integration Manual* for more information about software installation.

You must activate the Basic Display Set through the 9/PC Configuration Manager. To launch BDS:

1. Click the **Windows NT Start** button and select **Programs**. Click on **Rockwell Automation** to choose the **9pc** option. Select **Configuration Manager** to start the 9/PC Configuration Manager.
2. Select the **9/PC Operation** tab if it is not already selected. Select the **{start 9/PC}** button to activate the CNC.


Important: You must start the 9/PC CNC prior to starting BDS. Activating BDS before starting 9/PC, causes the following message to appear:



3. Select the **{Start BDS}** button on the 9/PC Configuration Manager. The **Allen-Bradley OCI File Handler** and **OCI Data Server** icons should appear on the task bar.




ATTENTION: If these program icons do not appear, check the Event Log for messages that may indicate the reason(s) for the icon's absence. If the problem persists after making the necessary changes, contact A-B Customer Support.




A Tour of the Basic Display Set

Most of the screens look very similar to those available with the 9/Series standard front panel. The first screen that appears is the power turn-on screen, similar to the one below.



Press any key to clear this screen. You see the screen that displays the axis position:



Power Up Conditions

When powering up BDS, you have the same screen size, password level, last active program directory, and font size as in the previous session.

Pulldown Menus

At the top of the BDS window is a menu bar, which contains the File and Options pulldown menus. These two pulldown menus allow you to manipulate BDS.

To access the File or Options pulldown menus:

1. Point your mouse or pointing device to the menu name.
2. Press your left mouse button to display the contents below the menu item.
3. Point to the desired menu item and release the mouse button.

You can also access the pulldown menus using the keyboard:

Use this Key Combination:	To Select the:
[ALT] + F	File menu
[ALT] + O	Options menu

File Menu

Selecting the **F**ile menu allows you to access the exit option.
Choosing **E**xit closes BDS.





ATTENTION: Closing BDS **DOES NOT** stop the 9/PC.



Options Menu

Selecting the **O**ptions menu gives you access to **C**ontrol **C**NC, **S**elect **C**NC, and **S**ize options.





Select CNC - allows you to change the CNC that BDS is connected to, while displaying the name of each CNC configured in your 9/PC Configuration Manager file. To select a specific CNC:


- click on the CNC name in the Select CNC box with your pointing device. Choose the OK button on the bottom of the screen. Your selection is now activated.

OR

- double click on the desired CNC name in the Select CNC box. Your selection is now activated.

To cancel your selection, choose the CANCEL button on the bottom of the Select CNC screen.

Size - allows you to change the width of the window you are currently working in. Window widths are based on the configured resolution of your computer monitor. The higher the resolution, the larger selection of window sizes you have.



Important: The size option is only available while softkey level 1 is displayed. Attempting to modify the screen size on any other softkey level causes an error.


Using the Softkeys

We use the term softkey to describe the row of 7 keys at the bottom of the BDS. Each function is displayed on the screen directly above the softkey. In this manual, softkey names are shown between the { } symbols.

BDS offers a variety of functions that can be initiated by using the softkeys. There are five softkeys whose function names are displayed in the softkey area at the bottom of the screen (lines 23-25). Move through BDS with the softkeys at the bottom of the screen. There are two ways to select these softkeys:

- using the function keys (F2-F8) on your keyboard
- with a pointing device (e.g., a mouse)

To access a softkey, use your keyboard or pointing device to select the appropriate function key.



We often describe softkeys as being on a certain level, for example softkey level 3. We use the level of the softkey to determine the location or necessary path to reach that particular softkey function. For example, to get to a softkey on level 3, you must press a specific softkey on level 1, followed by a specific softkey on level 2. For a listing of all the softkeys and their respective levels, refer to appendix A.

Softkey level 1 is the initial softkey level the control displays at power-up. Softkey level 1 always remains the same and all other levels are referenced from softkey level 1.


The softkeys on opposite ends of the softkey row have a specific use that remains standard throughout the different softkey levels.

On the:	Is the:
left	exit softkey displayed with the up arrow {↑}
right	continue softkey displayed with the right arrow {⇒}

- Use the exit softkey {↑} on the far left to regress softkey levels. For example, if you are currently on softkey level 3 and you press the exit softkey, the softkeys change to the softkeys previously displayed on softkey level 2. When you press the exit softkey while holding down the shift key, the softkey display is returned to softkey level 1 regardless of the current softkey level.
- When more than 5 softkey functions are available on the same level, the control activates the continue {⇒} softkey at the far right of the softkey area. When you press the continue softkey, the softkey functions change to the next set of softkeys on that level.


Important: The continue softkey is not active when the number of softkey functions on that level does not exceed 5.

For example:



When softkey level 1 is reached, the above set of softkeys is displayed. Pressing the continue softkey {⇒} displays the remaining softkey functions on softkey level 1.

(softkey level 1)




The exit softkey is not displayed since the softkeys are already on softkey level 1.

The softkey functions for level 1 and level 2 are explained in appendix A. Softkey functions for level 3, or higher, are explained in the sections that apply to their specific operations.

Important: Some of the softkey functions are purchased as optional features. This manual assumes that all available optional features have been purchased for the machine. If an option is not purchased, the softkey is blank.

Inputting Text

The input cursor is the cursor located on line 2 of the screen. It is available when you need to input data by using your keyboard (as needed in MDI mode, for example). The following section is a description of how to move the cursor and edit data on the input line by using the keys on the operator panel.



For BDS screens that require you to enter data, use the input line, as in the 9/Series standard front panel. To move through the input lines, use the arrow keys.

Cursor Operation:	Description:
Clearing error messages	To clear error messages from BDS, press the [TAB] or [DEL] key. Keep in mind that using your keyboard to clear an error message does not correct the error condition.
Deleting characters	To delete characters on the input lines move the cursor to the right of the character to delete. Pressing the [BACKSPACE] key deletes the character to the left of the cursor in the input line.
Deleting all characters on the input line	To delete all entered characters on the input lines press the [BACKSPACE] key while holding down the [SHIFT] key. All characters on the input line are deleted.
Sending information	To send information to the control from input line press the [ENTER] key. All information on the input line is sent to the control.

Performing CNC Functions from the PC Keyboard

The 9/Series operator panel has a keyboard with keys assigned for specific CNC functions. The Basic Display Set includes special key mapping so you can perform these functions on your PC keyboard:

If you want to:	press this on your PC keyboard:	the correlating key sequence on the 9/Series operator panel is:
enable the calculator function on the control	[F9]	Calculation Key [CALC]
delete the character to the left of the cursor on the input line(s)	[BACK SPACE]	[DEL]
toggle through the editor's layered softkeys	[F10]	N/A
clear the latest active error message	[DEL] or [TAB]	[CAN]
send the data entered on the input lines to the control	[ENTER] or [RETURN]	[TRANSMIT]
perform a block reset	[F11]	[RESET]
perform a control reset	[SHIFT] and [F11]	[RESET] + [SHIFT]
display mode selection softkeys	[F12]	[DISP SELECT]
enter an end-of-block character when writing an MDI program	[;]	[E.O.B]

The following subsections provide more information on specific function operations (e.g., calculator or block reset).

Reset Operations

Block Reset

Use the block reset feature to force the control to skip the block execution. To use the block reset function, program execution must be stopped. If program execution stops before the control has completely finished the block execution, a block reset aborts any portion of that block that has not been executed. If program execution stops after the complete block execution (as in the case of single block execution or a M00 etc.), the control aborts the execution of the entire following block.

Press the [**F11**] key on your keyboard to perform a block reset.

Control Reset

You can return the control to the default parameters, clear any programming errors, and cancel any MDI commands by executing a control reset. After you execute a control reset, any active program resets to the first block; any programmed offsets or rotations of the coordinate systems reset to default, and any MDI command is discarded. All of the operating parameters return to the standard AMP-assigned values, including any AMP-assigned G-codes active at power-up (except Inch/Metric which remains in its last programmed state at control reset).

Hold down the [**SHIFT**] and [**F11**] keys to execute a control reset.

Calculator Function

The 9/PC CNC is equipped to evaluate simple mathematical expressions during the course of operation or programming.

To use the calculator function, line 2 of the screen must be blank. There can be no prompt on the input line of the screen when you attempt to do calculations. This completely disables any calculation operation when in MDI mode. If you attempt to enter the calculator function while another prompt is active, the control generates the error message "CANNOT CALCULATE - PROMPT PRESENT."

Use the calculator function as follows:

1. Press the [**F9**] key on your keyboard. The "CALC:" prompt appears on the input line of the screen (line 2).
2. Enter a mathematical equation on the input line by pressing the desired keys on the operator panel.
3. Press the [**ENTER**] key to evaluate the expression. The answer to the expression is displayed on the input line.

Expressions entered on the input line cannot exceed a total of 25 characters. Only numeric or special mathematical operation characters as described below can be entered next to the "CALC:" prompt. Any character that is not numeric or an operation character you enter on the input line generates the error message "INVALID CHARACTER."

The largest number you can enter for a calculate function is 214748367. You cannot enter a number larger than 10 digits. If you enter a number that is too large (longer than 10 digits), the control displays the error message "NUMBER IS OUT OF RANGE". If the number entered or calculated is greater than 10 digits, control displays the error message "MATH OVERFLOW."

Any fractional numbers cannot exceed .999999 (6 decimal places). If you exceed this number of decimal places, the control automatically rounds off. If this seventh digit is less than 5, the control rounds down. If this seventh digit is 5 or greater, the control rounds up.

Any data entered on the input lines can be edited as described on page 2-10.

To disable the calculator function, press the [**F9**] key again. The "CALC:" prompt is removed from the input line.

Use the characters in Table 2.A to indicate mathematical operations.

Table 2.A
Mathematical Operators

*	Multiplication
/	Division
+	Addition
-	Subtraction
[]	Brackets
#	Get Paramacro Value

The control executes mathematical operations in this order:

1. Any part of the expression that is between the brackets [] is evaluated first. The values of paramacro variables are also substituted for the #xxxx as the first operation performed.
2. Multiplication and division are evaluated second.
3. Addition and subtraction are evaluated last.

If the same level of evaluation is performed the left most operation takes priority.

Example 2.1
Mathematic Expressions

Expression Entered	Result Displayed
12/4*3	9
12/[4*3]	1
12+2/2	13
[12+2]/2	7
12-4+3	11
12-[4+3]	5

Table 2.B lists the function commands available with the [F9] key.

Table 2.B
Mathematical Functions

Function	Meaning
SIN	Sine (degrees)
COS	Cosine (degrees)
TAN	Tangent (degrees)
ATAN	Arc Tangent (degrees)
ASIN	Arc Sine (degrees)
ACOS	Arc Cosine (degrees)
SQRT	Square Root
ABS	Absolute Value
BIN	Conversion from Decimal to Coded Decimal
BCD	Conversion from Coded Decimal to Decimal
ROUND	Rounding Off (nearest whole number)
FIX	Truncation Down
FUP	Truncation Up
LN	Logarithms (natural log)
EXP	Exponent

When you program these functions, place the value that the function is to be performed on in brackets, for example, SIN [10]. The exception to this is the arc tangent function. The format for ATAN requires the division of two values. For example, ATAN [10]/[2] is used to calculate the arc tangent of 5.

The functions in Table 2.B are executed from left to right in a program block. These functions are executed before the control executes any mathematical operators like addition or subtraction. This order of execution can only be changed by enclosing operations in brackets []. Operations enclosed in brackets are executed first.

Example 2.2
Format for [CALC] Functions

SIN[2]	This evaluates the sine of 2 degrees.
SQRT[14+2]	This evaluates the square root of 16.
SIN[SQRT[14+2]]	This evaluates the sine of the square root of 16.

Example 2.3 Mathematical Function Examples

Expression Entered	Result
SIN[90]	1.0
SQRT[16]	4.0
ABS[-4]	4.0
BIN[855]	357.0
BCD[357]	855.0
ROUND[12.5]	13.0
ROUND[12.4]	12.0
FIX[12.7]	12.0
FUP[12.2]	13.0
FUP[12.0]	12.0
LN[9]	2.197225
EXP[2]	7.389056

Important: Precaution must be taken when performing calculations within the brackets []. The operations within the bracket are performed first, and then the function is performed on this resultant. For example:

ROUND[2.8+2.6]; The result of this is 5.0

The values in the brackets are added together first and then rounded, not rounded and then added together.

Paramacro Variables in CALC Operations

Any paramacro variable can be accessed through the CALC function. Include a # sign followed by the paramacro variable number. When the calculation is performed the value of that paramacro variable is substituted into the equation. You can not change the value of paramacro variables with the CALC function. Local parameters are only available for the currently active nesting level of the control (main program, or one of four nested macro programs). You can not perform calculations that contain any paramacro variables if the control is currently executing a program block. The control must be in either cycle stop state, or E-Stop.

Example 2.4 Calling Paramacro Variables with the CALC Function

Expression Entered	Result Displayed
#100	Display current value of variable #100
12/#100*3	Divide 12 by the current value of #100 and multiply by 3
SIN[#31*3]	Multiply the value of #31 (for the current local parameter nesting level) by 3 and take the sine of that result

Navigating through the Display

If you choose, you can purchase a 9/PC CNC bundle pack that contains an LCD (10.4-in.) with or without a touch screen. Both have identical displays and graphics capabilities.

Certain lines of the screen are dedicated to displaying specific information:

Lines:	Display information:
line 1 machine/ system message area	If an error occurs or a message is generated for any reason during machine operation or program execution, the control displays the corresponding machine/system message in this area. Only the highest priority, most current message is displayed here.
line 2 input lines	When you enter data using the keyboard, the control displays the characters corresponding to the keys pressed until you press the [ENTER] key.
lines 4-20 data display area	The control displays axis position data, listing of the part program, tool offset data, G-, M-, H-, T-, F-, S-, and D-codes, and other data, as determined by the selected display. Refer to chapter 8.
lines 21-22 Logic message area	The control displays any messages generated by the logic program in this area
lines 23-25 softkey display area	The control displays the currently available softkey functions in this area.


The Push-button MTB Panel

Figure 2.1 shows the push-button MTB panel. Table 2.C explains the functions of the buttons on the MTB panel. Optional or custom MTB panels may be used. Refer to the documentation prepared by your system installer for details.

Throughout this manual, we show switches and button names that are found on your MTB panel between the < > symbols. The MTB panel uses defaults when you turn on power to the control. Table 2.C contains these defaults.

Most of the buttons on the MTB panel are configured by your system installer's logic program. We assume that your logic was written as intended for normal operation. If a switch does not work the way it is described in this manual, refer to documentation prepared by your system installer.

**Figure 2.1
Push-Button MTB Panel**



19930

**Table 2.C
Functions of the Buttons on the Push-button MTB Panel**

Switch or Button Name	How It Works
MODE SELECT	Selects the operation mode AUTO -- automatic mode MANUAL -- manual mode MDI -- manual data input mode
JOG SELECT	Selects the jog method to be active in manual mode INCREMENTAL -- incremental jog CONTINUOUS -- continuous jog HOME -- machine home
SPEED/MULTIPLY	Selects an axis feedrate or axis feed amount multiplication ratio used in the manual mode. Each selection modifies the active feedrate by a value set in AMP. Modification also depends on the setting of <JOG SELECT> as described below: <ul style="list-style-type: none"> INCREMENTAL When in incremental jog mode, SPEED/MULTIPLY alters the incremental jog distance by a factor set in AMP by your system installer. Your system installer sets a value for the selections. The incremental jog speed is fixed to medium but can still be controlled by <FEEDRATE OVERRIDE>. CONTINUOUS When in continuous jog mode, SPEED/MULTIPLY acts as a feedrate selection switch which has values set in AMP by your system installer. Your system installer sets a value for all 5 selections independently for each axis. <FEEDRATE OVERRIDE> can be used for speed adjustments. Important: The values for the different <SPEED/MULTIPLY> selections are configured by your system installer.
SPINDLE SPEED OVERRIDE	Selects the override for programmed spindle speeds in 5% increments within a range of 50% to 120%.
SPINDLE or SPINDLE DIRECTION	Selects spindle rotation, clockwise (CW), spindle stop (OFF), counterclockwise (CCW). Can be overridden by any programmed spindle direction command.
FEEDRATE OVERRIDE	Selects a feedrate override percentage for the feedrate programmed with an F-word in any of the feedrates modes (G93/G94/G95) and the reciprocation feedrate programmed with an E-word. <FEEDRATE OVERRIDE> has a range of 0% to 150% of the programmed feedrate and alters the programmed feedrate in 10% increments. When set to 0%, the control is effectively in feedhold.

Switch or Button Name	How It Works ■ = Default for Push-Button MTB Panel
RAPID FEEDRATE OVERRIDE	Selects the override for rapid feedrates. Select from F1, 25%, 50%, and 100% where F1 is a rapid feedrate override setting established in AMP by the system installer.
EMERGENCY STOP	This button stops machine operation and disables the spindle and axis drives when pressed.
E-STOP RESET	This button resets an emergency stop condition when pressed. Before pressing this button the condition that caused the E-Stop should be resolved.
CYCLE START	The control begins or resumes part program execution, MDI program execution, or program check when this button is pressed.
CYCLE STOP	Pressing this button causes the control to stop part program execution, MDI execution, or program check. If pressed during the execution of a program block, a cycle suspend state occurs.
SINGLE BLOCK	The control executes or checks one block of a part program or MDI entry each time the <CYCLE START> button is pressed when single block is active.
AXIS/DIRECTION	These buttons are used for manual operations. They select an axis and direction when <JOG SELECT> is set for continuous, incremental, or home. If <JOG SELECT> is set for handwheel, these buttons select an axis only. Direction is then determined by handwheel rotation.
TRVRS	Hold this button down while executing a continuous jog move to override the active feedrate and jog an axis in rapid traverse.
F1 - F6	The functions for these buttons are assigned by the system installer. Refer to the documentation prepared by the system installer for details.
ON	Turns on power to the 9/PC when connected to your 8520-OFC or a master control relay.
OFF	Turns off power to the 9/PC when connected to your 8520-OFC or a master control relay.

Important: Many of the override switch settings may be disabled by programming the correct M-code or setting a particular paramacro parameter. Refer to their respective sections for details on these features.

Power Procedures

The basic procedure for turning power on and off to 9/PC is described in this section. Refer to the *9/PC Installation and Integration Manual* for more specific procedures.

Starting the Basic Display Set

Follow this procedure to turn on power to the control:

1. Make sure your PC is on. Visually check to make sure that the machine is in normal operating condition.
2. Click the **Windows NT Start** button and select **Programs**.
3. Click on **Rockwell Automation** to access the **9pc** option. Under **9pc**, click on **Configuration Manager**.


Important: You must start the 9/PC prior to starting BDS. Starting BDS without starting on the Configuration Manager causes the error "CANNOT LINK TO ABOCISERVER\YOURCNCNAME" to display.

4. Select the **Start 9/PC** button on the Configuration Manager 9/PC Operation tab.
5. Select the **Start BDS** button on the Configuration Manager 9/PC Operation tab to launch BDS, the OCI File Handler, and the OCI DDE/OPC Data Server.

Important: If the screen does not display characters after you press the **Start BDS** button within a reasonable warm-up period (about 15 seconds), press **[Ctrl] + [Alt] + [Delete]** to stop BDS through the Windows NT Task Manager. Contact service personnel for further instructions.

After BDS is running, the BDS welcome screen appears and instructs you to press any button to continue.

You see a similar main menu screen:



The softkeys available on the main menu screen are referred to as “level 1” softkey functions. Some of the softkey functions are purchased as optional and may not appear exactly as shown. Refer to page 2-8 for more information about the softkeys.

Stopping the Basic Display Set

To turn off power to BDS, select **Exit** under the File menu.



ATTENTION: To prevent damage to the machine, never turn off power while a part program is being executed. Before turning off power, make sure that the control is in **CYCLE STOP**, you press the E-Stop button on the MTB panel, and you execute a proper shutdown (refer to page 2-1).

Control Conditions at Power-Up

After powering up the control or performing a control reset operation (see page 2-11), the control assumes a number of initial operating conditions. These are listed below:

- Initial Password Access is assigned to the level that was active when power was turned off (provided that level is a power-up level selected in access control). If the active level when power is turned off is not a power-up level, then the control defaults to the next lower level that is a power-up level. See page 2-23 on access control.
- The control is placed in E-Stop. The control is not allowed to come out of E-Stop if the default AMP is loaded at power-up, or if there is no logic program loaded in the system. An appropriate error message is displayed.
- The control defaults to **one** G-code from each of these groups (as set in AMP):

Modal Group:	G-code
0	G47 Linear Acc/Dec G47.1 S-Curve Acc/Dec G47.9 Acc/Dec Disabled
1	G00 Rapid traverse G01 Linear interpolation
2	G17 Plane Selected G18 Plane Selected G19 Plane Selected
3	G90 Absolute G91 Incremental
4	G22 Programmable Zone 2 and 3 (On) G22.1 Programmable Zone 2 (Off) 3 (On) G23 Programmable Zone 2 and 3 (Off) G23.1 Programmable Zone 2 (On) 3 (Off)
5	G94 Feed per minute G95 Feed per revolution
6*	G70 Inch mode G71 Metric mode
10	G98 Init Level Return G99 R Point Level Return

12	NONE G54 G55 G56 G57 G58 G59.1 G59.2 G59.3	Preset Work Coordinate System 1 Preset Work Coordinate System 2 Preset Work Coordinate System 3 Preset Work Coordinate System 4 Preset Work Coordinate System 5 Preset Work Coordinate System 6 Preset Work Coordinate System 7 Preset Work Coordinate System 8 Preset Work Coordinate System 9
13	G61 G62 G63 G64	Exact Stop Mode Auto Corner Override Mode Tapping Mode Cutting Mode
18	G07 G08	Radius Programming Mode Diameter Programming Mode
20	G39 G39.1	Cutter Comp Linear Cutter Comp Rounding
22	G07 G08	Short Block Feed Clamped Short Block Full Clamped
25	G60 G60.1 G60.2	Synchronous mode Asynchronous mode Autosynchronous mode

* This G code group is only established at power up. A control reset will not change the last programmed state of this modal G code group.

To show the current operating conditions at any time, access the G-code status screen as described in chapter 10. If you do this immediately after power-up, it shows the initial operating conditions selected in AMP along with other control power-up default conditions.

Emergency Stop Operations

Press the red **<EMERGENCY STOP>** button on the MTB panel (or any other E-Stop switches installed on the machine) to stop operations regardless of the condition of the control and the machine.



ATTENTION: To avoid damage to equipment or hazard to personnel, the system installer should connect the **<EMERGENCY STOP>** button, so that pressing the button opens the circuit connected to the E-STOP STATUS terminal on the 9/PC card. This should disable the axis drives and the spindle drive circuits, which should both be connected to this terminal. Refer to the integration manual or the documentation prepared by your system installer for details.

If equipped with a push-button MTB panel, the following occurs automatically after you press the **<EMERGENCY STOP>** button:

- The control displays “E-STOP” in the message area. This indicates that the control is in the emergency stop state.
- The red light in the **<CYCLE STOP>** button lights up to indicate that the control is in the feedhold state.
- Power to all axis drive motors is turned off.

Important: If you press the **<EMERGENCY STOP>** button while a part program is running, program execution can resume at the point of interruption. Refer to the mid-program start feature described in chapter 7.

Emergency Stop Reset

Before resetting the emergency stop state, first locate and eliminate the cause of the emergency stop.

If the **<EMERGENCY STOP>** button is locked in the pressed position, it must be released before the emergency stop state can be reset. The locked button can be released in different ways depending on its type. With the MTB panel, turn the button clockwise until it pops out.

To reset the emergency stop state, press the **<E-STOP RESET>** button. After the cause of the E-Stop is resolved, the control clears the “E-STOP” message. If the error condition is not cleared, the “E-STOP” message continues to flash as the control remains in E-Stop state.

If the E-Stop occurred during program execution, the control may reset the program when E-Stop reset is performed provided AMP is configured to do so. Assuming that a control reset is performed, program execution begins from the first block of the program when **<CYCLE START>** is pressed. If the current axis position prohibits this, the operator can manually jog the axes clear, or consider executing a Mid-Program Start. Refer to page 7-10. If no control reset is performed, the remainder of the program block being executed when E-Stop took place is aborted, and a **<CYCLE START>** begins program execution at the next block.

Important: If the cause of the E-Stop is not eliminated, the circuit connected to the E-STOP STATUS terminals remains open, and the emergency stop state is not reset even when the **<E-STOP RESET>** button is pressed.

Access Control

Access control lets the system installer assign different functions of the control to different users by means of a password. Refer to page 2-26 for a list of the functions that may be protected on the 9/PC CNC.

Each protectable function is assigned an access level that is made active when the operator enters the password. When an access level is made active, all functions that are assigned to that access level become available. Access levels range between 1 and 8 where 1 is the highest level and 8 is the lowest. A different password is assigned to each of the different access levels. Eight passwords can be assigned.

Access control only applies to the front panel and softkey inputs. It cannot control inputs from outside the system. For instance, if you control access to the delete function, the user can't delete a file, but a file can be deleted by Mini-DNC software or ODS.

Important: If you do not want to use password protection, simply select all functions as accessible for access level 8. Since access level 8 is automatically available at power up, no password is necessary to access any of the functions of the control. Password protection can also be disabled by assigning a level at the power-up level by using the "POWER UP LEVEL" parameter as described on page 2-26.

Assigning Access Levels and Passwords

This section describes setting or changing the functions assigned to a particular access level, and changing the password used to activate that access level.

Important: Functions or passwords can be assigned to another access level only if:

- If you have a higher access level than the access level you are attempting to change, this means that if your password is assigned to access level 6, you can only change the functions or passwords for access levels 7 and 8. Functions, or a password, cannot be assigned to access level 6 with a level 6 password.
- Functions that are not available to the current user cannot be assigned to other levels. If a user with access level 6 is changing a lower access level functions, access level 6 must have access to any functions that are changed. For example, if you are an access level 6 user, you do not have access to {SYSTEM SUPPORT}, you cannot assign or remove {SYSTEM SUPPORT} to access level 7.
- The current user must have access to the {ACCESS CONTROL} function.

To change the functions or password of a lower user number, follow these steps:

1. Press the **{PASSWORD}** softkey.


(softkey level 1)

	PRGRAM MANAGE	OFFSET	MACRO PARAM	PRGRAM CHECK	SYSTEM SUPORT	→
F2	F3	F4	F5	F6	F7	F8
		ERROR MESAGE	PASS- WORD	SWITCH LANG		→
F2	F3	F4	F5	F6	F7	F8

2. Press the **{ACCESS CONTRL}** softkey. If the **{ACCESS CONTRL}** softkey does not appear on the screen, the currently active access level is not allowed to use the **{ACCESS CONTRL}** function. Enter a password that has access to **{ACCESS CONTRL}**.

↑				ACCESS CONTRL		
F2	F3	F4	F5	F6	F7	F8

This screen appears.



The softkey names change to display the 8 access levels along with their corresponding passwords (provided that a password has been assigned to that access level). Only the password names of access levels that are lower than the currently active access level are shown.

- Press the softkey that corresponds to the access level that you want to change. The pressed softkey appears in reverse video, and the password name assigned to that access level is moved to the “PASSWORD NAME.”

Important: If you attempt to change the functions available to an access level that is equal to or higher than your the current access level, the error message “ACCESS TO THIS LEVEL IS NOT ALLOWED.” You cannot change the features that are assigned to your current access level or any level that is higher than your own.

(softkey level 3)

	UPDATE & EXIT	01	02	03	04	→
F2	F3	F4	F5	F6	F7	F8

- If you want to enter or change the password for the selected level, edit the password next to the “PASSWORD NAME” prompt by using the input cursor as described on page 2-10. If you also want to change the functions for this password, move on to step 5. To save the change made to the password and leave the access control screen press the {UPDATE & EXIT} softkey.

Functions that are currently available to the selected level are shown in reverse video on the access level screen.

- Use the up, down, right, and left cursor keys to select the functions to change for that access level. The selected function is shown with a flashing ⇨ to the left of the function.
- Pressing the [ENTER] key toggles the function between accessible and inaccessible for that access level.

Important: If you attempt to activate or deactivate a function that is not accessible to the current user’s access level, the message “ACCESS TO THIS FUNCTION NOT ALLOWED” is displayed. Only features that are accessible to your the current access level can be selected as accessible or inaccessible to a lower access level.

- Press the {UPDATE & EXIT} softkey to store the changes made to accessible functions for the user levels and return the control to softkey level 1.

(softkey level 3)

	UPDATE & EXIT	01	02	03	04	→
F2	F3	F4	F5	F6	F7	F8

Password-protectable Functions

The following section describes the functions on the 9/PC CNC that can be protected from an operator by the use of a password. If a user has access to a function, the parameter associated with that function is shown in reverse video on the access control screen.

Access to these functions can be controlled by passwords. Table 2.D describes the function that is enabled (the operator can perform them) if the parameter name is shown in reverse video. If the function is not shown in reverse video, the function is protected and cannot be accessed.

Some parameters enable more than one function. If a parameter that enables multiple functions is not selected as accessible, some of the functions that would be enabled by the parameter can be enabled individually by using other parameters.

Table 2.D
Password Protectable Functions

Parameter Name:	Function becomes accessible when parameter name is in reverse video:
1) ACTIVE PROGRAM	To access these features, both ACTIVE PROGRAM and PROGRAM MANAGE (number 2 below) must be assigned to the user. <ul style="list-style-type: none"> • {DE-ACT PRGRAM} — Deactivate the currently active part program. • {SEARCH} — Search a part program for a character string or sequence number to begin program execution at. • {MID ST PRGRAM} — Start program execution from some location other than the beginning and still set all of the parameters previously defined in the program active. • {SEQ STOP} — Choose a sequence number for program automatic program execution to stop at. • {TIME PARTS} — Logs data relevant to part program execution (e.g., number of workpieces cut, cycle time, etc.)
2) PROGRAM MANAGE	<ul style="list-style-type: none"> • {ACTIVE PRGRAM} — All of the functions listed above in number 1, provided ACTIVE PROGRAM is also selected. • {EDIT PRGRAM} — Edit an existing program or create a new program. • {DISPLY PRGRAM} — Display a program using the display function. • {COPY PRGRAM} — Copy a program to or from memory. • {DELETE PRGRAM} — Delete a single program stored in memory. • {VERIFY PRGRAM} — Verify that two programs are identical using the verify function. • {PRGRAM COMENT} — Add comments to a program name in the directory. • {RENAME PRGRAM} — Change a program name. • {REFORM MEMORY} — Delete all programs currently stored in memory.
3) EDIT PROGRAM	{EDIT PRGRAM} — Edit an existing program or create a new program.
4) COPY PROGRAM	{COPY PRGRAM} — Copy a program to or from memory.
5) RENAME PROGRAM	{RENAME PRGRAM} — Rename an existing program name.
6) DELETE PROGRAM	{DELETE PRGRAM} — Delete a single program stored in memory
7) DELETE ALL PROGRAMS	{REFORM MEMORY} — Delete all programs currently stored in memory.

Parameter Name:	Function becomes accessible when parameter name is in reverse video:
8) OFFSETS	<ul style="list-style-type: none"> • {WORK CO-ORD} — Display and alter the preset work coordinate system zero locations and the fixture offset value. • {TOOL WEAR} Display and alter the tool wear amount tables for the different tools. • {TOOL GEOMET} — Display and alter the tool geometry tables. • {TOOL MANAGE} — Alter the tool life indicators and other machine specific tool functions. • {RANDOM TOOL} — Allows the use of the random tool tables used to keep track of different tools in different tool pocket (refer to chapter 20).
9) TOOL WEAR	{TOOL WEAR} — Display and alter the tool wear amount table for the different tools.
10) TOOL GEOMETRY	{TOOL GEOMET} — Display and alter the tool geometry table.
11) ACTIVE OFFSET	{ACTIVE OFFSET} — Change the currently active offset number without requiring the programming of a different offset number.
12) BACKUP OFFSET	{BACKUP OFFSET} — Make a copy of the current tool offset data.
13) QUICK CHECK	{QUICK CHECK} — Use the syntax and format checker.
14) SYSTEM SUPPORT	<ul style="list-style-type: none"> • {PRGRAM PARAM} — Display and change the tables for programmable zones 1 and 2, the single-digit feedrates, and the fixed-cycle operating parameters. • {AMP} — Change any of the online AMP features. • {MONI-TOR} — Display the logic message editor, 1394 drives information, and the axis monitor for following error, distance to marker, etc. • {TIME PARTS} — Logs data relevant to part program execution (e.g., number of workpieces cut, cycle time, etc.) • PTOM SI/OEM} — Edit/enter system integrator messages that appear at power turn-on. • {SYSTEM TIMING} — Displays system timing values.
15) PROGRAM PARAMETERS	{PRGRAM PARAM} — Display and change the tables for programmable zones 1 and 2, and the fixed-cycle operating parameters.
16) ONLINE AMP	{AMP} — Display and change the online adjustable machine parameters.
17) PARAMACRO PARAMETERS	{MACRO PARAM} — Display or change any of the values in the paramacro tables without using programming commands.
18) ACCESS CONTROL	{ACCESS CONTRL} — Assign different functions to different access levels, change the current password, or view the functions assigned to the different access levels.
19) SWITCH LANGUAGE	{SWITCH LANG} — Change the current displays from one language to another.
20) POWER-UP LEVEL	When POWER-UP LEVEL is shown in reverse video, it indicates that if power is turned off when this level is active, this level automatically becomes active when power is turned back on. If this is not in reverse video, it indicates that the control defaults to level 8 access control at next power-up.
21) TIME PARTS	When TIME PARTS is not in reverse video, the operator can only perform the following functions on the time and parts screen: RUN TIME, CYCLE TIME, and LOT SIZE.
22) SI/OEM MESSAGE	{ENTER MESSAGE} — Enter a new message to be displayed on the control's power-up screen.
23) SCALING	When SCALING is not in reverse video, the operator still has access to the {SCALNG} softkey; however values on the screen may not be modified.
24) CHANGE DIRECTORY	Allows access to the protectable directory for file edit, direct execution selection, and allows access to the hard drive.


Entering Passwords

When you power-up, only functions that are not protectable and functions that are assigned to access level 8 are available (provided that the active level when power was turned off was not assigned the POWER UP LEVEL feature). To access the functions that are assigned to a specific access level, you must enter the password that corresponds to that access level. To enter a password, follow these steps:

1. Press the {**PASSWORD**} softkey.

(softkey level 1)

	PRGRAM MANAGE	OFFSET	MACRO PARAM	PRGRAM CHECK	SYSTEM SUPORT	→
F2	F3	F4	F5	F6	F7	F8
		ERROR MESAGE	PASS- WORD	SWITCH LANG		→
F2	F3	F4	F5	F6	F7	F8



2. Enter the password you want to activate by typing it in on the input line with the keys on the operator panel. The control displays * for the characters you entered. If you make an error entering the password, edit the input line as described on page 2-10.
3. When the password is correct, press the [ENTER] key. The access level that the password is assigned to is made active, and the control enables all of the functions that are assigned to that access level.

Changing Operating Modes

The control provides three basic operation modes:

- manual (MAN or MANUAL)
- manual data input (MDI)
- automatic (AUTO)

You can select a mode by using **<MODE SELECT>** on the MTB panel.

Depending on the current control status, a mode change request cannot be honored. Operating modes may not be changed if any of these are true:

- The control is in E-Stop.
- The control is in the cycle-suspend state. This results when a program is halted during the execution of a block.
- The control is executing a threading- or multiple-pass turning cycle.


Manual Mode

To operate the machine manually,

- select MAN or MANUAL under **<MODE SELECT>**

For details on Manual Mode operation, refer to chapter 4.

Figure 2.2
Manual Mode Screen




MDI Mode

To operate the machine in MDI mode,

- select MDI under <MODE SELECT>

For details on MDI operation, see page 4-9.

Figure 2.3
MDI Mode Screen




Automatic Mode

To operate the machine automatically,

- select AUTO under <MODE SELECT>

For details on automatic operation, see chapter 7.

Figure 2.4
Automatic Operation Screen



Displaying System and Machine Messages


The control has a message screen dedicated to displaying messages. The screen displays up to nine of the most current system messages and nine of the most current machine messages at a time. The message screen is also able to display a log of up to 999 system error messages that occurred since the last time memory was cleared.

Important: The control automatically displays the highest priority, single, active message on all screens (other than the message screen) on line 1 of the BDS. If more than one message occurs with the same priority, the control displays the most recent message (provided no other message is active with a higher priority).

Use the message screen to display all the messages that are currently active, or a log of the most recent messages. To access the message screen, follow these steps:

1. From the main menu press the continue {⇒} softkey to change the softkey functions.
2. Press the {**ERROR MESSAGE**} softkey to change the screen to the message display screen shown in Figure 2.5.


(softkey level 1)



The control displays the currently active messages in sections dedicated to:

- system messages in the top half of the screen
- machine messages in the bottom half of the screen

Figure 2.5
Message Display Screen



Important: For a listing of system messages and a brief description, refer to appendix B. For a description of machine messages, refer to documentation prepared by your system installer.

- Press the {**ERROR LOG**} softkey to display the **999** most recent messages that occurred on the control since memory was last cleared. Up to nine of the most recent messages appear on the display at one time. The “MESSAGE ACTIVE” screen changes to the “MESSAGE LOG” screen.

To display more messages, press the down cursor key while holding the [SHIFT] key. The next most current set of messages is displayed. The control displays up to eleven pages of the most current messages that have occurred since the last time memory was cleared.

(softkey level 2)

↑	ERROR LOG	CLEAR ACTIVE				
F2	F3	F4	F5	F6	F7	F8

- To return to softkey level 1 press the exit {↑} softkey while holding the [SHIFT] key.

Clearing Active Messages {CLEAR ACTIVE}

After the cause of a machine or system message has been resolved, some messages remain displayed on all screens until you clear them.



CAUTION: Not clearing the old messages from the screen can prevent messages that are generated later from being displayed. This occurs when the old resolved message has a higher priority than the newly generated message. The new message is still displayed on the message display screen as an active message, but does not appear in the message area of other screens.

Active messages are cleared from the screen in this way:

- Press the [TAB] or [DEL] key to clear the most recent active messages individually.
- Clear all active messages from the error message display screen by pressing the {**CLEAR ACTIVE**} softkey.

(softkey level 2)

↑	ERROR LOG	CLEAR ACTIVE				
F2	F3	F4	F5	F6	F7	F8

Important: Clearing active messages does not correct the problem that caused the error; it only clears the message from the active file.

{REFORM MEMORY}

You may want to perform a Reform Memory operation to delete all part programs stored in your 9/PC's memory.

Important: The {REFORM MEMORY} softkey will not clear the memory of your hard drive.



CAUTION: The {REFORM MEMORY} function erases all part programs that are stored in control memory.

To reformat control memory and delete all programs stored in memory, follow these steps:

1. Press the {PROGRAM MANAGE} softkey.

(softkey level 1)

	PROGRAM MANAGE	OFFSET	MACRO PARAM	PRGRAM CHECK	SYSTEM SUPPORT	→
F2	F3	F4	F5	F6	F7	F8
		ERROR MESSAGE	PASS- WORD	SWITCH LANG		→
F2	F3	F4	F5	F6	F7	F8

2. Press the {REFORM MEMORY} softkey.

(softkey level 2)

↑	ACTIVE PROGRAM	EDIT PROGRAM	RESTRT PROGRAM	DISPLY PROGRAM	COPY PROGRAM	→
F2	F3	F4	F5	F6	F7	F8
↑	DELETE PROGRAM	VERIFY PROGRAM	PROGRAM COMENT	RENAME PROGRAM	INPUT DEVICE	→
F2	F3	F4	F5	F6	F7	F8
↑	REFORM MEMORY	CHANGE DIR				→
F2	F3	F4	F5	F6	F7	F8

3. Press the {REFORM YES} softkey. All programs that are stored in control memory are deleted. To abort the operation, press the {REFORM NO} softkey.

(softkey level 3)

↑		REFORM YES	REFORM NO			
F2	F3	F4	F5	F6	F7	F8

It can take several seconds for the control to complete the operation. During this period, the softkeys on the operator panel are rendered inoperative.

Removing an Axis (Axis Detach)

This feature allows the removal of a rotary table or other axis attachment from a machine. When activated, the control ignores messages that may occur resulting from the loss of feedback from a removed axis such as servo errors, etc.

Important: This feature removes the selected axis from the control as an active axis. Any attempt to move the removed axis results in an error. This means that part programs that use the removed axis name cannot be executed. Jog moves and MDI commands that attempt to move the removed axis also result in an error.

This feature can be enabled in AMP. The axis must be selected as “Detached” to be considered removed. Refer to the documentation supplied by your system installer for the necessary steps involved in detaching an axis or physically removing axis hardware from your machine.

Time Parts Count Display Feature

There are three levels of access to the Time Parts screen. They are listed below in order of most restrictive to least restrictive. Refer to page 2-23 for details on password protection and access control.

Access:	Protection:
No	Restricts operator from Time Parts screen entirely (softkey {TIME PARTS} not accessible). Accomplished by denying access to “Active Program.”
Operator	Restricts operator from setting “Power-on time/overall” and “Workpieces cut/overall.” Accomplished by denying access to “Time Parts.”
Supervisor	Full access to all features of the Time Parts screen.

To access the Time Parts screen, follow these steps:

1. Press the {PROGRAM MANAGE} softkey.

(softkey level 1)

	PROGRAM MANAGE	OFFSET	MACRO PARAM	PROGRAM CHECK	SYSTEM SUPORT	→
F2	F3	F4	F5	F6	F7	F8

		ERROR MESSAGE	PASS-WORD	SWITCH LANG		→
F2	F3	F4	F5	F6	F7	F8

2. Press the {ACTIVE PROGRAM} softkey.

(softkey level 2)

↑	ACTIVE PROGRAM	EDIT PROGRAM	RESTRT PROGRAM	DISPLY PROGRAM	COPY PROGRAM	→
F2	F3	F4	F5	F6	F7	F8
↑	DELETE PROGRAM	VERIFE PROGRAM	PROGRAM COMENT	RENAME PROGRAM	INPUT DEVICE	→
F2	F3	F4	F5	F6	F7	F8
↑	REFORM MEMORY	CHANGE DIR				→
F2	F3	F4	F5	F6	F7	F8

3. Press the **{TIME PARTS}** softkey. This generates the screen shown in Figure 2.6.

(softkey level 3)





Figure 2.6
Time Parts Screen



Important: The date and time information is based on the date and time set on your PC and is read by the 9/PC when you start the CNC. Changing the date or time on your PC while 9/PC is running will not change the time and date displayed on the Time Parts screen. To resynchronize the time and date on your 9/PC with the time and date on your PC, you must stop and restart your 9/PC.

You can modify the values on this screen. Press the **{ED PRT INFO}** softkey as explained in the Screen Field Definitions that follow.

Press the exit softkey **{↑}** to save changes and return to the “Active Program” screen.

Time Part Screen Field Definitions

Program - is the currently active part program, displayed automatically by the control.

Power-on Time/Overall - indicates the total accumulated time that the control has been ON. This value is saved in backup memory each time the control is powered off, so it is restored at its previous value each time the control is turned ON. To clear this field to zero:

1. Press the {**ED PRT INFO**} softkey, provided that you have supervisor-level access.
2. Press the up or down cursor keys to move to this field or the next field without changing the current value.
3. Enter a Y at the prompt for this field.
4. Press [**ENTER**] to clear the current value.

Workpieces Cut/Overall - indicates the total number of part programs executed to completion by the control. Use this field to determine the need for periodic checkups or as a statement of warranty. This counter is incremented by one each time the control encounters an M02, M30, or an M99 in a main part program (M99 in a subprogram does not increment this counter, though M02 or M30 does). To clear this field to zero:

1. Press the {**ED PRT INFO**} softkey, provided that you have supervisor-level access.
2. Press the up or down cursor keys to move to this field or the next field without changing the current value.
3. Enter a Y at the prompt for this field.
4. Press [**ENTER**] to clear the current value.

Run Time - indicates the total accumulated time that part programs were **executing** with the control in automatic mode. Use this field with "Power-on Time/After Reset" to estimate the utilization ratio of the machine. To clear this field to zero:

1. Press the {**ED PRT INFO**} softkey if you have either operator-level or supervisor-level access.
2. Press the up or down cursor keys to move to this field or the next field without changing the current value.
3. Enter a Y at the prompt for this field.
4. Press [**ENTER**] to clear the current value.

Power-on Time/After Reset - indicates the total accumulated time that the control has been ON. This value is saved in backup memory each time the control is powered off, so it is restored at its previous value each time the control is turned ON. Use this field with “Run Time” to estimate the utilization ratio of the machine. The value for this field is cleared to zero when the “Run Time” field is cleared to zero; it cannot be changed independently.

Cycle Time - indicates the elapsed execution time for each individual part program. Cycle time begins counting when the cycle-start button is pressed and ends when an M02 reset or M30 is encountered. To reset this field to **zero**, use one of three methods:

- press the cycle-start button to initiate program execution
- turn off the control power
- follow these steps:
 1. Press the {**ED PRT INFO**} softkey if you have either operator-level or supervisor-level access.
 2. Press the up or down cursor keys to move to this field or the next field without changing the current value.
 3. Enter a Y at the prompt for this field.
 4. Press [**ENTER**] to clear the current value.

Workpieces Cut/After Reset - indicates the total number of part programs executed to completion by the control since the last time “Run Time” was reset. This counter is incremented by one each time the control encounters an M02, M30, or an M99 in a main part program (M99 in a subprogram does not increment this counter, though M02 or M30 does). The value for this field is cleared to zero when the “Run Time” field is cleared to zero; it cannot be changed independently.

Lot Size - is the number of times you need to execute this particular part program. To enter a new number:

1. Press the {**ED PRT INFO**} softkey if you have either operator-level or supervisor-level access.
2. Press the up or down cursor keys to move to this field or the next field without changing the current value.
3. Enter a numeric value at the prompt for this field.
4. Press [**ENTER**] to change the current value.

Remaining Workpieces - indicates the number of workpieces that still need to be cut in the lot. The value for this field is automatically set equal to the lot size each time the "Lot Size" value is changed. When the control encounters an M02, M30, or M99 in a main part program, the remaining workpieces field is decremented by one. The control tells the system installer's logic program when the lot remaining size is zero. At this point, press <CYCLE START> to automatically set the field back to the "Lot Size" value. Complete operation of this feature is somewhat logic dependant. Refer to the documentation supplied by your system installer.

Lot Completion Flag - is automatically set to zero by the control whenever a non-zero value is entered for "Lot Size." It is set to one when the "Remaining Workpieces" field reaches zero. It is again reset to zero when the next cycle start occurs after the remaining workpieces field has reached zero. Complete operation of this feature is somewhat logic dependant. See the documentation supplied by your system installer.

Press the exit softkey {↑} to save changes and return to the "Active Program" screen.

Part Program Storage


There are three directories available for storage and execution of part programs: main and protectable, which allow you to run programs resident on the CNC, and a directory on the PC's hard drive, as configured by the File Handler.

You can execute programs from the single directory on the hard drive. Refer to the Installation manual for more information about configuring your hard drive and storing part programs on your main and protectable drives. Refer to your 9/PC Integration Manual for information about locating your File Handler directory.

Choosing a Part Program Directory


When you power up your 9/PC system, it automatically returns you to the last active part program directory. To select a new part program directory:

1. From the BDS main menu, select {**PROGRAM MANAGE**}. The program directory screen appears and displays the contents of the last active part program directory.



2. To access the {**CHANGE DIR**} softkey layer, press [**F8**] twice. Select the {**CHANGE DIR**} softkey.

(softkey level 2)




The {**CHANGE DIR**} menu item allows you to scroll through the main, protectable, and hard drive directories. The part programs in the main and protectable directories reside in the control's memory. The programs in the hard drive reside on the personal computer.

Copying Part Programs Between Drives

To copy your part program between drives:

1. Select the {**PROGRAM MANAGE**} softkey.
2. If necessary, access the {**CHANGE DIR**} softkey to toggle to your desired directory. Access the {**CHANGE DIR**} softkey by pressing [**F8**] twice.


3. After choosing the desired directory, highlight the part program that you want copied.
4. After the selected program name, which appears on the Selected Program: line, type a comma, followed by the new program name. Select [F8] again to return to the {COPY PRGRAM} layer of softkeys.
5. Choose the source you want your program copied to.



6. Select the destination you want your part program copied to:



This screen appears:



7. Select the {COPY YES} softkey to copy the part program OR select the {COPY NO} softkey to abort the process.
8. If desired, select {VERIFY PRGRAM} to verify that the copied part program is identical to the original.

Part Program Sizes


When moving part programs from one device to your 9/PC, you will notice that the length of your program may change. Since various sources have different means of recording keystrokes, your file size may increase or decrease in size, without losing or gaining any information.

For example, 9/PC may record a return as one keystroke (end-of-block character), whereas the AMP records it as two (carriage return + line feed character). In this event, your AMP file may have originally been 452.4 meters, but after it is downloaded to the control, it may read as 449.8 meters.

Cycling Power

Whenever you are required to cycle power to your 9/PC (i.e., after downloading AMP), you must restart BDS. To restart BDS:

1. Select the “Select CNC” option under the Options menu.



2. Highlight the applicable CNC.
3. Click [OK] to restore the connection to that CNC.

END OF CHAPTER

Offset Tables and Setup

Chapter Overview

In this chapter we describe the basics for job setup. Major topics include:

Topic:	On page:
Changing the active tool offset	3-14
Work coordinate system offset table	3-15
Backing up offset tables	3-18
Programmable zone table	3-20

Tool Offset Tables {TOOL GEOMET} and {TOOL WEAR}


Use tool offsets to let the programmer always write a part program with respect to the same point on the machine regardless of the tool being used. Tool lengths are taken into account using tool length offsets as described in chapter 19. The radius of the tool tip and tool orientation in the turret are taken into account using TTRC as described in chapter 20. This section describes entering these values that are called later when the corresponding offset is activated.

Tool offsets are divided into two tables:

- Tool Geometry Table - This table is typically used to enter tool data for a brand new tool just being installed or replaced.
- Tool Wear Table - This table is typically used to record slight changes that occur to a tools shape during normal usage. Since the tools basic orientation does not change, no orientation data may be entered into this table.

When offset data is called in a part program, the control subtracts the value called from the wear table from the value called from the tool geometry data table. The result is used as the offset data for that tool. Typically when a new tool is installed, the wear offset value is zero. As the tool gets older, the wear value is increased.

Figure 3.1
Tool Offset



You can enter this data into the tool offset tables:

- Tool length offset data {**TOOL GEOMET**} and {**TOOL WEAR**}
- Tool tip radius data {**TOOL GEOMET**} and {**TOOL WEAR**}
- Tool orientation data {**TOOL GEOMET**}

Parameters for the resolution of the offset data are determined by the system installer in AMP. The range available to the system installer is 0.01 to 0.00001 mm (0.001 to 0.000001 inch) with a maximum number of 8 digits.

Tool Offset Numbers


Use a T-word to call out tool offset numbers in a program. The T-word specifies a one, two, or three-digit offset number. The control then accesses the values assigned to that offset number in the table. Offsets are activated as described in the sections on that specific type of offset.

For more information on calling offset numbers, refer to chapter 19.

Offset number "00" is not valid, but can be used to cancel tool offsets. Different offset numbers may be called from the tool geometry and tool wear table using the same T-word (depending on the T-word type selected in AMP). This means that wear offset data corresponding to offset number 1 may not need to correspond to tool geometry offset number 1, etc.

Tool Dimensional Parameters

Figure 3.2
Tool Dimensional Offsets




Tool Length (Tool Geometry Table)

The dimensions, entered into the tool geometry for length, reflect the distance from the tool tip to the gauge point on the tool holder. This gauge point actually moves to the coordinates programmed in a part program, if a tool offset is not activated.

We use the term “gauge point” to define the precise point on the turret from which all programmed tool paths originate. Offsets refer to the distance from this gauge point to the tip or edge of the tool that contacts the part being cut.

Use the tool length offset function to compensate for the difference between the tool position as mounted in the turret and the tool position assumed in writing a program. By using the tool length offset functions along with tool orientation data, a programmer can write a part program without further concern for tool position due to mounting. Measure offset values for each axis to allow for the difference between the assumed and actual cutting tool locations.

Figure 3.3
Tool Length Offsets



The Z offset table value corresponds to the actual Z distance from the tool tip to the gauge point. The X offset value is the distance on the axis from the tool tip to the gauge point. Consequently, when the control activates a tool offset, the Z axis is displaced per the table value, while the X axis is displaced half the table value.


Generally machines are configured such that axes move in the negative direction as they move the tool turret towards the workpiece (this refers to the main or A turret if a two turret lathe). In that case, if the installed tool protrudes in the negative direction its offset value is entered as positive.

The tool illustrated in Figure 3.3, for example, extends in both the -X and -Z directions, so its X and Z offsets would be entered as positive. This holds true regardless of which turret the tool is on.

Tool Tip Radius - TTR (Tool Geometry Table)

The control can compensate for any cutting error resulting from slight or even large rounding of the cutting tool tip. To do so, the radius of the cutting tool tip must be entered as the geometry data for tool tip radius compensation. For more information, refer to chapter 20.

Figure 3.4
Tool Tip Radius for Typical Lathe Tool



Tool Length (Wear Table)

The tool length wear compensation offset takes into account the wear that a tool incurs from normal usage. Enter a value in the table that is equal to the difference between the tool tip positions, before and after tool wear.

Tool Tip Radius Compensation - TTRC (Wear Table)


The tool tip radius wear compensation offset takes into account the normal wear that a tool tip incurs from normal usage. Enter a value in the table that is equal to the difference between the tool tip radius before and after tool wear. Tool tip radius wear compensation is factored into both the X and Z axes.

Tool Orientation Parameters

ORNT - Tool Orientation (Tool Geometry Data Table)

The control uses the value entered here to determine the orientation of the tool's cutting edge relative to the surface of the part. This is necessary for the control to perform TTRC correctly. Refer to chapter 20.

Figure 3.5
Tool Orientations for Rear Turret Lathe



The control uses the value entered here to determine the orientation of the tool when Tool Tip Radius Compensation is active. Each tool's orientation should be determined from Figure 3.5 and Figure 3.6 and its number entered (0-9) on the geometry offset table for the ORNT parameters. From that information the control can keep track of the orientation of the tool currently being used and help catch some programming errors.

Figure 3.6
Tool Orientations, Rear Turret Lathe
(Both A and B Turrets if Two-Turret Lathe)





Figure 3.7
Tool Orientations, Front Turret Lathe
(Both A and B Turrets if Two-Turret Lathe)



Setting Tool Offset Tables

You can set data in the offset tables by using one of six methods. The method described here requires that the offset data is manually measured and then directly keyed into the table. The other 5 methods are described in these sections:

- Using **{MEASURE}** (page 3-11)
- Programming G10s (chapter 19)
- Skip functions (chapter 26)
- Setting paramacro system parameters (chapter 27)
- Altering through the logic program (refer to the *9/PC Logic Reference Manual, 8520-9.2*)

When you use **logic** to modify either the work coordinate system tables or the tool offset tables, tool tip radius compensation should not be active (G40 mode). If tool tip radius compensation is active, be aware that the new offset is not placed in part program set-up buffers that have already been read into control memory. This results in the offset not being activated until several program blocks after the current block. The number of setup buffers is dependent on the number of block retrace steps configured in AMP and what software features are currently being used.

To manually display or alter the offset tables, follow these directions:

1. Press the **{OFFSET}** softkey.


(softkey level 1)

	PROGRAM MANAGE	OFFSET	MACRO PARAM	PROGRAM CHECK	SYSTEM SUPPORT	→
F2	F3	F4	F5	F6	F7	F8
		ERROR MESSAGE	PASS- WORD	SWITCH LANG		→
F2	F3	F4	F5	F6	F7	F8

2. Decide whether you want to display the tool geometry offsets or the tool wear offsets.

To display:	Press:
the geometry offsets (tool length offsets, the tool radius, and tool orientation)	{TOOL GEOMET} softkey. Figure 3.8 shows examples of tool offset screens.
the wear offsets (tool length and radius wear data)	{TOOL WEAR} softkey. Figure 3.8 shows examples of tool offset screens.

Figure 3.8
Tool Offset Screens




Tool Wear Table

Tool Geometry Table

3. Move the cursor to the offset data to be modified. Use the up, down, left, or right cursor keys to move the block cursor to the tool offset data on the current page. Press the **{MORE OFFSET}** softkey to change pages.

To search all pages for a specific offset number, press the **{SEARCH NUMBER}** softkey and key in the desired offset number. When you press the **<TRANSMIT>** key, the control locates the cursor at the offset number you are searching for. The tool offset data located at the cursor appears in reverse video.

(softkey level 3)



4. Select data entry type:

Unit selection **{INCH/METRIC}**

To select units of “mm” or “inch” for the offset data, press the **{INCH/METRIC}** softkey. The units used for the currently selected offset number change each time the softkey is pressed. When the units are altered, all data previously entered is converted to the newly selected units (Inch or Metric) for that offset number.

Diameter or Radius {RADI/DIAM}

If the offset value being changed has been selected in AMP as the diameter axis (typically the axis perpendicular to the spindle center line), data may be entered into the offset table as either a radius or diameter value. The current mode for this axis is displayed with an R for radius or a D for diameter mode next to that axes offset. Pressing the {**RADI/ DIAM**} softkey toggles the offset between these two modes.

This softkey does not change the current mode of control operation (as selected with G07 or G08); it only alters how data is entered into the table. For details on radius or diameter mode, refer to chapter 12 (G07/G08).

(softkey level 3)

↑	SEARCH NUMBER	REPLCE VALUE	ADD TO VALUE	CHANGE OFFSET	MORE OFFSET	→
F2	F3	F4	F5	F6	F7	F8
↑	MEAS- URE	INCH/ METRIC	RADI/ DIAM		COPY OFFSET	→
F2	F3	F4	F5	F6	F7	F8

5. Enter offset data; replace or add data as follows:

Press this softkey:	Then:
{ REPLCE VALUE }	Type in the new value. Press the [ENTER] key. The new value replaces the old value for that feedrate.
{ ADD TO VALUE }	Type in the number. Press the [ENTER] key. The new value is added to the old value for that area.

If desired, stored offset data can be copied from one axis to another axis for all offset numbers (rather than having to change each axis individually).

- A. Press the {**COPY OFFSET**} softkey.
- B. “COPY (SOURCE, DESTINATION):” appears. Enter the axis letter **from** which the data is coming, then a comma, and then enter the axis letter **to** which the data is going. For example,

COPY (SOURCE, DESTINATION): X,Z

copies the offset data from the X axis to the Z axis for all offset numbers.

Setting Offset Data Using {MEASURE}

The measure feature offers an easier method of establishing tool offsets. The control, not the operator, computes the tool length and wear offsets, and enters these values into the tool offset tables. The measure feature is used to measure tool length offset values for the wear or geometry tables; it should not be used to modify tool diameter offsets.

To enter tool offsets using measure, follow these steps:

1. Establish a fixed machine position without a tool in the tool holder. This position can be any fixed, nonmovable location on the machine that the tool can be jogged against consistently using a variety of different tools.

If you enter:	Then:
a tool length in the geometry offset table	jog the machine gauge line (on the axis being updated) to this position. The value of this position, located in the work coordinate system, must be recorded. The user keys in this value in steps 6 and 7. No tool offsets should be active and no tool should be in the tool holder.
a tool length wear in the wear offset table,	jog the machine gauge line to the fixed position. Add the original tool length offset from the tool geometry table to the fixed machine location. The user keys in this value in step 7. No tool offsets should be active and no tool should be in the tool holder. The value of this position, located in the work coordinate system, must be recorded.

2. Access the tool geometry or wear offset table.
3. Cursor down to the offset that you want to change. The offset can be displayed in either inch or metric measurements.
4. Load the tool that you want to measure into the tool holder.
5. Using incremental, continuous or handwheel mode, jog the tool tip to the fixed location determined in step 1.
6. Press the {MEASURE} softkey.
7. Key in the coordinate value of the fixed location determined in step 1.
8. Press the [ENTER] key.

The control now subtracts the keyed in position from the current tool position and enters this difference as the offset value into the table.

Tool Offset Range Verification

Tool offset range verification checks:

- the maximum values entering the tool offset tables
- the maximum change that can occur in either table

To use tool offset range verification, follow this softkey sequence:

1. Press the **{SYSTEM SUPORT}** softkey.

(softkey level 1)

	PROGRAM MANAGE	OFFSET	MACRO PARAM	PROGRAM CHECK	SYSTEM SUPORT	→
F2	F3	F4	F5	F6	F7	F8
		ERROR MESSAGE	PASS- WORD	SWITCH LANG		→
F2	F3	F4	F5	F6	F7	F8

2. Press the **{AMP}** softkey.

(softkey level 2)

↑	PROGRAM PARAM	AMP		MONI- TOR	TIME PARTS	→
F2	F3	F4	F5	F6	F7	F8
↑	PTOM SI/OEM		SYSTEM TIMING			→
F2	F3	F4	F5	F6	F7	F8

3. Press the **{AXIS PARAM}** softkey.


↑	AXIS PARAM	PATCH AMP	UPDATE BACKUP			
F2	F3	F4	F5	F6	F7	F8

4. Press the **{RANGE PARAM}** softkey.

(softkey level 4)

↑	REVERS ERROR	HOME CALIB	AXIS CALIB	SERVO PARAM	SPNDL PARAM	→
F2	F3	F4	F5	F6	F7	F8
↑	RANGE PARAM					→
F2	F3	F4	F5	F6	F7	F8

Your system installer initially sets these values in AMP. You can modify them with online AMP by using this screen:



About the Offset Range Verification Screen

- on a lathe, range checking units for this screen are always RADIUS, regardless of the program/control mode
- display format is fixed

Mode	Places to the left of the decimal point	Places to the right of the decimal point
inch	3	5
metric	4	5

- data entry is bounded by the programming resolution of the axes

When Does Verification Occur?

Verification occurs when a value enters the table from:

- data entry screens
- logic
- paramacros

Important: The control does not perform the verification if the value, old or new, is zero, nor does it check G10 data-setting codes.

Verify for Maximum Value

This value represents the absolute maximum value per table for all tool offsets in that table.

If you enter:	then:
a positive number greater than the maximum value	the control generates the error message: "OFFSET EXCEEDS MAX VALUE"
a negative number less than the negative of the maximum value	The control does not modify the value in the table.

Verify for Maximum Change

This change represents the amount an offset may change from its current value. If you exceed the amount set by the system installer in AMP, the change is not allowed. The control generates the error message “OFFSET EXCEEDS MAX CHANGE.”

Changing the Active Tool Offset {ACTIVE OFFSET}

Use {**ACTIVE OFFSET**} to allow the manual activation of tool offsets, without the need to program the correct T-word to call the corresponding offset number. This may be necessary when a broken tool has been replaced using the Jog Retract feature, or if a program is to start execution with a tool active in the chuck and no tool offsets programmed, etc.

Typically tool offsets are changed by programming a T-word in a program as described in chapter 19. This feature should be used only when it is necessary to activate one of the tool offset numbers manually.

Important: The control must be in either cycle stop or E-Stop states before an attempt is made to change the active offset using this method.

If it is necessary to change the current tool offset values or to activate tool offset numbers without programming a T-word, follow these steps:

1. Press the {**OFFSET**} softkey.

(softkey level 1)

	PRGRAM MANAGE	OFFSET	MACRO PARAM	PRGRAM CHECK	SYSTEM SUPPORT	→
F2	F3	F4	F5	F6	F7	F8
		ERROR MESSAGE	PASS- WORD	SWITCH LANG		→
F2	F3	F4	F5	F6	F7	F8

2. Activate an offset number as follows:

Press This softkey:	To activate:
the { TOOL GEOMET }	a tool geometry offset number
the { TOOL WEAR }	tool wear offset number

The tool offset table is displayed. Currently active offset values (if any) are indicated with an * to the right of the offset number.

3. Move the cursor on the offset table until the desired offset is shown in reverse video. Only one geometry offset and one wear offset number may be active at the same time.
4. Press the **{ACTIVE OFFSET}** softkey when the desired offset is selected. The tool offsets are made active as described in chapter 19.

(softkey level 3)

↑	SEARCH NUMBER	REPLCE VALUE	ADD TO VALUE	CHANGE OFFSET	MORE OFFSET	→
F2	F3	F4	F5	F6	F7	F8

Work Coordinate System Offset Table {WORK CO-ORD}

There are two types of data in the work coordinate system table. They are:

- the initial work coordinate system zero point locations that are called when programming G54 - G59.3.
- the external offset which is used to offset all of the G54 - G59.3 zero points to make the same set of work coordinate systems fit a variety of applications.

Zero Point Parameters

The zero point parameters refer to the zero point locations of all of the work coordinate systems called out by G54 - G59.3. Enter positions for these zero points as machine coordinate values. The control uses the specified machine coordinate position as the work coordinate system zero point. Refer to chapter 10 for details on work coordinate system.

Enter a machine coordinate system position for each axis of the work coordinate system below the corresponding G-code (G54-G59.3) as described on page 3-16.

External Offset

Use the external offset to modify all of the work coordinate system zero points. Use of the external offset is optional. The value entered here offsets all of the work coordinate systems by the specified amount. Enter external offsets in the work coordinate system tables as the external offset value.

This offset allows a programmer to use the same set of work coordinate system values in a variety of applications. Adjusting this value, for example, allows you to use the same work coordinate systems and programs after a different part or tool mounting fixture has been installed on the machine. You can also use it to offset all work coordinate systems when part programs are transferred from different machines with different mechanical features. Refer to chapter 10 for details on the external offset.

Setting Work Coordinate System Data

Set data in the control system table in one of these four ways:

- keying in the data directly into the table
- programming G10s (chapter 10)
- setting paramacro system variables (chapter 27)
- entering data through the logic program (refer to the *9/PC Logic Reference Manual*, 8520-9.2)

When you use **logic** to modify either the work coordinate system tables or the tool offset tables, tool tip radius compensation should not be active (G40 mode). If tool tip radius compensation is active, be aware that the new offset is not placed in part program set-up buffers that have already been read into control memory. This results in the offset not being activated until several program blocks after the current block. The number of setup buffers depends on the number of block retrace steps configured in AMP and what software features are currently being used.

To display or change the initial setups for the work coordinate system and external offset, follow these steps:

1. Press the **{OFFSET}** softkey on the main menu screen.

(softkey level 1)

	PROGRAM MANAGE	OFFSET	MACRO PARAM	PRGRAM CHECK	SYSTEM SUPORT	→
F2	F3	F4	F5	F6	F7	F8
		ERROR MESSAGE	PASS- WORD	SWITCH LANG		→
F2	F3	F4	F5	F6	F7	F8

- Press the **{WORK CO-ORD}** softkey to display the offset values for the work coordinate systems and the external offset. See Figure 3.9.

(softkey level 2)





Figure 3.9
Work Coordinate System Setting



- Move the cursor to the offset data that you want to modify. Use the up, down, left, or right cursor keys to move the block cursor to the offset data on the current page. Press the **{MORE OFFSET}** softkey to change pages. The selected item appears in reverse video.
- Select data entry type:

Unit selection **{INCH/METRIC}**

To select units of “mm” or “inch” for the offset data, press the **{INCH/METRIC}** softkey. The units used for the currently selected offset G-code or external offset change each time the softkey is pressed. When the units are altered, all data previously entered is converted to the newly selected units for that offset number.

Diameter or Radius {RADI/DIAM}

If the offset value being changed has been selected in AMP as the diameter axis (typically the axis perpendicular to the spindle center line), data may be entered into the offset table as either a radius or diameter value. The current mode for this axis is displayed with an R for radius or a D for diameter mode next to that axes offset. Pressing the {RADI/ DIAM} softkey toggles the offset between these two modes.

This softkey does not change the current mode of control operation (as selected with G07 or G08); it only alters how data is entered into the table. For details, refer to chapter 12 (G07/G08).

(softkey level 3)

↑	MEAS- URE	INCH/ METRIC	RADI/ DIAM		COPY OFFSET	→
F2	F3	F4	F5	F6	F7	F8

5. Replace or add data as follows:

To :	Press:
replace stored work coordinate data with new data	the {REPLCE VALUE} softkey, then type in the value and press [ENTER].
add to previously stored work coordinate data	the {ADD TO VALUE} softkey, then type the number and press [ENTER].

Important: The values for the work coordinate systems can be altered by using the G10 command in MDI or within a part program. For details, refer to chapter 10.

Backing Up Offset Tables

The control can save all of the information that is entered in the tool offset tables and the work coordinate system tables as a backup. This is accomplished by the control generating a program consisting of G10 blocks. These G10 blocks contain the offset numbers and their respective wear and geometry values. Any time your run this program, the set of values contained in these G10 blocks replace the current values in the offset tables. The G10 program can be saved in control memory.

This feature is very useful if the same tool or coordinate system offsets are to be used on different machines. The same offset tables can be easily set up by running this G10 program on other machines.


The offset table program can be saved in control memory as a program. This is very useful if the same tools are to be used on different machines. The offset tables can be easily set up by executing the same offset table program on all the other machines.

Important: Once the control begins executing a G10 program that has been previously generated, it clears any data that exists in the offset table being updated by that G10 command. This makes it impossible for a G10 block to simply add a few offset values. A G10 program must load the entire offset table each time it is run. Tool geometry and tool wear tables are separate offset tables. Loading data into one does not clear the other.

To back up the offset tables, follow these directions:

1. Press the **{OFFSET}** softkey.

(softkey level 1)



2. Press the **{BACKUP OFFSET}** softkey. The control displays the backup offset screen shown in Figure 3.10.

(softkey level 2)





Figure 3.10
Backup Offset Screen



3. Select the offsets to be backed up by moving the cursor to the desired offset by using the up and down cursor keys. The selected offset appears in reverse video. The four options include:
 - TOOL WEAR -- When wear is selected all data from the tool offset wear tables is stored as a G10 program.
 - TOOL GEOMETRY -- When geometry is selected all data from the tool offset geometry tables is stored as a G10 program.
 - WORK COORDINATE -- When work coordinate systems are selected the work coordinate offset information for the G-codes G54 - G59.3 and the external offset value are stored as a G10 program.
 - ALL -- When all is selected all data from the tool offset geometry and wear tables and work coordinate offset tables is stored as a G10 program.
4. Once the data to save has been selected, press the **{TO FILE}** softkey to send the G10 program to control memory. The control asks for a program name under which to store the program. Enter the program name by using the alphanumeric keys on the operator panel and press the **[ENTER]** key. Refer to chapter 9 on program names. The G10 program is saved under the file name just entered.

Programmable Zone Table

The programmable zone feature prevents tool motion from entering or exiting a designated area. For details on programmable zones, refer to chapter 11.

This table contains the values for programmable zones 2 and 3. These values define the boundaries for the programmable zones and are referenced from the machine coordinate system.

Important: These values may also be entered in AMP by the system installer. Programmable zone 3 table values may also be modified by programming a G22 command. Refer to chapter 11.

To display or alter the values in the programmable zone table, follow these steps:


1. Press the **{SYSTEM SUPPORT}** softkey.

(softkey level 1)

	PRGRAM MANAGE	OFFSET	MACRO PARAM	PRGRAM CHECK	SYSTEM SUPPORT	→
F2	F3	F4	F5	F6	F7	F8
		ERROR MESSAGE	PASS- WORD	SWITCH LANG		→
F2	F3	F4	F5	F6	F7	F8

- Press the **{PROGRAM PARAM}** softkey.

(softkey level 2)



- Press the **{ZONE LIMITS}** softkey to display the programmable zone table as shown in Figure 3.11.

(softkey level 3)





Figure 3.11
Programmable Zone Table



- Important:** Depending on the currently active program mode, programmable zone coordinates are displayed in inches or millimeters for a liner axis and in degrees for a rotary axis.
- Use the up or down cursor keys to move the block cursor to the data to be changed. Data located at the cursor appears in reverse video. Press the **{MORE LIMITS}** softkey to change pages.
 - You can replace data or add to it.

Press This Softkey:	Then:
{REPLCE VALUE}	type in the new value. Press [ENTER] .
{ADD TO VALUE}	type in the new number. Press [ENTER] .

6. Complete editing the inhibit zone parameters in two ways:

Press This Softkey:	To:
{UPDATE & EXIT}	store the changes made to the parameters and leave the inhibit zone screen.
{QUIT}	delete all changes made to the inhibit zones this session and leave the inhibit zone screen.

END OF CHAPTER

Manual/MDI Operation Modes

Chapter Overview

This chapter describes the manual and MDI operating modes. Major topics include:

Topic:	On page:
Mechanical handle feed	4-6
Removing an axis	4-6
Manual machine homing	4-7
MDI mode	4-9

Important: This manual assumes that the push-button MTB panel is being used and standard logic to run that MTB panel has been installed. For applications that use a custom MTB panel or that do not use standard logic to run the MTB panel, refer to documentation prepared by your system installer.


Manual Operating Mode

To go into the manual mode, select MANUAL under **<MODE SELECT>**.

When you select the manual mode, both the axis position data and the part program currently active are displayed in the data display area if the normal display is used for softkey level 1.

Press **<CYCLE STOP>** to abort manual operations. The system installer has the option, however, to designate some other switch to abort manual operations in the logic program. Refer to the documentation provided by your system installer for details.

Figure 4.1
Data Display in MANUAL Mode



Jogging an Axis

In the jog modes, the motion of the cutting tool is controlled by the use of pushbuttons, switches. Typically these are mounted on or near the MTB panel.

The cutting tool can be jogged by using three different methods:

- continuous jog -- the axes move continuously while a pushbutton on the MTB panel is held.
- incremental jog -- the axes move a predetermined amount each time a pushbutton on the MTB panel is pressed.

Normally, the axes can only be jogged in manual mode. Your system installer can write logic to allow jogging in the automatic and MDI modes. Refer to page 4-4 for more information about jog offsets.

The control can be equipped with an optional offset jogging feature, activated by a switch installed by the system installer. When this feature is active, all jog moves are used to offset the current work coordinate system and no position registers are changed. Refer to page 4-4 for more information about jog offsets.

Only normal single-axis jogs (one axis at a time in the continuous, or incremental modes) are permitted during a jog retract operation. Refer to page 7-14 for details about basic program execution.

Important: S-Curve Acc/Dec is not available during manual jogged motion.

Continuous Jog

To continuously jog an axis:

1. Select CONTINUOUS under <JOG SELECT>.
2. Select the feedrate for continuous jog under <SPEED/MULTIPLY>.
3. Press the <AXIS/DIRECTION> button for the axis and direction to jog. The axis moves while the button is held down.

If you want to:	Then:
alter the feedrate selected with <SPEED/MULTIPLY>	select a <FEEDRATE OVERRIDE> %
jog the axis at a special AMP assigned traverse feedrate and ignore the setting <SPEED/MULTIPLY>	press and hold the <TRVRS> when jogging
jog moves that use the traverse feedrate	select a <RAPID FEEDRATE OVERRIDE> %

Important: It is possible to jog more than one axis at a time. To jog multiple axes, press and hold more than one axis direction button. The selected axes will drive at the feedrate chosen under <SPEED/MULTIPLY>. If the selected feedrate is above a specific axis maximum allowable feedrate, that axis drives at its maximum feedrate. The feedrate for the other selected axes is not affected.

Incremental Jog

Incremental jog manually moves an axis a predetermined amount each time an <AXIS/DIRECTION> button is pressed. To use incremental jog:

1. Select INCREMENTAL under <JOG SELECT>.
2. Select the jog increment under <SPEED/MULTIPLY>. The jog increment is equal to an amount specified in AMP for each selection under <SPEED/MULTIPLY>.
3. Press the <AXIS/DIRECTION> button for the axis and direction to jog. The control makes one incremental move each time the <AXIS/DIRECTION> button is recognized. Until the control completes the execution of the incremental move, no other jog moves are recognized on that axis. This includes attempts to perform other incremental moves on that axis.

The control will normally jog the axes the selected distance and direction at the feedrate set in AMP for the MED feedrate. It is possible for the system installer to select a different feedrate with a specific logic program. Refer to documentation prepared by the system installer for details.

Important: You can jog more than one axis at a time. To jog multiple axes, press more than one axis direction button. The selected axes drive at the feedrate chosen under **<SPEED/MULTIPLY>**. If the selected feedrate is above a specific axis maximum allowable feedrate, that axis drives at its maximum feedrate. The feedrate for the other selected axes is not affected.

Jog Offset

The control may be equipped with an optional jog offset feature, activated by a switch installed by the system installer. When this function is active, all jog moves made are added as offsets to the current work coordinate system.

Normally, jogging occurs in the manual mode. The system installer has the option to enable a “Jog on the Fly” feature that will allow jogging in automatic or MDI mode for the purpose of jogging an offset. To jog in automatic or MDI mode both the “Jog on the Fly” and jog offset features must be active. Normally, the system installer will enable both of these features with the same switch. Refer to documentation provided by the system installer for details. “Jog on the Fly” can be performed at any time during automatic operation, even while blocks are being executed.

To use this feature, follow these directions:

1. Turn on the switch to activate the jog offset function. Refer to documentation provided by the system installer.
2. Change to manual mode unless the control is equipped for the “Jog on the Fly” feature which allows jogging in MDI and Automatic modes. If equipped with “Jog on the Fly,” turn on the switch to activate it. For details, refer to documentation prepared by the system installer.
3. Jog the axis by using any of the available jog types, with the exception of homing, as described on page 4-6. The control adds the amount of the jog move as offsets to each jogged axis immediately when the jog takes place.

Important: When the jog move is made, the axis position displays do not change on the screen unless the currently active screen is the absolute screen as described on page 8-4. This is because the value is being added to the work coordinate system offset and the control does not recognize any tool motion on the coordinate system.

Resetting Overtravels

The control stops tool motion during overtravel conditions. Overtravel conditions can occur from 3 causes:

- **Hardware Overtravel** -- the axes reach a travel limit, usually set by a limit switch or sensor mounted on the axis. Hardware overtravels are always active.
- **Software Overtravel** -- commands cause the cutting tool to pass a software travel limit. Software overtravels are active only after the axis has been homed provided the feature has been activated in AMP by the system installer.
- **Programmable Zone Overtravel** -- the axes reach a travel limit established by independent programmable areas. Programmable Zones are activated through programming the appropriate G-code.

These 3 causes of overtravel are described in detail in chapter 11.

When an overtravel condition occurs, all axis motion stops, the control is placed in cycle stop, and one of the following error messages is displayed.

Message:	Description:
HARDWARE OVERTRAVEL (-) BY AXIS (X)	indicates that the specified axis has tripped either the + or - hardware limit switch mounted on the machine.
SOFTWARE OVERTRAVEL (+) BY AXIS (X)	indicates that an attempt was made by the specified axis to enter the overtravel area defined by the softlimits in either a positive or negative direction.
VIOLATION OF ZONE (2) BY AXIS (X)	This message indicates that an attempt was made to enter the overtravel area defined by programmable zone 2 or 3.

When a software or zone overtravel has taken place, you cannot move the axis in the same direction as the overtravel. Only axis motion in the reverse direction is possible.

Reset a hardware overtravel condition depending on the E-Stop circuit design and the way logic was programmed by your system installer.

To reset a software or programmable zone overtravel condition:

1. Determine whether the control is in E-Stop. If it is not, go to step 4.
2. Look for and eliminate any other possible conditions that may have caused emergency stop, then make sure that it is safe to reset the emergency stop condition.

3. Press the **<E-STOP RESET>** button to reset the emergency stop condition. If the E-Stop does not reset, it is a result of some cause other than overtravel causing E-Stop.
4. Make sure it is safe to move the axis away from the overtravel limit.
5. Use any of the jog features described on page 4-1, except homing and jog offset, to manually move the axis away from the limit. Any attempt to jog the axis in the direction of the overtravel will not be allowed.

Mechanical Handle Feed (Servo Off)

This feature lets you disable the servo drives, and allows the axes to be moved by external means (such as a hand crank attached to the ball screw) without requiring the control to be in E-Stop. When this feature is enabled, all position displays get updated as the axes are moved.

This feature only enables when the control is in the Cycle Stop state and the axes are not being jogged at the time of request. To use this feature, it must be enabled in logic by your system installer. Refer to your system installer's documentation for details on how the "Mechanical Handle Feed" feature is activated and used.

Removing an Axis (Axis Detach)

Use this feature to allow the removal of a rotary table or other axis attachment from a machine without requiring the system to be reconfigured. When activated, the control ignores messages that may occur resulting from the loss of feedback from a removed axis such as servo errors.

Important: This feature removes the selected axis from the control as an active axis. Any attempt to move the removed axis results in an error. This means that part programs that use the removed axis name cannot be executed. Jog moves and MDI commands that attempt to move the removed axis also results in an error.


This feature can only be enabled in AMP. The axis must be selected as "Detached" to be considered removed. Refer to your system installers documentation for the necessary steps involved in actually physically removing axis hardware from a specific machine.

Manual Machine Homing

The machine home return operation means the positioning of a specified linear or rotary axis to a machine-dependent fixed position, which is called the machine home. This position is established via a home limit switch mounted on the machine and the encoder marker.

The execution of machine home establishes the machine coordinate system. Since all of the AMP-assigned work coordinate systems and all of the programmable zones are referenced from the zero point of the machine coordinate system, none of these features are available until the machine homing operation has been conducted. Homing the axis should be the first operation done on the control after power-up.

Figure 4.2
Machine Home




The following procedure describes how the control is homed manually by using the pushbuttons on the MTB panel. Manual homing may be different for some machines depending on the logic program written by your system installer.

Important: When a homing request is made the feedback device for the axis (typically an encoder) must encounter at least one marker before tripping the homing limit switch. If the axis is close to the home limit switch you should jog the axis away from this switch before attempting a homing operation.

Important: Automatic homing is available. Refer to page 13-11.

Figure 4.3
Manual Machine Home



To execute the manual return to machine home position:

1. Select HOME under <JOG SELECT>.
2. Place the control in manual mode. Refer to page 4-1.
3. Determine the direction that each axis must travel to reach the home limit switch. Refer to your system installer on the location of the home limit switch on a specific machine.
4. Press the <AXIS/DIRECTION> button for the axis and direction to home. You can select more than one axis at one time. The axis selected moves at the feedrate under <SPEED/MULTIPLY>.

Important: If you choose the wrong direction for an axis, it will continue to travel in the selected direction until it contacts a hard limit and an overtravel will occur. Refer to chapter 11. Your system installer has the option to enable some button or switch (typically Cycle Stop) through the logic program to abort a jog operation or prevent the user from homing the axis in the wrong direction. Refer to your system installer's documentation for details.

The axis homes when :

1. The axis moves until it trips its home limit switch, then the axis decelerates to a stop.
2. The axis then reverses direction and moves off the home limit switch at a feedrate specified in AMP.
3. The controller records the distance to the nearest encoder marker or null position.
4. The control then moves in a direction specified in AMP, an amount equal to the home calibration value, specified in AMP, plus the distance from the encoder marker or null position.

This locates the machine home position. When the axis reaches this position, the control resets the position registers to a machine coordinate value specified in AMP. This establishes the zero point of the machine coordinate system.

Important: During the machine home operation, softlimits and programmable zones are not active. All active coordinates offsets are cancelled.

MDI Mode

In manual data input (MDI) mode, machine operations can be controlled by entering program blocks directly by using the keys on the operator panel.

To begin MDI operations, select MDI under **<MODE SELECT>**.

Important: If desired, your system installer has the option of disabling G- or M-code AMP-defined paramacro calls in MDI mode. For details on paramacros, refer to chapter 27.


To insert blocks in an active, executing, program by using MDI, the control must be in the end of block state to allow the selection of MDI mode. If a program is interrupted while executing in automatic mode by pressing cycle stop, the control will not allow the selection of MDI since the control is in cycle suspended state not end of block state, and a mode change is not accepted.



ATTENTION: When program blocks are executed in MDI, no tool tip radius compensation (TTRC) is allowed. If TTRC was previously active before the MDI blocks are executed, it is temporarily canceled for the execution of the MDI blocks. Refer to chapter 20 for details on the effect of MDI on TTRC. Any TTRC G-codes that are programmed in MDI mode affect the cutter compensation mode (G41, G42, or G40) when compensation is reactivated.

Important: It is possible to call subprograms or paramacros within an MDI program, however, there are limitations to the allowable commands. Refer to chapter 27 on paramacros for details on illegal MDI commands for these features.

Figure 4.4
Program Display Screen in MDI Mode



MDI Basic Operation

Operating procedures in the MDI mode include:

1. When it is in MDI mode, the control accepts standard programming blocks.
2. Key in programming blocks (refer chapter 9). Each block, up to a maximum of 62 characters, is separated with an end of block statement. The blocks entered appear in the input area of the screen (line 2). The complete MDI program should be entered on these lines since once you send the blocks to control memory, they cannot be edited or added to.

The input cursor is the cursor shown on the input lines (line 2 on the screen). To edit information in the input area, use the **[BACKSPACE]** key to delete everything to the left of the cursor.

If you make a mistake keying in a character before it is sent, that character can be edited by using the input cursor described on page 2-10.

3. Pressing the **[ENTER]** key transmits the blocks to control memory. Once the blocks have been sent to control memory, you cannot send any more MDI blocks until all of the previous set has been executed.

The control displays the first 4 blocks of the MDI program entered on lines 17-20 with an ! (exclamation point) just to the left of the blocks. If you insert lines by using MDI within a program selected for automatic execution, the control inserts the MDI blocks just before the next block to be executed.

If you need to abort the MDI program due to an error in the MDI program or any other reason, discard the MDI program by executing a control reset operation.

- The MDI blocks can then be executed continuously by pressing the **<CYCLE START>** button in either the AUTO or MDI mode. The single block, jog retract, and block retrace features are also available for MDI programs (refer to pages 7-3, 7-27, and 7-30 respectively for details on these features).

The control displays an “@” symbol next to any MDI blocks that have been executed.


The error message:

“NO MORE MDI BLOCKS”

appears if you press cycle start in the MDI mode when there are no more MDI blocks remaining in memory to be executed.

If:	Then:
the MDI blocks were entered into an executing part program	the control returns to automatic mode and continues executing the part program.
you execute the MDI program in the MDI mode	execution halts when the control encounters the first block of the part program.

Figure 4.5
MDI Mode Program Screen



Important: Performing a block reset operation causes the control to abort the current MDI program block or skip the following MDI program block. See page 2-11 for details. By performing a control reset operation as described, the control erases all MDI blocks that have not been executed in the MDI program.

END OF CHAPTER

Editing Programs Online

Chapter Overview

You can create and edit part programs online with either the part program editor or any ASCII editor that runs on your PC. Since all programs stored on the hard drive must have a PPG extension, the OCI editor automatically saves your programs with a PPG extension. In this manual, we describe how to use the editor supplied with the OCI software.

Topic:	On page:
Selecting the program to edit	5-4
Editing programs	5-5
Deleting program {DELETE}	5-19
Renaming programs {RENAME}	5-20
Displaying a program {DISPLAY}	5-21
Displaying comments {COMENT}	5-21
Copying programs {COPY PRGRAM}	5-23

You can also edit programs offline with your personal computer. For more information about offline operations (e.g., uploading, copying, and some file management operations), refer to chapter 6.

Important: If you intend to execute part programs from the hard drive, save your part program to the default OCI directory defined for the OCI file handler by your system integrator. Refer to your system integration documentation for instructions.


The cycle editor is a subset of the line editor, and can only be activated when the line editor is active.

The cycle editor allows you to program canned cycles using a graphical representation of the cycle along with prompts for programming data. These screens prompt you for the basic syntax of the available canned cycles.

Creating a Part Program

Creating part programs to edit using OCI is the same as using the standard front panel. To create a new part program:

1. From the BDS main menu, select the {**PRGRAM MANAGE**} softkey. The program directory screen appears and displays the contents of the last active part program directory.
2. Use the up arrow to highlight the **NAME** line.



3. At the **SELECTED PROGRAM:** line, type in the program name.
4. Select the {**EDIT PRGRAM**} softkey to begin editing the program.

Subprograms and Paramacros

When creating a subprogram or paramacro, the program must match the 9/Series format of O12345. Programs with five or fewer numeric characters that are either created with the BDS part program editor or stored in the main and protectable directories are automatically expanded to the O12345 format. However, if you used another application to create the part program on the PC (including ODS), the numbered program name is not expanded. The following illustrates the format of numbered program names in the G65 block on the available drives:

On the Main and Protectable drives:

G65P1 - will use O00001

On the Hard drive:

G65P1 - will use O1.ppg

G65P00001 - will use only O00001.ppg. It will not use O1.ppg or 1.ppg.

If a subprogram resides on the hard directory, you must expand it in order for the control to recognize it. However, whenever you use the control to copy the program to the main directory, it will automatically be expanded.

Important: If a new program name is entered with five or fewer numeric characters, the control assumes that it is a subprogram and automatically inserts the letter O as the first character in the name. However, the control does not consider existing programs with more than five numeric characters to be subprograms.

Using Layered Softkeys

When you are in the line and cycle editors, layered softkeys appear at the bottom of the screens. The active layer is highlighted. To toggle through the main level of layered softkeys, use [F10]. When you reach your desired layer of softkeys, select the appropriate function key. The following is an example of layered softkeys:

```

F5 CONFIG          F6 CYCLE MODIF   F7 CUT & PASTE   F8 INCLUDE       F9 HELP
  DEL-LINE        OLD-LINE          SEARCH          SEQUENCE
                  MILL
  
```

Using Online Help

The OCI editor contains an online help function for reference information. Online help is accessible at any level of the editor, and while other processes (e.g., sequence and search) are active.

There are two types of help: Menu level and Data Entry Window level. Menu level help defines each softkey. Data Entry Window level help defines each data entry input parameter. Below is the first screen of online help at the main softkey level:

```

HELP                               p. 1 of 5
There are two different kinds of
help :

- Menu level: explains the meaning
of each softkey defined in active
menu.
- Data entry window level: explains
the meaning and the range of each
requested data input parameter.

To remove help pages, hit <HELP>
softkey again.

Use <Page Down> key to view all the
following Help pages.
  
```

To use online help from any level of the editor, select the {HELP} softkey. To exit online help, select the {HELP} softkey again.

Selecting the Program To Edit

This section provides information on how to select a part program for editing. You can only edit part programs on line that you have stored in control memory. If a part program is on tape or another storage device and you must edit it on line, copy this program to memory as described in chapter 9.


Important: You can edit programs that are selected as active for execution. Edit operations being performed on an active program must be exited before that program can actually be executed in automatic mode.

If an:	is displayed to the left of the part program name, it means that the program is currently:
A	active
E	open for editing
AE	active and open for editing

To begin an edit operation on an active or inactive part program:


1. Press the {PROGRAM MANAGE} softkey. The program directory screen appears (see Figure 5.1).

(softkey level 1)



The control displays this main part program directory screen:

Figure 5.1
Part Program Directory



2. Select the part program you want to edit using two methods:

- Key in the program name of the part program to edit or create.

or

- Move the cursor to the program name on the program directory screen using the up or down cursor keys.

Important: When assigning program names using the part program editor supplied the 9/PC, make sure that the directory name does not exceed eight characters.

Important: If you create a new program that is to be used as a subprogram, see chapter 10 on program names. Programs used as subprograms must have the letter O as the first character in the program name, followed by as many as 5 **numeric** characters.

3. Press the {**EDIT PROGRAM**} softkey.

(softkey level 2)

↑	ACTIVE PROGRAM	EDIT PROGRAM	RESTR PROGRAM	DISPLY PROGRAM	COPY PROGRAM	→
F2	F3	F4	F5	F6	F7	F8
↑	DELETE PROGRAM	VERIFY PROGRAM	PROGRAM COMMENT	RENAME PROGRAM	INPUT DEVICE	→
F2	F3	F4	F5	F6	F7	F8
↑	REFORM MEMORY	CHANGE DIR				→
F2	F3	F4	F5	F6	F7	F8

Editing a Part Program

Important: The following section describes the OCI Part Program Editor. You can create and edit part programs with either this part program editor or any ASCII editor that runs on your PC. In the event that your OEM or system installer selected an editor other than the one provided with this software, refer to that editor's documentation.

You can select programs to edit that are resident in the control's memory or on the hard or network drive of a PC. To select a part program from another directory, refer to page 2-40.

1. Select the **{EDIT PROGRAM}** softkey. The control displays the selected part program in the line editor:

```

PART PROGRAM EDITOR
Lines: 000012  File: IFFDEMO  Release: 1.00  Date: 01/24/1997
000001 N0001010D12
N0001010D12
S1950M06
G01 X22Z3F100
S100M04
X1.3
Z2
TSH6D7
M222.2
Z-1X-1.2F60
GOTO10
F5 CONFIG DEL-LINE F6 CYCLE MODIF OLD-LINE MILL F7 CUT & PASTE SEARCH LATHE_A F8 INCLUDE GRINDER F9 HELP SEQUENCE EXIT

```

Important: The **{CHANGE DIR}** softkey is deactivated once you are editing a part program.

Using Cut & Paste

The **{CUT & PASTE}** softkey allows you to select, delete, copy, and move the selected block range. Help, search, and exit options are available on every level in the cut and paste function. For more information about help, refer to page 5-3. For more information about search, refer to the previous section.

1. Select the **{CUT & PASTE}** softkey. A second level of layered softkeys appears.
2. Select the **{START SELECT}** softkey to begin choosing the lines that you want to include in the select range OR use the **{SEARCH}** softkey to search for the line that you want to include in the select range.

Use the arrow or page up and down keys to include more part program blocks in the current select range. All selected data appears in yellow.

Two things can be done with the selected data:

- **{END SELECT}** - marks the data as “to be acted upon” and will allow you to delete, copy, or move the selected blocks.
- **{DESELECT}** - turns off the selection and returns to the **{START SELECT}** level

After you select the desired data, you have the following options to choose from:

Select:	To:
{ DELETE }	delete the selected data. A confirmation box displays. To delete the selected data, enter YES . To keep the data selected without deleting it, enter NO . To confirm your choice, press [ENTER] on the numeric keypad.
{ COPY }	insert the selected data after the currently highlighted edit line data. You can create multiple copies since the data remains as the select range data until you select the { DESELECT } softkey.
{ MOVE }	move the selected data from its original location to the line(s) following the current edit line data. The data becomes deselected immediately after it is moved.
{ DESELECT }	turn off the current selection.
{ SEARCH }	search for a new string or line number. Refer to page 5-12 for more information.

3. To exit {**CUT & PASTE**}, select {**EXIT**}.

The maximum number of programs that you can have is **328**. To store a program, it will use at least one sector (2048bytes/1.3m) of memory. Use this table to find out how much part program space there is in your system.

If your system has	this is your part program storage
64K	150 meters
1MB	2589.6 meters/1,019,904 bytes
4MB	10540.4 meters/4,151,296 bytes

Including a Part Program

If you want to merge programs to the CNC, you must access them from your PC hard drive. Use the {**INCLUDE**} softkey to merge a whole part program into the program that you are editing.

Important: If you want to merge programs to the CNC, you must access them from your hard drive.

To include a part program:

1. Determine the point where you want to include another part program in the current program. Move the block that immediately precedes the inclusion point into the edit line.

2. Select the **{INCLUDE}** softkey. The system prompts you for a file name:

File name : [REDACTED]

3. Enter the full path name (up to 48 characters) of the part program that you want to include.
4. Press **[ENTER]** on the numeric keypad or the **{INCLUDE}** softkey again to begin the include operation.

Saving and Exiting

To save a part program and exit from the editor:

1. Press the **{EXIT}** softkey.
2. Press **Y** to save the part program OR
Press **N** to exit the editor without saving the program.
3. Press **[ENTER]** on the numeric keypad or select the **{EXIT}** softkey. The system returns to the program directory screen.

Using the Line Editor

As you activate the part program editor, the first screen you see is the line editor. Use the line editor to edit new or existing part programs.

Line Editor Dimensions

The line editor screen has 25 lines, which can display up to 90 characters each before wrapping to a new line. Part program blocks can contain a maximum of 127 characters, but can only display 89 characters on the edit line at a time. To view beyond the eighty-ninth character, use the arrow keys to scroll across the line display.

Navigating through the Line Editor


As we talk about using the editor, we'll be using terms that describe certain areas of the screen. Use this figure of a typical line editor screen to become familiar with the terms that we use:

Status line - displays the number of lines, file name, release number, and date.

Old-block line - displays what is in the edit line before your current edits are made. If the block in the edit line was incorrectly changed, press the {OLD LINE} softkey to restore the original block to the current program block.

Edit line - is the only place on the screen that allows you to make modifications. Changes to the edit line are not moved to the old-block line until you move to a new edit line.

Layered softkeys - display the softkeys for the line and cycle editors. The active layer is highlighted.



The OCI line editor is significantly different from the standard 9/Series editor. Use this table to learn how to navigate through the OCI editor:

If you want to:	Press
move to a specific line in the part program	the up and down arrow keys until you are at your desired location. The current line and line number are displayed on the second line of the screen.
scroll through the layered softkeys	F10
select a specific softkey	F10 until you highlight the layer that contains your selection. Then select the function key that corresponds to your selection.
move the cursor down one page	PgDn
move the cursor up one page	PgUp
go to the beginning of a block	Ctrl Left Arrow
go to the end of a block	Ctrl Right Arrow
go to the beginning of the part program and place the first block of the part program on the edit line	Ctrl Home
go to the end of the part program and place the last block of the part program on the edit line	Ctrl End
delete the character left of the cursor	Back Space
open a new line after the block displayed in the edit line OR accept the new data to a current block	Enter
split the block in the edit line at the cursor position.	End

Entering Blocks

Since the edit line is the only place on the screen that allows you to add data, the cursor remains on this line. Once you enter a block in the edit line, close the block by using the up and down arrow keys.

You can change existing blocks only when they are within the edit line. To modify an existing block, move the cursor to the edit line using the up or down arrow key.

Important: You can also move an existing block to the edit line by using the following keys: [PgUp], [PgDn], [Ctrl] + [Home], or [Ctrl] + [End].

Creating a New Line

You can create a new line in two ways:

- by pressing [ENTER] with the cursor in any position. The new line is inserted below the block in the edit line.
- by positioning the cursor in front of the block and pressing [END]. This action inserts a line before the block in the edit line.

Important: If you press [END] with the cursor positioned inside a block, the block will split. The only way to correct the split is to press the {OLD-LINE} softkey before performing any other action. This action restores the block that is in the edit line, but the last half of the split will be on the line below. To delete the last half of the split, highlight the split line and select the {DEL-LINE} softkey.

Creating a Blank Line

Similar to the standard front panel, OCI allows you to use blank lines in your part program. To insert a blank line in your part program, create a new line using [ENTER] or [END]. In the new line, use the space bar to add one blank space. When you exit the editor, the blank line will insert the end-of-block character.

Important: If you are using another editor, a carriage return will create an end-of-block character.

Deleting Lines

Use the `{DEL-LINE}` softkey to delete a block from the part program. The `{DEL-LINE}` softkey operates differently, depending on whether you press the softkey once or twice.

If you press <code>{DEL-LINE}</code> :	Then:
once	the contents of the block in the edit line are deleted. You can recover the deleted line with the <code>{OLD-LINE}</code> softkey
twice followed by the up/down arrow key	the block in the edit line is deleted with no possibility for recovery

Recovering Lines

You can recover lines using the `{OLD-LINE}` softkey in these cases:

- to restore the original text of a modified block in the edit line
- to recover a block deleted in the edit line after pressing the function key for the `{DEL-LINE}` softkey once
- to recover the original text when a block is split after pressing the `[END]` key while the cursor is inside of the block

Important: The `{OLD-LINE}` softkey does not delete the new block that was added. For details on deleting lines, see the previous section.

Numbering Lines

The `{SEQUENCE}` softkey allows you to number the lines of your part program.

1. Select the `{SEQUENCE}` softkey. The system prompts:

```
Start number : 1
Increment    : 1
```


2. At the **Start number** prompt, enter the number you want to start numbering at. The start number can range from 0 to 999000.
3. At the **Increment** prompt, enter the numerical increment that you want your lines to be numbered at (e.g., 10, 20, 30) using the numeric keypad. The increment can range from 0 to 200. Use 0 if you do not want the part program to be numbered or if you want to delete all of your line numbers.

```
Start number : 10
Increment    : 10
```

- To confirm line renumbering and exit the sequence screen, press [ENTER] or the {SEQUENCE} softkey.

Important: Sequence only renumbers the N-word if it is the first word in the block.

Sequence does not store any targets of GOTO statements in its memory.



Using the Search Softkey

The {SEARCH} softkey searches for strings or line numbers. When you select the {SEARCH} softkey, the display prompts you for string or line number to search for.

To search for a line number or a particular string:

- Select the {SEARCH} softkey. While search is active, the softkey appears in yellow. The system prompts:

```
Character string : ██████████
Line number      : 0
```

- Use the [RETURN] or up and down arrow keys to choose between a character string or line number search. Enter either the character string or line number you want to search for.

If you choose this type of search:	Then:
character string	enter up to 12 characters and press [ENTER] followed by either the up or down arrow key on the numeric keypad. The {SEARCH} softkey remains active until you press it again.
line number	enter a line number of up to 6 digits (without the N character) and press [ENTER] on the numeric keypad. When found, the line appears on the edit line. If the search number is greater than the last number of the file, then the last line of the program appears on the edit line. The {SEARCH} softkey is deactivated once the search is complete.

If the character string or line number cannot be found, the system returns an error.

Important: You cannot enter negative numbers in the line number search block. Entering negative numbers returns an error. To remove the error, select [ENTER] on the numeric keypad.

- If you want to abandon the search at anytime, select the {SEARCH} softkey.

Configuring the Cycle Editor

Before you use the cycle editor to edit part programs or select fixed cycles, you should customize the editor for your configuration. To customize the editor:

- Select the {CONFIG} softkey to begin configuring the cycle editor. The first of two configuration screens appears:

```

----- CONFIGURATION PARAMETERS -----
Keystroke      : 00
Cycle screen 1 : CYCmil
Cycle screen 2 : CYClata
Cycle screen 3 : CYCgrd
                                     1 of 2

```

- To move through the fields, press [ENTER] on the nonnumeric keypad or use the up and down arrow keys.

Use this table to set the parameters for your configuration:

Field	Description
Keystroke	This field displays the number of keystrokes that can be completed before they are saved in the recovery file. Values range from 0 to 999, with the default set at 80. If you enter 0, there is no recovery file management.
Cycle screen 1-3	In these fields, tell the system what cycles you want to display in the editor softkeys. You can enter up to three cycles in any combination. File names you can enter are: <ul style="list-style-type: none"> • CYCLata Cycles for type A lathes • CYCLatb Cycles for type B lathes • CYCLatc Cycles for type C lathes • CYCmil Mill Cycles • CYCgrd Grinder Cycles (surface and cylindrical)

Important: Recovery file management is used only if the DOS window (editor) crashes before the editor is exited.

- After you configure the global parameters screen, press [PgDn] to move to the next configuration screen:

```

----- CYCLE PARAMETERS -----
      AMP name      Symbolic
Name1             X             X
Name2             Y             Y
Name3             Z             Z
Name4             I             I
Name5             J             J
Name6             K             K
Name7
Name8
Name9                                     2 of 2

```

Important: The order of the AMP names do not necessarily reflect the axis names configured in AMP.

- If your machine configuration does not match the default parameters in the AMP column, enter your normally configured axis names in the AMP name column.

Important: We recommend that you do not change the symbolic names. The cycle editor provides you with symbolic names that the cycle editor recognizes (i.e., X, Y, Z, A, B, C, U, V, W) to represent the axis name configured in AMP.

Important: 9/PC axis names beginning with \$ cannot be used in the OCI cycle editor.

To move from field to field, use the [ENTER] key on the nonnumeric keypad. Once you enter all axes names, press [ENTER] on the numeric keypad to save your changes.

Important: Cycle names must be entered in capital letters.

- Press the {CONFIG} softkey again to return to the line editor.

Using the Cycle Editor (Quick View)


Included in the part program editor is a fixed-cycle editor, which automatically creates common tool paths using dimensions specific to the part you want to create. Use this editor to create programs using 9/PC cycles.

When you configured the cycle editor in the previous section, you selected the cycles that would be available in the cycle editor. For our example, this manual assumes your editor is configured to display the mill cycles. Your editor may be configured differently.

Important: Reducing the window size of the cycle editor using [ALT] + [ENTER] causes the editor to become frozen. To reactivate the editor, you must maximize the window by repeating the [ALT] + [ENTER] action.

Displaying the Cycle Prompts


1. If necessary, use [F10] to scroll to the layer in the softkey area that displays the cycle softkeys.
2. Press the function key that selects the type of cycles that you want. In our example, pressing [F6] causes the system to display a range of mill cycles:



The cycles for each control type are broken into different categories. In our example, the mill provides:

- Drilling Cycles
- Pocket Cycles
- Post Cycles
- Irregular Cycles
- Hemispherical Pocket Cycles
- Probe Cycles

- To display a set of cycles, press the function key that selects the set of cycles that you want to work with. In our example, pressing [DRILL2] displays:




- To select a cycle, enter the number displayed in the lower right corner of the graphic box. The system displays the format of the cycle and detailed graphic representation of the cycle. For a definition of each graphic, refer to page 5-16. In our example, we selected cycle 6 - G88:

Cycle format - are all parameters that need values for the cycle to work. Optional fields allow you to bypass it without entering data. Use the right arrow key to move to each parameter.

Cycle graphics - depict how the letter parameters affect basic cycle motion. The letter is highlighted as its associated parameter is entered.










Old-block line - displays what is in the edit line before any edits are made.

Layered softkeys - display the softkeys for the line and cycle editors. The active layer is highlighted.



- To return to the cycle screen, select [F6] again. If you wish to choose a different cycle, select that softkey.

The table below defines the graphics used in the cycle editor:

Graphic	Definition
	Dwell
	Spindle reverse (clockwise/counterclockwise)
	Stop spindle
	Shift direction
	Rapid move
	Feed move
	Cutting feed
	Rapid feed
	Manual operation

Available Cycles

The following table lists the available 9/PC cycles.

Control	Cycle Set	Cycles
Lathe Type A	Single Turning	G90, G94
	Compound Turning	G70, G71, G72, G73
	Threading	G32, G34, G76, G92
	Groove	G74, G75
	Drill1	G81, G82, G83, G83.1, G84, G84.1, G84.2, G84.3
	Drill2	G85, G86, G86.1, G87, G88, G89
Lathe Type B	Single Turning	G77, G79
	Compound Turning	G70, G71, G72, G73
	Threading	G33, G34, G76, G78
	Groove	G74, G75
	Drill1	G81, G82, G83, G83.1, G84, G84.1, G84.2, G84.3
	Drill2	G85, G86, G86.1, G87, G88, G89
Lathe Type C	Single Turning	G20, G24
	Compound Turning	G72, G73, G74, G75
	Threading	G33, G34, G21, G78
	Groove	G76, G77
	Drill1	G81, G82, G83, G83.1, G84, G84.1, G84.2, G84.3
	Drill2	G85, G86, G86.1, G87, G88, G89
Mill	Drill1	G73, G74, G74.1, G76, G81, G82, G83
	Drill2	G84., G84.1, G85, G86, G87, G88, G89
	Pocket	G88.1, G88.2
	Post	G88.3, G88.4
	Irregular	G89.1, G89.2
	Hemispherical Pocket	G88.5, G88.6
	Probe	G38, G38.1
Grinder	Surface	G81, G82, G83, G84, G85, G86
	Cylindrical	G81, G82, G83, G84, G85, G86, G87, G88
	Cylindrical 2	G89
	Turning	G20, G24, G33, G34

Important: Drilling cycles include tapping and boring.

- At the cycle format line, use the left and right arrow keys to move through the cycle screen to enter your desired values. Since most parameters are nonoptional, values must be entered sequentially.
- After entering all parameter values, press [**ENTER**] or the **{EXIT}** softkey to confirm the data at the input lines. You will then return to the cycle editor screen.

The most recently entered block appears at the bottom of the cycle editor screen.

- To exit the cycle editor, press the **{EXIT}** softkey.

Modifying an Existing Cycle Block

Once you insert a cycle block into a program, you can still modify it with the cycle editor, even though the program resides in the line editor. To modify an existing cycle block using the cycle editor:

1. Place the cycle block that you want to modify in the edit line.
2. Press the {**CYCLE MODIFY**} softkey to automatically activate the cycle editor.
3. Edit the cycle block by replacing the unwanted values with your replacement values.
4. Press [**ENTER**] on the numeric keypad to enter the new cycle block.

Important: When modifying parameters, the source line cycle parameter order (system-inserted characters) must be identical to the order in the cycle editor.

Deleting a Program {DELETE}

To delete part programs stored in memory:



ATTENTION: Once you delete a program from memory, it can not be recovered. Abort the delete program operation by pressing the {**DELETE NO**} softkey.

1. Press the {**PRGRAM MANAGE**} softkey.

(softkey level 1)

	PRGRAM MANAGE	OFFSET	MACRO PARAM	PRGRAM CHECK	SYSTEM SUPORT	→
F2	F3	F4	F5	F6	F7	F8
		ERROR MESSAGE	PASS- WORD	SWITCH LANG		→
F2	F3	F4	F5	F6	F7	F8

2. Press the {**DELETE PRGRAM**} softkey.

(softkey level 2)

↑	ACTIVE PROGRAM	EDIT PROGRAM	RESTRT PROGRAM	DISPLY PROGRAM	COPY PROGRAM	→
F2	F3	F4	F5	F6	F7	F8
↑	DELETE PROGRAM	VERIFY PROGRAM	PRGRAM COMENT	RENAME PROGRAM	INPUT DEVICE	→
F2	F3	F4	F5	F6	F7	F8
↑	REFORM MEMORY	CHANGE DIR				→
F2	F3	F4	F5	F6	F7	F8

3. Select one of these two choices:

- Key in the the program name and press the **{DELETE YES}** softkey
- Move the block cursor down until the desired program is in reverse video and press the **{DELETE YES}** softkey.

(softkey level 3)

↑		DELETE YES	DELETE NO			
F2	F3	F4	F5	F6	F7	F8

You can delete all programs at once by formatting the RAM disk as described in chapter 2.

Renaming Programs {RENAME}

To change the program names assigned to the part programs stored in memory:

1. Press the **{PRGRAM MANAGE}** softkey.

(softkey level 1)

	PRGRAM MANAGE	OFFSET	MACRO PARAM	PRGRAM CHECK	SYSTEM SUPORT	→
F2	F3	F4	F5	F6	F7	F8
		ERROR MESAGE	PASS- WORD	SWITCH LANG		→
F2	F3	F4	F5	F6	F7	F8

2. Press the **{RENAME PRGRAM}** softkey.

(softkey level 2)

↑	ACTIVE PROGRAM	EDIT PROGRAM	RESTRT PROGRAM	DISPLY PROGRAM	COPY PROGRAM	→
F2	F3	F4	F5	F6	F7	F8
↑	DELETE PROGRAM	VERIFY PROGRAM	PRGRAM COMENT	RENAME PROGRAM	INPUT DEVICE	→
F2	F3	F4	F5	F6	F7	F8
↑	REFORM MEMORY	CHANGE DIR				→
F2	F3	F4	F5	F6	F7	F8

3. Key in the current program name or cursor down until the desired program is in reverse video. Then:

- Type in a comma, the new program name.
- Press the **{RENAME YES}** softkey. To abort the operation press the **{RENAME NO}** softkey.

:current-program-name, new-program-name

(softkey level 3)

↑	RENAME YES	RENAME NO				
F2	F3	F4	F5	F6	F7	F8

Displaying a Program {DISPLY PRGRAM}

The control has a part program display feature that allows viewing (but not editing) of any part program.

Follow these steps to display a part program stored in the control's memory.

1. Press the {PROGRAM MANAGE} softkey.

(softkey level 1)

	PROGRAM MANAGE	OFFSET	MACRO PARAM	PROGRAM CHECK	SYSTEM SUPPORT	→
F2	F3	F4	F5	F6	F7	F8
		ERROR MESSAGE	PASS- WORD	SWITCH LANG		→
F2	F3	F4	F5	F6	F7	F8

2. Select the input device using the {INPUT DEVICE} softkey (as described in chapter 7). This is only necessary if the currently active input device is not the device that the part program to display is currently resident on. The default input device is control memory.
3. Move the block cursor to the program to be displayed.
4. Press the {DISPLY PRGRAM} softkey.

(softkey level 2)

↑	ACTIVE PROGRAM	EDIT PROGRAM	RESTRT PROGRAM	DISPLY PROGRAM	COPY PROGRAM	→
F2	F3	F4	F5	F6	F7	F8
↑	DELETE PROGRAM	VERIFY PROGRAM	PROGRAM COMENT	RENAME PROGRAM	INPUT DEVICE	→
F2	F3	F4	F5	F6	F7	F8
↑	REFORM MEMORY	CHANGE DIR				→
F2	F3	F4	F5	F6	F7	F8

5. To scroll the part program blocks, hold down the [SHIFT] key, then press the up or down cursor keys.
6. To end the displaying operation, press the exit {↑} softkey. The display returns to the program directory screen.

Displaying Comments {PROGRAM COMENT}

You can assign a short comment on the program directory screens to each individual program. These comments are used to identify a program when it is selected for automatic operation or to be edited.

Important: These are not normally the same as a comment block made within a part program. Comment blocks are described on page 9-4. If a comment block is assigned as the **first** block of the part program, it will be displayed on the program directory screen as a comment. Any other comment blocks have no affect on the comment display.

Important: The {PROGRAM COMMENT} feature does not allow you to add comments to programs stored in the hard drive directory.

To assign a comment to a program without using a comment block as the first block of the program, follow the steps below:

1. Press the {PROGRAM MANAGE} softkey. This displays the program directory screen. Any existing comments that have previously been assigned to a program are displayed to the right of the program name.

(softkey level 1)

	PROGRAM MANAGE	OFFSET	MACRO PARAM	PROGRAM CHECK	SYSTEM SUPPORT	→
F2	F3	F4	F5	F6	F7	F8
		ERROR MESSAGE	PASS- WORD	SWITCH LANG		→
F2	F3	F4	F5	F6	F7	F8

2. Use the up or down cursor keys to select the program to add the comment to. The selected program name appears in reverse video.
3. Press the {PROGRAM COMMENT} softkey. The comment softkey appears in reverse video and the control displays the prompt "COMMENT:" on line 2 of the screen.

(softkey level 2)

↑	ACTIVE PROGRAM	EDIT PROGRAM	RESTR PROGRAM	DISPLY PROGRAM	COPY PROGRAM	→
F2	F3	F4	F5	F6	F7	F8
↑	DELETE PROGRAM	VERIFY PROGRAM	PROGRAM COMMENT	RENAME PROGRAM	INPUT DEVICE	→
F2	F3	F4	F5	F6	F7	F8
↑	REFORM MEMORY	CHANGE DIR				→
F2	F3	F4	F5	F6	F7	F8

If a comment has previously been entered, it is displayed to the right of the "COMMENT" prompt. This comment can be edited using the input cursor as described on page 2-10, or the old comment can be deleted by pressing the [BACKSPACE] key.

Important: The {PROGRAM COMMENT} feature does not allow you to add comments to programs stored in the hard drive directory.

4. Type in the new comment or edit the old comment by keying it in using the keyboard. Up to 28 characters can be entered on single process systems, and 14 characters on a dual processing system.
5. When the new comment is correctly displayed on line 2 of the screen, press the [ENTER] key. The new comment is displayed next to the selected program.

Copying Programs {COPY PRGRAM}

This section describes making a duplicate of a part program in control memory.

To copy part programs stored in memory using different program names:

1. Press the {PROGRAM MANAGE} softkey.

(softkey level 1)

	PROGRAM MANAGE	OFFSET	MACRO PARAM	PRGRAM CHECK	SYSTEM SUPORT	→
F2	F3	F4	F5	F6	F7	F8
		ERROR MESSAGE	PASS- WORD	SWITCH LANG		→
F2	F3	F4	F5	F6	F7	F8

2. Press the {COPY PRGRAM} softkey.

(softkey level 2)

↑	ACTIVE PRGRAM	EDIT PRGRAM	RESTRT PRGRAM	DISPLY PRGRAM	COPY PRGRAM	→
F2	F3	F4	F5	F6	F7	F8
↑	DELETE PRGRAM	VERIFY PRGRAM	PRGRAM COMENT	RENAME PRGRAM	INPUT DEVICE	→
F2	F3	F4	F5	F6	F7	F8
↑	REFORM MEMORY	CHANGE DIR				→
F2	F3	F4	F5	F6	F7	F8

3. Key in or cursor down to the program name of the program to be copied.
4. Key in a comma followed by the a new program name for the duplicate program.

COPY: *FromYourProgramName,ToYourProgramName*

5. Press the {MEM TO MEM} softkey.

(softkey level 3)


↑					MEM TO MEM	
F2	F3	F4	F5	F6	F7	F8

6. Select the destination you want your part program to be copied to.

(softkey level 4)

↑	TO MAIN	TO PROTEC	TO HARDD			
F2	F3	F4	F5	F6	F7	F8

A similar screen appears:



7. Select softkey {COPY YES} or {COPY NO}. {COPY YES} copies the part program, while {COPY NO} aborts the copy operation.
8. If you want to verify that the copied program identically matches the original, use the {VERIFY PROGRAM} feature described in chapter 9.

Important: You can not copy part programs can not copy part programs stored on the main part program directory to the protectable directory and vice versa.

Selecting the Protectable Part Program Directory

This section contains information on how to select the protectable part program directory. Use this directory to store part programs that you wish to control access to. When part programs that have previously been protected through encryption are downloaded to the control from ODS or the Mini DNC package, they are automatically stored in the protectable part program directory.

Important: The {CHANGE DIR} softkey controls access to the protectable part program directory. This softkey is password protected. You must have the proper password to access this softkey.

If you have access to the {CHANGE DIR} softkey, you can:

- perform any of the program edit functions on the protected programs

- directly select and activate any of the protected programs
- view programs executing from this directory


You can only call a protected program from a main program using a subprogram, G-code macro, or M-code macro call without access to the {CHANGE DIR} softkey.

If you do not have access to the {CHANGE DIR} softkey, you cannot view the executing blocks of the program called from the protected directory.


To access the protectable part program directory:

1. Press the {PROGRAM MANAGE} softkey.

(softkey level 1)




The control displays the hard drive directory screen:




2. Press the {CHANGE DIR} softkey.

(softkey level 2)



Important: The control does not display the {CHANGE DIR} softkey if your password does not allow you access to it.

The control displays the protectable directory screen:



The programs in this directory are protected. This means:

- they are processed the same as unprotected programs
- the blocks of protected programs are not displayed during program execution unless you have access to the {CHANGE DIR} softkey (in place of the protected program blocks, the last user non-protected programming block is displayed)
- you can cycle stop during program execution (but you cannot single block through a program)

END OF CHAPTER

Editing Programs Offline

Chapter Overview

This chapter describes how to use the Offline Development System (ODS) to edit part programs. Major sections include:

Topic:	On page:
Selecting the part program application	6-2
Editing off line	6-2
Downloading from ODS	6-5
Uploading to ODS	6-9

Use the Offline Development System (ODS) to write or edit part programs. Once you complete these part programs, download them to the PC that contains the 9/PC control. Programs that already exist on the control can be uploaded to the PC for editing or backup. You can edit programs on ODS by using the screen or text editor that is configured in ODS. You can purchase enhancements to this feature in a Mini-DNC package from Allen-Bradley. If you purchased the Mini-DNC package, see its accompanying documentation.

We make these assumptions:

- ODS is installed on the PC that the 9/PC is installed in or that on a PC that is networked with the PC where the 9/PC is installed
- a compatible screen or text editor has been configured using the Text Editor Setup option of the F5-Configuration menu
- the programmer understands the basics of the ODS system and how it operates

For additional information, see the ODS manual, publication MCD-5.1.


Important: Be aware that some features described here may not be available with your ODS. Some may require the purchase of the Mini-DNC package to be functional.

Selecting the Part Program Application

Selecting the Part Program application provides access to the part program utilities of ODS. To select the Part Program application:

1. Return to the main menu line of ODS.
2. Press [F3] to pull down the Application menu:

The PC displays this screen:



3. Press [R] to select the Part Program option.

The status line of the screen displayed by the PC shows that the Part Program application has been selected.

Editing Part Programs Offline


Use the Edit Part Program utility of ODS to edit part programs on a PC. Programs that already exist on the control can be uploaded to the PC for editing. These programs or programs created using ODS can be edited using the screen or text editor that is configured in ODS.

To edit part programs thorough ODS:

1. Select the Part Program Application. Refer to the previous section.


2. Press [F4] to pull down the Utility menu:

The PC displays this screen:



3. Press [E] to select the Part Program option.

The PC displays this screen:




4. Select a new or existing file.

To create a new file, type in the new file name. To open an existing file use the arrow keys to select a file or type in a file name.

Press [ENTER] when done, or [ESC] to cancel.

After you select a file, the PC displays a screen explaining the text editor:



Use the configured screen or text editor to edit part programs. The editor must be compatible with the ODS operating system. The editor must be configured using the Text Editor Setup option of the F5-Configuration menu at the main menu line. For details on how to use a specific screen or text editor, such as ending an edit session, displaying a program, etc., see the documentation provided with the screen or text editor.

You can find details about programming blocks in later chapters.

Important: The end of block statements, ";" used to separate blocks on the control should not be entered with the screen or text editor. The control automatically inserts the end of block statements ";" at the end of each line when the program is downloaded to the control.

The maximum number of programs that you can have is **328**. To store a program, it will use at least one sector (2048bytes/1.3m) of memory. Use this table to find out how much part program space there is in your system.

If your system has	this is your part program storage
64K	150 meters
1MB	2589.6 meters/1,019,904 bytes
4MB	10540.4 meters/4,151,296 bytes

Downloading Part Programs from ODS

After using the part program edit utility to create or edit a part program file offline, the programmer can download this part program to the control or to a storage device by using the Download application of ODS.


Important: When you download a program from ODS to the control, it is automatically inserted into the normal program directory on the control. The control automatically inserts the end of block statements ";" at the end of each line when the program is downloaded to the control.

Important: Use the Download application of ODS to download part programs to your Main and Protectable directories only.


To download a part program from ODS to the control's memory, follow these steps:

1. Make sure you are at ODS' main menu line.
2. Press [F3] to pull down the Application menu.

The PC displays this screen:




3. Use the arrow keys to highlight the Download application, then press [ENTER] or press [D].
4. Press [F4] to pull down the Utility menu.



5. Use the arrow keys to highlight the Send Part Program option, then press [ENTER], or press [R].
6. Use the arrow keys to highlight the download destination or press the letter that corresponds to the download destination. When selected, press [ENTER].

The PC displays the part program files that are stored in the active project directory of the 9/PC:



7. Use the arrow keys to highlight the name or type in the part program name to download, then press [ENTER].

Important: You can upload and download more than one part program by using wildcards ("*" or "?") in place of all or part of a file name. Refer to the PC's DOS manual for additional information about using wildcards.

If the selected part program file name already exists on the control, the PC displays this screen:




Important: The currently active or open part program on the control can not be renamed or overwritten during a download procedure.

If you select this option:	This happens:
Rename	the PC renames the existing file, which has the same name as the file being uploaded, on the PC. The PC displays the part program files stored on the PC. Type in the new name for the existing part program on the control.
Overwrite	the part program file being downloaded overwrites the file having the same name on the control.
Abort	the download process is discontinued and the PC prompts the programmer for additional files to download.

Important: If you enter a wildcard in place of a file name, the Abort option is repeated for each file that matches the wildcard. Pressing the [ESC] key quits the abort wildcard process.


After selecting the Rename or Overwrite option, or if the file being downloaded did not already exist on the control, the PC displays this screen:



The percentage of the download process that has currently been completed is displayed on the screen. This value is updated continually throughout the download process.

When you download a program to a control, the control does not display a message to indicate that a download is taking place. If you download a large program it can take several minutes for the control to complete the download. As the program downloads, the control updates the size of the program shown.


When the download process is complete, the PC displays this screen:



8. Select “Yes” or “No.”

If you select:	Then:
Yes	the system prompts the programmer through the download procedure again
No	the PC returns to ODS the main menu line.

If the PC was unable to complete the download procedure in the allotted time frame, it displays this screen:




Pressing any key causes the PC to return to the ODS main menu.

UPLOAD Part Programs to ODS


The programmer can upload a part program from the control's memory to the PC by using the ODS Upload application. This allows the part program to be edited or stored on the PC.

1. Interface the PC with the control.
2. Return to the main menu line of ODS.
3. Press [F3] to pull down the Application menu.

The PC displays this screen:




4. Use the arrow keys to highlight the Upload application, then press [ENTER] or press [U] .
5. Press [F4] to pull down the Utility menu.



6. Use the arrow keys to highlight the Get Part Program option, then press [ENTER], or press [R] .
7. Use the arrow keys to highlight the upload origin, then press [ENTER] or press the letter that corresponds to the upload origin.

The PC displays the part program files that are stored on the control:




8. Use the arrow keys to highlight the name of the part program to be uploaded to the PC or type in the part program name, then press [ENTER].

When you upload a program from the control, the control does not display a message to indicate that an upload is taking place. If you upload a large program it may take several minutes for the upload to complete. If you try to edit the program while it is uploading you see an error message that says the program is already open. You have to wait until the upload is complete to edit the program.


Important: You can upload and download more than one part program by using wildcards (“*” or “?”) in place of all or part of a file name. Refer to the PC’s DOS manual for additional information about using wildcards.

If the selected part program already exists on the PC, the PC displays this screen:



If you select the Rename option, the PC renames the existing file, which has the same name as the file being uploaded, on the PC.

The PC displays the part program files stored on the PC:




9. Type in the new name for the existing part program file on the PC.

If you select this option:	This happens:
Overwrite	the part program file being uploaded overwrites the file having the same name on the PC.
Abort	the upload process is discontinued and the PC prompts the programmer for additional files to upload.

Important: If you enter a wildcard in place of a file name, the Abort option is repeated for each file that matches the wildcard. Pressing the [ESC] key quits the abort wildcard process.


If the name of the part program that was entered does not exist on the PC or the Overwrite option was selected the PC displays this screen:



The percentage of the upload process that has currently been completed is displayed on the screen. This value is updated continually throughout the upload process.

When you upload a program from the control, the control does not display a message to indicate that an upload is taking place. If you upload a large program it can take several minutes for the upload to complete. If you try to edit the program while it is uploading, you see an error message that says the program is already open. You have to wait until the upload is complete to edit the program.

After the part program has been uploaded to the PC, the PC displays this screen:



Select "Yes" or "No."

If you select:	Then:
Yes	the system prompts the programmer through the upload procedure again
No	the PC returns to ODS the main menu line.

END OF CHAPTER

Running a Program

Chapter Overview

This chapter describes how to test a part program and execute it in automatic mode. Major topics include:

Topic:	On page:
Selecting special running condition	7-1
Selecting a program	7-5
Deselecting a part program	7-7
Program search	7-8
Program execution	7-14
Programmable block execution	7-21
Jog retract	7-27
Block retrace	7-30

Selecting Special Running Conditions

The following subsections describe some of the functions available on the 9/PC that affect how it executes a program. The use of these “special running conditions” is optional. They are activated either through the MTB panel, through programming, or some combination of the two.

Block Delete

When programming a slash “/” followed by a numeric value (1-9) anywhere in a block, 9/PC skips (does not execute) all remaining programmed commands in that block if a optionally installed switch on the MTB panel is activated. If the “block delete type” parameter in AMP is set to “delete whole,” then the entire block is deleted regardless of the position of the block delete character. For details on the block delete feature, refer to page 9-5.

To activate the block delete feature, your system installer may have installed a switch corresponding to a block delete number (refer to the documentation prepared by your system installer).

Miscellaneous Function Lock

When the MISCELLANEOUS FUNCTION LOCK is made active, 9/PC displays M-, second auxiliary functions (B-codes), S-, and T-codes in the part program and activates the corresponding Tool Wear Offset, except for M00, M01, M02, M30, M98, M99.

To activate the MISCELLANEOUS FUNCTION LOCK feature, your system installer may have installed a switch corresponding to the MISCELLANEOUS FUNCTION LOCK feature (refer to documentation prepared by your system installer).

Sequence Stop {SEQ STOP}

Use this feature to cause automatic program execution to stop after a specified block. This block is determined by assigning its sequence number (N-word) as the sequence stop block. This sequence number may be entered before or after part program execution begins. If this sequence number is entered after program execution begins, it must be entered before 9/PC executed that block. If it is not entered before the block is executed, it is ignored and execution continues as normal.

Automatic execution stops after the sequence stop block is completed. 9/PC is placed in cycle stop. To resume execution from the current position in the program, press the <CYCLE START> button.

Important: Once you enter a sequence stop number for a program, it remains active for all programs that are executed until it is replaced with a different sequence stop number, or power is lost. Not entering a value for the sequence stop number or entering a value of zero results in the sequence stop function being canceled.

If you call a subprogram or macro that also contains a sequence number that corresponds to the sequence stop number, program execution stops in the subprogram or macro at the corresponding sequence number.

To enter a sequence number to stop execution:

1. Press the {PROGRAM MANAGE} softkey. A program must already have been selected for automatic execution as described in chapter 7.

(softkey level 1)

	PROGRAM MANAGE	OFFSET	MACRO PARAM	PROGRAM CHECK	SYSTEM SUPPORT	→
F2	F3	F4	F5	F6	F7	F8
		ERROR MESSAGE	PASS- WORD	SWITCH LANG		→
F2	F3	F4	F5	F6	F7	F8

- Press the **{ACTIVE PROGRAM}** softkey.

(softkey level 2)

↑	ACTIVE PROGRAM	EDIT PROGRAM	RESTRT PROGRAM	DISPLY PROGRAM	COPY PROGRAM	→
F2	F3	F4	F5	F6	F7	F8
↑	DELETE PROGRAM	VERIFY PROGRAM	PROGRAM COMMENT	RENAME PROGRAM	INPUT DEVICE	→
F2	F3	F4	F5	F6	F7	F8
↑	REFORM MEMORY	CHANGE DIR				→
F2	F3	F4	F5	F6	F7	F8

- Press the **{SEQ STOP}** softkey.

(softkey level 3)

↑	DE-ACT PROGRAM	SEARCH	MID ST PROGRAM			→
F2	F3	F4	F5	F6	F7	F8
↑	SEQ STOP				TIME PARTS	→
F2	F3	F4	F5	F6	F7	F8

- Key in the sequence number where you want automatic operation in the part program to stop, then press the **[ENTER]** key.


Important: 9/PC stops automatic operation after it completes the commands in the block.

- Press the **<CYCLE START>** button to continue execution of the program from the point at which program execution was stopped.

Single Block

In single block mode, 9/PC executes the part program block by block. Each time you press the **<CYCLE START>** button, 9/PC executes one block of commands in the part program when in single block mode.

Figure 7.1
Single Block



To activate the single block function, press the **<SINGLE BLOCK>** button. The light inside the button lights up when active.

If you press the **<SINGLE BLOCK>** button while 9/PC is running a part program in the automatic or MDI mode, 9/PC activates the single block function after it completes the commands in the block that is currently being executed.

The **<SINGLE BLOCK>** button is a toggle switch. If you press it again while the single block function is active, the function is canceled and the light inside the button turns off. You can execute the remaining program blocks normally by pressing the **<CYCLE START>** button.

Selecting a Part Program Input Device

Before selecting a part program, you must tell 9/PC where the part program currently resides. The program can reside:

- in the control's RAM memory
- in the PC's hard disk

To view the part program input device:

1. Press the **{PROGRAM MANAGE}** softkey.

(softkey level 1)

	PROGRAM MANAGE	OFFSET	MACRO PARAM	PRGRAM CHECK	SYSTEM SUPORT	→
F2	F3	F4	F5	F6	F7	F8
		ERROR MESSAGE	PASS- WORD	SWITCH LANG		→
F2	F3	F4	F5	F6	F7	F8

2. Press the **{INPUT DEVICE}** softkey.

(softkey level 2)

↑	ACTIVE PROGRAM	EDIT PROGRAM	RESTRT PROGRAM	DISPLY PROGRAM	COPY PROGRAM	→
F2	F3	F4	F5	F6	F7	F8
↑	DELETE PROGRAM	VERIFY PROGRAM	PROGRAM COMENT	RENAME PROGRAM	INPUT DEVICE	→
F2	F3	F4	F5	F6	F7	F8
↑	REFORM MEMORY	CHANGE DIR				→
F2	F3	F4	F5	F6	F7	F8

By default, **{FROM MEMORY}** is the location that the part program is read from. Clicking on the **{FROM MEMORY}** softkey returns you to the previous level.

			FROM MEMORY			
F2	F3	F4	F5	F6	F7	F8

Important: The 9/PC has three directories available for storage and part program execution: main, protectable, and the PC's hard drive. To select a different location for part programs to be executed from, use the **{CHANGE DIR}** softkey. For more information about the **{CHANGE DIR}** softkey, refer to page 2-40.

To activate a part program, it must be selected as discussed in the following section.

Selecting a Part Program

To select a program for automatic execution, follow these steps:

Important: Consider the following when selecting a program:


- 9/PC cannot select a program for execution if that program file is still open for editing. Refer to chapter 5 to learn how to exit the edit mode.
- Your system installer may have written logic to allow some other method of part program selection. Refer to the documentation prepared by your system installer for additional information.

- Before selecting a part program to activate, the input device must have been previously selected as described on page 7-5. The default condition selects the part program out of control memory.
- If a program was previously activated and not deactivated, 9/PC cannot select a different part program. If you want a different part program, you must first deactivate the active program as described on page 7-7. You can use a different method to select a program; it is described in chapter 7.


To select a program for automatic execution:

1. Press the {PROGRAM MANAGE} softkey.

(softkey level 1)



This screen appears:



Important: This screen shows program NINEPC as active and being edited. Make sure no part program is currently already active. If a part program is currently active, 9/PC cannot select a different part program until the currently active one is deactivated. Refer to page 7-7 to learn how to deactivate a part program.

If a program is:	This appears to the right of a program name:
active	A
being edited	E

- Key in the name of the part program to activate. If the program is being selected from control memory, the \uparrow or \downarrow cursor keys may be used to select the program to activate from the directory screen.
- Press the **{ACTIVE PROGRAM}** softkey to activate the selected program. 9/PC displays the part program name, followed by the first few blocks of the selected program.

Important: Before you can execute the program, you must place 9/PC in automatic mode.

Deselecting a Part Program

To select a different part program for automatic execution, you must deactivate the part program that is currently active. Follow these steps:

- Press the **{PROGRAM MANAGE}** softkey. 9/PC displays the program directory screen.

(softkey level 1)

	PROGRAM MANAGE	OFFSET	MACRO PARAM	PROGRAM CHECK	SYSTEM SUPPORT	→
F2	F3	F4	F5	F6	F7	F8
		ERROR MESSAGE	PASS- WORD	SWITCH LANG		→
F2	F3	F4	F5	F6	F7	F8

- Press the **{ACTIVE PROGRAM}** softkey. 9/PC displays the first few blocks of the currently active program.

(softkey level 2)

↑	ACTIVE PROGRAM	EDIT PROGRAM	RESTRT PROGRAM	DISPLY PROGRAM	COPY PROGRAM	→
F2	F3	F4	F5	F6	F7	F8
↑	DELETE PROGRAM	VERIFY PROGRAM	PROGRAM COMENT	RENAME PROGRAM	INPUT DEVICE	→
F2	F3	F4	F5	F6	F7	F8
↑	REFORM MEMORY	CHANGE DIR				→
F2	F3	F4	F5	F6	F7	F8

- If the program selected is not the active program you wanted, press the **{DEC-ACT PROGRAM}** softkey. 9/PC deactivates the part program and return to the directory screen.

(softkey level 3)

↑	DE-ACT PROGRAM	SEARCH	MID ST PROGRAM			→
F2	F3	F4	F5	F6	F7	F8
↑	SEQ STOP				TIME PARTS	→
F2	F3	F4	F5	F6	F7	F8

Program Search {SEARCH}

Use the Program Search feature to begin program execution from some block other than the beginning of the program. This feature requires the operator to establish the necessary G-, M-, S-, F-, and T-words, work coordinate offsets, etc. that should be active for that block's execution.

9/PC can start a program at a chosen block and establishing any previous G-, M-, S-, F-, and T-words, work coordinate offsets, etc. that were established in previous blocks using the search with memory feature. For details, refer to page 7-10.

The program search feature is not effective for subprograms and paramacs; only blocks that are in the main program can be searched.

To perform a program search operation:

1. Press the **{PROGRAM MANAGE}** softkey. The program to search must have been previously selected for automatic execution as described in page 7-5.

(softkey level 1)

	PRGRAM MANAGE	OFFSET	MACRO PARAM	PRGRAM CHECK	SYSTEM SUPOUT	→
F2	F3	F4	F5	F6	F7	F8
		ERROR MESAGE	PASS- WORD	SWITCH LANG		→
F2	F3	F4	F5	F6	F7	F8

2. Press the **{ACTIVE PRGRAM}** softkey.

(softkey level 2)

↑	ACTIVE PRGRAM	EDIT PRGRAM	RESTRT PRGRAM	DISPLY PRGRAM	COPY PRGRAM	→
F2	F3	F4	F5	F6	F7	F8
↑	DELETE PRGRAM	VERIFY PRGRAM	PRGRAM COMENT	RENAME PRGRAM	INPUT DEVICE	→
F2	F3	F4	F5	F6	F7	F8
↑	REFORM MEMORY	CHANGE DIR				→
F2	F3	F4	F5	F6	F7	F8

3. Press the **{SEARCH}** softkey.

(softkey level 3)

↑	DE-ACT PRGRAM	SEARCH	MID ST PRGRAM			→
F2	F3	F4	F5	F6	F7	F8
↑	SEQ STOP				TIME PARTS	→
F2	F3	F4	F5	F6	F7	F8

4. Choose from the six search options:

If you are searching for:	Press this softkey:
a sequence number	{N SEARCH}
an O-word	{O SEARCH}
the end of each block	{EOB SEARCH}
the program one line at a time	{SLEW}
a specific character string	{STRING SEARCH}

5. When you use the SLEW or the EOB search options:

If you want to:	Press this softkey:
move to the next or previous blocks in the program	{FORWRD} or {REVRSE}
return to the top of the program (the beginning of the first block)	{TOP OF PRGRAM}
exit, when the desired block is found	{EXIT}

Important: When performing an EOB search, the search is executed from the beginning of the part program, NOT from the point of display.

When you use the N search, O search, or STRING search features, first key in the desired N number, O number, or character string you want to search for. After it has been keyed in:

If you want to:	Press this softkey:
start the search	[ENTER]
search for the entered value in the forward or reverse direction	{FORWRD} or {REVRSE}
return to the top of the program (the beginning of the first block)	{TOP OF PRGRAM}
exit when the desired block is found.	{EXIT}

If no number is keyed in for an N or O search, 9/PC simply searches for the next N- or O-word in the program.

Important: If the system cannot locate an N or O word when conducting an N or O search, the cursor positions itself directly below the the last block in the program (M02).

Important: If performing a STRING search, program execution begins at the beginning of the block that contains the desired character string. This is not necessarily the location of the string in the program block.



ATTENTION: It may be necessary to position the cutting tool at a location that allows this block to execute without damaging the workpiece or cutting tool. This can be done through a manual operation or through MDI.

Search with Recall {MID ST PROGRAM}

Use the Mid-Start Program feature to begin program execution from some block other than the first block of the program. This feature will scan the program as it searches and from within the search area:

- send to logic the last programmed modal G-codes from each modal group.
- send to logic the last programmed modal M-codes from each modal group and set its associated logic strobe (nonmodal codes including user-defined M-codes are not sent to logic).
- send to logic the last programmed T-code and set its associated logic strobe
- send to logic the last programmed auxiliary function code (B-word) and set its associated logic strobe
- send to logic the last programmed spindle commanded speed and set its associated logic strobe
- resolve paramacro equations and assign paramacro variable values

Important: Note on dual process systems (not available in release 1 of 9/PC), shared paramacro variables can be different than expected depending on the state of the part program in the other process. Equations that use logic paramacro variables may also evaluate differently since no paramacro interaction with logic occurs during a search operation.

- establishes any work coordinate system, including all offsets and rotations to the work coordinate system.

Important: Incremental moves that occur during a program search with recall operation, are always referenced from the last known absolute position in the part program. If no absolute position is specified in the searched part program blocks, 9/PC will use the current axis position as the start point for incremental moves.

When a search with recall is performed, 9/PC finds a character string or sequence number in a specific block for execution to begin from. Note that execution always begins from the beginning of the block, regardless of the location in the block of the searched string or sequence number. This searched block must be a block that would normally be executed during the full programs execution (a block that would be skipped by some means such as a jump, etc., cannot be searched for).

The program search with recall feature may be used to search into any subprograms or paramacros that may be contained in the main program. This is provided of course, that the searched block is in the path of normal program execution.

Important: The search with recall feature will not:

- send logic nonmodal M-codes including user-defined groups 0 - 3, group 4, group 5, and group 6 M-codes.
- read from or write paramacro variables to logic

Important: This feature will not search into any cycle that calls a set of profile blocks (typically specified with the P- and Q-word in the cycle). Refer to the description of your cycle for details on profile blocks.

- send to logic gear change requests based on spindle speed

To perform a program search with recall, follow these steps:

1. Press the **{PROGRAM MANAGE}** softkey.

(softkey level 1)

	PROGRAM MANAGE	OFFSET	MACRO PARAM	PROGRAM CHECK	SYSTEM SUPPORT	→
F2	F3	F4	F5	F6	F7	F8

		ERROR MESSAGE	PASS- WORD	SWITCH LANG		→
F2	F3	F4	F5	F6	F7	F8

2. Press the **{ACTIVE PROGRAM}** softkey.

(softkey level 2)

↑	ACTIVE PROGRAM	EDIT PROGRAM	RESTRT PROGRAM	DISPLY PROGRAM	COPY PROGRAM	→
F2	F3	F4	F5	F6	F7	F8
↑	DELETE PROGRAM	VERIFY PROGRAM	PROGRAM COMENT	RENAME PROGRAM	INPUT DEVICE	→
F2	F3	F4	F5	F6	F7	F8
↑	REFORM MEMORY	CHANGE DIR				→
F2	F3	F4	F5	F6	F7	F8

Make sure that the program to search is the currently active program. If it is not, select it for automatic execution as discussed on page 7-5.

3. Press the **{MID ST PROGRAM}** softkey.

(softkey level 3)

↑	DE-ACT PROGRAM	SEARCH	MID ST PROGRAM			→
F2	F3	F4	F5	F6	F7	F8
↑	SEQ STOP				TIME PARTS	→
F2	F3	F4	F5	F6	F7	F8

4. To search for a sequence number press the **{SEQ # SEARCH}** softkey. To search for a character string press the **{STRING SEARCH}** softkey.

(softkey level 4)

↑	SEQ # SEARCH	STRING SEARCH				
F2	F3	F4	F5	F6	F7	F8

5. Key in the desired character string or sequence number to search for and press the **[ENTER]** key. 9/PC puts an @ symbol to the left of the block immediately before the block that automatic execution begins from.

If this is not the block to begin execution from press either the:

{CONT} softkey to continue to search for the entered character string or sequence number.

{TOP OF PROGRAM} to return to the first block in the program.

{QUIT} softkey to end either the sequence number search or the character string search operations.

(softkey level 5)

	CONT	TOP OF PROGRAM	QUIT	EXIT	EXIT & MOVE	
F2	F3	F4	F5	F6	F7	F8



ATTENTION: When you exit a mid-program start (search with memory), M- and S-codes are sent to logic. If, during normal execution, that program activated a spindle, mid-program start may also start it. To prevent this, your system installer can use the BR_BLKSTAT flag, which indicates 9/PC is in mid-program start.

6. Press the **{EXIT}** or the **{EXIT & MOVE}** softkey once the program is at the desired location.

{EXIT} - Use this softkey if the tool is at the exact location for execution of the searched program block. While 9/PC searches for your starting block it performs calculations to determine what the absolute position of the axes should be before your selected block is executed. If the cutting tool is not at this position when you press the **{EXIT}** softkey, 9/PC aborts the mid-start operation. When this occurs 9/PC displays the message "AXIS POSITION INCORRECT".

{EXIT & MOVE} - Use this softkey if the tool is not at the exact location for execution of the searched block. Be aware that the absolute position of the axes necessary at the start of the searched block is dependant on the previous blocks. There can be offsets activated or incremental moves that can make it difficult for you to determine the exact absolute starting point for the axes. 9/PC generates a motion block to place the tool at the position necessary to generate the intended contour when the searched block is executed. The block generated is always a linear move with a feedrate based on the last motion block prior to the searched block. If the last motion block was a cutting move with a feedrate, then the generated block will be a linear move at that cutting feedrate. If the last motion block was a rapid move, that the generated block will be a linear move at the rapid feedrate.



ATTENTION: It is the responsibility of the system installer's logic application to make sure proper activation of all necessary machine functions has occurred before allowing a search with recall operation to continue. You should verify that all machine functions are in the correct state before pressing **<CYCLE START>**.

A message is generated telling the operator to check that all generated modal codes are correct. This message reads "WARNING - VERIFY MODAL CODES". These modal codes should be checked on the G- or M-code status screen.

9/PC begins program execution from the selected block when you press the **<CYCLE START>** button. If you have pressed the **{EXIT & MOVE}** button 9/PC first executes the generated block to place the tool at the proper location. If you do not want 9/PC to execute this generated block you can perform a block reset to abort the generated block.

Program interrupts that are enabled in blocks prior to the searched block (M96L__P__), are active and available for execution once the active program begins execution. Interrupts can not be executed while the mid-program search operation is taking place.

Basic Program Execution

After a program is written or loaded into 9/PC, it should be thoroughly tested before a part is mounted and machined. 9/PC offers three distinct testing modes in addition to fully automatic operation.

These modes are briefly described below in the order in which they would normally be implemented.

- QuickCheck™ (refer to page 7-16) — This mode is a basic syntax checker for a part program. It checks that proper format and syntax has been followed. No actual axis motion is produced during QuickCheck, however, offsets and coordinate system shifts are performed.
- Axis Inhibit (refer to page 7-17) -- The axis inhibit mode allows the execution of a program to take place without moving a selected axis or axes. Programmed feedrates are active and the program executes in approximately the same time as normal program execution. Axis motion is simulated for any of the non-moving axes by all of the position displays changing at the programmed feedrate.
- Dry Run (refer to page 7-18) -- Dry run simply replaces all F-word feedrates in a program with a special feedrate determined by the system installer in AMP.
- Part Production/Automatic (refer to page 7-19) -- In automatic mode all of the axes are active and all of the programmed feedrates are in effect.

All of these modes of execution begin program execution when you press the <CYCLE START> button.

When you see this to the left of the block:	9/PC:
*	is executing a part program block.
@	has completed the execution of a block. The @ symbol is usually only seen in single block mode or in cases where it is necessary to indicate what block automatic execution begins after.

You can interrupt Axis Inhibit, Dry Run, and Automatic operation by using any of the operations listed below. Execution can be resumed at the interrupted location by pressing the <CYCLE START> button.

(1) Pressing <CYCLE STOP>

When you press the <CYCLE STOP> button, motion of the cutting tool decelerates and stops, and 9/PC stops automatic operation. If you press the <CYCLE STOP> button during a dwell, the dwell is interrupted and any remaining time/revolutions for the dwell are stored for later execution.

(2) Execution of an M00 or M01 in a Part Program

Execution of:	Description:
M00	9/PC stops automatic operation after it executes the remaining commands in the M00 block.
M01	if the OPTIONAL STOP condition is set to ON, 9/PC stops automatic operation after it executes the remaining commands in the M01 block. If the OPTIONAL STOP condition is set to OFF, the M01 is ignored and 9/PC continues executing the part program as normal. The optional stop condition may be turned off or on using a switch installed by your system installer.

(3) Entering a Sequence Stop Number

To interrupt execution at a specific block in the part program, use the sequence stop feature described on page 7-2. 9/PC stops automatic operation after it completes the commands in the designated block.

(4) Feedhold Status

Your system installer may have written logic to allow the activation of a feedhold state through the use of a button or switch. When activated 9/PC decelerates all moving axes to a feedrate of zero until the feedhold state is deactivated. For details on using feedhold, refer to documentation provided by your system installer.


QuickCheck

QuickCheck is a basic syntax checker for a part program. It checks that proper format and syntax have been followed during programming. No actual axis motion is produced in QuickCheck mode.

To use the QuickCheck feature, follow these steps.

1. Select a program to check as described on page 7-5 and return to softkey level 1.
2. Press the {PROGRAM CHECK} softkey.

(softkey level 1)



3. Press the {QUICK CHECK} softkey.

(softkey level 2)



4. Press the {SYNTAX ONLY} softkey.

(softkey level 3)



When you press the {SYNTAX ONLY} softkey, it appears in reverse video.

5. Press the <CYCLE START> button.

When you press the <CYCLE START> button, the program blocks are executed.

If a program block contains an error, the program check stops and 9/PC displays the message "ERROR FOUND."

To continue checking the remaining program blocks, press the <CYCLE START> button again. If no more errors are found, 9/PC displays the message "COMPLETED WITH ERROR(S)" and the part program is automatically deactivated to allow editing.

If 9/PC finds no errors during QuickCheck the program screen displays the message "COMPLETED WITH NO ERRORS". 9/PC then automatically resets the program to the first block.

To disable QuickCheck, press the {STOP CHECK} softkey.



ATTENTION: Note that when a program is run during quick check mode, 9/PC performs all coordinate system offset operations. This means that changes to the coordinate systems or coordinate offset tables are made (G10 blocks, changes to G92 and G52 offsets, and changes to the active work coordinate systems G54-G59.9). All of these changes are discarded at any termination of QuickCheck. The pre-QuickCheck values are restored when the {**Stop Check**} softkey is pressed. Note that program changes to the active offset or tool offset tables are not made in QuickCheck mode.

Axis Inhibit Mode

When you activate AXIS INHIBIT, 9/PC can execute a part program without moving specified axes. 9/PC simulates axis motion by updating the axis location and feedrate displays, using the commanded feedrates, acceleration, and deceleration.

The program is executed in approximately the same amount of time as it would be in automatic mode, even though some or all axes may not move. You can use the axis inhibit feature in conjunction with Dry Run.



ATTENTION: When testing a program using Axis Inhibit 9/PC still recognizes and executes M-, B-, S-, and T-codes. To ignore M-, B-, S-, and T-codes, execute Axis inhibit in conjunction with miscellaneous function lock. Refer to page 7-1.

You can activate AXIS INHIBIT to inhibit motion of any or all of the axes depending on the configuration determined by your system installer. This includes jogging moves. When axis motion has been inhibited for a single axis, the remaining axes still execute normally and the axis location display is updated as if axis motion were occurring on all axes.



ATTENTION: Axes not selected for axis inhibit move as they would if the program were executed in automatic mode.

You can activate the Axis Inhibit feature using a switch installed by your system installer (refer to the documentation provided by the system installer). 9/PC must be in cycle stop or E-Stop to activate or deactivate the Axis Inhibit feature. Any attempt to activate or deactivate the feature during program execution or when in cycle suspend or feedhold states is ignored. Attempts to activate the Axis Inhibit feature during jogging are also ignored.

Press **<CYCLE START>** to program execution with the Axis Inhibit feature. Make sure you select a program for execution. Refer to page 7-5.

You can stop program execution with Axis Inhibit at any time by using any of the methods described for normal program execution or by pressing the **<EMERGENCY STOP>** button.



ATTENTION: Axes not selected for axis inhibit move as they would if the program were executed in automatic mode.

The spindle motion may also be inhibited by using a switch installed by your system installer. Refer to the documentation provided by your system installer.

Dry Run Mode

The Dry Run function permits the checking of a part program to make sure that machine motions are correct. It is intended to be executed without the material or part mounted. The dry run function replaces all programmed feedrates with the maximum cutting feedrate. Jogging moves and moves that are programmed using rapid traverse (G00) are not affected by dry run.

The Axis Inhibit feature can be used in conjunction with Dry Run if desired.

If you use the external decel feature simultaneously with the Dry Run feature, the feedrates that are assigned to External decel feature are used and the Dry run request is ignored.

You can use the **<FEEDRATE OVERRIDE>** to modify the cutting feedrate. Your system installer determines in AMP if rapid feedrates are overrides by the **<RAPID FEEDRATE OVERRIDE>** switch/button or the **<FEEDRATE OVERRIDE>** switch during Dry Run.




ATTENTION: When testing a program using Dry Run, 9/PC still recognizes and executes M-, B-, S-, and T-codes. To ignore M-, B-, S-, and T-codes, execute Dry Run in conjunction with miscellaneous function lock. Refer to page 7-1.



ATTENTION: Your system installer can write logic to allow the operator to select DRY RUN at any time. This means that during normal automatic operation, the operator can select maximum cutting feedrate and replace all feedrates programmed with an F-word with the AMP assigned DRY RUN feedrate. This can result in damage to the machine, part, or injury to the operator.

Figure 7.2
Dry Run



The Dry Run feature can be activated using a switch installed by your system installer (refer to the documentation provided by your system installer).


Part Production/Automatic Mode

Automatic mode is the normal operating mode of 9/PC. A program that is run in the automatic mode is executed with all of the axes active and all of the programmed feedrates active.

To select the automatic mode, place the **<MODE SELECT>** switch/button (on the MTB panel) in the AUTO position.

Automatic mode is the default mode whenever AUTO appears on the Main Menu screen, and it is always active unless one of the program checking modes has been selected.

Figure 7.3
Main Menu Screen in AUTO Mode




In automatic mode, 9/PC manages machine operations according to the commands in a part program.

Command:	Process:
CYCLE START	begins part program execution
CYCLE STOP	stops part program execution



ATTENTION: Always test a program prior to automatic operation. Always verify that the workspace is clear and all safety features are intact before pressing <CYCLE START>.

Figure 7.4
Automatic Mode



Execution of a part program continues until 9/PC encounters an M02 or M30. If 9/PC does not encounter an M02 or M30 at the end of a program, the error message “MISSING M02/M30” appears.

You can stop execution at any time by using any of the methods described on page 7-5 or by pressing the <EMERGENCY STOP> button.

Programmable Block Execution

Use the Programmable Synchronous/Asynchronous Block Execution feature to set the mode that determines how your part program and the machine’s logic are synchronized.

There are three types of programmable block execution:

- Synchronous — G60
- Asynchronous — G60.1
- Autosynchronous — G60.2

Important: Each of these G-codes must be programmed in a nonmotion blocks. Blocks that contain these G-codes are executed in Synchronous mode.

Synchronous Mode (G60)

Use the “Synchronous Mode” to force at least one logic scan to occur for the start of each program block. This mode causes the 9/PC to activate the next sequential program block only after the control triggers the machine logic to run. Execution of this G-code happens at a time interval set by your system installer in AMP.

Synchronous mode allows the following to occur on the active program block:

- logic to decode any M-code, T-word, or any other auxiliary words in the block
- logic to hold the block in pre- or postblock state

Important: In G60 mode, the time interval for interpolation is the Coarse Scan Time.

Important: If your system is executing very short motion blocks while in Synchronous Mode, you may experience delays between blocks waiting for the logic to complete.

Asynchronous Mode (G60.1)

Use “Asynchronous Mode” to allow multiple blocks to be activated during a single scan of logic. This mode causes the 9/PC to execute:

- motion blocks at the fastest rate possible (Fine Foreground Scan Time)
- nonmotion blocks at the fastest rate possible, allowing multiple, contiguous nonmotion blocks to be executed within one system scan time

Asynchronous Mode may be used if your part program contains blocks that execute more quickly than the programmed system logic scan time, but within the 9/PC Fine Foreground Scan Time.

Important: In G60.1 mode, the time interval for interpolation is the Fine Foreground Scan Time.

This mode permits very short duration blocks to run without the delay of waiting for the logic to complete. It is important to note that certain types of blocks cannot be executed in Asynchronous Mode. Refer to the following table for limitations in this mode:

This action:	Causes this 9/PC condition:
Programming auxiliary functions (S, T, M)	a decode error and cycle stop
Programming G-codes in groups 9, 10, 17, 21, 23	
Programming CSS or any fixed cycles	
Execution of a threading block	
Solid tapping	
Execution of any time-dependent paramacro calculations ¹	
Logic request for postblock, preblock, or transfer inhibit	

¹Time-dependent paramacros include logic input flags, system clock, coordinates of commanded position, machine coordinate position, skip signal position work coordinate position, skip signal position machine coordinate position, and current following error. For more information regarding these paramacros, refer to chapter 27, *Paramacros*.

Important: When the logic program requests transfer-inhibit and postblock conditions in asynchronous mode preblock, the control is forced into a CYCLE STOP state and returns an error.



ATTENTION: When in asynchronous mode, the CNC flag status is not updated with the execution of each part program block.

Autosynchronous Mode (G60.2)

Use “Autosynchronous Mode” to allow the control to switch between synchronous and asynchronous block execution, depending upon the contents of the part program block.

In Autosynchronous Mode, it is not necessary for the part program to change the execution mode. The control handles all part program blocks by automatically selecting either synchronous or asynchronous mode. The control makes this selection based upon the contents of the block. Refer to the following table for limitations in this mode:

This action	Causes this 9/PC condition
Programming auxiliary functions (S, T, M)	execution of the block in synchronous mode
Programming G-codes in groups 9, 10, 17, 21, 23	
Programming CSS or any fixed cycles	
Execution of a threading block	
Solid tapping	
Execution of any time-dependent paramacro calculations ¹	execution of the block in asynchronous mode
Execution of all motion-only blocks	
Logic request for postblock, preblock, or transfer inhibit	a decode error and cycle stop

¹Time-dependent paramacros include logic input flags, system clock, coordinates of commanded position, machine coordinate position, skip signal position work coordinate position, skip signal position machine coordinate position, and current following error. For more information regarding these paramacros, refer to chapter 27, *Paramacros*.

Important: Certain logic requests require a CYCLE START if Autosynchronous Mode is active.

Interrupted Program Recover {RESTRT PRGRAM}

Use the program recover feature to resume a program that was executing and was interrupted by some means such as a control reset, E-Stop, or even power failure in some cases. This feature scans the program as it searches for the interrupted block and from within the search area:

- send to logic the last programmed modal G-codes from each modal group.
- send to logic the last programmed modal M-codes from each modal group and set its associated logic strobe (nonmodal codes including user-defined M-codes are not sent to logic).
- send to logic the last programmed T-code and set its associated logic strobe
- send to logic the last programmed auxiliary function code (B-word) and set its associated logic strobe
- send to logic the last programmed spindle commanded speed and set its associated logic strobe
- resolve paramacro equations and assign paramacro variable values (note equations that use logic paramacro variables may evaluate differently since no paramacro interaction with logic occurs during a search operation).
- establishes any work coordinate system, including all offsets and rotations to the work coordinate system.

Important: Incremental moves that occur during a interrupted program recover operation, are always referenced from the last known absolute position in the part program. If no absolute position is specified in the searched part program blocks, 9/PC will use the current axis position as the start point for incremental moves.

Unless **Cutter Compensation** is active, when a program recover is performed, 9/PC automatically returns the program to the beginning of the block that was interrupted. In the case of power failure, 9/PC will even reselect the program that was active prior to the interruption.

When a program recover is performed 9/PC automatically returns the program to the beginning of the block that was interrupted. In the case of power fail 9/PC will even re-select the program as active.



ATTENTION: When a program recover is performed 9/PC automatically returns the program to the beginning of the block that was originally interrupted. The beginning of the block is probably not the point that axis motion was interrupted. For absolute linear moves this causes no problem if the tool is still somewhere along the path of the block that program execution was interrupted while cutting. In incremental or circular mode however, if the cutting tool is still located at the point that program execution was interrupted a restart may damage the part. If a program recover operation is performed in incremental mode it is important that the cutting tool be at the location that the interrupted program block began, not the location that the program was interrupted at.

This feature may also be used to search into any subprogram or paramacro that may be contained in the main program.



ATTENTION: It is the responsibility of the system installers logic application to make sure proper activation of all necessary machine functions has occurred before allowing a interrupted program to continue. You should verify that all machine functions are in the correct state before pressing **<CYCLE START>**.

Important: The interrupted program recover feature will not:

- send logic nonmodal M-codes including user-defined groups 0 - 3, group 4, group 5, and group 6 M-codes.
- read from or write paramacro variables to logic
- send to logic gear change requests based on spindle speed

To perform a program restore operation after automatic program execution has been interrupted follow these steps:

1. Press the {PROGRAM MANAGE} softkey.

(softkey level 1)

	PROGRAM MANAGE	OFFSET	MACRO PARAM	PROGRAM CHECK	SYSTEM SUPPORT	→
F2	F3	F4	F5	F6	F7	F8

		ERROR MESSAGE	PASS- WORD	SWITCH LANG		→
F2	F3	F4	F5	F6	F7	F8

Important: DO NOT SELECT A PROGRAM AS AN ACTIVE PROGRAM. Do not disable the currently active program (if any). If a program is re-selected as active or disabled by the operator the program restore feature is canceled.

2. Press the {RESTRT PROGRAM} softkey. 9/PC automatically re-selects the interrupted program if it was disabled by 9/PC when power was lost.

(softkey level 2)

↑	ACTIVE PROGRAM	EDIT PROGRAM	RESTRT PROGRAM	DISPLY PROGRAM	COPY PROGRAM	→
F2	F3	F4	F5	F6	F7	F8

↑	DELETE PROGRAM	VERIFY PROGRAM	PROGRAM COMENT	RENAME PROGRAM	INPUT DEVICE	→
F2	F3	F4	F5	F6	F7	F8

↑	REFORM MEMORY	CHANGE DIR				→
F2	F3	F4	F5	F6	F7	F8

3. To automatically search for the block in the current program that was interrupted press the {EXEC} softkey.

9/PC will locate an @ symbol to the left of the block immediately before the block that automatic execution was interrupted at.

```

MEMORY      AUTO      STOP
@G91 M05 X-20;
G16.22 Z-5;
Y10.;
X-20;
    
```

This is where execution was interrupted. →

	PROGRAM	A B S	TARGET
F2	F3	F4	F5

If this is not the block to begin execution from, press the {QUIT} softkey. The program restore feature will be aborted.



ATTENTION: When you exit a program restart operation (search with memory), M- and S-codes are sent to logic. If, during normal execution, that program activated a spindle, mid-program start may also start it.

4. Press the **{EXIT}** softkey if the block selected is the block to begin program execution from. If it not the desired block, it will be necessary to disable the program or perform a search with memory operation to locate the desired block manually.

Press the **{EXIT & MOVE}** softkey if you wish to exit this particular program and search another program.

(softkey level 3)

	EXEC	QUIT	EXIT	EXIT & MOVE		
F2	F3	F4	F5	F6	F7	F8

When the **{CYCLE START}** button is pressed 9/PC resumes program execution from the block selected with the program restart feature.

Jog Retract

Use the jog retract feature to allow for inspection or change of the cutting tool during automatic program execution. It allows the cutting tool to be jogged from the workpiece in multiple steps, and then returned to the workpiece automatically by having 9/PC retrace the jogging steps that were used.

9/PC remembers up to 15 jog retract moves. The actual number of moves retained can vary from 0 to 15 as determined by an AMP parameter set by your system installer. 9/PC returns the tool along the jog retract path at a feedrate specified in AMP.

Important: If the same axis is used in succession during a jog retract operation, 9/PC assumes that only one jog retract move has been executed on that axis.

Only simple single axes jog moves can be performed during the jog retract function. You cannot perform multiple axis jogs, and jogging offset.

Tool offsets can be changed at any time during jog retract. Refer to page 3-14. 9/PC does not make these offsets active until the execution of the first block after the tool has been returned from jog retract.



ATTENTION: If the Jog Retract function is deactivated during its execution (performing a control reset, E-Stop, etc.), attempting to return the tool by pressing **<CYCLE START>** can cause the Jog Retract function to abort. The program returns to the start point of jog retract along a linear path. In the event that Jog Retract is deactivated during execution, we recommend that the cutting tool be jogged to the point from which jog retract was started prior to pressing **<CYCLE START>** to avoid possible part or tool damage.


To perform a jog retract operation:

1. Press the **<CYCLE STOP>** or activate **<SINGLE BLOCK>** feature button to stop program execution.
2. Press the **<JOG RETRACT>** button. The light inside the button turns on to indicate that the function is active.
3. Move the cutting tool from the workpiece using either continuous jog, or incremental jog operations (refer to page 4-1 for jogging information.)
4. Inspect and change the tool or tool offset as desired. Details on how to do this are on page 3-14.
5. After completing the desired inspection or tool change, press the **<CYCLE START>** button. Any tool offset changes you have made become active when the cycle start is requested. The tool returns to the location where jog retract began, following the same path used when you jogged the tool away from the work piece (+ or - any new tool offset values).

You can press **<CYCLE STOP>** during the tools automatic return to the jog retract start position. When this is done, the tool can be retracted from this point using jog moves and 9/PC adds these moves to any remaining jog retract steps that have not yet been returned.

6. Once the cutting tool is fully returned from a jog retract operation, 9/PC continues on in the part program unless in single block mode. If in single block mode, 9/PC goes to the cycle stop state when the return from jog retract is completed. Press **<CYCLE START>** again to resume program execution.

Figure 7.5
Jog Retract Operation



In Figure 7.5, 9/PC only recognized six jog moves upon returning instead of the actual 11 moves that were made to retract the tool. This is because the jog retract feature records consecutive jog moves on the same axis as one move.



ATTENTION: If the number of jog retract moves performed exceeds the maximum allowed number set in AMP, 9/PC moves the cutting tool directly from the final point of jog retract to the last remembered jog retract point along a straight line when you press **<CYCLE START>**. The tool is then returned in the normal jog retract fashion.

Figure 7.6
Jog Retract Moves that Exceed the Maximum Allowed in AMP




Figure 7.6 emphasizes the possible problems that can result from exceeding the maximum allowed jog retract moves. In this example, the number of allowed moves set in AMP is four.

When you press the cycle start button at the end of the 7th jog move, 9/PC ignores moves 5, 6, and 7 and takes the shortest path to the endpoint of exit move 4. This is because the maximum number of jog retract moves set in AMP has been exceeded. After reaching the endpoint of move 4, 9/PC continues the jog retract return operation as normal.

If the jogging moves of 5, 6, and 7 were intended to avoid a protrusion during the jog retract, a collision could result when returning the tool.

Block Retrace

The block retrace function allows the operator to retrace the motion created by up to 15 consecutive part program blocks. The actual number of retrace blocks allowed is set by your system installer in AMP, and can vary from 1 to 15.

Important: For maximum control efficiency when executing programs, we recommend that the maximum number of allowable block retraces is set as small as possible for the current machine application. This is because the number of allowable Block Retraces directly affects 9/PCs block look ahead operation.

This function can only be enabled when 9/PC is in cycle stop or cycle suspend state, and it is ignored if 9/PC has already executed an M02 or M30 end of program.

To perform a block retrace operation:

1. Press the **<CYCLE STOP>** or activate the **<SINGLE BLOCK>** feature button to stop program execution.
2. Press the **<BLOCK RETRACE>** button.

After you press the **<BLOCK RETRACE>** button, 9/PC retraces the block that was being executed when the cycle stop occurred or retraces the block just completed if you press the single block button, provided that the block is a legal block for retrace.

While the block retrace function is active, the light in the **<BLOCK RETRACE>** button is on. The block that was shown as active when the block retrace was activated still appears as the currently active block in the program display area during the entire use of the block retrace function.

Important: If you use the **<CYCLE STOP>** button to halt execution to begin a block retrace, 9/PC re-executes the portion of the block that has been executed. For example, if the block requests an axis move of 20 millimeters and the axis has moved 12 mm when you press the **<CYCLE STOP>** button, a block retrace reverses the axis direction 12 mm.

All retraced blocks are executed at the feedrate programmed for that block though this may be modified by the use of the **<FEEDRATE OVERRIDE>** switch. Refer to chapter 17.

Press the **<CYCLE START>** button at any time during a block retrace to return the cutting tool to normal forward execution. Program execution returns to the normal forward direction from the currently retraced block. 9/PC executes the retraced blocks in normal order until the tool is positioned at the start point of block retrace. From this point it continues program execution in a normal fashion unless **<SINGLE BLOCK>** is active. If **<SINGLE BLOCK>** is active, 9/PC halts execution when the return from block retract is complete.

While block retrace is active, 9/PC disables all jog features with the exception of **<JOG RETRACT>**. Refer to page 7-14. MDI is not available to insert blocks during a block retrace operation.

The block retrace function is unable to retrace any of these blocks and an attempt to do so results in an error message:


- Threading
- Tapping
- Boring
- Inch/Metric changes (unit conversion)
- A block that commands a tool change operation

- A block that commands a change in the coordinate system
- Any block that is followed by a Manual Jog Move except a Jog Retract
- The number of blocks retraced is already equal to the maximum number of retraceable blocks as determined in AMP
- Certain Paramacro Parameter Assignments
- Interrupt Macros



ATTENTION: If the block retrace function is deactivated during its execution (performing a control reset, E-STOP, etc.), attempting to return the tool by pressing cycle start can cause an undesired return path. The tool returns to the start point of block retrace along a linear path. This is most likely not the retracted path. To avoid possible part or tool damage, we recommend that the cutting tool be jogged to the point from which block retrace was started prior to pressing cycle start.

Figure 7.7
Pressing Cycle Start When Retract Path is Lost



END OF CHAPTER

Data Display

Chapter Overview

This chapter gives a description of the different data displays available on the control.

Selection of Axis Position Data Display

Pressing the [F12] key displays the softkeys for selecting the axis position data screens.

The control provides eight different axes position data screens as described in Table 8.A. Four of these screens may be displayed in normal, large (4 axis triple size or 8 axis double size), or small characters if desired. Normal size is the default.

Table 8.A
Display Select Softkeys

Display	Description
{PRGRAM}	Axis position in the current work coordinate system is displayed. Each time this softkey is pressed the display toggles between normal and large.
{ABS}	Axis position in the machine coordinate system is displayed. Each time this softkey is pressed the display toggles between normal, large, and small ¹ .
{TARGET}	Coordinate values, in the current work coordinate system, of the end point of commanded axis motion is displayed. Each time this softkey is pressed the display toggles between normal, large, and small ¹ .
{DTG} Distance to go	Distance from the current position to the end point of the commanded axis move displayed. Each time this softkey is pressed the display toggles between normal, large, and small.
{AXIS SELECT}	This softkey is used to select which axes are going to be displayed on normal (when more than 9 axes are available) and large displays. Small displays always show all system axes.
{M CODE STATUS}	M-codes that are currently active are displayed.
{PROGRAM DTG}	This screen provides a multiple display of information from the program display screen and the distance to go screen.
{All}	This screen provides a multiple display of position information program, target, absolute, and distance to go screens. The all display is only available on systems with 8 or fewer axes. On systems with more than 8 axes, other combination screens are available which display a subset of the data available on the ALL display.
{G CODE STATUS}	G-codes that are currently active are displayed.

The screens described above may also show in addition to axis position:

- The current unit system being used (millimeters or inches)
- E-Stop
- The current feedrate
- The current spindle speed of the controlling spindle
- The current tool and tool offset numbers
- The active program name (if any)

- The active subprogram name (if any)
- The current operating mode (MDI, manual or automatic)
- The current operating status (cycle stop, suspend, start, feedhold)
- The current block executing (sequence number)
- Up to four blocks of the current program selected for program execution
- Subprogram paramacro 01 canned cycle repeat count executing

To select an axis position data display :

1. Press the **[F12]** key to display the softkeys for selecting axis position data screens. Press the **[F12]** key at any time from any softkey level. Pressing the page **{→}** softkey displays additional selections.
2. Press the softkey corresponding to the display wanted. The softkeys will toggle between large, and regular display mode each time the corresponding softkey is pressed, provided that screen is available as a large display.

The “large” display is available only for the axis position screens (Program, Absolute, Target, and Distance to Go).

For example, immediately after power up and accessing the **[F12]** feature, pressing the **{DTG}** softkey displays the distance to go in normal size. Pressing it again changes the display to show the distance to go in large character size.

The control can display any four axes in triple-height characters and any eight axes in double-height characters.


3. To return to softkey level 1, press the **[F12]** key again. The most recently selected data position screen will remain in effect for softkey level 1 until either power is turned off or a different position display screen is selected. The default screen selected at power up is the regular size program display.

The following figures show the axis position data display that will result when the corresponding softkey is pressed.

{PROGRAM}

Axis position in the current work coordinate system displayed in normal size characters.


Figure 8.1
Result After Pressing {PROGRAM} Softkey



{PROGRAM} (Large Display)

Axis position in the current work coordinate system displayed in large characters.


Figure 8.2
Results After Pressing {PROGRAM} (Large Display) Softkey



{ABS}

The axis position data in the machine coordinate system.


Figure 8.3
Results After Pressing {ABS} Softkey



{ABS} (Large Display)

Axis position in the machine coordinate system displayed in large characters.


Figure 8.4
Results After Pressing {ABS} (Large Display) Softkey



{Target}


The coordinate values of the end point of the currently executing axis move is displayed at a position in the current work coordinate system.

Figure 8.5
Results After Pressing {TARGET} Softkey

**{Target} (Large Display)**

The coordinate values in the current work coordinate system, of the end point of commanded axis moves in normal size characters.


Figure 8.6
Results after Pressing {TARGET} Softkey



{DTG}

The distance from the current position to the command end point, of the commanded axis in normal size characters.


Figure 8.7
Results After Pressing {DTG} Softkey



{DTG} (Large Display)

The distance from current position to the command end point of the commanded axis move in large characters.

Figure 8.8
Results After Pressing {DTG} (Large Display) Softkey




{AXIS SELECT}

Important: {AXIS SELECT} is available only during a large character display.

When you press {AXIS SELECT}, the control displays the axis names in the softkey area. Press a specific axis letter softkey to toggle the position display of that axis on and off.

If a normal size display is being viewed the axis select features can select the axes for these normal size displays.

Figure 8.9
Results After Pressing {AXIS SELECT} Softkey

**{M CODE STATUS}**

The currently active system M-codes are displayed. This screen indicates the last programmed M-code in the modal group. It is the logic programmer's responsibility to make sure proper machine action takes place when the M-code is programmed.

To access this screen, press the {→} button.

(softkey level 1)






Figure 8.10
Result After Pressing {M CODE} Softkey



{PROGRAM DTG}

This screen provides a multiple display of position information from the program screen and the distance to go screen.


Figure 8.11
Program, Distance to Go Screen



{ALL}


This screen provides a multiple display of position information from the program, distance to go, absolute, and target screen.

Figure 8.12
Result After Pressing {ALL} Softkey



The {ALL} selection is not available for more than six axes.


Important: If you have more than six axes, then you will not have an {ALL} softkey. A {PRG TAR} and a {PRG ABS} softkey appear.



{G CODE STATUS}

The currently active G-codes are displayed.

Figure 8.13
Results After Pressing {G CODE} Softkey




Changing Languages

The 9/PC control is equipped to display all screens, softkeys, and messages in multiple languages.

Press the {SWITCH LANG} softkey to access these languages.

(softkey level 1)



Each time you press the {SWITCH LANG} softkey, the language displayed on the screen changes. The system installer can password protect this softkey.

The 9/PC control is equipped to display five languages. The languages available and the order they are displayed are fixed in this order:

- English
- French
- German
- Spanish
- Italian

Power Turn-on Screen

When the 9/PC is started, the BDS displays the power turn-on screen.

The following section discusses how to modify information displayed on this screen at power up.

Editing the System Integrator Message Lines

To edit the system integrator message lines of the power turn-on screen, do the following:

1. Press the **{SYSTEM SUPPORT}** softkey.

(softkey level 1)

	PROGRAM MANAGE	OFFSET	MACRO PARAM	PROGRAM CHECK	SYSTEM SUPPORT	→
F2	F3	F4	F5	F6	F7	F8
		ERROR MESSAGE	PASS- WORD	SWITCH LANG		→
F2	F3	F4	F5	F6	F7	F8

The control brings you to softkey level 2.

2. Press the **{PTOM SI/OEM}** softkey.


(softkey level 2)

↑	PROGRAM PARAM	AMP		MONI- TOR	TIME PARTS	→
F2	F3	F4	F5	F6	F7	F8
↑	PTOM SI/OEM		SYSTEM TIMING			→
F2	F3	F4	F5	F6	F7	F8

The control changes the screen to display the PTO screen, as shown in this section.


There are three lines available for system integrator messages. The softkeys used to change these lines are **password protected**.

These three lines are available for system integrator messages.



- Use the up or down cursor keys to highlight the line that you want to change on the PTO screen. The line selected is shown in reverse video.
- Press the {**ENTER MESSAGE**} softkey. This highlights the softkey, and the control displays the input prompt "PTO MESSAGE:" at the top of the screen. Also, the current text, if any, of the selected message line is shown on the input line next to the prompt. (The text may be edited like any other input string.)

(softkey level 3)



- Once you edit the line, press the [**ENTER**] key to transfer the edited line to the PTO screen. After you press the [**ENTER**] key, you can either:
 - edit another line
 - exit the PTO screen by pressing the up arrow softkey
Changes to the system integrator message lines are automatically saved when you exit the PTO screen.

END OF CHAPTER

Introduction to Programming

Chapter Overview

The 9/PC control performs machining operations by executing a series of commands that make up a part program. These commands are interpreted by the control which then directs axis motion, spindle rotation, tool selection, and other CNC functions.

Part programs can be executed from the control's memory or from the hard disk.

This chapter begins with an explanation of CNC part program format. The remainder of the chapter deals with the contents of a part program, including:

Topic:	On page:
Program configuration	9-1
Program names	9-3
Sequence numbers	9-4
Subprograms	9-6
Word formats and functions	9-10
Word descriptions	9-15


Program Configuration

Each individual machining operation performed by the control is determined by the control's interpretation of a group of words or codes (commands) called a "block." Individual blocks in a part program define each machining process. Part programs consist of a number of blocks that define a complete operation of a part.

Part program blocks are made up of:

Component of program block:	Description:
character	a number, a letter, or a symbol that means something specific to the control. For example, 1 G ; are characters that the control recognizes as meaningful information.
address	a letter that defines the instruction for the control. Examples of addresses are: G, X, Z, F.
word	an address followed by a numeric value. Examples of words are: G01, X10.5, F1., M2. Each word requires a specific format for its numeric part. These formats are given on page 9-15.
code	industry standards for many of the G- and M-codes used here. For that reason, they are often referred to as G- or M- "codes."
parameter	a number of fixed cycles that are initiated by a specific G-code. Other words appearing in those G-code blocks are referred to as "parameters" because their values are relevant only to that G-code. For example, a Z-word generally refers to a Z axis move, but when it appears in a block with a G83 peck drilling cycle, its value refers to the depth of the hole to be drilled. In that case, it is a "parameter" of the G83 fixed cycle.

A block is a set of words and characters that defines the operations of the control. For example:



The 9/PC control sequentially executes blocks in a part program to conduct the required machining operation.

Important: To make jumps, loops, or calculations within an executing program or subprogram, use the paramacro features described in chapter 27.

A part program has a:

Part program section:	Description:
Beginning	sets up the control and the machine to perform the operations wanted
Middle	performs the machining operations
End	returns the machine to a safe stop position, and preparing the control for the next part program

The blocks programmed vary for each section of the program. As an example, consider the following simple example program.

Example 9.1 Sample Part Program

G91G21;	} beginning
G00X28. ; G33Z-64.E4. ; G00X5 ;	} middle
Z2. ; M02 ;	} end

Program Names

You can enter up to eight alphanumeric characters for program names.

Subprograms are designated with the letter O followed by five **numbers**. If you enter a new program name with 5 numeric characters, the control assumes that it is a subprogram and automatically inserts the letter O as the first character in the name. The control does **not** consider programs with more than 5 numeric characters as subprograms.

The control lists subprograms in numerical order from lowest to highest. The main programs are listed in alphabetical order, following the subprograms.

Entering Program Names

To enter a program name:

1. Press the softkey {**PROGRAM MANAGE**}. This calls up the program directory, which lists subprograms first, then programs by alphabetical order.
2. Type in the name of a new program or one already listed. You cannot enter spaces or special characters.
3. Press {**EDIT**}. This initiates the editing mode for the program selected.

Example 9.2 Entering Subprogram Names

Name entered	Program name stored by control
O00123	O00123
O123	O00123
123	O00123
12345	O12345

Example 9.3 Legal Program Name Blocks

```
O12345;
O12345(TAPPING PROGRAM);
O333
O2;
```

Sequence Numbers

Each block in a part program can be assigned a sequence number to distinguish one block from another. Sequence numbers begin with an N address, followed by a one to five digit numeric value.

Sequence numbers can be assigned at random to specific blocks or to all blocks. If you assign sequence numbers to blocks, you can designate their sequence numbers. Sequence numbers are necessary to make program jumps and to specify a block for paramacro calls and returns.

Below is an example of two blocks with sequence numbers 10000 and 10010.

```
N10000 X5. Z4. ;
N10010 X2. Z2. ;
```

When you assign sequence numbers to blocks the N-word comes first in the block except when you designate block delete. See page 9-5. It is not necessary to program the N-word first in the block. The control still finds it for jumps; however, it will not find renumber operations.

If more than one N-word is in a block, the control uses only the first N-word encountered for that block number.

Different blocks can be assigned the same sequence number. If this number is called by a “GOTO” or some other command, the first block found by the control with the sequence number that is closest to the calling block is used. The control first searches for the sequence number in the forward direction (from the calling block), then it searches in the reverse direction (from the calling block). How the control reacts if the sequence number is not found is determined by the specific operation being used.

The control has a programming feature that renumbers existing sequence numbers or assigns all block sequence numbers.

Comment Blocks

Information between the control out code “(” and the control in code “)” within a part program is regarded as a comment, and it is not handled as significant information. The comment can be described in up to 128 characters (including the control out/in codes), consisting of alphanumeric characters and special symbols.

Example 9.4 Program Block With Comment

```
N00010G91X5.(CHANGE TO INC. MOVE X 5);
```

Block Delete and Multilevel Delete

When you program a slash “/” followed by a numeric value (1-9) anywhere in a block, the control skips (does not execute) all remaining programmed commands. The block delete feature is turned on with an optionally installed switch on the MTB panel.

Your system installer determines in AMP if the entire block is deleted or if only the characters to the right of the block delete / are deleted. If the entire block is to be deleted, it is done regardless of the position of the / character in the block.

Example 9.5 Block Delete in a Part Program

Program Block	Comment
N1000 X__ Z__;	first block
N1010 Z__;	second block
/1N1020 X__;	control skips this block if switch 1 is on
/1/2N1030 X__;	control skips this block if switch 1 or switch 2 are on
/N1032 X__;	control skips this block if switch 1 is on
N1040 X__;	
/2N1050 X__;	control skips this block if switch 2 is on

The control always reads several blocks into its buffer memory so that it can prepare for moves and commands before it executes them. The switch controlling a block delete must be set **before** that block is read into buffer memory, otherwise it will not be skipped.

The control considers a “/” without a number to mean “/1.” However, “/1” must be programmed if more than one block delete number is to be used in a block.

The block delete is active for sequence number search and dry run operations.

The control ignores the block delete when you load a part program from tape or another device into control memory. The control also ignores the block delete when a part program is saved on punched tape or another device from control memory.

For details on the block delete switch(s), see the logic reference manual and the documentation prepared by your system installer.

End of Block Statement

All program blocks must have an end of block statement as the last character in the block. This character tells the control how to separate data into blocks. The control uses the “;” to mark the end of a block.

Important: When performing an EOB search, the search is executed from the beginning of the part program, NOT from the point of display.

To specify an end of block character “;” at the keyboard use the [EOB] key on the operator panel. If you are editing part programs off line you cannot enter the end of block character when blocks are keyed in. Refer to chapter 7. The control automatically inserts end of block “;” when the program is downloaded.

Using Subprograms

When the same series of blocks is repeated more than once it is usually easier to program them using a subprogram.

The key difference between a subprogram and a G65 paramacro is that a paramacro always gets a new set of local parameters. A subprogram uses the same set of local parameters that the main program used. See chapter 27 for details on paramacros and local parameters.

This section explains:

- Main and subprograms
- Subprogram calls

Important: To make jumps, loops, or calculations within an executing program or subprogram, use any of the paramacro features described in chapter 27.

You can call a subprogram in an MDI command; however, a MDI command cannot contain an M99 code.



ATTENTION: Any edits that you make to a subprogram or paramacro program (as described on page 5-2) that have already been called for automatic execution are ignored until the calling program is disabled and reactivated. Subprograms and paramacros are called for automatic execution the instant that the calling program is selected as active (as described on page 7-5).

Subprogram Call (M98)

Generally, programs are executed sequentially. When you enter an M98Pnnnnn command (“nnnnn” representing a subprogram number) in a program, the control merges the subprogram (designated by the address P) before the block that immediately follows the M98 command. The control issues the error message “CANNOT OPEN SUBPROGRAM”, if it cannot find the subprogram designated by the M98 command.

For example,

```
M98 P00001 ;
```

would cause execution to transfer from the current program to the subprogram numbered 00001.

Important: For a program to be used as a subprogram it must have a program name starting with the letter O followed by up to a 5 digit numeric value. When calling the subprogram with a P-word only the numeric value is used. The letter O is omitted.

You might want to execute a subprogram more than one time. For example,

```
M98PnnnnnLmm;
```

would cause the subprogram numbered nnnnn to be merged in the main program mm times. When you enter an L command in a M98 command, the control merges the subprogram (designated by the address P) before the block that immediately follows the M98 command as many times as designated by the L-word. Both the P- and L-words must follow the M98 command in a program block.

Omission of an L-word is regarded as L1. An L-word cannot be a negative value or have a value of zero.

Important: If M02 or M30 codes are found in a subprogram before the program reads an M99, execution stops. The program resets or rewinds if an M30 code is executed, or the program ends if the M02 code is executed.

Main and Subprogram Return

M99 code acts as a return command in both sub- and main programs; however, there are specific differences:

Using M99 in a Main Program

If you use M99 in a:	M99:
Main program	executes all commands in the block, regardless if information is programmed in the block to the right of the M99 command
	clears all modal codes similar to an M02 or M30 (simulates start-up conditions)
	resets the current main program to the first block
	automatically performs a cycle start on the program after it is reset and program execution starts over.
Subprogram	tells the control the end of a subprogram
	will not merge any commands within a file that is used as a subprogram and follows a M99 code in the main program into the calling program.

Using M99 in a Subprogram

Program the M99 code anywhere in a program block, provided no axis words are programmed to the left of M99. Any information (other than axis words) programmed to the left of M99 is executed as part of the subprogram, while information (including axis words) programmed in the block to the right of the M99 command is ignored.

If you program:	Then:
M99X10;	X10 is ignored in this subprogram block
X10M99;	X10 generates an error in this subprogram
M03M99;	M03 is executed as normal in this subprogram

Example 9.6 Subprogram Calls and Returns

MAIN PROGRAM	SUBPROGRAM 1	SUBPROGRAM 2
(MAIN PROGRAM);	(SUBPROGRAM 1);	(SUBPROGRAM 2);
N00010...;	N00110;	N00210;
N00020...;	N00120...;	N00220...M99;
N00030M98P1;	N00130M99;	
N00040...;	N00140...;	
N00050...;	N00150M30;	
N00060M98P2L2;		
N00070M30;		

This path of execution results when you select the main program in Example 9.6 as the active program:

```


(MAIN PROGRAM);
N00010...;
N00020...;
N00030M98P1;
(SUBPROGRAM 1);
N00110;
N00120...;
N00130M99;
N00040...;
N00050...;
N00060M98P2L2;
(SUBPROGRAM 2);
N00210;
N00220...M99;
(SUBPROGRAM 2);
N00210;
N00220...M99;
N00070M30;

```

Subprogram Nesting

We use the term nesting to describe one program calling another. The program called is a nested program. When a subprogram is called from the main program it is on the first nesting level or nesting level 1. If that subprogram in turn calls another subprogram, the called subprogram is in nesting level 2. Subprograms can be nested up to a maximum of 4 levels.

Figure 9.1
Subprogram Nesting




Important: Calling a macro does not add to the nesting level of any active subprograms. Up to 4 subprograms can still be nested, but the combined total of nested macros and subprograms cannot exceed 8. See chapter 27 for information on macros.

Word Formats and Functions

Words in a part program consist of addresses and numeric values.

Component:	Description:
Address	A character to designate the assigned word function.
Numeric value	A numeral to express the event called out by the word.

Figure 9.2
Word Configuration



For each word used in a part program, there is a format that designates the number of digits allowable as a numeric value for that word. The format for an M-code or word, for example, is normally M2 which indicates that an M address can be followed by only two digits.

For words that allow the use of a decimal point in a numeric value, the decimal point format is used. In this case, the numeral to the left of the decimal point indicates the number of digits acceptable as integers, and the numeral to the right of the decimal point indicates the number of fractional digits acceptable.

The format "X3.4" for an X-word, indicates that three digits to the left and four digits to the right of the decimal are acceptable as numeric values. With this format selected, the maximum programmable value for an X-word would be 999.9999.

Leading Zero and Trailing Zero Suppression

The system installer can choose from these programming format types in AMP:

- **Leading Zero Suppression** -- enable or disable
- **Trailing Zero Suppression** -- enable or disable

Table 9.A shows the effects of leading zero suppression (LZS) and trailing zero suppression (TZS). It presumes that your system installer has set a format of X5.2 (integer 5 digits, decimal 2 digits) in AMP. Different formats would result in different decimal point placement compared to those shown below, but the end result would be comparable.

Table 9.A
How the Control Interprets Numeric Values

Programmed X Value	Position Interpreted by the Control		
	TZS Disabled LZS Disabled	TZS Disabled LZS Enabled	TZS Enabled LZS Disabled
X123456.	ERROR	ERROR	ERROR
X12345.6	12345.60	12345.60	12345.60
X1234.56	1234.56	1234.56	1234.56
X123.456	123.45	123.45	123.45
X12345	12345.00	123.45	12345.00
X012345	ERROR	123.45	1234.50
X123456	ERROR	1234.56	12345.60
X1234567	ERROR	12345.67	12345.67
X12345678	ERROR	ERROR	ERROR

Using LZS and TZS with G-codes

The following table illustrates how the control interprets different G-Codes in leading zero and trailing zero suppression modes.

Leading Zero Suppression Mode (decimal assumed at end if not programmed)		Trailing Zero Suppression Mode (2-digit G-code assumed unless decimal point programmed)	
Program this:	Results in this:	Program this:	Results in this:
G02	2	G02	2
G2	2	G2	20
G2.	2	G2.	2
G92	92	G92	92
G920	920	G920	920 or 92 (if no AMP defined macro 920)
G92.1	92.1	G92.1	92.1

Important: If backing up a table using a G10 program (such as the offset tables or coordinate system tables), keep in mind the G10 program output is generated in the current format of the control (LZS or TZS). If you intend to transport this table to a different machine it must also be using the same format.

Programming without Numeric Values

Your system installer can also set an AMP parameter to generate an error or use a value of zero for characters that are programmed without numeric values. If this AMP feature is disabled, programming:

```
GX;    rapid move to X zero (control assumes G00 X0;)
M;    program stop (control assumes M00)
```

would result in the actions described in the comments following the blocks. If the feature is enabled, the error “NUMERIC MISSING” would have occurred upon execution of either of those blocks.

Word Descriptions and Ranges

Table 9.B shows, in alphabetical order, the addresses for words that are recognized by the control, their typical formats, and their general meanings. Since most of these formats are configured in AMP, refer to the documentation prepared by your system installer.

Many of the addresses can be altered in AMP. This table assumes the most common names (such as X and Z for the main axes). Alterable addresses are indicated by the note “AMP assigned.”

Later sections discuss these words in more detail, including variations in their meanings when they are associated with certain G-codes. All words discussed in this manual assume that the format and addresses in the following table have not been changed by your system installer.

Important: The formats in this table indicate the maximum number of digits left and the maximum number of digits right of the decimal point for each word. In many cases, they are not valid together since the control allows a maximum of 8 total digits. Refer to your system installer’s manual for specific formats.

Table 9.B
Word Formats and Descriptions

Address	Valid Range inch	Valid Range metric	Function
A	8.6 3.3	8.5 3.3	Rotary axis about X (AMP assigned) Angle in QuickPath Plus programming
B	3.0	3.0	Second miscellaneous function (AMP assigned)
C	8.6 8.6	8.5 8.5	Rotary axis about Z (AMP assigned) Chamfer length in QuickPath Plus programming
D	8.6	8.5	Fixed cycle parameter
E	2.6	3.7	Thread lead
F	8.6	8.5	Feedrate function (F-word)
G	2.1	2.1	Preparatory function (G-code)
I	8.6 8.6 8.6 8.6	8.5 8.5 8.5 8.5	X arc center in circular interpolation X lead in helical interpolation Parameter in fixed cycles (AMP assigned) Exit move vector in cutter compensation
J	8.6 8.6	8.5 8.5	Parameter in fixed cycles (AMP assigned) Exit move vector in cutter compensation
K	8.6 8.6 8.6	8.5 8.5 8.5	Z arc center in circular interpolation Parameter in fixed cycles (AMP assigned) Exit move vector in cutter compensation
L	3.0	3.0	Number of repetitions
M	3.0	3.0	Miscellaneous function
N	5.0	5.0	Sequence number
O	5.0	5.0	Program name
P	5.0 5.3	5.0 5.3	Subprogram name Length of dwell in G04 and fixed cycles
Q	8.6	8.5	Parameter in fixed cycles
R	8.6 8.6 8.6	8.5 8.5 8.5	Arc radius Return point in fixed cycles QuickPath Plus radius designation
S	5.3 3.3 4.3	5.3 3.3 3.3	Spindle rpm function Spindle Orient CSS
T	6.0	6.0	Tool selection function
U	8.6 5.3	8.5 5.3	Incremental axis name (Lathe A only) Length of dwell in G04 and fixed cycles
V	8.6	8.5	Incremental axis name (Lathe A only)
W	8.6	8.5	Incremental axis name (Lathe A only)
X	8.6 5.3	8.5 5.3	Main axis (AMP assigned) Length of dwell in G04
Z	8.6	8.5	Main axis (AMP assigned)

Minimum and Maximum Axis Motion (Programming Resolution)

The maximum programmable value accepted by the control is 99,999,999. The minimum is .000001 inch or .00001mm. The actual range of programmable values depends on specifications determined by your system installer.

By using AMP to establish the format of numeric values for words, your system installer sets the “programming resolution” for axis motion, the smallest programmable distance of axis motion.

Table 9.C
Programming Resolutions

Formats as set in AMP	_.3	_.4	_.5	_.6
Corresponding Resolution	0.001	0.0001	0.00001	0.000001

Refer to your system installer’s documentation for the programming resolutions and ranges in a specific system.

Word Descriptions

This section describes general features of the words used in programming. Later chapters in this manual describe how to use these words in detail.

Axis Names

Axis words are made up of an axis name followed by the desired numeric value for that word.

For axis names, the system installer chooses from:

A B C U V W X Y Z \$X \$Y \$Z \$B \$C

These are assigned in AMP. This manual assumes primary axes one, two, and three to be labeled X, Y, and Z respectively. Integrand words for these axes are assumed to be I, J, and K respectively. Incremental or parallel axis names for these axes are assumed to be U, V, W, respectively.

A_L,R,C (QuickPathPlus Words)

To simplify programming an angle, corner radius, or chamfer between two lines, all that is necessary is the angle between the lines and the radius or chamfer size connecting them. This method of programming can be used to simplify the cutting of many complex parts.

QuickPath words are made up of the addresses below followed by the desired numeric value.

If you see:	It means:
,A	angle
L	length
,R	corner radius
,C	chamfer size


Important: A comma “,” must precede the ,R and ,C address characters for the control to recognize them as radius or chamfer words.

For more details and examples using these words, see chapters 14 and 15.

F-Words (Feedrates)

An F-word with numeric values specifies feedrates for the cutting tool in linear interpolation (G01), and circular interpolation (G02/G03) modes. The feedrate is the speed along a vector of the commanded axes, as shown in Figure 9.3.

Figure 9.3
Feedrate Vectors



The term “feed” refers to moving a tool at a specific velocity in a cutting path. “Feedrate” is the velocity programmed for the feed of a tool.

Feedrates are expressed by the distance of movement per interval. Depending on the mode of the control and the results you want, the distance can be millimeters, inches, meters, or revolutions. The interval can be minutes or revolutions.

Table 9.D
Feedrate Units

Unit/Interval	Abbreviation	Typically Used For:
millimeters per minute	mmpm	linear axis feedrates
inches per minute	ipm	linear axis feedrates
revolutions per minute	rpm	rotary axis feedrates
millimeters per rev	mmpr	threading
inches per rev	ipr	threading

In a metric part program for a linear axis, a feedrate of 100 millimeters per minute (mmpm) typically would be written as F100.; (depending on the active word format).

For details on programming feedrates by using the different feedrate modes, see chapter 17. It also describes special preassigned feedrates.

Important: Feedrates programmed in any of the feedrate modes (G94 or G95) can be overridden by use of the **<FEEDRATE OVERRIDE>** switch.

G-Codes (Preparatory Functions)

The preparatory function is designated by a G-code consisting of address G followed by a two-digit value. In some cases, the G-code may have an additional decimal digit. Because many of these are set by industry standards, they are usually referred to as G-codes. The G-codes are classified as modal and nonmodal.

Modal	the G-code remains in effect until another G-code in the same G-code group is programmed.
Nonmodal	the G-code is in effect only in the block in which it is programmed.

Important: When you program more than one G-code from the **same** modal group in a block, the control executes the block as the G-codes occur in the block sequentially from left to right. Any mode that is being changed in a block only applies to the values to the right of the G-code. Characters to the left of the G-code still use the old operating mode.

When the control executes an M02 or M30 code the system installer determines in AMP if the modal M- and G-codes reset to their default values. These default values become active at power up, E-Stop reset, or control reset. Your system installer determines these defaults in AMP.

Important: G-codes can also be expressed in terms of a parametric expression (for example G[#12+6]). For details, see chapter 27.

Example 9.7 explains execution of modal G-codes, using G00 and G01, both classified into the same G-code group.

Example 9.7 Programming Modal G-codes

G00 X1. Z2. ;	G00 mode is effective
Z3. ;	G00 mode is effective
G01 X2. Z1. ;	G01 mode is made effective
X3. Z3. ;	G01 mode is in effect
G00 X1.Z2. ;	G00 mode becomes effective again
G01 G00 Z3, ;	G00 mode is in effect
G01 G91 Z2 ;	G01 and G91 both in effect

Example 9.8 is an example of nonmodal G-code execution.

Example 9.8 Programming Nonmodal G-codes

G00 X1. Z21 ;	G00 mode is effective
G28 X2. ;	G28 mode, this block only
X2. Z1. ;	G00 mode is effective
G04 P2. X4. ;	G04 active followed by move in G00

Example 9.9 Changing Modes Mid-block

N10G90X10G91Y10 ;	X10 is absolute (G90) Y10 is incremental (G91).
N20X20 ;	X20 is incremental (G91).
N30X30G90Y10 ;	X30 is incremental (G91), Y10 is absolute (G90).

Table 9.E breaks down the G-codes into their modal groups. For example, G-codes in group 01 are modal only with other G-codes in group 01. G-codes in the 00 group are nonmodal, and they are effective only in the block in which they are programmed.

The 9/PC control provides 3 G-code systems for your lathe system. They are systems A, B, and C. Your system installer determines which G-code system is used for a specific application in AMP.

Important: This manual makes the assumption that G-code system C is used.

Table 9.E
G-code Table

A	B	C	Modal	Function	Type
G00			01	Rapid Positioning	Modal
G01		Linear Interpolation			
G02		Circular Interpolation (Clockwise)			
G03		Circular Interpolation (Counterclockwise)			
G04			00	Dwell	Nonmodal
G07			18	Programming Using Radius Values	Modal
G08				Programming Using Diameter Values	
G09			00	Exact Stop	Nonmodal
G10L2				Setup Work Coordinate Offset Table	
G10L3				Setup Tool Management Table	
G10L10				Setup Tool Offset Values Geometry Table	
G10L11				Setup Tool Offset Values Wear Table	
G10.1				Setup Random Tool Table	
G11				Setup Tool Management Table (Cancel)	
G12.1			21	Spindle 1 Controlling	Modal
G12.2				Spindle 2 Controlling	
G14			19	Scaling (Disable)	Modal
G14.1				Scaling (Enable)	
G15			15	Virtual C (Cancel)	
G16.1				Virtual C Cylindrical Interpolation	
G16.2				Virtual C End Face Milling	
G17			02	Plane Selection	
G18				Plane Selection	
G19				Plane Selection	
G90	G77	G20	01	Single Pass O.D. and I.D. Roughing	
G92	G78	G21		Single Pass Thread Cycle	
G94	G79	G24		Single Pass Rough Facing Cycle	
G22			04	Programmable Zone 2 and 3 (On)	
G22.1				Programmable Zone 3 (On)	
G23				Programmable Zone 2 and 3 (Off)	
G23.1				Programmable Zone (Off)	
G27			00	Machine Home Return Check	Nonmodal
G28				Automatic Return to Machine Home	
G29				Automatic Return from Machine Home	
G30				Return to Secondary home	
G31				External Skip Function 1	
G31.1				External Skip Function 1	
G31.2				External Skip Function 2	
G31.3				External Skip Function 3	
G31.4				External Skip Function 4	
G32	G33	G33	01	Constant Lead Thread Cutting	Modal
G34				Variable Lead Thread Cutting	
G36			22	Short Block Acc/Dec (Enable)	
G36.1				Short Block Acc/Dec (Disable)	

A	B	C	Modal	Function	Type
G37			00	Tool Gauging Skip Function 1	Nonmodal
G37.1				Tool Gauging Skip Function 1	
G37.2				Tool Gauging Skip Function 2	
G37.3				Tool Gauging Skip Function 3	
G37.4				Tool Gauging Skip Function 4	
G39			20	Tool Tip Radius Compensation (Linear Generated Block)	Modal
G39.1				Tool Tip Radius Compensation (Circular Generated Block)	
G40			07	Tool Tip Radius Compensation (Cancel)	
G41				Tool Tip Radius Compensation (Left)	
G42				Tool Tip Radius Compensation (Right)	
G45			23	Disable Spindle Synchronization	
G46				Set Spindle Positional Synchronization	
G46.1				Set Active Spindle Speed Synchronization	
G47			24	Linear Acc/Dec in All Modes	
G47.1				S-Curve Acc/Dec for Positioning and Exact Stop Mode	
G47.9				Infinite Acc/Dec (No Acc/Dec) (AMP-selectable only)	
G50.1			11	Programmable Mirror Image (Cancel)	Modal
G51.1				Programmable Mirror Image	
G52			00	Offset Coordinate Zero Points	Nonmodal
G53				Motion in Machine Coordinate System	
G54			12	Preset Work Coordinate System 1	Modal
G55				Preset Work Coordinate System 2	
G56				Preset Work Coordinate System 3	
G57				Preset Work Coordinate System 4	
G58				Preset Work Coordinate System 5	
G59				Preset Work Coordinate System 6	
G59.1				Preset Work Coordinate System 7	
G59.2				Preset Work Coordinate System 8	
G59.3				Preset Work Coordinate System 9	
G60			25	Synchronous Logic/Block Synchronization Mode	Modal
G60.1				Asynchronous Logic/Block Synchronization Mode	
G60.2				Autosynchronous Logic/Block Synchronization Mode	
G61			13	Exact Stop Mode	Modal
G62				Automatic Corner Override	
G63				Tapping Mode	
G64				Cutting Mode	
G65			00	Paramacro Call	Nonmodal
G66			14	Paramacro call	Modal
G66.1				Paramacro call	
G67				Paramacro call cancel	
G20	G20	G70	06	Inch system selection	
G21	G21	G71		Metric system selection	

A	B	C	Modal	Function	Type		
G70	G70	G72	00	O.D. and I.D. Finishing Cycle	Nonmodal		
G71	G71	G73		O.D. and I.D. Roughing Cycle			
G72	G72	G74		Rough facing cycle			
G73	G73	G75		Casting/forging roughing cycle			
G74	G74	G76		Face Grooving Cycle			
G75	G75	G77		O.D. and I.D. Grooving Cycle			
G76	G76	G78		O.D. and I.D. Multi-Pass Threading Routine			
G80				09		Cancel or end fixed cycle	Modal
G81			Drilling cycle (no dwell, rapid out)				
G82			Drilling cycle (dwell, rapid out)				
G83			Deep hole peck drilling cycle				
G83.1			Deep hole peck drilling cycle (dwell)				
G84			Right hand tapping cycle				
G84.1			Left hand tapping cycle				
G84.2			Right hand solid tapping cycle				
G84.3			Left hand solid tapping cycle				
G85			Boring cycle (no dwell, feed out)				
G86			Boring cycle (spindle stop, rapid out)				
G86.1			Boring cycle (spindle shift)				
G87			Back boring cycle				
G88			Boring cycle (spindle stop, manual out)		Modal		
G89			Boring cycle (dwell, feed out)				
--	G90	G90	03		Absolute mode		
--	G91	G91			Incremental mode		
G50	G92	G92	00	Coordinate offset using tool positions	Nonmodal		
G50	G92	G92		Maximum CSS Spindle RPM			
G92.1				Coordinate system offset cancel			
G92.2				Cancel select offsets			
G98	G94	G94	05	Feed per minute mode	Modal		
G99	G95	G95		Feed per revolution mode			
G96			17	CSS ON	Modal		
G97				RPM Spindle Speed Mode			
--	G98	G98	10	Initial level return drilling cycles	Modal		
--	G99	G99		R-point level return drilling cycles			

A set of default G-codes becomes effective at power up, when the control is reset, or an emergency stop condition is reset. These default G-codes are selected by your system installer in AMP. These default G-codes can be seen on the status display screen after power up or control reset.

I J K Integrand Words

This section describes the axis integrand words. Integrand words define parameters that relate to a specific axis for a canned cycle, probing cycle, or circular motion block, but they are not limited to these operations. For example, in circular motion blocks the axis integrands are used to define the center point of the arc being cut.

Your system installer has the option of assigning either I, J, K, or none as the axis integrand name for a specific axis. This manual makes the following assumption:

Integrand Name:	Axis:
I	integrand name for the X axis
J	integrand name for the C or Y axis
K	integrand name for the Z axis

Important: Refer to your system installers documentation to make sure the assumptions are true. If this assumption is not true, it is all examples and formats in this manual that use a I, J, or K need to have their letters replaced with your system installers integrand words accordingly.

M-Codes (Miscellaneous Functions)

The miscellaneous function is designated with an address M followed by a 2- or 3-digit numeric value. Because many of these are set by industry standards, they are usually referred to as M-codes.

When a miscellaneous function is designated in a block containing axis motion commands, the control's logic program determines whether the M-codes:

- execute at the same time as the axis motion
- execute before the axis motion
- execute after the axis motion is completed

This order of execution can also be altered by using the paramacro feature, system parameter #3003. See chapter 27.

Your system installer determines in AMP if M- and G-codes get reset every time the control executes an M02 or M30 end of program command. If the control does reset M- and G-codes, modal M- and G-codes default back to their power up condition, and nonmodal M- and G-codes are reset to their default values. If M- and G-codes do not reset, all modal M- and G-codes remain at their present value and nonmodal M- and G-codes remain at their present values.

Table 9.F shows the basic M-codes for the 9/PC control. A part program block can contain as many basic M-codes as you want. If you program more than one M-code from any modal group in the same block, the rightmost M-code in that block for that modal group is the active M-code for the block.

Your system installer can define additional M-codes in logic. Up to 4 M-codes can be activated in any one block. If more than 4 are programmed in any one block, the right most 4 in that block are activated. Other user M-codes in the block are ignored. Refer to documentation provided by your system installer for details on non-basic M-codes and their operation.

Table 9.F
M-codes

M-code Number	Modal or Nonmodal	Group Number	Function
M00	NM	4	Program stop
M01	NM	4	Optional program stop
M02	NM	4	Program end
M30	NM	4	Program end and reset (tape rewind)
PRIMARY SPINDLE			
M03	M	7	Spindle positive rotation (cw)
M04	M	7	Spindle negative rotation (ccw)
M05	M	7	Spindle stop
M19	M	7	Spindle orient
SPINDLE 2			
M03.2	M	11	Spindle positive rotation (cw)
M04.2	M	11	Spindle negative rotation (ccw)
M05.2	M	11	Spindle stop
M19.2	M	11	Spindle orient
M07	M	8	Mist coolant on
M08	M	8	Flood coolant on
M09	M	8	Coolant off
M48	M	9	Overrides enabled
M49	M	9	Overrides disabled
M58	M	10	CSS permit
M59	M	10	CSS prohibit
M98	NM	5	Sub-program call
M99	NM	5	Sub-program end and program jump

(1) Program Stop (M00)

When you execute M00, execution stops after the block containing the M00 is executed. At this time, the CRT displays the “PROG STOP” message. To restart the operation, press the <CYCLE START> button.

(2) Optional Program Stop (M01)

The optional program stop function has the same effect as the program stop function, except that it is controlled by an external switch. When the OPTIONAL PROGRAM STOP switch is placed in the OFF position, the M01 code in the program is ignored. This switch and the appropriate logic programming are the responsibility of your system installer.

(3) End of Program (M02)

If you execute a program from control memory, the M02 code acts the same as an M30. Program execution stops and the control enters the cycle stop state. The program is reset to the first block and a <CYCLE START> begins part program execution over again. See M99 for auto cycle start.

With some machines, the M02 code can also result in a spindle and coolant supply stop. For details, refer to the instruction manual prepared by your system installer.

(4) End of Program, Tape Rewind (M30)

If you execute a program from control memory, the M30 code acts the same as an M02. Program execution stops and the control enters the cycle stop state. The program is reset to the first block and a <CYCLE START> begins part program execution again. See M99 for auto cycle start.

With some machines, the M30 code can also result in a spindle and coolant supply stop. For details, refer to the instruction manual prepared by your system installer.

(5) Overrides Enabled (M48)

When you execute M48, the feedrate override, rapid feedrate override, and the spindle speed override functions become effective. These are enabled on power up without requiring this M code to be executed. An M48 cancels an M49 and your system installer can choose which is active upon power-up.

(6) Overrides Disabled (M49)

Use the override cancel M-code (M49) to ignore any override set by the operator on the MTB panel. When you ignore the override setting, the axis feedrate, rapid feedrate, and the spindle speed override values are all set to 100 percent. An M49 cancels an M48 and your system installer can choose which is active upon power-up. This override setting is ignored if you are using programmed motion.

(7) Constant Surface Speed Mode Disabled (M58)

M58 cancels M59 mode, and it allows the control to recognize programmed G96 constant surface speed mode and S-words to be specified. The spindle resumes the speed it was revolving at prior to the designation of M59.



ATTENTION: Restoring the constant surface speed mode might cause the spindle speed to increase or decrease rapidly, depending on the cutting tool position.

(8) Constant Surface Speed Mode Disabled (M59)

M59 cancels M58 and G96, making the constant surface speed mode ineffective. The spindle continues to revolve at the speed it was at the moment the M59 executed.

Z or the spindle speed can be directly designated using an S code.

(9) Subprogram Call (M98)

When you execute M98, a subprogram is called and executed. This word can be used in any program including an MDI program. For details on programming an M98, see page 9-6.

(10) End of Subprogram or Main Program Auto Start (M99)**M99 End of Subprogram or Paramacro program**

When you execute M99, subprogram execution is completed and program execution returns to the calling program. This word is not valid in an MDI command, but it can be contained in a subprogram called by an MDI command. For details on programming an M99, see page 9-6 or chapter 27.

M99 End of Main Program with Auto Start

If you execute a program from memory, an M99 as the last block in a main program stops program execution at that location. The program is reset to the first block and a **<CYCLE START>** automatically starts program execution for you.



ATTENTION: The M99 code is commonly used as the end of program for fully automated systems that automatically load the next part to be machined. This code requires that some logic interface be written that assures the part is fully loaded and ready for machining before block execution is allowed to restart. Failure to do so can cause injury to operators or damage to equipment.

For these systems some logic interface should be written to assure that the part is fully loaded before program execution is restarted.

Important: You cannot use these M-codes when TTRC is active.

Other more specific M-codes are described in later sections that deal specifically with their functions.

Important: When you activate the MISCELLANEOUS FUNCTION LOCK feature, the control displays M-, B-, S-, and T-words in the part program and activates the corresponding Tool Wear Offset, with the exception of M00, M01, M02, M30, M98, and M99.

2nd Miscellaneous Function (B-Word)

Your system installer may decide to use the 2nd miscellaneous functions to distinguish a set of miscellaneous functions from the normal M-code miscellaneous functions. This manual assumes the B-word is used to call second auxiliary functions. Any alphabetic character which is not used for other functions may be used instead of B by setting the proper AMP parameter. For details, refer to documentation prepared by your system installer, or the AMP programming manual.

The B-word is designated by a 2- or 3-digit numeric value following address B. Unlike M-codes, each block can contain only one B-word.

Important: When you activate the MISCELLANEOUS FUNCTION LOCK feature, the control displays M-, B-, S-, and T-words in the part program and activates the corresponding Tool Wear Offset, with the exception of M00, M01, M02, M30, M98, and M99. This feature is described on page 7-1.

N-Words (Sequence Numbers)

Each block in a part program can be assigned up to a 5-digit numeric value following an N address. These numbers are referred to as sequence numbers and are used to distinguish one block from another.

Sequence numbers can be assigned at random to specific blocks or to all blocks if desired. Blocks assigned sequence numbers can be called later by designating their sequence number. Sequence numbers are necessary to make program jumps and to specify a block for subprogram calls and returns. For details on sequence number, refer to page 9-4.

O-Words (Program Names)

The O-word is used to define a program name. To use an O-word as a program name it must be the first block entered in a program. An O-word can have up to 5 numeric characters following it.

P, L Words (Main Program Jumps and Subprogram Calls)

When the same series of blocks are repeated more than once it is usually easier to program them using a subprogram.

This section explains:

- Main and subprograms
- Subprogram calls

Important: To make jumps, loops, or calculations within an executing program or subprogram, use any of the paramacro features described in chapter 27.

P-words in a subprogram call (M98) or paramacro call are used to designate the specific program being called. The P address is followed by the program name being called.

L-words in a subprogram call (M98) and some cycles are used to designate a repeat count for a subprogram. The number following the L address designates the number of times a subprogram is executed consecutively before execution is returned to the main program.

For details on subprograms, refer to page 9-6.

S-Words (Spindle Speed)

The spindle function has two modes:

Spindle Mode:	Function:
Constant Surface Speed Mode (G96)	maintains a workpiece's speed across a tool equal to a desired cutting speed independent of the diameter.
Constant Spindle RPM Mode (G97)	maintains a constant spindle speed equal to the designated S-word making the actual cutting speed dependant on the working diameter.

Spindle speed and cutting speed values are programmed designated by an S-word, followed by up to 4 digits. S-words are modal and remain active until you designate another S-word is designated. Use a common S-word to program all of the spindles AMPed to be in the system.

Important: Your system installer sets a maximum speed in AMP for each gear range for each spindle configured in AMP. If an S-word is programmed requesting a spindle speed that exceeds this limit. The spindle speed holds at the AMP-defined maximum. A new value may be set for this maximum RPM by programming a G92 code followed by an S-word. Refer to chapter 16.

When programming an S-word in a block that contains axis motion commands, the logic program has the option to temporarily suspend the axis motion commands until the spindle reaches speed. The control has the ability to take the programmed spindle speed and automatically search for the gear range that is AMPed to allow the necessary RPM. The operation of gear changing and how it is implemented is very logic dependant. Refer to your system installer's documentation for details on how a gear change operation is performed.

For details on programming spindle speeds, refer to chapter 16.

Important: When you activate, the MISCELLANEOUS FUNCTION LOCK feature, the control displays M-, B-, S-, and T-words in the part program and activates the corresponding Tool Wear Offset, with the exception of M00, M01, M02, M30, M98, and M99. This feature is activated as described on page 7-1.


Override spindle speeds designated in a program with the **<SPINDLE SPEED OVERRIDE>** switch on the MTB panel. This switch can be positioned in five percent increments within a range of 50 - 120 percent. For details, refer to your system installer's instruction manual.

Use the override cancel M-code (M49) to ignore any override set on the MTB panel. When the override setting is ignored, the axis feedrate, rapid feedrate, and the spindle speed values are all set to 100 percent. For more information on spindle functions, refer to chapter 16.

T- Words (Tool Selection and Tool Length Offset)

Modern machining processes usually require a machine that is capable of selecting different tools. Typically tools are mounted in a turret and assigned tool numbers as illustrated in Figure 9.4.

Figure 9.4
Typical Tool Turret



These data are set in the offset table corresponding to different offset numbers:

- tool length offset data
- tool tip radius data
- tool wear compensation data
- tool orientation data

Refer to chapter 3.

The selection of a tool number and an offset number for that tool is done by programming a T-word.

Important: When you activate the MISCELLANEOUS FUNCTION LOCK feature, the control displays M-, B-, S-, and T-words in the part program and activates the corresponding Tool Wear Offset, with the exception of M00, M01, M02, M30, M98, and M99. This feature can be activated through the front panel screen as described in chapter 2.

The format for a T-word is determined in AMP by the system installer. Six format selections are available as shown in Table 9.G.

Table 9.G
T-word Formats

Format Type	Wear Offset #	Geometry Offset #
(1) 1 DGT GEOM + WEAR	last digit	same as wear
(2) 2 DGT GEOM + WEAR	last two digits	same as wear #
(3) 3 DGT GEOM + WEAR	last three digits	same as wear #
(4) 1 DGT WEAR	last digit	same as tool #
(5) 2 DGT WEAR	last two digits	same as tool #
(6) 3 DGT WEAR	last three digits	same as tool #

For details on programming a T-word discussing tool length offsets, refer to chapter 19.

END OF CHAPTER

Basic Control Operation

Chapter Overview

This chapter covers the control of the coordinate systems on the 9/PC control. G-words in this chapter are among the first programmed because they define the coordinate systems of the machine in which axis motion is programmed. This chapter describes:

Information about:	On page:
Machine coordinate system	10-1
Preset Work coordinate systems G54-59.3	10-2
Work coordinate systems external offset	10-9
Offsetting the work coordinate systems	10-12
Logic offsets	10-20

A thorough understanding of this group makes programming easier by allowing full control of the coordinate systems.

Machine (Absolute) Coordinate System

The 9/PC control has two types of coordinate systems.

Coordinate System:	Description:
work coordinate system	defined based on the coordinate system used in the part drawing of a part to be cut by the machine. Programs are usually written based on the work coordinate system.
machine coordinate system (often referred to as the absolute coordinate system)	unique to the individual machine tool.


The machine coordinate system is the basic coordinate system set for every machine. It is established after completion of the machine-homing operation. It cannot be offset or shifted in anyway. Its position is determined in AMP by your system installer.

Important: Before you can activate any coordinate system, the machine must be homed. The homing operation refers to the positioning of the axes to a machine-dependent, fixed position which is called the machine home. For more on machine homing, refer to page 4-7.

The zero point of the machine coordinate system is referenced from the machine home point. This is done by assigning a coordinated location to the machine home point. The home position for each axis can be given any legal coordinates, such as 15.00, -20.0000, or -2.256.

Once you establish, the machine coordinate system is not affected by a control reset operation or any other programming or operator operation.

Figure 10.1
Machine Coordinate System, Home Coordinate Assignment



In Figure 10.1, your system installer defined the machine coordinate system zero point by assigning the machine home point to have the coordinates $X=10$ and $Z=15$.

The coordinate values assigned to the machine home point do not affect the position of machine home. The position of machine home is fixed by your system installer.

Important: Normally, the control displays the current axes positions in respect to active work coordinate system. The position in the machine coordinate system can be displayed by selecting the absolute screen as described in chapter 8.

Motion in the Machine Coordinate System (G53)

Although axis motion is usually commanded in the work coordinate system, axis motion is possible when a G53 is programmed in a block if you reference coordinate values in the machine coordinate system.

G90G53X__Z__;

The X- and Z-words above specify coordinate positions in the machine coordinate system. These coordinate values indicate the end point of the next move in the machine coordinate system. The tool travels to this position in either G00 or G01 mode, depending on which is active when the G53 block is executed. Any attempt to execute a G53 block in G02 or G03 mode generates an error.


The G53 code is not modal. It is effective only in the block in which it is called. After a G53 block, the control returns to the coordinate system that was in effect prior to the G53 blocks execution.

Important: The control must be in absolute mode (G90) when the G53 command is executed. If a G53 is executed while in incremental mode (G91), the control ignores the G53 code and any axis words in the G53 block.

**Example 10.1
Motion In The Machine Coordinate System.**

Program block	Comment
N1 G00X30Z30;	axis motion in work coordinate system.
N2 G53X25Z10;	axis motion in machine coordinate system.
N3 X20Z50;	axis motion in work coordinate system.

**Figure 10.2
Results of Example 12.1**




Preset Work Coordinate System (G54 - 59.3)

When you cut a workpiece using a part program made from a part drawing, you want to match the zero point on the coordinate system of the part drawing with the zero point of the work coordinate system.

As shown in the illustrations in Figure 10.3, you establish the work coordinate system by programming the distance between the desired zero point of the work coordinate system and the zero point of the machine coordinate system.

Figure 10.3
Work Coordinate System




There are 7 preset work coordinate systems selected using G54 - G59.3. The required work coordinate system can be selected by specifying any of these G-codes in the program.

Work coordinate systems called out by G54 - G59.3 have zero points that you enter in a work coordinate system table (see page 4.3). These zero points are in the form of offset values from the machine coordinate system zero point.

The control establishes the machine coordinate system immediately after you complete the machine home operation. The default work coordinate system, determined in AMP by your system installer, is activated simultaneously. The default work coordinate system is established when you execute a control reset operation, E-STOP, G92.1, or power up. The default work coordinate system is the sum of the external offset value (if any), and the offsets of the default coordinate system selected in AMP (G54-G59.3 or none). If the default coordinate system is selected as none, the default work coordinate system is simply the external offset (if any). This manual assumes G54 to be the default coordinate system and no external offset has been entered.


Figure 10.4
Work Coordinate System Definition



In Figure 10.4, the machine coordinate system was defined by declaring the fixed position machine home as the point $X=-3$, $Z=-2$. Then the G54 work coordinate system zero point was defined by the coordinates $X=2$, $Z=3$ in the machine coordinate system.

Coordinate positions in a part program are manipulated as coordinate values in the default work coordinate system, unless another coordinate system is selected by programming G54-G59.3.

Figure 10.5
Examples of Work Coordinate System Definition




To change work coordinate systems, specify the G-code corresponding to the work coordinate system you want in a program block. Any axis motion commands in a block that contains a change from one work coordinate system to another is executed in the work coordinate system specified in that block.

Example 10.2
Changing Work Coordinate Systems

Program Block	Comment
G54 ;	
G00 X20 . Z20 . ;	axis motion in the G54 work coordinate system.
G55 X10 . Z10 . ;	axis motion to the point X10. Z10. in the G55 work coordinate system.
X2 . Z3 . ;	axis Motion in the G55 work coordinate system.

Figure 10.6
Results of Example 12.2



Altering Work Coordinate System (G10L2)

There are 3 methods to change the value of a work coordinate system zero point in the work coordinate system table. Two methods can be found in the following sections:

Method:	Chapter:
manually alter the work coordinate system table	3
alter the paramacro system parameter values 5221- 5386	27

The third method, and the one described in this section, alters the work coordinate system table through G10 programming. Changing the values in the table using any of these methods does not cause axis motion. It does immediately shift the active coordinate system by the amount entered. The format for altering the work coordinate systems using G10 is:

```
G10 L2 P__ O__ X__ Z__;
```

Important: The order of the words in this program block is important. The L, P, and O words must be programmed before any axis words are programmed in the G10 block. Failing to follow this order can result in data being misinterpreted and loaded into the table incorrectly.

Where :	Is :
L2	tells the control that you want to alter the coordinate system tables.
P__	<p>specifies which coordinate system (G54 through G59.3) you want to work on. P1 through P9 correspond to the work coordinate systems G54 through G59.3.</p> <p>P1 = G54 work coord. system P6 = G59 work coord. system P2 = G55 work coord. system P7 = G59.1 work coord. system P3 = G56 work coord. system P8 = G59.2 work coord. system P4 = G57 work coord. system P9 = G59.3 work coord. system P5 = G58 work coord. system</p>
O__	<p>specifies whether the value entered for the diameter axis is a radius or diameter value. (O is non-modal.)</p> <p>O1=value entered for the diameter axis is a radius value. O2=value entered for the diameter axis is a diameter value.</p> <p>Important: If you program O1 or O2 in a G10 code, the G10 code is not affected by a previously programmed G07 or G08 (radius/diameter programming). However, if no O-code is specified, or if the O-code is out of range (for example, O3), then the G10 code is affected by a G07/G08.</p>
x_z_	specify the location of the zero point of the specified work coordinate system relative to machine coordinate system.

Important: G10 blocks cannot be programmed when TTRC is active.

Incremental/Absolute Mode and the G10L2 Command

When you program in:	Then:
incremental mode (G91)	any values entered into the work coordinate system table using the G10 command are added to the currently active work coordinate system values.
absolute mode (G90)	any values entered into the work coordinate system table using the G10 command replace the currently active work coordinate system values.


Example 10.3 and Figure 10.7 illustrate how the work coordinate system is shifted by using G10.

Example 10.3 Work Coordinate System Shift Using G10

Program block	Work coordinate Position	Absolute coord. Position
G54G01X25.Z25.;	X25 Z25	X50 Z45
G91;		
G10L2P1O2X10.Z10.;	X15 Z15	X50 Z45
or		
G54G01X25.Z25.;	X25 Z25	X50 Z45
G90;		
G10L2P1O2X35.Z30.;	X15 Z15	X50 Z45

Important: This modification is permanent. The new table values for the work coordinate systems are saved even when control power is turned off.

Figure 10.7
Results of Example 12.3




Work Coordinate System External Offset

The external offset allows all work coordinate system zero points to be shifted simultaneously, relative to the machine coordinate system. This offset can compensate for part positioning shifts that result when a different chuck is installed. It can also compensate for tool position shifts that result from a different tool turret.

The external offset can also be used to match the work coordinate systems on mechanically different machines. The machines can then use the same part program with the same G54-G59.3 coordinate values. This allows part programs to be less machine dependant.

Figure 10.8
External Offsets



Important: Once an external offset is entered into the coordinate offset table it cannot be canceled. This offset remains active even after power has been turned off. It becomes a permanent part of all work coordinate systems including the default work coordinate system.

Altering External Offset (G10L2)

There are three methods to change the value of an external offset in the work coordinate system table. Two methods can be found in the following sections:

Method:	Chapter:
manually alter the external offset value in the work coordinate system table	3
alter the paramacro system parameter values 5201- 5206	27

The third method, and the one described in this section, alters the external system table through G10 programming. Changing these values in the table using any of these methods does not cause axis motion. It does immediately shift the active coordinate system by the amount entered.

The values entered into the external offset are added to the work coordinate system zero point values each time a work coordinate system is called. The format for altering the external offset using G10 is:

G10 L2 P0 O__ X__ Z__;

Where :	It :
L2	tells the control that you want to alter the coordinate system tables.
P0	designates the external offset as the offset to update.
O__	<p>specifies whether the value entered for the diameter axis is a radius or diameter value. (O is non-modal.)</p> <p style="margin-left: 40px;">O1=value entered for the diameter axis is a radius value. O2=value entered for the diameter axis is a diameter value.</p> <p>Important: If you program O1 or O2 in a G10 code, the G10 code is not affected by a previously programmed G07 or G08 (radius/diameter programming). However, if no O-code is specified, or if the O-code is out of range (for example, O3), then the G10 code is affected by a G07/G08.</p>
X__Z__	specifies the location of the zero point of the specified work coordinate system relative to machine coordinate system.

When you execute this block, the control immediately shifts the currently active work coordinate system by the new external offset amount.


Example 10.4 and Figure 10.9 illustrate how the work coordinate system is shifted using G10.

Example 10.4
Changing the External Offset Through G10 Programming

Program Block	Comments
G10L2P1O1X-15.Z-10.;	defines work coordinate system zero point to be at X-15, Z-10 from the machine coordinate system zero point
G90; G10L2P0O1X-15.Z-20.;	sets external offset of X-15, Z-20 moving work coordinate system zero point to be at X-30, Z-30 from the machine coordinate system zero point
G90; G10L2P0O1X-30.Z-30.;	sets external offset of X-30, Z-30 moving work coordinate system zero point to be at X-30, Z-30 from the machine coordinate system zero point

Important: This modification is permanent. The new table values for the work coordinate systems are saved even when control power is turned off.

Figure 10.9
Results of Example 10.4



Offsetting the Work Coordinate Systems

This section describes the more temporary ways of offsetting the work coordinate systems. These offsets are activated through programming, and they are canceled when you remove power to the control. They may also be cancelled by an M02, M30, or control reset, depending upon the selections made in AMP by your system installer.

Important: All of these offsets are global in nature. This means that they apply to all work coordinate systems. When you change work coordinate systems (programming G54-G59) consider the effects of these offsets on the new work coordinate system.

Tool geometry and wear offsets **are not** effected by an offset made to the work coordinate system.

Important: We recommend that tool offsets for geometry and wear be canceled before you execute any work coordinate system offsets. If tool offsets are not canceled, the work coordinate system offset is added to the active tool offset. This can cause confusion when you change tool offsets later in the program. See page 19-4 on canceling tool offsets.

Coordinate Offset Using Tool Position (G92)

Use the G92 command in a part program to offset the currently active work coordinate system relative to the current tool position. A G92 block in a program offsets the zero point of the work coordinate system a specified distance from the current tool position.

G92.2 cancels G92 without canceling any other work coordinates. This differs from G92.1, which cancels all coordinate system offsets. A control reset may cancel this offset, depending upon the selections made in AMP by your system installer.

When a G92 command is executed in a program, it cancels any other active work coordinate system offsets that may have been in effect including G52 offsets, set zero, or jogged offsets. External offsets are not affected. When the logic flag BW_INHR is set, it cancels G92.

Important: A tool offset is not automatically canceled when you execute a G92 block. This can result in undesired effects on the work coordinate system when tool offsets are changed later.

The following G92 block offsets the work coordinate system so that the current tool position takes on the coordinate values programmed in the G92 block.

```
G92 X___ Z___;
```

For example specifying values of zero for all axes in a G92 block causes the current tool position to become the zero point of the current work coordinate system.

Execution of a G92 block does not produce any axis motion.

Important: Any axis not specified in the G92 block is not offset, and the current coordinate position for that axis remains unchanged.


Once the work coordinate system is offset, all absolute positioning commands in the program are executed as coordinate values in the offset coordinate system.

**Example 10.5
Work Coordinate System Offset (G92)**

Program Block	Comment
G54 G00 ;	G54 work coordinate system
X35. Z25. ;	rapid move to X35, Z25 in the G54 work coordinate system
G92X10. Z10. ;	Redefines current axis position to have the coordinates X10, Z10

The zero point of the offset G54 work coordinate system is 10 units away from the current tool location in both the X and Z directions. If the Z value had not been entered in the G92 block, the Z coordinate location would have remained unchanged (Z25.)

Figure 10.10
Results of Example 12.5




ATTENTION: G92 offsets are global. Changing from one coordinate system to another does not cancel the offset. Do not specify a change in coordinate systems (G54-G59.3) unless the effects of the offset have been considered.

Example 10.6 shows the effect of changing work coordinate systems while the G92 offset is active.

Example 10.6
Changing Work Coordinate Systems With Offset Active

Program	Comment
N1 G10L2P1X0Z0 ;	Define G54 work coordinate system zero point to be positioned X0, Z0 away from the machine coordinate system
N2 G10L2P2X20.Z25. ;	Define G55 work coordinate system zero point to be positioned X20, Z25 away from the machine coordinate system
N3 G55X10.Z5. ;	Move to X10, Z5 in the G55 work coordinate system
N4 G54X10.Z5. ;	Move to X10, Z5 in the G54 work coordinate system
N5 G92X-5.Z-5. ;	Offset current tool position to be at X-5, Z-5
N6 X15.Z0. ;	Move to X15, Z0 (offset still active)
N7 G55X10.Z5. ;	Move back to X10, Z5 in the G55 work coordinate system with the G92 offset still active

Figure 10.11
Results of Example 12.6



In Figure 10.11, the offset entered for the G54 work coordinate system has also shifted the G55 coordinate system. Any offsets described in this section alter all of the work coordinate system (G54 - G59) at the same time.

Offsetting Coordinate Zero Points (G52)

To offset a work coordinate system an incremental amount from its zero point, program a G52 block that includes the axis names and distances to be offset.

```
G52 X__ Z__ ;
```


This command offsets the current work coordinate system by the axis values that follow the G52 command.

Example 10.7 Work Coordinate System Offset by G52

Program Block	Machine Coordinate Position	Work Coordinate Position
G01X25.Z25.;	X25 Z25	X25 Z25
G52X10.Z10.;	X25 Z25	X15 Z15

In this example, no axis motion takes place when the G52 block is executed. The work coordinate system position values change. See Figure 10.12.

Figure 10.12
Results of Example 10.7



The G52 work coordinate system zero point offset can be canceled by programming a G52 block with zero values for the axes to be cancelled. The following block would cancel the work coordinate system offset for the X axis only.

```
G52 X0;
```

A G52 offset can also be canceled by executing a G92 or G92.1, performing a control reset or an E-STOP reset operation, or executing an end of program M30 or M02. A G92 command only cancels a G52 offset if one is active when the G92 block is executed. A G52 offset can be activated at some time after the G92 block is executed even if a G92 offset is still in effect.



ATTENTION: G52 offsets are global. Changing from one coordinate system to another does not cancel the offset. Do not specify a change in coordinate systems (G54-G59) unless the effects of the offset have been considered.

Set Zero Offset

When you perform a Set Zero operation, the control shifts the current work coordinate system so that the current tool's position is the zero point of the coordinate system. The axis where you want to perform a set zero on is selected through logic (refer to your system installer's documentation).

The Set Zero offset is similar to the execution of a G92 X0 Z0 block, with one exception. Unlike a G92, the set zero does **not** cancel a G52 offset. The G52 remains active and continues to offset the current tool position in the work coordinate system. When the G52 offset is canceled later, the coordinate system shifts.

The Set Zero offset can be canceled by programming a G92.1 command, executing a control reset operation, executing an E-STOP reset operation, or programming an end of program M30 or M02 command. A control reset may cancel the Set Zero offset, depending upon the selections made in AMP by your system installer.



ATTENTION: Set Zero offsets are global. Changing from one coordinate system to another does not cancel the offset. Do not specify a change in coordinate systems (G54-G59) unless the effects of the offset have been considered.

Example 10.8 Typical Set Zero Offset Application

Operation	Comment
-Manual jog-	axes are manually jogged to a location where the operator has determined that a special operation must be performed.
-Set Zero-	operator performs a Set Zero offset to establish the work coordinate system zero point at the current axis location
-Run program-	a generic special operation program can now be executed from the axis coordinate position that resulted from the manual jog and Set Zero

The set zero offset can be performed through an optional switch installed by your system installer.

Jog Offset

The jog offset feature lets you manually create a desired offset by jogging the axes during an automatic or MDI operation.

Important: This feature functions only if your system installer has supplied a special switch and the appropriate logic programming. See the “Jog Offsets” and “Jog-on-the-fly” logic flags in the logic reference manual or refer to the documentation supplied by your system installer.

Press a special switch after interrupting an automatic or MDI operation to activate this feature. Any manual jog moves you make are added to the current work coordinate position as an offset. When you press cycle start to continue execution, the jogged distance for each axis remains as a coordinate offset for that axis.



ATTENTION: Jog offsets are global. Changing from one coordinate system to another does not cancel the offset. Do not specify a change in coordinate systems (G54-G59) unless the effects of the offset have been considered.

You can cancel the jog offset by programming a G92.1 command, executing a control reset operation, executing an E-STOP reset operation, or programming an end of program M30 or M02 command.

To use this feature, follow these steps:

1. Press **<CYCLE STOP>** or **<SINGLE BLOCK>** on the MTB panel to interrupt automatic or MDI operation.
2. Turn on the switch to activate the jog offset feature (refer to documentation provided by your system installer).
3. Change to manual mode, unless the control is equipped for the “Jog-on-the-Fly” feature which allows jogging in automatic or MDI modes (refer to documentation prepared by your system installer).
4. Jog the axes using any of the available jog types (with the exception of homing) as described on page 4-1. The control adds the amount of the jog move as an offset for each jogged axis.
5. Return to Automatic or MDI mode. When you press the **<CYCLE START>** button, execution continues from the new tool location at the jogged offset.

Important: When you move the jog offset, the axis position displays do not change on the screen unless the currently active screen is displaying absolute position coordinates. This is because the coordinate values in the work coordinate system are being offset as the axes are being jogged.

Canceling Coordinate System Offsets (G92.1)

The G92.1 command cancels these offsets:

- G92 work coordinate system offset
- G52 zero point offset
- Set zero offset
- Jog offset
- Reset G54 - G59.3 coordinate system to default condition

It does not cancel an external offset. Refer to page 10-9.

The G92.1 block also reestablishes the default work coordinate system as set in AMP by your system installer. It cancels or activates the coordinate system (G54-G59.3) as set in AMP to establish the default coordinate system.

You must program the G92.1 block with no axis words. Axis words in a G92.1 block generate an error. When you execute the G92.1 block, all G92, G52, set zero, and Jog offsets are canceled on all axes. You cannot cancel the offsets on only one or more of the axes.


No axis motion takes place during execution of a G92.1 block. Axes remain at their last programmed positions while the work coordinate system adjusts to remove all offsets.

Example 10.9 demonstrates the G92.1 offset cancel.

**Example 10.9
G52 Offset Cancelled by a G92.1**

Program Blocks	Comment
N1 G01Y25.X25.;	move to Y25, X25
N2 G52Y10.X10.;	work coordinate system is offset by Y10, X10
N3 Y25.X25.;	move to Y25, X25 in the offset coordinate system
N4 G92.1;	G52 offset is cancelled, program position displays axis position at X35Y35.

**Figure 10.13
Results of Example 12.9**



Canceling Selected Coordinate System Offsets (G92.2)

The G92.2 command cancels these offsets:

- G92 work coordinate system offset
- Set zero offset
- Jog offset

It does not:

- cancel an external offset
- reset the current work coordinate system (G54-G59.3)
- cancel a G52 offset

The G92.2 block must be programmed with no axis words. Axis words in a G92.2 block generate an error. When you execute the G92.2 block, all G92, set zero, and Jog offsets are canceled on all axes. You cannot cancel the offsets on only one or more of the axes.

No axis motion takes place during execution of a G92.2 block. Axes remain at their last programmed position while the work coordinate system adjusts to remove these offsets.

Logic Offsets

Your system installer has the option of activating, deactivating, or altering the value of these offsets through logic:

- Work coordinate systems
- External offset
- Tool length offsets (geometry and wear)
- Tool tip radius offsets (geometry and wear)
- Tool orientation

These offsets can be modified through a custom display page created by your system installer or through some other input to logic.

There can be an impact on the activation of offsets if a part program is already active for automatic execution. Typically, any blocks that have been read into the control's look-ahead buffer use the newly modified offset value. If a cutter compensation offset has been modified by logic, the control does not update the look-ahead buffer unless the offset is currently active. Refer to documentation supplied by your system installer for details on specific logic offset operations.

END OF CHAPTER


Overtravels and Programmable Zones

Chapter Overview

Overtravels and programmable zones define areas that restrict the movable range of the cutting tool. The 9/PC control is equipped to establish two overtravel areas and two programmable zones as illustrated in Figure 11.1.

Topic:	On page:
Hardware overtravels	11-2
Software overtravels	11-3
Programmable zone 2	11-5
Programmable zone 3	11-7

Figure 11.1
Overtravels



There are two types of overtravels:

1. **Hardware overtravels** -- Established by your system installer by mounting mechanical limit switches on the movable range of the axes
2. **Software overtravels** -- Established in AMP by your system installer designating coordinate values in the machine coordinate system

There are two types of Programmable Zones.

Zone:	Description:
Programmable Zone 2	Established by the operator, or person in charge of job setup. The machine coordinate system boundaries for this zone are entered in a table. Programmable zones may be turned on and off in the part program.
Programmable Zone 3	Established by the operator, programmer, or person in charge of job setup. The machine coordinate system boundaries for this zone are entered in a table or through programming . Programmable zones may be turned on and off in the part program.

Hardware Overtravels

When the machine tool is set up your system installer should have installed a set of two mechanical limit switches on each axis. These limit switches are installed in a position so that when the machine attempts to move beyond a range determined by your system installer the limit switch is tripped. When the limit switch is tripped axis motion stops. The area defined by these limit switches is referred to as the hardware overtravel.




ATTENTION: The area defined by a hardware overtravel does **not** take into account any tool offsets. This can allow the actual tool to enter the restricted area without the axes entering it.

These switches are installed to prevent the machine from motion that exceeds a range that can cause damage to the machine. Frequently your system installer wires the hardware overtravel directly into the E-STOP string. This stops all motion and disables the axis drives. Refer to the literature provided by your system installer for instructions on moving axes out of hardware overtravel.

Software Overtravels


The coordinate values of the points defining the software overtravels are set in AMP by your system installer. This overtravel can only be disabled by your system installer in AMP. If your system installer has enabled the software overtravels, the control is not allowed to exit the area defined by the software overtravels.

Figure 11.2
Software Overtravels Established in AMP



Your system installer selects values that represent a maximum and a minimum value in the form of coordinate values for each axis. These coordinate values define points on the machine coordinate system. The axes are not allowed to move past the coordinate value representing the maximum and minimum value on each axis. This limited range of motion is referred to as the software overtravels.

Figure 11.3
Area Defining Software Overtravel



Typically the software overtravels are located within the hardware overtravels (maximum axis travel defined by the limit switches on each axis), and they are used to keep the axes within the range your system installer determines is usable for that particular machine's application.

The area defined by the software overtravels becomes effective after completion of the initial homing operation at power up. For details on how the control reacts to a entry into an overtravel area, refer to page 11-12.



ATTENTION: The area defined by a software overtravel does not take in to account any offsets. This allows the actual tool to enter the restricted area without the axes absolute position entering it. Make sure this is considered when the software overtravel is established.

Programmable Zone 2

Programmable zone 2 defines an area which the tool **cannot enter**. Generally, zones are used to protect some vital area of the machine or part located within the software overtravels.


Important: Programmable zones are defined using coordinates in the machine coordinate system. They are **not** affected by any changes in the work coordinate system, including external offsets.



ATTENTION: Programmable zones only protect the tool tip from entering the zone (as determined with the currently active tool length offset). They do not protect other moving members from collision with objects in the programmable zone's boundary.

Values for programmable zone 2 are entered in the programmable zone tables as described on page 3-20. These values represent a maximum and a minimum value in the form of machine coordinate values for each axis. The area defined by these points establishes the boundaries for programmable zone 2.

Figure 11.4
Area Defining Programmable Zone 2



Important: When changing a tool offset or activating a programmable zone 2, the current tool tip location must be outside of the area defined by programmable zone 2.

Programming this G-code:	turns Zone 2:	turns Zone 3:
G22	On	On
G22.1	Off	On
G23	Off	Off
G23.1	No Change*	Off

* A G23.1 turns on programmable zone 2 if it is the default power up condition configured in AMP (also activated at a control reset). G23.1 does not turn on programmable zone 2 when it is activated in a part program.

G23 is normally automatically made active at power up, though this is ultimately determined by the system installer in AMP. Your system installer also determines in AMP if an M02 or M30, control reset, or E-Stop reset cancels programmable zones that you have turned on or off while executing your program.

Important: If you program a G22, any axis words included in the block are stored as the coordinates for programmable zone 3. Refer to page 11-7.


If you attempt to program some other command in a G22 or G23 block, for example:

```
G22 G01 X12.;
```

the control issues the error message:

“UNUSABLE WORDS IN ZONE BLOCK”

Figure 11.5
Programmable Zone 2



For details on how the control reacts to entry into a prohibited area, see page 11-12.

Programmable Zone 3

Programmable zone 3 can define an area which the tool **cannot enter or an area the tool cannot exit**. The current tool location determines when programmable zone 3 is made active. Generally, zones are used to protect some vital area of the machine or part located within the software overtravels.


Important: Programmable zones are defined using coordinates in the machine coordinate system. They are **not** affected by any changes in the work coordinate system, including external offsets.



ATTENTION: Programmable zones only protect the tool tip from entering the zone (as determined with the currently active tool length offset). They do not protect other moving members from collision with objects in the programmable zone's boundary.

Values for programmable zone 3 are entered either in the programmable zone table (described on page 3-20) or through a G22 program block. A maximum and a minimum coordinate value (in the machine coordinate system) are assigned for each axis. The resulting coordinates define the boundaries for programmable zone 3.


Figure 11.6
Area Defining Programmable Zone 3



Unlike the software overtravels and programmable zone 2, programmable zone 3 can define either an area that the cutting tool can not exit or an area that the cutting tool can not enter. This is determined by the current tool location when programmable zone 3 is made active.

3. The software overtravels: define an area that the cutting tool may not exit if the tool is currently inside the zone when the zone is activated.
4. Programmable Zone 3: defines an area that the cutting tool cannot enter if the tool is outside the zone when activated or: defines an area that the cutting tool cannot exit if the tool is inside the zone when activated.

Figure 11.7
Programmable Zone 3



Programmable zone 3 becomes active when either the G22 or G22.1 code is executed. It is made inactive when the G23 or G23.1 code is executed.

Program G-code:	To turn on these zones:	To turn off these zones:
G22	2 and 3	not applicable
G22.1	3	2
G23	not applicable	2 and 3
G23.1	2*	3

* A G23.1 only turns on programmable zone 2 if it is activated via a control reset or power up condition. G23.1 does not turn on programmable zone 2 if it is programmed. To turn on programmable zone 2 and turn off programmable zone 3, first program a G22 followed by a G23.1 to turn off programmable zone 3. Programming G23.1 has no affect on zone 2.

G22.1 and G23.1 are modal (G22.1 cancels G23.1, and G23.1 cancels G22.1).

Important: G22.1, G23, and G23.1 must be programmed in blocks without other commands. If you program a G22, any axis words included in the block are stored as the coordinates for programmable zone 3.

If you program other commands other than a G-code in the same modal group in a G22, G22.1, G23, or G23.1 block, this error message appears:

“UNNECESSARY WORDS IN ZONE BLOCK”

Programming Zone 3 Values (3 or fewer axes)

You can reassign values for the parameters that establish programmable zone 3 by programming axis words in a G22 program block. Two methods are available. This section discusses programming values for zone 3 when three or fewer axes have been configured on the system (this does not include any spindle).

Define values for programmable zone 3 using the G22 command followed by axis words in the following format:

G22 X__ Z__ U__ I__ K__ J__ ;

Where:	Defines:
Absolute axis words (normally X, Z, and U)	maximum zone limits
Integrand words (normally I, K, and J)	minimum zone limits

These axis words can vary. Refer to your system installer’s documentation. The following example assumes a three axis lathe configuration. Absolute axis names are X, Z, and U. Integrand for these axis words are I, K, and J respectively.

This block:	Results in:
G22 X10 I-10 Z14 K-14 U1 J-1;	upper and lower zone 3 limits for X, Z, and U axes are changed. Zones 2 and 3 are both activated,
G22 X10 Z10 U20;	upper zone 3 limits are changed for X, Z, and U axes. Zones 2 and 3 are both activated.
G22 I-10 Z10 K-5 J-3;	lower zone 3 limits for X and U axes are changed. Both upper and lower limits for Z axis zone 3 are changed. Zones 2 and 3 are both activated.
G22 K-10;	lower zone 3 limit for Z axis is changed. Zones 2 and 3 are both activate.

The zone values entered in a G22 block always reference coordinate values in the machine coordinate system.

If a value for a maximum axis parameter is less than the value set for an axis current minimum parameter, or if a value for a minimum axis parameter is set greater than the value set for an axis current maximum value, the control displays the message:

“INVALID VALUE (MAX < MIN) FOR ZONE 3 AXIS (X)”

This message displays the name of the axis that has been set incorrectly. It does not indicate if it is the minimum or maximum value that is incorrect.

If the same integrand word is assigned in AMP by the system installer to more than one axis, that integrand word will set the lower zone 3 limit for all axes with that integrand.

Programming Zone 3 Values (4 or more axes)

You can reassign values for the parameters that establish programmable zone 3 by programming axis words in a G22 program block. Two methods are available. This section discusses programming values for zone 3 when four or more axes have been configured on the system (this does not include any spindle).

This method differs from the three axis method in that the same integrands can be used again for different axes (necessary since the control only supports three integrand words). Assume the following AMP configuration:

Absolute Axis name	X	Y	Z	U	V	W	A	B	C
Axis Integrand	I	J	K	I	J	K	I	J	K

These axis words can vary. Refer to your system installer's documentation.

Define values for programmable zone 3 using the G22 command followed by axis words in the following format:

```
G22 X__ Y__ Z__ I__ J__ K__;  
G22 U__ V__ W__ I__ J__ K__;  
G22 A__ B__ C__ I__ J__ K__;
```

Where:	Defines:
Absolute axis words	maximum zone limits
Integrand words (normally I, J, and K)	minimum zone limits

Using this method, the same integrand word assigned in AMP to more than one axis correspond only to the absolute axis words programmed in the G22 block. Integrand words cannot be programmed alone (without a absolute axis word in the G22 block). The following example assumes a machine with axes configured as shown above.

These blocks:	Results in:
G22 X10 I-10 Y14 J-14 Z1 K-1; G22 U5 I-5 V13 J-2 W11 K10; G22 A3 I2 B7 J-7 C12 K11;	upper and lower zone 3 limits for all 9 axes are changed. Zones 2 and 3 are both activated when the first block in this series of blocks is executed.
G22 X1 Y2 Z3 U4 V5 W6 A7 B8 C9;	upper zone 3 limits are changed for all 9 axes. Zones 2 and 3 are both activated.
G22 X1 Y2 Z3 U4 V5 W6 A7 B8 C9 I-1 J-2 K-3;	upper and lower zone 3 limits for all 9 axes are changed. (I sets lower for X, U, and A; J sets lower for Y, V, and B; K sets lower limits for Z, W, and C). Zones 2 and 3 are both activate.
G22 K-10;	error is generated. Current status of zones remains in current state (on or off).



ATTENTION: When using multiple blocks to set the zone 3 limits, keep in mind zone 3 is activated after the first G22 block. This will result in zone 3 being activated before you have completed changes to the zone 3 values. This can cause the control to miss-interpret zone 3 as an internal or external zone, depending on the tool location at the time of the zone activation.

The zone values entered in a G22 block always reference coordinate values in the machine coordinate system.

If a value for a maximum axis parameter is less than the value set for an axis current minimum parameter, or if a value for a minimum axis parameter is set greater than the value set for an axis current maximum value, the control displays the message:

“INVALID VALUE (MAX < MIN) FOR ZONE 3 AXIS (X)”

This message displays the name of the axis that has been set incorrectly. It does not indicate if it is the minimum or maximum value that is incorrect.

Resetting Overtravels

Tool motion stops during overtravel conditions that occur from 3 causes:

Cause:	Description:
Hardware overtravel	the axes reach a travel limit, usually set by a limit switch or sensor mounted on the axis. Hardware overtravels are always active.
Software overtravel	commands cause the axis to pass a software travel limit. Software overtravels are active only after the axis has been homed provided the feature has been activated in AMP by the system installer.
Programmable zone overtravel	The tool reached a travel limit established by independent programmable areas. Programmable Zones are activated through programming the appropriate G-code.

In all cases, the control issues an error message. When an overtravel condition occurs, all axis motion stops, the control goes into cycle stop and one of these error messages appears.

Error Message:	Description:
HARDWARE OVERTRAVEL (-) BY AXIS (X)	indicates that the specified axis has tripped either the + or - hardware limit switch mounted on the machine.
SOFTWARE OVERTRAVEL (+) BY AXIS (X)	indicates that the specified axis has entered the overtravel area defined by the software overtravel limits in either a positive or negative direction.
VIOLATION OF ZONE (2) BY AXIS (X)	indicates that a tool has reached the specified axis overtravel area defined by either programmable zone 2 or 3.

When an overtravel of any type occurs, axes cannot move in the same direction as the feed causing the overtravel. Only axis motion in the reverse direction is possible.

How a hardware overtravel condition is reset depends on the E-STOP circuit design and the way logic was programmed by your system installer.

To reset a software or programmable zone overtravel condition:

1. Determine whether the control is in E-Stop. If it is not, go to step 4.
2. Eliminate any other possible conditions that may have caused an emergency stop, then make sure that it is safe to reset the emergency stop condition.
3. Press the **<E-STOP RESET>** button to reset the emergency stop condition. If the E-Stop does not reset, it is a result of some cause other than overtravel.
4. Make sure it is safe to move the axis away from the overtravel limit.
5. Use any of the jog features described on page 4-1 except homing, to manually move the axis away from the limit.

END OF CHAPTER

Coordinate Control

Chapter Overview

This chapter describes 9/PC coordinate control.

For information about:	See page:
Plane selection G17, G18,G19	12-1
Absolute/Incremental modes G90, G91	12-2
Inch/Metric modes G70, G71	12-4
Radius/Diameter modes G07, G08	12-4
Scaling G14, G14.1	12-6

Plane Selection (G17, G18, G19)

The 9/PC control has a number of features that operate in specific planes. For that reason, it is frequently necessary to change the active plane by using a G17, G18, or G19 code. The G18 plane is always active at power-up.

Some of the features that are plane-dependant are:

- Circular interpolation
- Tool tip radius compensation
- Many fixed cycle operations

Important: Your system installer determines the axis names and planes defined by G17, G18, and G19 in AMP. Your system may not have planes assigned exactly as listed below. Refer to the documentation prepared by your system installer.

Typical axis names and their corresponding plane assignment are shown below (this manual assumes this configuration throughout):

Code:	Plane defined by the:
G17	none
G18	Z and X axes (or axes parallel to Z and X)
G19	none

Planes can be altered to accommodate additional axes parallel to the principle axes by programming those axes in a G17, G18, or G19 block. See Example 12.1.

Example 12.1 Altering Planes for Parallel Axes

Assuming the system installer has made the following assignments in AMP:

```
G18    -- the ZX plane.
U axis -- parallel to Z axis
V axis -- parallel to X axis
```

Program block	Plane selected	Axis Motion
G18;	selects ZX plane	None
G18 U0;	selects UX plane	U axis moves to zero
G18 V0;	selects ZV plane	V axis moves to zero
G18 U0V0;	selects UV plane	U & V axes move to zero

This manual assumes your system installer has selected the G18 plane to be activated when an end-of-program block is read (M02 or M30), a control or E-STOP reset is performed, or power to the control is turned off.

Important: Any axis word in a block with plane select G-codes (G17, G18, G19) causes axis motion on that axis. If no value is specified with that axis word, the control assumes a value of zero or generates an error depending on how your system is AMPed.

Absolute/Incremental Modes (G90, G91)

There are two methods for programming axis positioning commands:

- absolute positioning
- incremental positioning.

In the absolute mode, coordinates are referenced from the zero point of the active coordinate system. Absolute mode is established by programming a G90.

```
G90X40.Z20.;
```

In the above block, the control moves the axes to a position X40, Z20 as referenced on the active coordinate system.

G90 is a modal G-code, and it remains active until cancelled by a G91.

In the incremental mode, coordinates are referenced from the current axis position. Programming a G91 establishes an incremental mode.

```
G91X40.Z20.;
```


In the above block, the control moves the cutting tool away from the current axis position, a distance of 40 units on the X axis and 20 units on the Z axis.

G91 is a modal G-code and remains active until cancelled by a G90.

Example 12.2
Absolute vs Incremental Commands

Absolute Command	Incremental Command
G90X20.Z10.;	G91X10.Z-25.;

Figure 12.1
Results of Incremental VS Absolute Example



Lathe G-code, System A

If using G-code system A, G90 and G91 are not available. To program moves in absolute mode using G-code system A, call out axis positions using X, Z, and C axis words.

Important: Absolute and incremental axes addresses are assigned in AMP by your system installer, and they differ from those shown here.

Absolute command, G code system A

X40.Z20.;

To program incremental moves using G-code system A, call out axis positions using U, W, and V.

Incremental command, G code system A

U20.W-25.;

The above commands are not modal. Incremental and absolute commands can be programmed at any time, even in the same block.

Table 12.A shows the typical command addresses for absolute and incremental programming in G-code system A. Refer to the documentation provided by your system installer for axis names in your system.

Table 12.A
Absolute and Incremental Addresses, G-code System A

Absolute Commands	Incremental Commands	Remarks
X	U	X axis motion command
Z	W	Z axis motion command
C	V	C axis motion command

Inch/Metric Modes (G70, G71)

A unit system (inch or metric) can be selected by programming either G70 for the inch system or G71 for the metric system. These unit system G-codes should be among the first blocks written in a program.

Important: Inch/Metric Modes (G70, G71) are only available on lathe C.

Both G70 and G71 are modal, and they cancel each other. The default unit system selected by the control at power-up is determined in AMP by your system installer.

The currently active unit system is usually displayed on the screen for softkey level 1 in lines 3 or 4 between the [] symbols. If the screen selected for display of softkey level 1 is the status screen, the active system G-code (G71 or G70) is displayed among the active system G-codes.

Some of the functions that are affected by the active unit system (inch or metric) are:

- Position commands
- Feedrate commands
- Axis feed amount for fixed amount feed operation

Radius/Diameter Modes (G07, G08)

Usually, workpieces on CNC lathes are cylindrical. The control allows workpiece dimensions programming as either radius or diameter values.

G08 places the control in diameter programming mode. This mode remains active until cancelled by a G07.

G07 places the control in radius programming mode. This mode remains active until cancelled by a G08.

Either G08 or G07 can be selected by your system installer in AMP to be the active mode at power-up. The currently active G-code can be displayed by selecting the status screen. Refer to page 8-1.


If program execution branches to a subprogram that changes to radius or diameter mode, the control always reverts to the mode of the calling program when subprogram execution is completed.

**Example 12.3
Diameter/Radius Programming**

Assume X is the diameter axis

Diameter Programming Mode (G08)	Radius Programming Mode (G07)
Incremental	Incremental
<pre>G90G00X0Z35; G91G01F.1X12; Z-10 G02Z-4X8I4; G01Z-15;</pre>	<pre>G90G00X0Z35; G91G01F.1X6; Z-10 G02Z-4X4I4; G01Z-15;</pre>
Absolute	Absolute
<pre>G90G00X0Z35; G01F.1X12; Z25; G02Z21X20I4; G01Z6;</pre>	<pre>G90G00X0Z35; G01F.1X6; Z25; G02Z21X10I4; G01Z6;</pre>

**Figure 12.2
Diameter/Radius Programming**



Important: The following must always be programmed as radius value, regardless of whether G07 or G08 is active:

- Most of the X axis infeed amounts or similar values (addresses D, I, K) used in Simple and Compound fixed cycles (G70 - G78).
- Center point designation (addresses R, I, K) for circular interpolation.
- Feedrates in the X-axis direction (change in radius per revolution G95 or radius per minute G94).
- The threading cycle parameter E or F when face threading is being programmed.

Position displays are impacted by radius diameter mode. The diameter/radius axis selected in AMP displays either an R or a D next to it, indicating which mode it is currently in and represented on the CRT. This even applies to the machine coordinate system (absolute display).

Scaling

Use the scaling feature to reduce or enlarge a programmed shape. Enable this feature by programming a G14.1 block as shown below:

```
G14.1 X__ Z__ P__;
```

Where :	Is :
X and Z	the axis or axes to be scaled and the center of scaling for those axes.
P	the scaling magnification factor for the specified axes.

The axes programmed in the G14.1 block determine which axes are scaled. The corresponding axis word values specify the center of scaling for each axis. This position is the axis coordinate around which the scaling operation is performed.

The scaling magnification factor (P) is the amount of scaling to be applied to the programmed axes. Each axis can have a different scale factor by programming them in separate G14.1 blocks. The scaling range is from 0.00001 to 999.99999. A scale factor less than one reduces a programmed move, while a scale factor greater than one enlarges a programmed move.


If no P-word is programmed or if P0 is programmed in the G14.1 block, the default magnification factor is used. If the programmed P-word value is out of range, the CRT displays an error message.

When absolute mode (G90) is active, scaling moves are referenced from the programmed center of scaling.

Example 12.4 Scaling with Absolute Mode Active

Program block	Comment
G07 G90 G00 X30. Z60.;	radius mode, absolute mode
G14.1 X0 P.5;	scale X axis only, by .5
G01 X12.;	feedrate move X to X6
Z38.;	feedrate move Z to Z38
X20.;	feedrate move X to X10
G14;	cancel scaling
G00 X30. Z60.;	rapid return

Figure 12.3
Results of Example 12.4




When incremental mode (G91) is active, the control ignores the programmed centers of scaling. The control performs scaling on the axes programmed in the G14.1 block, but the scaling moves are referenced from their current axis positions, **not** the programmed center of scaling or the active coordinate zero point.

Important: The center of scaling may be specified in either incremental or absolute mode (G90/G91) in the G14.1 block. But unlike other features in the control, both modes cannot be programmed in the same block.

Example 12.5 Scaling with Incremental Mode Active

Program block	Comment
G07 G90 G00 X30. Z60.;	radius mode, absolute mode
G91;	incremental mode
G14.1 X1.023 P.5;	scale X by .5 (X value is ignored)
G01 X-18.;	feedrate move X to X21
Z-22.;	feedrate move Z to Z38
X8.;	feedrate move X to X25
G14;	cancel scaling
G00 X5. Z30.;	rapid return

Figure 12.4
Results of Example 12.5



G14 disables scaling on all axes. When you disable scaling, the center of scaling and any scaling magnification factors are cleared. The next time you enable scaling, these values must be reset. In addition to G14, M99 in the main program, M02, M30, and a control reset operation disables scaling. The system powers up with scaling disabled.


Your system installer specifies in AMP, on an axis by axis basis, whether scaling is allowed. Refer to the literature provided by your system installer for additional information.

The control provides the logic program with the option of monitoring which axes are currently being scaled, on an axis-by-axis basis, through the logic flag BR_SCAX. Refer the *9/PC Logic Reference Manual* for additional information.

Scaling Axis Position Display Screens

When you enable scaling for a particular axis, the letter “P” is displayed next to the axis name on all axis position display screens. Figure 12.5 shows scaling enabled on all axes.

Figure 12.5
Axis Position Display Screen Showing Scaling Enabled



Scaling Magnification Data Screen

The scaling magnification data screen lists for all axes, the:

- currently active scaling magnification amount
- current center of scaling
- default scaling magnification amount


The currently active scaling magnification amount and the current center of scaling for the axes can only be monitored through this screen. The default scaling magnification amount for the axes can be monitored or changed through this screen.

The default scaling magnification values should be changed only when the control is in a stopped state. If the default values are changed, the new default values do not become active until the next G14.1 block is executed.

To access the scaling magnification data screen, follow these steps:

1. Press the {**OFFSET**} softkey on the main menu screen.

(softkey level 1)



2. Press the {**SCALNG**} softkey to display the scaling magnification data screen. See Figure 12.6.

(softkey level 2)





Figure 12.6
Scaling Magnification Data Screen



Important: If an axis is configured as a rotary axis, the scaling magnification display screen displays dashes instead of numbers for that axis. Rotary axes cannot be scaled.

The left column lists the current center of scaling for each axis. When scaling is cancelled, the current center of scaling for each axis is set to zero. The format of this value is determined by the word format of the selected axis.

The middle column lists the currently active scaling magnification value for each axis. When scaling is cancelled, the current scaling magnification value for each axis is set to 1.00000.

The right column lists the current scaling magnification default value for each axis. This value is used if P is not programmed or if P0 is programmed in the G14.1 block. The range of the default value is 0.00001 to 999.99999 with a word format of 3.5. The default values are stored in memory when the control is powered down. When the control is powered up, these values are restored from memory.

3. Use the up or down cursor keys to move the block cursor to the default value to be changed. The selected default value appears in reverse video.
4. To replace stored default scaling magnification value, key in the new default value and press the {REPLCE VALUE} softkey.

Scaling Restrictions

While scaling is enabled, these restrictions apply:

- Scaling affects only programmed axis motion. All manual axis motions and logic axis mover motions are performed at full scale.
- Scaling does not affect M-, F-, S-, T-, and B-word functions. The F-word is scaled if the control is in inverse time mode (G93). Scaling while in inverse time mode is applied as follows:

$$\text{Scaled F word (when in G93 mode)} = \frac{\text{Programmed F word}}{\text{Largest Scale Factor}}$$

- Scaling is disabled during G27, G28, and G30 automatic home operations. For a G29 automatic return from home operation, scaling is re-enabled after the intermediate point is reached.
- When changing work coordinates (G54-G59.3), the center of scaling is transferred from the old work coordinate system to the new work coordinate system. The offset distance from the tool position in the old work coordinate system to the tool position in the new work coordinate system is not scaled.
- Scaling is applied to G52 and G92 offsets. The center of scaling shifts when the work coordinate systems are shifted by a G92 offset or by changing coordinate offset values. When using a G52 offset, the center of scaling is adjusted to the new local coordinate systems.

- Scaling is not applied to these offsets:
 - external
 - tool wear
 - tool geometry
 - tool radius
 - tool length
- Scaling is not applied to blocks containing:
 - dwells (G04)
 - data setting codes (G10., G10.1)
 - macro calls (G56, G66, G66.1)

In the case of macro calls, the data passed via local parameters is not scaled unless the data is used inside of the macro for motion.

- G22, programmable zone 2 check on and data setting, is not scaled.
- G53, absolute positions moves, is not scaled.
- Rotary axes cannot be scaled.
- In circular mode, the scale factors for the axes of the active plane have to be the same. The control generates an error if the scale factors of the axes are not equal.
- Scaling is applied to these fixed cycles as shown below. The axis letters may vary depending on how AMP is configured.
- G31, G31.1 - G31.4

Gxx X__Z__

X (scaled)
Z (scaled)

- G37, G37.1 - G37.4

Gxx Z__

Z (scaled)

- G73, G74, G76, G82, G83, G84
G85, G86, G87, G88, G89

Gxx X__Y__Z__R__I__Q__K__P__F__L__

X (scaled)
Y (scaled)
Z (scaled)
R (scaled)
I (not scaled)
Q (not scaled)
K (not scaled)
P (not scaled)
F (not scaled)
L (not scaled)

Important: R uses the scale factor associated with the axis that is perpendicular to the active plane.

These cycles assume that Lathe type C is selected:

- G73, G74, G75

Scaling is not applied to the block containing the G-code. Scaling is applied to the contour blocks defining the workpiece.

- G76, G77

Gxx X__Z__I__K__F__D__

X (scaled)

Z (scaled)

I (scaled)

K (not scaled)

F (not scaled)

D (not scaled)

- G78

G78 X__Z__K__D__F__E__A__P__I__

X (scaled)

Z (scaled)

K (not scaled)

D (not scaled)

F (not scaled)

E (not scaled)

A (not scaled)

P (not scaled)

I (scaled)

- G33

G33 Z__F__E__Q

G33 X__Z__F__E__Q

G33 X__F__E__Q

X (scaled)

Z (scaled)

E (not scaled)

F (not scaled)

Q (not scaled)

- G34
G34 Z_F_E_Q_K
G34 X_Z_F_E_Q_K
G34 X_F_E_Q_K
X (scaled)
Z (scaled)
E (not scaled)
F (not scaled)
Q (not scaled)
K (scaled)
- G20
G20 X_Z_I_
X (scaled)
Z (scaled)
I (scaled)



ATTENTION: This cycle cuts more metal when scaling is enabled.

- G21
G21 X_Z_F_E_
X (scaled)
Z (scaled)
F (not scaled)
E (not scaled)
- G24
G24 X_Z_K_
X (scaled)
Z (scaled)
K (scaled)



ATTENTION: This cycle cuts more metal when scaling is enabled.

- G81

G81 X_Z_R_F_L_

X (scaled)

Z (scaled)

R (scaled)

F (not scaled)

L (not scaled)

Important: R uses the scale factor associated with the axis that is perpendicular to the active plane.

END OF CHAPTER

Axis Motion

Chapter Overview

This chapter covers the group of G-words that generates axis motion or dwell data blocks. Major topics include:

Information about:	On page:
Positioning axes	13-1
Automatic machine home	13-11
Dwell (G04)	13-18
Programmable mirror image	13-19
Axis clamp	13-22

Positioning Axes

Use these four basic G-codes to produce axis motion:

- G00 Rapid Positioning
- G01 Linear interpolation
- G02 Circular interpolation (clockwise)
- G03 Circular interpolation (counter-clockwise)

After the execution of a positioning command the program proceeds to the next block only after an in-position check function confirms that all commanded axes have reached the in-position band. Your system installer sets the in-position band width in AMP. Refer to chapter 17 for details on the G-codes that you can use to modify the in-position band check.

Rapid Positioning Mode (G00)

G00 X__ Z__ ;

Where :	Is :
G00	The G00 code establishes the positioning mode. In positioning mode, the cutting tool is fed along a straight line at the rapid feedrate determined in AMP by your system installer.
xz	The end point of the move generated by the G00 block in the current work coordinate system.

You can perform a rapid positioning in the absolute mode (G90), or the incremental mode (G91).


Your system installer determines the feedrate for the rapid positioning mode in AMP, individually for each axis. The feedrate of a positioning move that drives more than one axis is limited by the rapid rate set for the slower axis. The slower axis is driven at its rapid rate, while the feedrate for other axes is reduced to maintain a linear move. This also assures that all axes start and stop at the same time.

G00 is a modal command and remains in effect until it is cancelled by a G-code of the same group. For a listing of G-code groups, see appendix C.

Example 13.1
Positioning (G00)

Absolute command	Incremental command
G08	G08
G90G00X75.Z55.;	G91G00X-35.Z-80.;

Figure 13.1
G00 Positioning, Results of Example 13.1



Important: Any F-word designated in the positioning mode is stored as the active feedrate in control memory, but it is ignored during positioning mode (G00).

Linear Interpolation Mode (G01)

The format for linear interpolation mode is:

G01 X ____ Z ____ F ____ ;


Where :	Is :
G01	G01 establishes the linear interpolation mode. In linear interpolation mode, the cutting tool is fed along a straight line at the currently programmed feedrate.
XZ	This is the location of the end point of the linear move in the current work coordinate system.
F	The F-word represents the feedrate for axis moves that take place in the G01, G02, and G03 modes. The F-word does not have to be programmed in the G01 block however, if the F-word is not programmed a feedrate must have been made active in some previous block.

Linear interpolation can be performed in the absolute mode (G90), or the incremental mode (G91).

Example 13.2 Linear Interpolation

Absolute command	Incremental command
G08 ;	G08 ;
G90G01X30.Z60.F.1;	G91G01X10.Z-65.F.1;

Figure 13.2
Results of Linear Interpolation (G01), Example 13.2



Once the feedrate, F, is programmed it remains effective until another feedrate is programmed (F is modal). You can override programmed F-words. For details, see chapter 18.

Example 13.3 Modal Feedrates

Program Block	Comment
G91G01X10.Z20.F.1;	F.1 is effective until
Z35.;	another feedrate is
X40.Z35.;	programmed
Z44.F.3;	F.3 is effective

The feedrate for a multi-axis move is specified as the vectorial feedrate. The control adjusts the individual axis feeds to obtain the programmed feedrate. For details on feedrates, see chapter 18.


Circulate Interpolation Mode (G02, G03)

G02 and G03 establish the circular interpolation mode.

In this mode:	The tool:
G02	moves along a clockwise arc
G03	moves along a counterclockwise arc.

Figure 13.3 shows clockwise and counterclockwise orientation relative to the positive X and Z axes.

Figure 13.3
Circular Interpolation Direction



You must establish a plane before the control performs the correct arc. This should have been done by your system installer, typically assigning the Z and X axes to the G18 plane. This becomes the default plane that the control assumes when:

- power is turned on
- E-Stop is reset
- the control is reset

Circular interpolation can be performed in the absolute (G90) or incremental (G91) mode.

Important: S-Curve Acc/Dec mode is not available with circular interpolation mode.

The format for circular interpolation in the ZX plane is:

$$\begin{matrix} \{G02\} \\ G03 \end{matrix} X_ Z_ \left\{ \begin{matrix} I_ K_ \\ R_ \end{matrix} \right\} F_ ;$$


Where :	Is :
X, Z	In absolute (G90) mode, these are the work coordinate values of the end point. In incremental (G91) mode, these are the positions of the end point in reference to the start point.
I, K	These determine the position of the arc center. They are the incremental distance on each axis from the start point of the arc to the center point. These values are always incremental, regardless of the established positioning mode (absolute or incremental). I is parallel to X axis, and K is parallel to Z axis, but this can be configured in AMP. These are not necessary if programming the R parameter.
R	Rather than defining a center with I, K, the option exists to define an arc radius using R. The sign of this entry determines the arc centerpoint location. If R is programmed as a positive value, the centerpoint is located so that an arc less than 180° is generated. If R is programmed as a negative value, the centerpoint is located so that an arc greater than 180° is generated. Refer to Figure 13.5 for an example.
F	Another option is to enter a feedrate tangential to the arc. If omitted, the control uses the feedrate active prior to this block.

Example 13.4
Circular Interpolation G18 (ZX Plane)

Absolute Mode	Incremental Mode
G08G02; X50.Z45.I15.K0F.1;	G08G02; X30.Z-15.I15.K0F.1;
or	or
G08G02; X50.Z45.R15.F.1;	G08G02; X30.Z-15.R15.F.1;

In Example 13.4, the K-word can be omitted. If either I or K is omitted from the circular block, the control assumes they have a value of 0, unless an R-word is present.

Figure 13.4
Results of Circular Interpolation, Example 13.4




When you program an arc using the radius (R) value, two arcs are possible (Figure 13.5). Program the R-word with a positive or negative value to distinguish between these arcs.

Example 13.5 Arc Programmed Using Radius

Arc 1	Arc 2
center angle less than 180 degrees	center angle greater than 180 degrees
G90G02X25.Z40.R18.F.1;	G90G02X25.Z40.R-18.F.1;

Figure 13.5
Results of An Arc Programmed with Radius Command,
Example 13.5



Important: Any axis that is not specified when programming a circle remains at its current axis position value. This results in the arc's end point having the same coordinate value as the start point of the arc for that axis.


If you do not specify the end point of the arc, or if the end point is the same as the start point, two results are possible:

- if you use I and/or K to program the arc center, the control cuts a full circle
- if you use R to program the radius of the arc, no arc is made (the control does not move either axis)

Example 13.6 Arc End Points Same As Start Points

Arc 1-Full Circle	Arc 2-No Motion
G02I-5.K5.F.1;	G02R7.07F.1;
or	or
G02X15.Z5.I-5.K5.F.1;	G02X15.Z5.R7.07F.1;

Figure 13.6
Results of An Arc with End Point Equal To Start Point, Example 13.6



If you program a radius command, R, in the same block as I, and/or K, the control gives the R priority. The I-, and/or K-words are then ignored.

Important: Your system installer can specify the maximum allowed difference between the starting radius of the arc and the ending radius of the arc. If the difference exceeds the allowed value set in AMP, an error occurs.

Positioning Rotary Axes

This section describes how to program a rotary axis. A rotary axis is a non-linear axis that typically rotates about a fixed point. A rotary axis is not the same as a spindle which uses an M19 to orient to a specific angle. A spindle orient (M19) cannot move simultaneously with the other axes in the system. A rotary axis is capable of rotating when other axes are being moved.

Your system installer must determine which axes are rotary axes or linear axes, in AMP. Your system installer also determines in AMP the address that is used to command a rotary axis. This manual assumes that the C-word is used to program a rotary axis. Refer to your system installer's documentation for the rotary axis words used in a specific system.

A rotary axis is programmed in degrees. This manual assumes that your system installer has configured the rotary axis to “roll over” at 359.99° . After the rotary axis exceeds 359.99° of rotation, its position display rolls over to 0° and starts increasing. If the axis rotates to a position less than 0° , its position display rolls over to 359.99° and starts decreasing.

Typically a rotary axis is programmed in a block by itself or with linear moves (rapid G00 or cutting G01 moves). You can program a rotary axis in a block that contains circular moves (G02 or G03).

Programming in absolute or incremental

You can program rotary axes in absolute or incremental mode.

In absolute mode (G90), the rotary axis is programmed to angular positions. These positions are programmed between 0° and 359.99° . The sign given to this angular position determines the direction that the rotary axis travels to reach the programmed angle. For example, programming:

```
G90C25;
```

in a part program causes the rotary axis C, to rotate to an angle of 25° (referenced from a position 0 determined by your system installer) and rotate the axis in the positive direction to reach this position. Programming:

```
G90C-25;
```

in a part program causes the rotary axis C, to rotate to an angle of 25° and rotate the axis in the negative direction to reach this position.

In incremental mode (G91), the rotary axis is programmed to move in an angular distance (not to a specified angle as in absolute). The maximum incremental departure depends on the programming format selected in AMP by your system installer. The sign of the angle determines what direction the rotary axis rotates. For example, if the current C axis position is 25° and this block is programmed:

```
G91C50;
```

the C axis would rotate 50° in the positive direction. The new C axis position would be 75° .

If the current C axis position is 25° and this block is programmed:

```
G91C-50;
```

the C axis would rotate 50° in the negative direction. The new C axis position would be 335° .

In this mode:	you:
incremental (G91)	program a value greater than the rollover amount results in the rotary axis making one or more complete revolutions.
absolute (G90)	cannot program a rotary axis move greater than the rollover amount.
circular interpolation (G02 or G03)	cannot program a rotary axis move unless these conditions are met:: <ul style="list-style-type: none"> • the rotary axis cannot be in the active plane • the rotary axis must be programmed in the same block as a valid circular move made with the axes in the active plane

Important: You can program the largest move with a rotary axis is equal to the rollover amount. Any attempt to program a move that generates more motion than the rollover amount is truncated and moved to the position that has the same numerical endpoint as the programmed position. For example if this incremental move is programmed from a position of 10°:

```
G91C370;
```

the actual endpoint of the above move is still 20°; however, the rotary axis did not get there by revolving one revolution. Instead, it positioned itself directly to 20° without passing 20 once as expected.

Determining Rotary axis feedrates

The feedrate for a rotary axis is determined in much the same way as linear axes.

When the control is in rapid mode (G00), the feedrate for the rotary axis is the rapid feedrate for that axis as set in AMP. Remember that if other axes are moving in the same block, the feedrate for the block is limited by the axis that takes the longest time to complete its programmed move at its rapid speed. (refer to chapter 17 for details).

When the control is in one of the cutting modes (G01, G02, or G03), the control uses the programmed feedrate to calculate the angular velocity of the rotary axis. This feedrate is still limited to the maximum cutting feedrate (feedrate clamp) as determined in AMP.

When you program in this mode:	The rotary feedrate units are in:
G94 feed per minute	degrees per minute.
G95 feed per revolution	degrees per revolution of the spindle.

In any event, if a rotary axis is programmed in a block with other axis moves in either rapid (G00) or cutting (G01, G02, or G03) modes, all axes reach their destinations at the same instant.



ATTENTION: When programming a rotary axis remember that the programmed feedrate is in units of angular velocity. This means that the actual cutting feedrate depends on the tools distance from the center of rotation of the rotary axis.

Logic Axis Mover

Your system installer has the option of controlling selected axes through the logic program. When an axis is under logic control, the operator and part program have no control on that axis. Jog commands, as well as part program commands, are typically ignored unless logic has been written to manipulate these values in some manner.

Be aware that it is possible to disable axis position displays on the BDS for an axis under logic control. Refer to the documentation provided by your system installer for details on an axis controlled by logic.

Important: You must be in G60 mode to use the Logic Axis Mover option. If you are not in G60 mode, your system will return an error message.

Important: S-Curve Acc/Dec mode is not available with Logic Axis Mover.

Automatic Motion to and from Machine Home

Machine tools have a fixed machine home position that is used to establish the coordinate systems. The 9/PC control offers two methods for homing a machine after power up.

Operation:	Description:
Manual machine home	uses switches or buttons on the MTB panel provided solely for this purpose. Manual homing is described in detail in chapter 4.
Automatic machine home	uses a programmed machine home code.

Automatic Machine Homing (G28)

You accomplish automatic homing by the using a G28 code. When programmed as the first motion block in a part program, (or through MDI) a G28 automatically homes any axes programmed in the G28 block that have not yet been homed. Only axes that have their axis words programmed in the G28 block are homed.

Homing follows the sequence of homing events described in chapter 4.

The coordinate values that are programmed with the axis words in a G28 block are stored by the control as intermediate point values (described in the next section).

If all the axes programmed in the G28 block have already been homed when the G28 code is executed, then the control considers it an “Automatic Return to Machine Home” as described in the next section.

Important: When a homing request is made the feedback device for the axis (typically an encoder) must encounter at least one marker before tripping the homing limit switch. If the axis is close to the home limit switch you should jog the axis away from this switch before attempting a homing operation.

Automatic Machine Homing (G28) with Distance Coded Markers

The following outlines automatic machine homing (G28) for an axis with DCM feedback if the axis **has not** already been homed:

1. The axis moves at a speed and direction defined in AMP by G28 Home Speed and G28 Direction to Home, respectively.

The axis will come to a stop once the axis crosses two consecutive markers on the DCM scale.

- Important:** To determine an absolute position using DCMs, you must encounter at least two consecutive markers. Thus, if the axis position will not accommodate this assumption, the axis must be moved to another position before attempting a homing operation.
2. When the output command equals 0 (i.e., the axis stops), the control will determine the absolute position. Refer to your AMP manual for more information about DCM Homing for Absolute Position.

If your axis **is already homed**, refer to the Automatic Return to Home (G28) section later in this chapter.

Important: DCM axis homing must be performed manually or by programming a G28. Attempting to program any motion command other than a G28 will result in the decode error “MUST HOME AXIS”.

Automatic Return to Machine Home (G28)

When a G28 is executed in a part program (or through MDI) after the axes have already been homed, it causes a return to machine home. In this case, the axes specified in the G28 block simply go to their respective home positions in the machine coordinate system after moving to a programmed intermediate point. They do **not** repeat the homing routine of moving to the limit switches and searching for the encoder marker. For example, executing the block:

```
G28 X__ Z__;
```

in either absolute or incremental mode would return the axes automatically to the machine home via an intermediate point. The control stores the intermediate point specified by the axis words (X, Z) in memory to be used as the point of return for the automatic return **from** machine home operation called out by G29.


The return operation generates two axis moves both executed at the rapid feedrate. The first move is to the intermediate point, and the second is to the axis home position.

Although this command moves the axes at rapid feedrate as if in G00 mode, it is not modal. If G01, G02, or G03 modes are active, they are only temporarily canceled for the return to home moves.

Only the axes specified in the G28 block are returned to home. For example:

N1 G28 X4.0;	(X axis is moved to home after moving to 4.0)
N2 G28 X4.0 Z2.0;	(X and Z axes are moved to home after moving to (4.0, 2.0))

Figure 13.7
Automatic Return to Machine Home (G28)



Usually a G28 is followed by a G29 (automatic return from machine home) in a part program; however, the control stores the intermediate point in memory for use with any subsequent G29 block executed before power down. Only one intermediate point is stored for each axis. When a G28 is programmed with a new intermediate point, any axis not programmed in that block remains at the old value.

For example:

N1 G28 X4.0 Z3.0;	Intermediate point X=4 Z=3
N2 G28 Z2.0;	New intermediate point X=4, Z=2

Important: When the control executes a G28 or G30 block it temporarily removes any tool offsets and cutter compensation during the axis move to the intermediate point. The offsets and/or cutter compensation are automatically re-activated during the first block containing axis motion following the G28 or G30, unless that block is a G29 block. If a G29 follows, the offsets and/or cutter compensation remain deactivated on the way to the intermediate point and are reactivated when the axis moves from the intermediate point back to the point indicated in the G29 block.

Automatic Return from Machine Home (G29)

When a G29 is executed in a part program (or through MDI), the axis or axes move first to the intermediate point, and then to the position indicated in the G29 block. If a G28 was just executed, then this has the effect of returning the axis from machine home.

For example, executing the block:

```
G29 X7.0 Z1.5;
```

in absolute mode would move the axes to (7.0, 1.5) after passing through the intermediate point stored in control memory. In incremental mode, this block would move the axes to a position that is X7.0 and Z1.5 units away from the home point.

The intermediate point is stored in control memory after a G28 return to machine home or a G30 move to alternate home is executed. A G29 block is usually executed after a G28 or G30 block, typically to return the cutting tool to the part after a tool change.

Although this command moves the axes at rapid feedrate as if in G00 mode, it is not modal. If G01, G02, or G03 modes are active, they are temporarily canceled for the return from home moves.

Only the axes specified in the G29 block are moved. For example:

N1 G28 X5.0 Z1.0;	(X and Z axes are moved to home after moving to X=5.0 Z=1.0)
N2 G29 X3.;	(X moves to X=5.0 then to X=3.0 --- Z does not move)


Example 13.7 Automatic Return From Machine Home

```

N00010 X100.Z50.;
N00020 Z150.;
N00030 G28X150.Z180.;
N00040 G29X200.Z100.;

```

Figure 13.8
Automatic Return From Machine Home, Results of Example 13.7



Important: When a G29 is executed, tool offsets and/or cutter compensation are deactivated on the way to the intermediate point, and they are reactivated when the axis moves from the intermediate point back to the point indicated in the G29 block.

Machine Home Return Check (G27)

A G27 causes the control to move the axes at rapid directly to the machine home position. Only the axes included in the G27 block are moved.

```
G27 X__ Z__;
```

The value entered with the axis name in the G27 block must be the machine home coordinate for that axis. If it is not, no axis motion takes place and the control issues the error message:

“INVALID ENDPOINT IN G27 BLOCK”

Aside from this endpoint check, the only difference between a G27 block and a G00 block requesting a move to the machine home coordinates is that the G27 is not modal. If G01, G02, or G03 modes were active before the G27 was executed, they are reactivated immediately after the G27 block is completed.

G27 block commands are usually given after tool offset modes have been cancelled.

If an attempt is made to execute a G27 before the axes have been homed, the control goes to cycle stop and displays this error message:

“MACHINE HOME REQUIRED OR G28”

Move to Alternate Home (G30)

The G30 command is similar to the G28 command. The main difference is the axis or axes move to an alternate home position instead of machine home. Any axis programmed in the G30 block must have been homed prior to G30 execution.

The alternate home positions are defined for each axis in AMP by your system installer.

To use the G30 command follow this format:

```
G30 X__ Z__;  
      or          (second alternate home position)  
G30 P2 X__ Z__;
```

The axis words in the above block establish the intermediate point in the same manner as the G28 code described on page 13-12. Axes move to the intermediate point defined in the G30 block prior to moving to the alternate home position. This intermediate point is the same intermediate point as the one discussed with the G28 code. When intermediate values are programmed in a G28 block, they replace G30 intermediate point values and visa-versa. This intermediate point is used by the G29 automatic return code.

Only those axes included in the G30 block are sent to the alternate home position.

A typical application for the G30 command would be if the automatic tool changer were located at a position other than machine home.

If an axis included in the G30 block has not been homed, block execution stops and this error message appears:

“MACHINE HOME REQUIRED OR G28”

Important: When the control executes a G28 or G30 block, it temporarily removes any tool offsets and cutter compensation during the axis move to the intermediate point. The offsets and/or cutter compensation are automatically re-activated during the first block containing axis motion following the G28 or G30, unless that block is a G29 block. If a G29 follows, the offsets and/or cutter compensation remain deactivated on the way to the intermediate point and are re-activated when the axis moves from the intermediate point back to the point indicated in the G29 block.

Dwell (G04)

The G04 command delays the execution of the next data block. Dwell length is specified in either of two types.

- Seconds
- Number of spindle revolutions

The type used is normally dependant on the feedrate mode (G94 or G95) active at the time. The type can also be permanently fixed to “seconds” regardless of G94 or G95 mode, by setting the proper AMP parameter. Dwell is not possible in the G93 inverse time feed mode.

Dwell - Seconds

In the G94 mode (feed per minute) G04 suspends execution of the commands in the next block for a programmed length of time in seconds.

```
G94G04 P__; X__; U__;
```

Specify the required dwell time by either a P-, X-, or U-word in units of seconds. It does not matter which of these three words you use, as long as only one appears in the same block. The allowable dwell time is 0.001 - 99999.999 seconds.

When you program a dwell in seconds your system installer has the option of writing logic to allow a portion of the dwell to be skipped. If this feature is used, when the appropriate signal is sent to logic (from a switch or other device) the control automatically skips any portion of the dwell that has not been executed and proceeds to the next block in the program. The axes positions when the skip signal is sent to logic is recorded and stored as system parameters #5071 - #5076. See specifics on the G31 skip cycles for details.

Dwell - Number of Spindle Revolutions

In the G95 mode (feed per revolution), G04 suspends execution of commands in the next block for the time it takes the controlling spindle to turn a designated number of revolutions.

G95G04 P__; X__; U__;

Specify the required dwell length by either a P-, X-, or U-word in units of spindle revolutions. It does not matter which of these three words you use, as long as only one appears in the same block. The allowable range is 0.001 - 99999.999 revolutions.

Mirror Image (G50.1, G51.1)

There are two types of mirroring. They are:

Mirror image:	Activate through:
programmable	programming a G50.1 and G51.1
manual	logic

Programmable Mirror Image (G50.1, G51.1)

Use the programmable mirror image feature to mirror (duplicate yet reversed) axis motion commands about some defined plane.

Activate this feature using the G51.1 code. Cancel it using the G50.1 code. Mirroring takes place about the axis position specified in the G51.1 code.

The format for the G51.1 code is:

G51.1X__ Z__ ;

The axis motion commands in any following blocks are executed with the motion direction reversed (including incremental moves) as if a mirror were placed on the designated point parallel with the axis. The G51.1 code is modal and remains in effect until cancelled by a G50.1 command.

Use the axis word programmed with the G51.1 command to define the mirroring location. The defined location intercepts the programmed axis at the programmed position. If only one axis is programmed, the mirroring plane is perpendicular to that axis. If more than one axis is programmed, the mirror plane passes through these points.

Important: The control mirrors only those axes that are programmed out in the G51.1 block. Axes not programmed in the G51.1 block execute normally.

A G50.1 block cancels the mirror image function.


G50.1X__ Z__ ;

The control only cancels the mirror feature for those axes that are programmed in the G50.1 block. Axes not programmed in the G50.1 block remain mirrored. There is no significance to the values programmed with the axis words in a G50.1 block. Axis values might not be required, depending on how the way AMP was configured by your system installer. In either case, the control ignores these values.

Example 13.8
Programmable Mirror Image

Main Program	Comment
(Mirror);	comment block, main program
G00G90;	rapid positioning, absolute mode
M98P8500;	call subprogram 8500
G51.1Z75.;	mirror active on X
M98P8500;	call subprogram 8500
G51.1X75.;	mirror active on Z (and X)
M98P8500;	call subprogram 8500
G50.1Z0;	cancel mirror on Z (active on X only)
M98P8500;	call subprogram 8500
G50.1X0;	cancel mirror on X (no mirroring)
M30;	
Subprogram	Comment
O8500;	program number
G00G90Z60.X90.;	rapid to start point
G01X120.F.1;	move 1
G03Z30.X90.R30;	move 2
G01Z60.;	move 3
M99;	return from subprogram

Figure 13.9
Programmable Mirror Image, Results of Example 13.8



When the mirror image function is active on only one of a pair of axes, the control:

- executes a reverse of programmed G02/G03 arcs. G02 becomes counter-clockwise and G03 becomes clockwise
- activates a reverse of programmed G41/G42 cutter compensation. G41 becomes tool right and G42 becomes tool left

Manual Mirror Image

In addition to the programmable mirror image feature, the control can also be equipped with an optional mirror image switch, installed by your system installer that activates the manual mirror image feature.

The manual mirror image feature differs from the programmable mirror image feature. When you use manual mirror image, the location of the mirrored plane is fixed along the selected axis in the current work coordinate system. This means that the mirror plane is parallel to the selected axis. It passes through the zero point of the currently active work coordinate system.

The mirrored plane is fixed and cannot be moved from along the selected axis. This mirrored plane is the equivalent of programming a programmable mirror image and using all zero values for the axis words.

Your system installer can install a switch for each of the 4 available axes. What axes are mirrored with what switches depends on the logic program in your system. You can mirror about more than one axis using more than one manual mirror image switch at the same time or one switch can control more than one axis. Refer to documentation prepared by your system installer for details.

Important: You can use programmable mirror image at the same time as manual mirror image. The programmable mirror image is done first, followed by the manual mirror image. The same axis can be mirrored by programmable and manual mirror image at the same time.

Axis Clamp

Use this feature to disable the axis position display and allow an axis to be clamped into position. Typically an axis clamp is performed by the execution of an M-code in a part program or by a switch of some type controlled by the operator. Your system installer determines how the axis clamp feature is enabled in logic. Refer to your system installer's documentation for details.

When an axis is clamped, the control freezes the axis position displays at their position. Any drift or movement generated by some external force does not generate any corrective response from the axis servo. This prevents the servo from trying to move an axis back into position when it has been mechanically clamped so it cannot move.

Any movement of the axis when it is clamped is added to the current value of the following error. You can view this on the screen displaying following error. Refer to the Integration manual. If the following axis error exceeds its allowable maximum following error (set in AMP), an error is generated and the control goes into E-Stop.

When the axis is unclamped, the control position display is reactivated and the servo returns the axis to the necessary position for zero following error.

END OF CHAPTER

Using QuickPath Plus™

Chapter Overview

The QuickPath Plus feature offers a convenient programming method to simplify programming with the 9/PC control.

We discuss some QuickPath Plus features in this chapter. Major topics include:

Topic:	On page:
Programming	14-1
Linear QuickPath	14-2
Circular QuickPath	14-6

This method of programming can prove useful in simplifying the programming of a part directly from a part drawing.

The most significant advantage to the QuickPath Plus feature is the programmer no longer has the need to calculate the endpoint of every block or every point of intersection. QuickPath Plus determines these points from angles and lengths.

QuickPath Plus uses these addresses:

,A	Angle	This word is used to define the angle of a tool path. This manual assumes that the ,A-word is used. The angle is always measured counterclockwise from the first axis defining the currently active plane. The angle is in units of degrees.
L	Length	This word is used to define the length of a linear tool path, the direction of which is determined by the angle (,A). It is always interpreted as an incremental value.

Programming QuickPath Plus

When programming QuickPath Plus, remember:

- Any axis words that are programmed must be in the current plane, and angles are measured from the first axis defining that plane. All examples in this section assume that the ZX plane is active (angles are measured relative to the Z axis).
- QPP always uses “,A” as the angle word. When you create new programs, always program the QPP angle with ,A. Your system installer has the ability to define in AMP an additional letter that can also be used for the QPP angle. Refer to your system installer’s documentation. This additional QPP angle word is provided only for program compatibility with older systems.
- The angle word (,A) is always interpreted as an absolute angle, regardless of the current mode (G90 or G91).

- The L-word is always interpreted as an incremental distance from the current position regardless of the current mode (G90 or G91). Radius or diameter mode (G08 - G09) has no effect on the ,A- or L-word.
- If you must program more than one block to perform the QuickPath Plus operation being used, and an error is made in one of the program blocks, the control always shows the error as being in the first block of the two blocks, regardless of whether the error is in the first or the second block. If programming in **<SINGLE BLOCK>** mode, the control stops after the execution of the first block as normal.
- If you must program more than one block to perform the QuickPath Plus operation being used, a maximum of 4 non motion blocks can be programmed between these blocks. A non motion block is any block that does not generate axis motion on one of the two axis in the current plane.
- These G-codes cause a syntax error if programmed in any QuickPath Plus block:
 - All G-codes in G-code Group 0 (except G04, G09, and G60)
 - All G-codes in G-code Group 1 (except G00, G01, G02, and G03).
 - All G-codes in G-code group 4, 6, 9, 10, 11, and 16.

The G-code table in appendix C lists the G-codes and their group numbers.

- If you must program more than one block to perform a QuickPath Plus operation, it causes an error if the current plane is changed to some other parallel plane in between these blocks.
- If an angle is programmed in a circular QuickPath Plus block, an error is generated.
- If an L-word is programmed in a G13, or G13.1 block an error is generated.

Linear QuickPath Plus

One End Coordinate

Many times part drawings give a programmer only one axis dimension for a tool path and require that the other axis dimension be calculated by the angle. This QuickPath Plus feature eliminates the need for this calculation. This must be a linear block. Refer to page 14-6 for circular block.

The format for this block is:

$$,A_ \left\{ \begin{array}{c} X_ \\ Z_ \end{array} \right\} ;$$

Where :	Is :
,A Angle	This word is used to define the angle of a tool path. This manual assumes that the ,A-word is used. The angle is a positive value when measured counterclockwise from the first axis defining the currently active plane and a negative value when measured clockwise. The angle is in units of degrees.
X,Z End Point	This word is used to program one of the coordinates of the end point of a linear path. The control calculates the other end point automatically. This can be any axis word that is in the current plane.

Only one axes word from the current plane can be programmed in this block. Any axis word that is not in the current plane is executed as a normal linear move to that coordinate and combined with the QuickPath Plus generated tool path. If both axis words from the current plane are entered in the block, the angle is ignored and the control moves to the coordinate position programmed with the axis words. All examples in this section assume that the ZX plane is active.

Important: If the programmed tool path is going to be parallel to an axis in the current plane, the axis word for the end point in the block should be for the axis in the current plane that is not parallel to the tool path. This means if the value of the angle (,A-word) is 0° or 180° , the second axis in the plane must be programmed in the block. If the value of the angle is 90° or 270° , the first axis in the plane must be programmed in the block.


Example 14.1
Angle Designation:

```

N10 G01 X0.0 Z25.0 F.1.;
N20 X15. ,A90;
N30 Z5. ,A165;

```

Figure 14.1
Results of Angle Designation, Example 14.1



Important: Circular QuickPath Plus can also use an angle (,A) in a program block. This is described on page 14-6.

No End Coordinate Known (L)

This feature of QuickPath Plus allows the programmer to define a tool path using only the start point angle and length of a tool path. This must be a linear block.

The format for this block is:

```
,A__ L__;
```


Where :	Is :
,A Angle	This word is used to define the angle of a tool path. This manual assumes that the ,A-word is used. The angle is a positive value when measured counterclockwise from the first axis defining the currently active plane and a negative value when measured clockwise. The angle is in units of degrees.
L Length	This word determines the length of the tool path. It is measured from the start point to the end point of the move along a linear path. No coordinate points are necessary.

Important: If any axis word from the current plane is designated in the block, the L-word is ignored and the control calculates the end point from the angle and the axis word. If an angle (,A) or a length (L) is programmed in a block that also contains both axis words in the current plane, then QuickPath Plus is not performed and the control ignores the ,A- and the L-words in the block.

Example 14.2 Angle with Length Designation:

```
N10 G01 X0. Z25. F.1.;  
N20 ,A90 L15;  
N30 ,A165 L20.7;
```

Figure 14.2
Results of Angle With Length Designation, Example 14.2



No Intersection Known

This feature of QuickPath Plus allows the programmer to define two intersecting, consecutive, linear tool paths without knowing the point where the actual intersection takes place. Both of these blocks must be linear blocks and programmed in absolute mode. The angle of both of these lines must be known.

This is done with a sequence of two linear blocks (in the current plane) in which QPP is used to calculate the end point of the first block. The start point of the first block is the current tool position.

Important: The second block of these two blocks must be programmed in absolute mode. Any attempt to program the second block in incremental generates an error.

The format for these blocks is:

```
N1 ,A__;  
N2 ,A__Z__X__;
```

Where :	Is :
,A Angle	This word is used to define the angle of a tool path. This manual assumes that the ,A-word is used. The angle is a positive value when measured counterclockwise from the first axis defining the currently active plane and a negative value when measured clockwise. The angle is in units of degrees.
ZX End Point of second block	These represent the actual coordinate location of the end point of the second block. They must be programmed as absolute values and must be axes in the current plane.


Important: There may be up to four program blocks between the two blocks in the above format. The only requirement being that these blocks may not generate axis motion in the current plane.

Both of these blocks must be programmed in the same plane. If the current plane is changed between these two blocks execution, the control generates an error.

Example 14.3 QuickPath Plus When An Intersection is Unknown

```
N10 G01 X0. Z25. F.1;  
N20 ,A90;  
N30 ,A165 X20.Z5.;
```

Figure 14.3
Results of Unknown Intersection, Example 14.3



If the control cannot determine an intersection point for the two linear paths (for example, if the paths are parallel), an error occurs.


Circular QuickPath Plus (G13, G13.1)

The programmer uses the Circular QuickPath when a drawing does not call out the actual intersection of two consecutive tool paths and at least one of the tool paths is circular. This prevents the programmer from having to do any complex calculations to determine end points and start points when an arc is involved.

For most cases of circular QuickPath Plus there may be two possible intersection points for the two defined blocks. Define which intersection is desired using either G13 or G13.1 in the first of the two blocks.

Programming:	Defines:
G13	the first intersection that occurs when the tool path of the first block intersects with the second block
G13.1	the second intersection that occurs when the tool path of the first block intersects with the second block.

Figure 14.4
G13 vs G13.1 Intersections



When programming circular QuickPath Plus, remember:

- When there is only one intersection involved with the tool paths, you can program the G13 and G13.1 codes interchangeably. One of these G-codes must be programmed however.
- The G13 or G13.1 code must be programmed in the first of the two blocks defining the two tool paths.
- If the arc is programmed with an R-word, the two tool paths must be tangent. The sign (+ or -) of the R-word determines the arc center location as described on page 13-4.
- The angle word (,A) cannot be programmed in a circular block.
- Both absolute coordinate values in the current plane must be programmed for the second block. **Both must be programmed** regardless of whether the final coordinates change or not.

Linear to Circular blocks

When the coordinates of the intersection of a linear path into a circular path are unknown, use the following format. G13 or G13.1 must be programmed. These blocks must be programmed in absolute.

Format:


```
G13G01 ,A__ ;      or      G13G01 ,A__ ;
G02 Z__X__K__I__ ;      G02 Z__X__R__ ;
```

Important: If the second block is an arc and it is programmed by using I, and K integrand, the values programmed with I, and K are not measured from the start point of the arc as normally done. This is because the start point of the arc is normally unknown when using this format. The integrands specify the distance from the end point of the arc to the center point.

Example 14.4 Line Into Arc Without Programming Intersection

```
G00Z25.X0. ;
G01G13.1,A90 ;
G03Z7.X15.K9.21I-2. ;
```

Figure 14.5
Results Of Line into Arc Without Intersection, Example 14.4



Important: You cannot program R to specify the arc radius for linear-to-circular block combinations unless the two tool paths are tangent.

Circular to Linear blocks

When the coordinates of the intersection of a circular path into a linear path are unknown, use the following format. G13 or G13.1 must be programmed in the first of the two blocks. These blocks must be programmed in absolute.

Format:

```
G13G02I__K__ ; or G13G02R__ ;
G01,A__Z__X__ ; G01,A__Z__X__ ;
```


Important: K values are the normal integrand values when you use this format (measured from start point of arc to arc center).

Example 14.5

Arc Into Line Without Programming Intersection Point

```
G0X0Z0. ;
G13G03K4I10F.1 ;
G01,A0X10Z20 ;
```


Figure 14.6
Results of Arc Into Line Without Intersection, Example 14.5



Important: R cannot be programmed to specify the arc radius for linear to circular block combinations unless the two tool paths are tangent.

Circular to Circular blocks

When the coordinates of the point of intersection of a circular path into a circular path are unknown, use the following format. G13 or G13.1 must be programmed. If using this format, the **R-word cannot be used** to specify the radius of an arc in either of the circular blocks. These blocks must be programmed in absolute.

Format:

```
G13G02K_I_ ;
G02 Z_X_K_I_ ;
```


Important: The I, K integrand vectors are not necessarily the same values as discussed for normal circular interpolation when you use this QuickPath Plus format. The integrands of the first circular block specify the distance from the START point to the center of the circle. The integrands of the second circular block specify the distance from the END point to the center of the circle (this is the reverse of normal). At least one of these integrand words must be programmed in each of the two circular blocks.

Neither circular block can contain an angle word (,A) when you use this format.

Example 14.6
Arc Into Arc Without Programming Intersection

```
G0X0.Z0.;  
G13.G03I5F.1;  
G02X12Z5I-2.75K2;
```

Figure 14.7
Results Arc Into Arc Without Intersection, Example 14.6



END OF CHAPTER

Chamfering and Corner Radius

Chapter Overview

During cornering, the 9/PC control has the option of performing either a chamfer (a linear transition between the blocks) or a corner radius (an arc transition between blocks).

,C	Chamfer size	This word is used to define a chamfer length that connects two intersecting tool paths. This word determines the distance that the chamfer begins and ends from the tool paths intersection.
,R	Corner radius	This word is used to define the radius of an arc that is tangent to two intersecting tool paths.

This chapter describes chamfering and corner radius in detail. Major topics include:

Topic:	On page:
Chamfering	15-2
Corner radius	15-3

Both the chamfer and the corner radius features are generated between two motion blocks that must be programmed in the same plane. The motion block with the corner chamfering (,C) or the corner radius (,R) word is defined as the first cornering block. The next motion block in the cornering plane is defined as the second block.

If more than one ,C- or ,R-word is programmed in the same block, only the right-most word is used; others are ignored. The second block can also have a corner chamfering or corner rounding word in it. If it does, the second block is also used as the first block of the next corner chamfering or corner rounding.



ATTENTION: If you make a programming error of some type is made in the block defining the second tool path in the chamfer or radius blocks, the control is not able to cut the correct chamfer or radius. Instead, the first block is executed to its programmed endpoint. This can cause damage to the part or cutting tool.

There is a limit of 4 non-motion blocks allowed between the first and second motion blocks defining the corner transition. A nonmotion block is any block that does not generate axis motion in the currently active plane. The control generates an error if more than four nonmotion blocks are programmed between the cornering plane.

Use the chamfering and corner radius features are often used in conjunction with QuickPath Plus. They can be programmed in either absolute (G90) or incremental (G91) modes.

Chamfering

Program a chamfer size following the address ,C to cut a chamfer between consecutive tool paths. The chamfer word must follow a comma (,) and is programmed in the first of two paths connected by the chamfer. The value following the ,C address is the amount of tool path cut of each programmed tool path by the chamfer. The angle that the chamfer makes with the tool paths is dependant on the size of the chamfer.

Measure the chamfer size from the intersection of the two blocks.


If the block:	Then:
linear	distance programmed with the ,C-word is measured from the intersection of the two tool paths along the linear path.
circular	then the chamfer distance programmed is applied as a chord length on the arc measured from the intersection between the two blocks. This applies regardless of the combination of arcs and lines to be chamfered.

The ,C-word can be programmed any where in a block as long as no space is programmed between the comma and the chamfer distance.

Example 15.1 Basic Chamfering Using ,C

```
N10 Z25.0 X0.0 F.1.;
N20 G01X20.,C5.0;
N30 Z5.0;
```


Figure 15.1
Results of Chamfering Using ,C from Example 15.1



Example 15.2 Linear to Circular Motions with Chamfer

```
N10X0.Z0.F.1;
N20X10.Z10.,C5;
N30G02X20.Z20.R10;
```

Figure 15.2
Results of Linear to Circular Motions with Chamfer, Example 15.2



Corner Radius

Use the ,R command to program a radius between two intersecting tool paths. The R command must be programmed after a comma (.). Program the ,R followed by the radius size in the block where the first path is programmed. The control looks ahead to the block commanding the second path and automatically inserts the circular rounding block to meet that path. This inserted circular block is always tangent to both programmed tool paths. If the control cannot generate an arc that is tangent to both paths with the programmed ,R, then the control generates an error.

Block:	Description:
The first corner radius	always terminates at the point on the block where the rounding block is tangent to the first block
The rounding	terminates at the point where the generated rounding block is tangent to the second rounding block.
The second rounding	starts from the end point of the generated circular block and continues on to the programmed end point of the second block.

The R-word can be programmed any where in a block as long as no space is programmed between the ,R and the radius length.

Important: If the two motion blocks are tangent to each other, then any corner rounding commands are ignored.


Example 15.3
Programming a Radius for a Circular Path into a Linear path.

```

N10Z10X30.F.1;
N20G02X10.Z10.R10,R3;
N30Z30.X10.;

```

Figure 15.3
Results of Radius for a Circular Path into a Linear path,
Example 15.3




Example 15.4
Radius and Chamfer with QuickPath Plus

```

N10Z25.X0.F.1;
N20G01A90,C2.;
N30Z15.X20.A180,R5.;
N40X40.;
N50Z5.;

```

Figure 15.4
Results of Radius and Chamfer, Example 15.4



**Considerations with
Chamfering and Corner
Radius**

When using chamfering and corner radius, remember:

- If the control is executing in single block mode, the control enters the cycle stop state after executing the first block and the adjacent chamfer or corner radius.
- If non-motion blocks are programmed separating the two intersecting blocks for the corner radius and chamfer features, the control executes the chamfer or radius immediately after the first block. The non-motion blocks are executed after the control has executed the chamfer or radius.
- Any negative signs programmed with the ,C- or ,R-words are ignored. Use the absolute value of the word to cut the chamfer or radius. For example ,C-10 is used as ,C10.

- An error is generated if the length of a chamfer is larger than the programmed length of the first or second move, or for corner rounding if the programmed corner radius is so large that the tangent point on both of the two programmed blocks does not exist.
- An error is generated if you attempt to change planes between blocks that are chamfer or corner radius blocks.
- You must program ,C and ,R in blocks that contain axis motion in the current plane. If they are programmed in a block that does not contain axis motion in the currently active plane, the control generates an error.
- ,C and ,R cannot be programmed in a block that contains any of the following:
 - Any fixed cycle G-codes
 - Any dwell commands
 - Thread cutting blocks
 - Programmable zone G-codes
- Your system installer determines in AMP the resolution of the ,C- and ,R-words for both inch and metric programming. Refer to documentation prepared by your system installer for details.

END OF CHAPTER

Spindles

Chapter Overview


This chapter describes spindle speed control, orientation, and direction, and the virtual C axis.

Topic:	Refer to page:
Spindle Speed Control	16-1
Controlling Spindles (G12.1, G12.2)	16-8
Spindle Orientation (M19, M19.2)	16-9
Spindle Direction (M03, M04, M05)	16-11
Virtual C Axis	16-11
Synchronized Spindles	16-21

Spindle Speed Control

Relative speed of the revolving workpiece to the cutting tool tip is referred to as the cutting speed. Required cutting speeds can be attained by designating proper spindle speeds. Figure 16.1 illustrates the relationship between workpiece diameter (D), spindle speed (N) and cutting speed (V).

Figure 16.1
Relationship between Cutting Speed, Spindle Speed, and Diameter



In this case, cutting speed V is expressed with this equation:

$$V = (3.14159) (D) (N) / 1000$$

To cut a 150-mm-diameter workpiece at a cutting speed of 200 m/min, the spindle speed to provide the required cutting speed is calculated to be approximately 1325 rpm using the above equation. This means that by designating “S1325;” in a part program, cutting is conducted at a cutting speed of 200 m/min.

When cutting tapers, which have different workpiece diameters at different cutting points, spindle speeds need to vary during the cutting process to maintain proper cutting speed. To compensate for this problem, the control has a feature to allow designating the required cutting speed V , directly in a part program. With this feature, the control changes spindle speed as the diameter of the workpiece changes to maintain a fixed cutting speed. This feature is referred to as the “constant surface speed mode” or CSS.

The spindle function has two modes:

- Constant Surface Speed Mode (G96) maintains a workpiece’s speed across a tool equal to a desired cutting speed dependent on the working diameter. Refer to page 16-3.
- Constant Spindle RPM Mode (G97) maintains a constant spindle speed equal to the programmed S-word making cutting speed independent of the working diameter. Refer to page 16-7.

Spindle Speed (S-word)

Use the S-word to program the spindle speed for all configured spindles. The common S-word can be applied per spindle by associating the S-word in the same block with the spindle directional M-codes. Refer to page 16-11 for information about spindle directional M-codes. If no directional M-code is programmed in the block with the S-word, then the S-word is applied to the active controlling spindle.



ATTENTION: The displayed S-word always shows the controlling spindle’s programmed spindle speed. When the non-controlling spindles are configured, their S-word display must be handled by some other means. Refer to the system installer’s documentation for display capabilities of the active spindle speed for auxiliary spindles.

The S-word units represent revolutions per minute (RPM) in most cases. Only during CSS programming are the S-word units different. While CSS mode is active, the S-word units represent surface feet per minute. Only the controlling spindle can change its S-word mode from RPM to CSS.

Constant Surface Speed (G96)

The G96 command maintains a constant cutting speed (programmed by the S parameter) by monitoring the cutting tool's position with respect to the center line of the spindle.

In the G96 mode the S-word is used to program the cutting speed. Actual units for the S-word are surface meters per minute in metric or surface feet per minute in the inch system. To maintain a cutting speed of 200 m/min, for example, write the program as:

```
G96 S200;
```

G96 mode must also first be enabled by programming an M58 code. Refer to the notes on CSS on page 16-6 for details. The G96 code is modal and remains active until it is cancelled by the G97 code or disabled with an M59 code.

Important: When changing from G97 to G96 mode, if an S-word is specified in the G96 block, the cutting speed changes to the value indicated by the S-word. If no S-word is contained in the G96 block the control uses the current cutting speed of the tool as the CSS cutting speed. The spindle speed then changes relative to the tool position to maintain this CSS cutting speed.

Important: The system installer determines in AMP what axis is used to determine the cutting diameter. The programmer has the option of changing the diameter axis by programming a P-word when in the G96 mode. P-words range from P1 to P9. A P-word to change diameter axis may be programmed in any block where in the G96 mode as long as that block does not contain a dwell. Refer to the system installer's documentation for details on what P-word programs the axis that is perpendicular to the part diameter. Normally the P-word is not programmed for CSS. If not programmed the system installer's default axis is used. This manual assumes the X axis determines the cutting diameter.

Your system installer determines CSS axis assignment in AMP. You can change the CSS axis by programming a P-word (P0 through P9) **in the G96 block** when activating CSS.

Each P-word corresponds to a specific axis assigned to it in AMP. Any CSS axis changes made by programming a P-word in the G96 block remain in effect regardless of what mode the control is in. The default CSS axis is assigned to P0 and is active on power-up and after a control reset.

Use this equation to calculate constant surface speed:

$$N = K V / D$$


$$\text{RPM} = \text{Surface speed per minute} / (.262 \times \text{diameter})$$

Where :	Is :
N	Spindle speed (rpm)
K	Constant 318.31 ($1000/\pi$) for metric system or 3.8197 ($12/\pi$) for inch system
V	Surface speed (m/min or feet/min)
D	Cutting diameter (mm or inch)

Figure 16.2 shows how the spindle speed changes as the cutting diameter changes when:

- constant K is 318.31
- the necessary surface speed is 200 m/min
- the maximum spindle speed is 3500 rpm

Figure 16.2
Constant Surface Speed Mode (G96)



ATTENTION: During the blocks when CSS mode (G96) is active, the programmed S-word units are surface speed per minute. For systems allowing multiple spindles, when CSS is active, the S-word units for all spindles is surface speed per minute. To maintain RPM units on the non-controlling spindles, do not program them while CSS is active on the controlling spindle.

Cutting Tool Position	Cutting Diameter (mm)	Spindle Speed (rpm)
1	200	318
2	100	636
3	0	3500 *

* The calculated spindle speed would be infinite because the diameter of the workpiece at cutting position 3 is zero (0). However, since the maximum spindle speed is set in AMP, the control sets the spindle speed at this maximum value.

Important: If it is desirable to prevent the spindle speed from reaching a maximum RPM a ceiling can be placed on the spindle speed at a rate below the maximum AMP setting. For details, refer to the CSS notes on page 16-6.

Relationships between spindle speeds and cutting diameters are shown in Table 16.A for different surface speeds.

Table 16.A
Spindle RPM as related to cutting diameter and programmed CSS

	Programmed Surface Speed, Feet/min. (meters/min.)								
	100(30)	200(61)	300(91)	400(122)	500(152)	1000(305)	1500(457)	2000(610)	
1(25)	382	764	1146	1527	1910	3820	5730	7640	
2(51)	191	382	573	764	955	1910	2865	3820	
3(76)	127	254	382	509	637	1273	1910	2546	
4(102)	95	191	286	382	477	955	1432	1910	
5(127)	76	153	229	306	382	764	1146	1528	
Cutting Diameter, Inches (mm)	6(152)	64	127	191	255	382	637	955	1273
	8(203)	47	95	143	191	239	477	716	955
	10(254)	38	76	115	153	191	382	573	764
	12(305)	32	64	95	127	159	318	477	637
	14(356)	27	55	82	109	163	273	409	546
	16(406)	24	48	72	95	143	239	358	477
	18(457)	21	42	64	85	127	212	318	424
	20(508)	19	38	57	76	115	191	286	382
	25(635)	15	31	46	61	92	153	229	306
	30(762)	12	25	38	51	76	127	191	255

Notes on Constant Surface Speed

- Normally the system installer sets a maximum speed in AMP; however, the programmer has the option of lowering this maximum speed if desired. An allowable upper limit for RPM can be programmed by a G92 followed by an S value in RPM. This upper limit is valid only for the G96 mode and is ignored in G97 mode. The value for this upper limit can not exceed the value set in AMP for the maximum spindle RPM.

To enter 3500 rpm as the upper limit, program:

```
G92S3500;
```

In G96 mode, spindle speeds increase as the workpiece diameter decreases. When the spindle speed reaches the upper limit, it is held at this value even if the theoretical spindle speed exceeds that value. This maximum RPM may also be affected by the maximum gear speed set for a specific gear in AMP.

Important: The G92s command to set a new max spindle RPM in CSS may not be programmed while CSS is active.

Important: The G92, maximum spindle RPM limit for CSS, programmed in a block is applied as the CSS limit for the currently active controlling spindle (selected with the G12 code). For systems allowing multiple spindles, if the controlling spindle is changed between the G92 and CSS activation, then the required G92 limit may not be active for the proper spindle.

The G92 maximum spindle RPM is canceled only after power is shut down, a control reset is performed, or when the control goes into E-Stop. M02 or M30 cannot cancel this value. When canceled, the system installers maximum speed becomes effective again.

- Spindle speed during rapid traverse

In the G96 mode, when rapid axis feed starts, spindle speeds are controlled in one of two ways:

The spindle speed changes as X axis moves.

or

The control calculates the spindle speed attained at the end of the move and uses that spindle speed for the entire rapid move.

The system installer selects in AMP which spindle speed control type he wants.

- Activating and deactivating CSS mode with M-codes (M58/M59)

Use M58 or M59 to turn constant surface speed mode on or off.

When M59 is programmed, the control ignores G96 mode and the spindle revolves at the same speed as when this M-code is executed. When M58 is executed, the G96 mode becomes active again.

If an S-code is programmed in the same block as an M59, G96 mode is ignored and the S-code value is registered in memory as a constant surface speed S-code, but the spindle speed does not change with diameter.

When programming M58, the M59 code is cancelled and the G96 mode becomes active again. The spindle maintains the same surface speed that was in effect prior to the execution of M59 unless an S-code was specified in the M59 block.



ATTENTION: Restoring the constant surface speed mode might cause the spindle speed to change rapidly, depending on the cutting tool position.

- Displayed spindle speed during CSS

The CRT display normally shows the current spindle speed in RPM following the S-word. This is true during CSS also. The display shows the actual spindle RPM, not the surface speed.

- CSS R-word programming

The optional R-word lets you specify a surface footage value to be applied at a point other than the current axis position. The R-word defines the incremental distance from the current tool tip to the spindle centerline. The sign of the R-word defines on which side of the spindle centerline the tool tip is positioned.

The R-word is recognized only in a G96 block; its value is valid as long as CSS mode is active and may only be changed when a G96 is programmed in the block.

If you change the S-word (surface footage) while in G96 mode and if an R-value was previously programmed in a G96 block, the R-value is not cancelled.

Important: An R0 and no R-word do not mean the same thing. An R-word of zero means that the spindle centerline is the tool tip position. No R-word means to use the current position.

RPM Spindle Speed Mode (G97)

In the G97 mode, the spindle revolves at the programmed RPM regardless of the position of the cutting tool.

For example, to revolve the spindle at 500 rpm, program:

```
G97 S500 M03;
```

The G97 code is modal and remains active until it is cancelled by the G96 code.

Important: If an S-word is specified in the G97 block when you change from G96 to G97 mode, the control uses the S-word as the new RPM value. If no S-word is contained in the G97 block, the control uses the current RPM of the tool as the programmed spindle RPM. The spindle speed then remains at this constant RPM.

Controlling Spindles (G12.1, G12.2)

Use the G12 code to program the active controlling spindle for all programmed axes motions for features and modes requiring spindle operation. The G12 code is modal as only one spindle can be the controlling spindle. All other spindles are auxiliary spindles.

- G12.1 — Spindle 1 Controlling
- G12.2 — Spindle 2 Controlling

Table 16.B lists the allowed spindle capabilities.

Table 16.B
Spindle Capabilities

Control Type	Number of Spindles	Spindle Type
9/PC	2	Primary Auxiliary 2

Spindles 1 and 2 must be configured in AMP, and the associated spindle parameters must be set properly to provide for the required spindle functions.

For systems with no spindle configured, simulated spindle feedback is provided for the primary spindle. This allows all control features that require spindle feedback, i.e., IPR feedrate, threading, CSS, to simulate the feedback from a spindle even through the AMPed system configuration contained no spindle. The default is 4000 count-per-rev device.

Important: On the 9/PC control, if the auxiliary spindles are programmed but have not been configured as active through AMP, this error is given as decode errors on any blocks that contain the G12.2 code:

“SPINDLE 2 NOT CONFIGURED”

Spindle Orientation (M19, M19.2)

For each possible spindle configured, the control is equipped to perform a spindle orient operation. This operation is used to rotate the spindle to a given angle. Typically this may be used to orient the spindle for load/unload operations, to position a chuck for automatic chuck wrench operation, etc. This orient operation is not the same as using a spindle as an axis for positioning. Refer to *Virtual C Axis*, on page 16-11. An orient operation is performed separately from axis motions and cannot be interpolated with normal axis motions.

There are two types of spindle orients available. They are:

- Open-loop orient - The spindle does not use a feedback device for this type of orient. The final destination of the spindle when performing an open-loop orient is determined by logic. Typically there is some form of hardware switch used to determine the spindle is at the proper position. When the open-loop orient is performed the spindle is turned at an AMP-defined RPM and in an AMP-defined direction.
- Closed-loop orient - The spindle must be equipped with a feedback device. The final destination of the spindle when performing a closed-loop orient may be determined in AMP, or entered in a program block requesting an orient. When the closed-loop orient is performed, the spindle is positioned at an AMP-defined RPM.

If the spindle is:	the orient will:
turning	complete in the same direction as the spindle is currently revolving. If the spindle is turning faster than the orient speed defined in AMP, it first slows to that orient speed before performing the orient.
not turning	be performed in whichever direction that results in the spindle reaching the required position by using the shortest angular distance.

Important: A spindle orient is also sometimes automatically requested by the control when performing some of the drilling cycles described in chapter 25. This drilling cycle orient orients to either the AMP-defined position if using a closed-loop orient type or to the position defined as the open-loop orient position.

Important: In systems allowing multiple spindles, only one M19 code can be in a block. If two M19 codes appear in one block, e.g., M19.2 M19, this error message appears, "ONLY ONE M19 ALLOWED PER BLOCK."

Refer to your system installer's documentation to determine which orient your system is equipped to perform. This manual assumes that a closed-loop type orient is available. If an open-loop orient is used, refer to the system installer's documentation for details on its operation, as it is highly logic dependant.

Both open- and closed-loop spindle orienters can be requested either by programming the appropriate spindle orient code (M19, M19.2) in a program block, or by requesting one through logic. If closed-loop orient is requested through logic, the orient angle is fixed at the default orient angle preset by the system installer in AMP.

If a closed-loop orient is requested by programming the appropriate spindle orient code (M19, M19.2), the option exists to orient the spindle to the AMP-defined orient position or to a position programmed with an S parameter in the M19 block. The S parameter defines an angle at which the spindle is positioned relative to an angle of zero that is fixed for a specific machine. Refer to the documentation prepared by the system installer. This S parameter always programs an absolute angular position. The angle programmed is not affected by incremental or absolute programming mode (if open-loop orient is being used, the value programmed with the S parameter is ignored).

The M19 code is modal. However, each time it is necessary to orient to a specific angle, an M19 with an S-word must be programmed. Programming an S-word alone replaces the current modal spindle speed used later when the M19 mode is canceled. Cancel the M19 spindle orient by programming one of the other spindle mode M-codes.

To cancel spindle orient:	Program:	Meaning:
Spindle 1 code M19	M03 M04 M05	Spindle 1 clockwise Spindle 1 counterclockwise Spindle 1 stop
Spindle 2 code M19.2	M03.2 M04.2 M05.2	Spindle 2 clockwise Spindle 2 counterclockwise Spindle 2 stop

Spindle Direction (M03, M04, M05)

Use the spindle directional M-codes to program each configured spindle program controlled spindle rotation.

Table 16.C lists the spindle direction codes.

Table 16.C
Spindle Directional Codes

Spindle Type	Directional Code	This means:
Primary	M03 M04 M05	Spindle 1 clockwise Spindle 1 counterclockwise Spindle stop
Spindle 2	M03.2 M04.2 M05.2	Spindle 2 clockwise Spindle 2 counterclockwise Spindle 2 stop

Each spindle can have independent rotational control, and the rotational speed is programmed by using the S-word. If a directional spindle code is programmed in the same block as the S-word, then that S-word is applied to each of the block's associated spindles.

Example 16.1 Spindle Synchronization with 2 Spindles Configured in AMP

N0001 M05	Spindle 1 stop
N0002 M05.2	Spindle 2 stop
N0003 M03 M04.2 S150	Spindle 1 clockwise 150 rpm Spindle 2 counterclockwise 150 rpm
N0004 M03.2 S10	Spindle 2 clockwise 10 rpm

Important: On the 9/PC control, if the auxiliary spindle directional M-codes are programmed but the auxiliary spindles have not been configured as active through AMP, this error is given as decode error on any blocks that have directional M-codes of the associated spindle programmed:

“SPINDLE 2 NOT CONFIGURED”

Virtual C Axis

The Virtual C Axis feature allows the control to interpolate a rotary axis (typically the lathe spindle) with the machine axes. This allows for circular machining along the circumference or across the face of a workpiece while it is rotated, as shown in Figure 16.3 and Figure 16.5.

If the spindle is used as the virtual C axis, it may require that an alternate motor and/or higher precision feedback device be used. The alternate motor would be configured as a closed-loop rotary axis. Refer to the documentation provided by your system installer.

This description assumes that the lathe spindle has been configured in AMP to be used as the virtual C axis.

We refer to this axis:	As:
the virtual C axis	C
the axis along the spindle center line (also called the park axis)	Z
the axis perpendicular to the spindle center line (also called the feed axis)	X

Refer to the literature provided by your system installer for the axis names used by your machine.

To function as a virtual C axis, the lathe spindle must have a precision encoder that provides position data to the control. There can be only one encoder marker per revolution of the spindle. When the virtual C axis feature is activated, the control switches spindle operation from an open-loop spindle to a closed-loop virtual C positioning axis.



ATTENTION: It is the responsibility of the operator (or the control's logic program) to change spindle gears as required to attain one revolution of the encoder per revolution of the spindle prior to execution of the G16.1.

While the virtual C axis feature is active, programmed spindle commands (M03, M04, M05, or M19) do not affect the operation of the lathe spindle. It is up to the control's logic program to interpret these part program commands and take appropriate action, such as directing them to a "live tool" spindle.

Typically a live tool powered by an external drive and mounted on the X and Z axes is used to machine contours on the workpiece during virtual C operation. Operation of the live tool is controlled through logic.

The control uses the BR_VIRTC flag to indicate to logic that the virtual C axis feature is active. Refer to the documentation prepared by your system installer for details.

Virtual C Programming Restrictions

When the virtual C axis feature is enabled, these programming restrictions apply:

- The control must be in feedrate per minute mode (G94), not feedrate per revolution mode, before beginning virtual C programming


- Work coordinate system offsets (G52, G54-G59, and G92) for the park and feed axes (Z and X) are temporarily cancelled when in G16.1 mode. Offsets for other axes are not affected
- Tool offsets and cutter compensation/TTRC offsets are allowed during Virtual C programming
- Cutter compensation ignores the tool orientation and treats the programmed tool as a mill tool (orientation 0)
- Activation of offsets through logic is disabled
- Jog on the fly is disabled
- Integrand circle/arc programming is not permitted during G02/G03 blocks. Only direct radius (R) programming is allowed

Only the primary spindle (selected with G12.1) can be used in coordination with virtual C. On systems allowing auxiliary spindles, if the auxiliary spindle is the controlling spindle when virtual C is activated, this error message appears, "ILLEGAL CODE DURING VIRTUAL C."

Virtual C Axis, Cylindrical Interpolation

Cylindrical interpolation coordinates the motion of the virtual C axis with that of the linear machine axes to machine contours on the side of a cylindrical workpiece as shown in Figure 16.3. Virtual C cylindrical interpolation mode is turned on using a G16.1 block and turned off with a G15 block (or a G16.2 block requesting end face milling). A G15 block can not contain any axis words.

Figure 16.3
Virtual C Axis Cylindrical Interpolation



The following are not allowed during cylindrical interpolation:

- automatic motion to and from home G27, G28, G29, or G30
- work coordinate changes and shifts G53, G54-G59, G59.1, G59.2, G59.3, G50/G92, G52, G92.1
- all turning and threading cycles
- all drilling, tapping, and boring cycles

Cylindrical Interpolation Block Format

The format for the G16.1 block (virtual C axis cylindrical interpolation) is:

```
G16.1 R__ F__; C__ Z__;
```

Where:	Is:
R	the radius at which the feed axis (typically the X axis) is positioned at the start of cylindrical interpolation. Can be used to alter the feed axis depth if programmed in a G16.1 block <u>during</u> cylindrical interpolation.
C	the angular coordinate (if in G90 absolute mode) or the angular distance (if in G91 incremental mode) to which the virtual C axis is to move.
Z	the coordinate (if in G90 absolute mode) or the linear distance (if in G91 incremental mode) to which the Z axis is to move.
F	the feedrate to be used by the feed axis to position to radius R, and used by the Z axis when commanded to move while G16.1 is active. It also controls the virtual C axis speed as though it were a rotary axis. Refer to chapter 17.

These parameters and their application are described in detail in the paragraphs that follow:

The valued entered for the R parameter should place the tool at the radius of the desired cutting depth into the part.

Important: R must be programmed in the initial G16.1 block. If R is not programmed in the initial G16.1 block, the error message “CYLINDER RADIUS IS ZERO” appears. At power turn-on, program-end (M02, M30, or M99) or control reset, the virtual C axis feature is turned off and the R value is set to zero. It must then be re-entered in the next G16.1 block.

The radius specified by the R parameter is modal and does not need to be included in subsequent cylindrical interpolation blocks. Programming a G16.1 block with a different R value modifies the feed depth to the new radius. Feed depths cannot be changed using the X parameter when G16.1 is active. Programming an X generates the error message “FEED AXIS MOTION NOT ALLOWED.”

Figure 16.3 illustrates the tool position if the AMP parameter **Feed Axis Park Location** is selected as “Farthest from Machine Zero.” If “Nearest to Machine Zero” were selected, then the tool would be positioned for cutting into the part from the negative side of the X axis. Refer to the information provided by your system installer.

A C or Z axis position may be programmed with the R parameter in the initial G16.1 block. However, once G16.1 mode is established, only the Z parameter can be programmed in the same block as the R parameter. When it is, the Z axis motion executes first followed by feed axis motion to radius R.

If a C axis position is programmed, the C axis rotates to the specified angle. If the C and Z axes are programmed together in the same block, then a vector motion results around the circumference of the part.

If G02 or G03 circular interpolation is made active while in G16.1 cylindrical interpolation mode, a circular cut can be made around the circumference of the part (such as the shape cut in Figure 16.3). This is accomplished by programming the C and Z axis endpoints along with the desired circle radius R as described in chapter 14. The R parameter now defines the radius of the circular path to be cut, not the feed axis position.

Important: When programming circular interpolation in G16.1 mode, only radius programming (using R) may be used. Integrand programming (using I, K) is not allowed and generates the error message “CIRCLE PROGRAMMING ERROR.” Refer to chapter 13.

Important: C axis motion is programmed as an angular value. When programming circular interpolation in G16.1 mode, this angular value has to be derived from a C axis arc length (based on the cutting radius). Refer to Example 16.2.

To perform G02/G03 circular interpolation while in G16.1 mode, the linear axis (Z) and the virtual C axis (C) must move to the endpoint of the arc of radius R made on the side of the cylinder.

In incremental mode (G91) the C axis arc length along with the programmed Z move length, must position the C and Z axes at a legal endpoint for the arc radius defined by the R value in the G02/G03 block.

In absolute mode (G90) the coordinate defined by the C axis arc along with the coordinate programmed for the Z axis, must position the C and Z axes at a legal endpoint for the arc radius defined by the R value in the G02/G03 block.

When cylindrical interpolation is activated, the circle plane is set to ZC. The C and Z axes become the two axes of the circle plane and remain so, as long as the G16.1 mode is active. If the active plane is changed, the change does not become effective until the G16.1 mode is cancelled, and is superseded if the G16.1 plane is reactivated.

Cylindrical Interpolation Operation

When virtual C axis cylindrical interpolation is activated, the control terminates any spindle operations and defines the current spindle position as zero degrees. If the AMP parameter **Automatic Home on Virtual C Entry** is set to “YES,” a homing operation was performed prior to this. The control then switches spindle operation from an open-loop spindle to a closed-loop positioning axis.

Important: If orientation of the part is important, or if you expect to leave G16.1 mode and then return and continue work on a specific area of the part, the primary spindle should be homed each time you enter the G16.1 mode. If the AMP parameter **Automatic Home on Virtual C Entry** is set to “NO” (refer to the documentation provided by your system installer), you need to home the virtual C axis, typically by programming a M19S0.

The control positions the tool on the cylindrical work surface with two distinct moves. In the first move, all programmed axis moves in the initial G16.1 block (including the C axis) are executed. This move takes place at the rapid feedrate for the axes.

In the second move, the feed axis (X) is moved at the active cutting feedrate to the radius specified by R.

The blocks following the G16.1 block determine the contour to be machined on the side of the cylindrical workpiece. The moves of the virtual C axis and the machine axes are interpolated to produce the programmed contours.

The following example makes a circumferential cut, followed by a 90 degree arc, followed by a linear cut, all made into the side of a cylindrical workpiece. The C axis angle in the G03 block of this program was derived from the equation that follows this example. Figure 16.4 illustrates the results.

Example 16.2 Virtual C Axis, Cylindrical Interpolation

```

N1 G91 M05;
N2 G16.1;
N3 C10. Z-40.;
N4 C60.;
N5 G03 Z8. C18.335 R8.;
N6 Z20.;
N7 G16.1 R30.;
N8 G15;


```

The angle for the C move in the G03 block above was determined by using this equation, with $L = 8$ and $R = 25$.

$$\theta = \frac{360 (L)}{2 \pi (R)}$$

Where :	Is :
θ	The angle to be programmed for the virtual C axis.
L	The length of the arc along the circumference of the cylinder, as required to define a legal endpoint for the arc programmed in the G02/G03 block.
R	The radius at which the feed axis is positioned. This is the active R value programmed in the initial G16.1 block, <u>not</u> the R radius for the G02/G03 block.


Figure 16.4
Results of Cylindrical Interpolation, Example 16.2



Virtual C Axis, End Face Milling

End face milling coordinates the motion of the virtual C axis with that of the linear machine axes to machine contours on the end face of a workpiece as shown in Figure 16.5. Virtual C axis end face milling is turned on using a G16.2 block and turned off with a G15 block (or a G16.1 block requesting cylindrical interpolation). A G15 block can not contain any axis words.

Figure 16.5
Virtual C Axis End Face Milling



The following are not allowed during end face milling:

- Automatic motion to and from home G27, G28, G29, or G30
- Work coordinate changes and shifts G53, G54-G59, G59.1, G59.2, G59.3, G50/G92, G52, G92.1
- All Turning and Threading cycles
- All Drilling, Tapping, and Boring cycles

For ease of programming and to help the programmer visualize contours, a simulated axis (end face milling axis) perpendicular to the X axis is utilized with this feature. This axis name, its incremental axis name (if Lathe Type A), and its integrand name are defined in AMP. This description assumes that those names are Y, V, and J respectively. Refer to the literature provided by your system installer for specific information.

End Face Milling Block Format

The block used to activate virtual C axis end face milling has this format:

```
G16.2 X__ Y__ Z__ R__ F__
```

Where :	Is :
X	The coordinate (if in G90 absolute mode) or the linear distance (if in G91 incremental mode) to which the X axis is to move. Be aware that this value is affected by diameter (G08) or radius (G07) programming mode.
Y	The coordinate (if in G90 absolute mode) or the linear distance (if in G91 incremental mode) to which the simulated Y axis is to move.
Z	The coordinate (if in G90 absolute mode) or the linear distance (if in G91 incremental mode) to which the Z axis is to move. This axis determines depth of cut in End Face Milling.
R	The radius of the arc to be cut in the face of the part. This parameter can be used only if G02 or G03 circular interpolation has been activated, and must be programmed with the correct X and Y coordinates. Refer to chapter 13.
F	The feedrate to be used by the X, Y, and Z axes when commanded to move while G16.2 is active.

These parameters and their application are described in detail in the paragraphs that follow:

Any axis motions except for C axis motions can be programmed in the G16.2 block. The control generates C axis motion in response to programmed requests for simulated Y axis motion. This allows the programmer to enter his contour moves as though he were working with an XY plane, with cutting depth controlled by the Z axis.

If G02 or G03 circular interpolation is made active while in G16.2 end face milling mode, circular cuts can be made in the face of the part (for example, the corners could be rounded in the contour illustrated in Figure 16.5). This is accomplished by programming the X and Y axis endpoints along with the desired circle radius R as described in chapter 13. The R parameter used here defines the radius of the circular path to be cut.

Important: When programming circular interpolation in G16.2 mode, only radius programming (using R) may be used. Integrand programming (using I, J) is not allowed and generates the error message “CIRCLE PROGRAMMING ERROR.”

Important: When programming circular interpolation in incremental mode (G91), the programmed X move length along with the programmed Y move length, must position the X and Y axes at a legal endpoint for the circular radius defined by the R value in the G02/G03 block. In absolute mode (G90) the coordinate programmed for the X axis along with the coordinate programmed for the Y axis, must position the X and Y axes at a legal endpoint for the circular radius defined by the R value in the G02/G03 block.

When end face milling is activated, the circle plane is set to XY. The X axis becomes the primary axis of the circle plane and remains so, as long as the G16.2 mode is active. If the active plane is changed, the change does not become effective until the G16.2 mode is cancelled, and is superseded if the G16.2 plane is reactivated.

End Face Milling Operation

When virtual C axis end face milling is activated, the control terminates any primary spindle operations and defines the current primary spindle position as zero degrees. If the AMP parameter **Automatic Home on Virtual C Entry** is set to “YES,” a homing operation was performed prior to this. The control then switches primary spindle operation from an open-loop spindle to a closed-loop positioning axis.

Important: If orientation of the part is important, or if you expect to leave G16.2 mode and then return and continue work on a specific area of the part, the primary spindle should be homed each time you enter the G16.2 mode. If the AMP parameter **Automatic Home on Virtual C Entry** is set to “NO” (refer to the documentation provided by your system installer), you need to home the virtual C axis, typically by programming a M19S0.

The blocks following the G16.2 block determine the contour to be machined on the end face of the cylindrical workpiece. The moves of the virtual C axis and the machine axes are interpolated to provide the programmed contours on the workpiece face.

Example 16.3 generates a square cut in the face of a part similar to that show in Figure 16.5.

Example 16.3
Virtual C Axis, End Face Milling

```
N1 G91 M05 X-20.;
N2 G16.2 Z-5.;
N3 Y10.;
N4 X-20.;
N5 Y-20.;
N6 X20.;
N7 Y-10.;
N8 Z5.;
N9 G15;
```

Synchronized Spindles

Use this feature to synchronize the position and/or velocity between two spindles with feedback using your 9/PC control.

Two types of synchronization are available:

- Velocity — synchronizes only the speed between two spindles
- Velocity and Position — synchronizes the speed and angular position between two spindles

Prior to activation, you are responsible for selecting the proper gear ranges and ratios. The gear ratio between the feedback device and the spindle must be 1:1. Any other type, including nonunit ratios, will not allow repeatability of the orientation of your spindle and may cause positioning offset inaccuracies.

Spindle Configuration

Your system installer selects two spindles to make up the synchronization pair, which consists of the controlling and follower spindles. During synchronization, the controlling spindle initiates spindle motion while the follower spindle attempts to synchronize with it. Your system installer determines the configuration of these spindles. Refer to your system installer's documentation for more information about spindle configuration.

Gear ranges are set separately for each spindle. If the controlling spindle speed is outside of the current follower spindle gear range when a seek is attempted, the controlling spindle will ramp to within the follower's limits set in AMP.

Selecting the Controlling Spindle

The synchronized spindle's controlling spindle, which is determined by your system installer, must be programmed as the part program's controlling spindle in your part program prior to synchronization. Use one of the G12 codes (G12.1, and G12.2) to designate the active controlling spindle for spindle synchronization. Refer to page 16-8 for more information about the G12 codes and your system installer's documentation to identify your controlling spindle.

Important: Typically, the programmed speed of the controlling spindle dictates the speed of the follower spindle. For more information about valid gear ranges, refer to page 16-26.

Using the Spindle Synchronization Feature

Use these three G-codes to manipulate the spindle synchronization feature:

- Set spindle positional synchronization (G46)—sets the follower spindle speed/direction and relative position offset to match the controlling spindle.
- Set active spindle speed synchronization (G46.1)—sets the follower spindle speed/direction to match the controlling spindle.
- Deactive spindle synchronization (G45)—shuts off synchronization while maintaining the controlling and follower spindles' current speed and direction.

Activate Spindle Positional Synchronization (G46)

Use the “Activate Spindle Positional Synchronization” to synchronize speed and position. The position is based on a programmed S-word (degrees). If you do not program an S-word in the G46 block, it will automatically go to the relative positional offset, set by your system installer. Refer to your system installer's documentation for more information.

During a G46, the spindles attempt to match speeds. Once the speeds are matched, the spindles attempt to synchronize their relative positional offset. Once synchronization is achieved, the active spindle speed and mode (M03, M04, M05, or M19) programmed for the follower spindle is replaced by the current controlling spindle speed and mode.

Important: Changes in spindle speeds that would normally occur as a result of CSS or other programmed changes to spindle speeds, directions, and spindle speed override will not occur until synchronization is achieved.

The format for the G46 block is as follows:

```
G46 S__;
```

Where:	Defines:
S	the angular offset between two spindles (degrees)

Important: No other program letters are allowed in the G46 block except auxiliary letters and system installer M-codes.


The following example assumes that the controlling and follower spindles were defined as spindle 2 and spindle 1, respectively, by your system installer.

**Example 16.4
Spindle Synchronization**

M03 S200;	Spindle 1 clockwise 200 rpm
M04.2 S400;	Spindle 2 counterclockwise at 400 rpm
G12.2;	Spindle 2 as controlling spindle
G46 S90;	Spindle 1 changes direction and accelerates to spindle 2's speed; spindle 1 synchronizes angular position with spindle 2 (offset 90 degrees)

Example 16.5 shows two spindles attempting synchronization to transfer a part. The following steps describe the synchronization process in this example.

1. The follower spindle, 2, attempts to match its velocity with the controlling spindle (1).
2. Once velocities are matched, spindle 2 reaches its relative position, which is offset from the position of spindle 1.
3. When synchronization is achieved, the spindle axis advances to engage the part.
4. Spindle 2 clamps the part held by spindle 1.
5. Spindle 1 unclamps, transferring the part to spindle 2.
6. The spindles move apart and synchronization is disabled (G45).

Example 16.5**Activate Spindle Speed Synchronization (G46.1)**

Use the “Activate Spindle Speed Synchronization” to synchronize speed and direction only. Using G46.1 does not guarantee a consistent positional offset between the two spindles. During a G46.1, the follower spindle attempts to synchronize speeds with the controlling spindle. Once synchronization is achieved, the current spindle speed and mode (M03, M04, M05, or M19) programmed for the follower spindle is replaced by the current controlling spindle speed and mode programmed. The original follower spindle speed and direction is not retained.

Important: Changes that occur as a result of CSS or other programmed changes to spindle speeds, directions, and spindle speed override will not occur until synchronization is achieved.

The format for the G46.1 cycle is as follows:

```
G46.1;
```

Important: No other program letters are allowed in the G46.1 block except auxiliary letters and system installer M-codes.

Deactivate Spindle Synchronization (G45)

Use G45 to deactivate the synchronized spindle feature. When synchronization is deactivated, the follower spindle will remain in the same state (M03, M04, M05, or M19) and at the last programmed speed for controlling spindle until you change the program settings or if your system installer writes logic to recommend the spindle.

The format for the G45 cycle is as follows:

G45 ;

Important: No other program letters are allowed in the G45 block except auxiliary letters and system installer M-codes.

Special Considerations for Spindle Synchronization

When using the synchronized spindle feature, remember:

- you cannot retrace through a synchronization block (G45, G46, or G46.1). However, you can retrace through blocks where synchronization was already active.
- gear changes are not allowed during synchronization. If spindle speeds exceed the gear range of either spindle, the spindles will be limited to the more restrictive spindle's values.
- due to the servo switch from open- to closed-loop during synchronization, a one-iteration hesitation in the spindles may be seen when this switch occurs. This small deceleration may be more apparent in systems with a smaller spindle motor or if synchronization is done at higher speeds.
- Program Restart, Mid-Start, and Interrupt Macros will be allowed. If synchronization is disabled during an interrupt macro, it will resynchronize upon return, in the event that all of the condition checks listed in this section allow it to, otherwise a decode error will result. Mid-Start and restart must also pass all conditions described in this section.
- you are responsible for selecting proper gear ranges prior to activating synchronization.

The following features cannot be used while synchronization is active:

- solid-tapping
- Virtual C programming

The following features cannot be used while synchronization is ramping:

- deep-hole peck drilling
- threading

Important: Virtual C and threading are available on synchronized spindles once synchronization is achieved.

- When synchronization is active, any part program commands destined for the follower spindle (i.e., M03, M03.2, G12.1, and G12.2) will cause an error.

Important: Typically, the programmed speed of the controlling spindle dictates the speed of the follower spindle. In the event that the programmed speed exceeds the maximum or drops below the minimum allowable values for the synchronized pair, the spindle speed will be restricted to those allowable values, as shown on page 16-26.

- the example below shows what will happen when:
 - no overlap occurs between the controlling and follower spindles' gear ranges
 - the controlling spindle has a higher gear range than the follower spindle
 - the controlling spindle has a lower gear range than the follower spindle

Example 16.6
Valid Gear Ranges for Synchronized Spindles

Controlling Spindle Gear Range (RPM)	Follower Spindle Gear Range (RPM)	Requested Spindle Speed (RPM)	Valid Programmed Spindle Speeds (RPM)	Spindles will Synchronize at (RPM):
1000 to 3000	100 to 300	1500	None	N/A
1000 to 3000	800 to 1500	1800	1000 to 1500	1500
1000 to 3000	1800 to 3200	1500	1800 to 3000	1800

END OF CHAPTER

Programming Feedrates

Chapter Overview

This chapter describes 9/PC control feedrates, including special AMP assigned feedrates and automatic acceleration/deceleration.

For information about:	See page:
Feedrates	17-1
Special AMP-assigned Feedrates	17-8
Automatic Acceleration/Deceleration	17-9

Feedrates

Feedrates are programmed by an F-word followed by a numeric value. You can enter feedrates in a part program block or through MDI. They become effective in the block in which they are programmed and apply to all G01, G02 and G03 axis motion. If the block requires rapid traverse motion (G00), the programmed feedrate is ignored for that block, but is stored in control memory as the active feedrate.

Feedrates are modal. They remain active in control memory unless replaced with a different feedrate programmed with an F-word.


Feedrate modes are either G95 (cutting tool distance per workpiece revolution) or G94 (cutting tool distance per minute). Table 17.A shows the possible feedrate units depending on axis type.

Table 17.A
Feedrate Units

Active G-code	Linear Axis Feed	Rotary Axis Feed
G71 and G94	millimeters/min.	degrees/min.
G71 and G95	millimeters/rev.	degrees/rev.
G70 and G94	inches/min.	degrees/min.
G70 and G95	inches/rev.	degrees/rev.

Feedrates for linear and circular interpolation are “vector” feedrates. All axes move simultaneously at independent feedrates so that the rate along the effective path is equal to the programmed feedrate. See Figure 17.1.

Figure 17.1
Programming a Tangential Feedrate



For example, if a feedrate is programmed as F100.0 millimeters per minute, and a linear move is made from X0, Z0 to X10, Z10, the feedrate along that 45 degree angular path would be 100.0 mmpm. The actual feedrate of each axis is approximately 70.7 mm per minute.

Feedrates Applied During TTRC

When the cutting tool is offset from a programmed path (as in the case of TTRC), the programmed feedrate is applied to the center of the tool radius for all linear and outside arc paths.


For these paths:	The result:
linear	is not significant because the speed of the tool tip relative to the part surface remains the same as the programmed feedrate.
outside arc	speed of the tool tip relative to the part surface is less than the programmed feedrate. This generally causes no problem and so the control does not take corrective action.
inside arc	speed of the tool tip relative to the part surface would be greater than the programmed feedrate. Since this could cause excessive tool loading and poor cutting performance, the 9/PC control automatically takes corrective action.

For **outside** arc paths, the speed of the tool tip relative to the part surface can be determined using the following formula:

$$\text{Tool tip speed} = F \times \frac{R_p}{R_c}$$

Where :	Is :
F	programmed feedrate
R _c	radius of the arc measured to the center of the tool radius
R _p	programmed radius of the arc

Figure 17.2
Inside and Outside Arc Feedrates with TTRC



For **inside** arc paths, the control automatically maintains the **programmed_feedrate at the tool tip**. The actual tool radius center feedrate reduces as needed through the arc path, and then it returns to the programmed feedrate after the arc is completed.

During inside arc paths, the control decreases the tool radius center feedrate by the ratio of R_c/R_p . If the R_c value is very small compared to R_p , as in the case of a small arc being cut with a large diameter tool, the value of R_c/R_p is nearly zero, and the tool radius center feedrate becomes excessively small.

To avoid this problem, your system installer must set a minimum feed reduction percentage (MFR) in AMP. This sets a minimum feedrate to be used whenever the value of R_c/R_p is very small. If $R_c/R_p < \text{MFR}$, the control reduces the tool radius center feedrate no more than the MFR percentage.


Feed Per Minute Mode (G94)

In the G94 mode (feed per minute), the numeric value following address F represents the distance the axis or axes move (in inches or millimeters) per minute. If the axis is a rotary axis, the F-word value represents the number of degrees the axis rotates per minute.

To program a feedrate of 55 mm of tool motion per minute program:

```
G94 F55.;
```

Figure 17.3
Feed Per Minute Mode (G94)



When changing from G95 to G94 modes, you must program a feedrate in the first G94 block.

Since the G94 code is modal, any F-word designated in any block after the G94 is considered a feed distance per minute until a G95 is executed.

Important: The controlling spindle determines which spindle per revolution value to use when calculating the feed per revolution.

Feed Per Revolution Mode (G95)

In the G95 mode (feed per revolution), the numeric value following address F represents the distance the axis or axes move (in inches or millimeters) per revolution of the spindle. If the axis is a rotary axis, the F-word value represents the number of degrees the axis rotates per revolution of the spindle.



To program a feedrate of 1.5 mm per revolution of workpiece program:

```
G95 F1.5;
```

When changing from G94 to G95 modes, you must program a feedrate in the first G95 block.

Since the G95 code is modal any F-word designated in any block after the G95 is considered a feed distance per spindle revolution until a G94 is executed.

Figure 17.4
Feed Per Revolution Mode (G95)



Rapid Feedrate

Rapid feedrate drives all active axes at a speed which creates a linear move. The control determines which axis must travel the furthest and drives that axis at its maximum feedrate assigned in AMP. Use rapid feedrate to position the tool to a specified point at a high speed. It is called during the execution of a G00 code followed by an axis motion command and in many of the canned cycles for positioning.

After the execution of a rapid move the control restores the previously commanded feedrate.

You can drive axes at their maximum allowable speeds during the jogging operations by holding down the **<TRVRS>** button while executing a jog move. (For details on jogging an axis refer to chapter 4).

Use rapid feedrate to position axes to a specified point at a high speed. It is called by executing a G00 followed by an axis motion command. It also is called automatically for some of the motions made by the fixed cycles. Refer to the fixed cycle specifications.

When you command more than one axis to move at rapid feedrate, they are driven together to produce a linear move. The control drives one of the axes at its rapid feedrate and reduces the feedrate of the others as required to make certain that all axes start and stop at the same time.

Feedrate Overrides

<FEEDRATE OVERRIDE> Switch

You can override feedrates programmed in any of the feedrate modes (G93/94/95) using the <FEEDRATE OVERRIDE> switch on the MTB panel. The <FEEDRATE OVERRIDE> switch has a range of 0-150% of the programmed feedrate, and it can alter the programmed feedrate in 10 percent increments.

The control checks whether the feedrate resulting from the <FEEDRATE OVERRIDE> switch setting exceeds the maximum cutting feedrate set in AMP. If it does, the feedrate is restricted to the AMP maximum.

An M49 (overrides disabled) causes the override amounts that are set by the switches on the MTB panel to be ignored by the control. With M49 active, the override switches for feedrate, rapid feedrate, and spindle speed are all set to 100%. They can be enabled by programming an M48 (overrides enabled). Refer to chapter 9 for details.

The feedrate override switch overrides the current axis feedrate. This may or may not be the currently programmed feedrate. In cases where Acc/Dec or the feedrate clamp features have overridden the programmed feedrate, the feedrate override switch adjusts the new Acc/Dec or clamped feedrate.

<RAPID FEEDRATE OVERRIDE>

Use <RAPID FEEDRATE OVERRIDE> on the MTB panel to override the rapid feedrate for G00 mode in four increments:

- F1 -- percent value set in AMP by your system installer
- 25%
- 50%
- 100%.

Important: Normally this override is not active for any dry run motions (refer to chapter 7) unless otherwise specified in logic by your system installer.

Important: This override is also effective for jog moves that use the rapid feedrate (refer to jogging using the <TRVRS> button in chapter 4).

Feedrate override switches disable

An M49 forces the override amounts that are set with the MTB panel to be ignored by the control. With M49 active, the overrides for feedrate, rapid feedrate, and spindle speed are all set to 100 percent. You can enable them by programming an M48 (overrides enabled). Refer to chapter 9 for details.


Feedhold

Your system installer can write logic to allow the activation of a feedhold state through the use of a button or switch. When activated, the control decelerates and holds the current feedrate for all axes to zero until the feedhold state is deactivated. For details on using feedhold, refer to documentation provided by your system installer.

Feedrate Limits (Clamp)

The maximum allowable speed for each axis is set in AMP. If any axis feedrate exceeds the maximum allowable speed for that axis the control automatically adjusts the feedrate to a value that does not cause axis speed to exceed its set limit.

Figure 17.5
Feedrate Clamp



In Figure 17.5, when the commanded feedrate is F_p it causes the Z-axis feedrate to exceed the maximum feedrate (F_{ZMAX}). The control then adjusts the feedrate for both axes so that F becomes the actual feedrate.

When the feedrate is “clamped” to a value below the programmed feedrate the control displays a flashing C next to the current axes feedrate. The displayed axis feedrate is the actual feedrate of the tool, not necessarily the programmed feedrate.

Special AMP-assigned Feedrates

You can select special feedrates that are assigned in AMP. This section covers the feedrates assigned in AMP for the external feedrate switch.

External Deceleration Feedrate Switch

Your system installer can install an optional external deceleration switch. Typically this is a mechanical switch mounted on the machine axes inside the hardware overtravel switches. Refer to documentation prepared by your system installer for details on the application and location of this switch.

When you activate this feature, any axis moves that are to take place at a cutting feedrate (G01, G02, G03, etc.) use a special feedrate assigned in AMP. Any axis moves that are to take place at a rapid feedrate (G00, etc.) also uses a special feedrate assigned in AMP. These feedrates are independent of each other and typically have different values. These feedrate changes take place immediately when the feature becomes active, even if this is in the middle of block execution.

Important: The feedrate set for the external deceleration feature for cutting moves cannot exceed the maximum cutting feedrate.

If you use this feature simultaneously with the Dry Run feature, the feedrates that are assigned to the External deceleration feature are used. The feedrates for this feature are not related to the Dry Run feedrates, although the operation of this feature is similar to Dry Run.

This feedrate is unaffected by the <FEEDRATE OVERRIDE> switch and the <RAPID FEEDRATE OVERRIDE> settings, and it operates as if the switches are set at 100 percent. Blocks that are programmed to move at the rapid feedrate are still executed in the rapid mode.

Use this feature to protect the machine from harsh or sudden stops. If a very high feedrate is active at the time that a hardware overtravel occurs, damage to the machine can result or the machine can coast past a safe range for axis motion. If the switch is installed before the overtravel area, the feedrate of the move is reduced and the amount of coast into the overtravel area is much less.

If the current feedrate is less than the feedrate set for the external deceleration feature, it is accelerated to the external deceleration feedrate. This can cause problems with part finish or can damage the tool if this feedrate is higher than that which the part should be cut.



ATTENTION: Your system installer can write logic to allow the operator to select the external deceleration feedrate at any time. This means that during normal automatic operation, you can select external deceleration and replace all feedrates in the program with the external deceleration feedrates. This can result in damage to the machine, part, or injury to the operator.

Automatic Acceleration/Deceleration

There are three types of axis acceleration/deceleration available. They are:

- Exponential Acc/Dec
- Uniform or Linear Acc/Dec
- S-Curve Acc/Dec

These are used to produce smooth starting and stopping of the machines axes and prevent damage to the machine resulting from harsh movements.

Your system installer determines the acc/dec parameter type (exponential or linear) for some manual motion types. To determine which motion types are configurable, refer to the following table. Refer to your system installer's documentation for more information about how your system is configured.

Refer to the table below to determine the type of acceleration/deceleration performed for manual motion and programmed moves.

Refer to the table below to determine the type of acceleration/deceleration performed for manual motion and programmed moves.


Table 17.A
Acc/Dec Type Performed with Manual Motion and Programmed Moves

Motion Type	Always Uses Exponential Acc/Dec	Configurable in AMP by System Installer via Manual Acc/Dec Mode	Always Uses Linear Acc/Dec	Linear or S-Curve Acc/Dec per G-code
Homing	✓			
All programmed moves except for G00 and exact stop			✓	
Manual continuous motion		✓		
Manual incremental motion		✓		
Logic axis mover		✓		
All moves programmed in G00 (positioning) mode				✓

Exponential Acc/Dec

To begin and complete a smooth axis motion, the 9/PC control uses an exponential function curve to automatically accelerate/decelerate an axis. Your system installer sets the acceleration/deceleration time constant "T" for each axis in AMP. Figure 17.6 shows axis motion using exponential Acc/Dec.


Figure 17.6
Exponential Acceleration/Deceleration



Linear Acc/Dec

Axis motion response lag can be minimized by using Linear Acc/Dec for the commanded feedrates. The system installer sets Linear Acc/Dec values for interpolation for each axis in AMP. Figure 17.7 shows axis motion using Linear Acc/Dec.


Figure 17.7
Linear Acc/Dec



S-Curve Acc/Dec

When S-Curve Acc/Dec is enabled, the control changes the velocity profile to have an S-Curve shape during acceleration and deceleration when in Positioning or Exact Stop mode. This feature reduces the machine's axis shock and vibration for the commanded feedrates. Figure 17.8 shows axis motion using S-Curve Acc/Dec.

Figure 17.8
S-Curve Acc/Dec



Programmable Acc/Dec

Programmable Acc/Dec allows you to change the Linear Acc/Dec modes and values within an active part program via G47.x and G48.x codes.

You cannot retrace through programmable acc/dec blocks (G47.x and G48.x). However, you can retrace through blocks where programmable acc/dec was already active.

Selecting Linear Acc/Dec Modes (G47.x -- modal)

Programming a G47.x in your part program allows you to switch Linear Acc/Dec modes in nonmotion blocks. If S-Curve Acc/Dec is active, all positioning moves within fixed cycles will use this mode.

- G47 - Linear Acc/Dec in All Modes
- G47.1 - S-Curve Acc/Dec for Positioning and Exact Stop Mode Only
- G47.9 - Infinite Acc/Dec (No Acc/Dec) (Enabled by your system installer in AMP)

Important: For optimum S-Curve Acc/Dec functionality, any block preceding a G47.1 block will decel to 0.

The table below shows you the interaction between contouring, positioning, exact stop moves, and acc/dec type (i.e., linear, exponential, S-Curve, and disabled).

Table 17.A
Interaction Between Contouring, Positioning, Exact Stop, and Acc/Dec Modes

Programming:	In this mode will result in:			
	G00	G01	G02	G03
G47	Linear/ Exponential ¹	Linear	Linear	Linear
G47 & G09/G61	Linear/ Exponential ¹	Linear	Linear	Linear
G47.1	S-Curve/ Exponential ²	Linear	Linear	Linear
G47.1 & G09/G61	S-Curve/ Exponential ²	S-Curve	Linear	Linear
G47.9	Disabled	Disabled	Disabled	Disabled
G47.9 & G09/G61	Disabled	Disabled	Disabled	Disabled

¹Linear/Exponential is a function of Positioning Acc/Dec. If Exponential is AMPed, this is the acc/dec type, otherwise, the type is Linear.

²S-Curve/Exponential is a function of Positioning Acc/Dec. If Exponential is AMPed, this is the acc/dec type, otherwise, the type is S-Curve.

Selecting Linear Acc/Dec Values (G48.n -- nonmodal)

Programming a G48.x in your part program allows you to switch Linear Acc/Dec values in nonmotion blocks. Axis values in G48.n blocks will always be treated as absolute, even if the control is in incremental mode.

Below is the format for calling G48 commands. Use this format with the axis names assigned by your system installer:

G48.n X_Y_Z_

Where :	In this mode :	Sets up :	Macros :
XYZ	G48.1	acceleration ramps for Linear Acc/Dec mode	#5631 to 5642
	G48.2	deceleration ramps for Linear Acc/Dec mode	#5651 to 5662
	G48.3	acceleration ramps for S-Curve Acc/Dec mode	#5671 to 5682
	G48.4	deceleration ramps for S-Curve Acc/Dec mode	#5691 to 5701
	G48.5	jerk limits	#5711 to 5722

Important: The allowable programmed range for the axis word depends on the configured format. Note that the axis word format also conforms to your current Inch/Metric settings. If you exceed these allowable ranges set by your system installer, you may use paramacros to override this limit.

For example, if the allowable programmed range for the axis word is 3.4 (e.g., 999.9999 max input) and the desired jerk limit is 100,000 mm/sec³, you may set Paramacro #1 to 1000,000 and program a G48.5 X#1 to set the jerk limit to 100,000. This method can be used for any of the G48 programming blocks.

Example 17.1 Allowable Programmed Range

```
#1 = 100000;
```

```
G48.5 X #1;
```


Important: The part program G48.n adjustments to Acc/Dec Ramps are not applied to jog moves. The AMPed Linear Acc/Dec mode rates are used when Manual Acc/Dec mode is linear.

Precautions on Corner Cutting

When Acc/Dec is active, the control automatically performs Acc/Dec to give a smooth acceleration/deceleration for cutting tool motion.

However, there are cases in which Acc/Dec can result in rounded corners on a part during cutting. In Figure 17.9, this problem is obvious when the direction of cutting changes from the X axis to the Z axis. In this case, the X axis decelerates as it completes its move, while the Z axis is at rest. As soon as the X axis reaches the AMP defined in-position band, the Z axis begins accelerating to make its commanded move. Since the Z axis begins motions before the X axis finishes, a slight rounding results.

Figure 17.9
Rounding of Corners



Use these G-codes to eliminate corner rounding:

Exact Stop (G09 -- nonmodal)

If a programmed motion block includes a G09, the axis moves to the commanded position, decelerates, and comes to a complete stop before the next axis motion block is executed. The G09 can be programmed in rapid (G00), feedrate (G01), or circular (G02/G03) motion blocks, but it is active only for the block in which it is programmed.

Exact Stop Mode (G61 -- modal)

G61 establishes the exact stop mode. The axes move to the commanded position, decelerate and come to a complete stop before the next motion block is executed. To cancel this mode, program G62, or G63.

Cutting Mode (G64 -- modal)

G64 establishes the cutting mode. This is the normal mode for axis motion and is generally selected by your system installer as the default mode active on power up. Block completes when the axes reach the interpolated endpoint. To cancel this code, program G61, G62, or G63.


Tapping Mode (G63 -- modal)

In the G63 tapping mode, the feedrate override value is fixed at 100 percent, and a cycle stop is ignored. Axis motion commands are executed without deceleration before the end point. The program proceeds to the next block without checking in position status, similar to the operation of G64. To cancel this code, program G61 or G62.

Automatic Corner Override (G62 -- modal)

In cutter compensation mode (G41/G42), the load on the cutter increases while moving inside a corner. If the G62 automatic corner override mode is active, the control automatically overrides the programmed feedrate to reduce the load on the cutter. To cancel this code, program G61 or G63.

Figure 17.10
Automatic Corner Override (G62)



When the corner angle, A , is larger than the value set for “min. angle for corner override” in AMP, the programmed feedrate is overridden from point “a” to point “b,” and from point “b” to point “c.”

The system installer sets these values in AMP:

- **Min angle for corner override** - minimum angle (A) between programmed paths before corner override is activated
- **Corner override distance (DTC)** - vector distance from, and of current move (b) to point on programmed path (a) where corner override is activated
- **Corner override distance (DFC)** - vector distance from end of current move (b) to point on programmed path (c) where corner override is deactivated

- **Corner override percent** - amount that feedrate is to be reduced once corner override is activated

To use an exact stop function while the automatic corner override mode (G62) is active, use the G09 instead of the G61. This is because G61 and G62 belong to the same G modal group and cancel each other if programmed. Be aware that G09 is non-modal.

Spindle Acceleration (Ramp)


Your system installer has the ability to change the rate in which a spindle is accelerated. AMP allows the option of either a 20 millisecond ramp (2ms intervals) or an immediate step in spindle speed. By writing the appropriate logic your system installer may also in effect generate a spindle “ramp” for even smoother spindle acceleration. Refer to documentation prepared by your system installer.

Short Block Acc/Dec Check (G36, G36.1)

In the default mode (G36), the Acc/Dec feature sometimes limits axis feedrates far below the programmed feedrate. This occurs when the length of axis motion in a block is short relative to the length of time necessary to accelerate and decelerate the axis.

In the default mode (G36), the control limits the axis feedrate in any block to the maximum speed from which it can properly decelerate to a stop before that block ends. For example, consider the velocity profile of an axis moving from Z4.8 to Z4.9 in Figure 17.11.


Figure 17.11
Programmed Feedrate Not Reached



12162-1

Normally this causes no problem. However, in cases where a series of very short axis moves in separate blocks exist, this limitation to the feedrate can cause finish problems as well as increased cycle time. Figure 17.12 shows the velocity profile that would result from a series of short Z axis moves from 4.8 to 4.9 to 5.0 to 5.1 to 5.2.

Figure 17.12
Feedrate Limited Because of a Series of Short Moves




To avoid this feedrate limitation, the short block Acc/Dec clamp can be disabled by programming a G36.1. In this mode, the control assumes that no rapid decelerations are required and allows axis velocities to go higher than they otherwise would. Activate G36.1 mode only when:

- no sudden changes in programmed feedrate within consecutive short motion blocks exists (this includes requesting a feedhold or cycle stop)
- no drastic change in programmed direction is present within the short blocks

If any of these conditions are not met during the G36.1 mode, the control can overshoot positions since the axes do not have time to decelerate. For example, consider the following position and velocity plots if a drastic change in direction is requested after the move from Z5.0 to Z5.1 when in G36.1 mode (see Figure 17.13). The position Z5.1 is overshoot and the axis would have to reverse direction to reach proper position.

Figure 17.13
Drastic Change in Direction while in Short Block Mode (G36.1)



ATTENTION: The programmer must consider the direction and feedrate transitions from block to block when the short block Acc/Dec check is disabled (G36.1 mode). If the transition exceeds the deceleration ramp of the axis, damage to the part or equipment can occur.

G36 and G36.1 are modal. The control should only be in short block check disable mode (G36.1) when executing a series of fast short blocks that contain only slight changes in direction and velocity. What constitutes a slight change in direction and velocity depends on the Acc/Dec ramp configured for your machine.


- G36 - Short Block Acc/Dec clamp Enable
- G36.1 - Short Block Acc/Dec clamp Disabled

G36 is the default mode, and it is established at power-up, E-Stop reset, and end of program (M02, M30, or M99). The recommended method of programming G36 and G36.1 is to program a relatively long entry and exit move into and out of the mode.

- The **entry move** should be a long move, in the general direction of the first short move, and at the same feedrate as the first short move. This entry move should be long enough for the axes to reach programmed speed. Program the G36.1 code in this entry block
- The **exit move** should be a long move, in the general direction of the last short move, and at the same feedrate as the last short move. This exit move should be long enough for the axes to decelerate properly without overshooting their end points. Program the G36 code in this exit block

Figure 17.14 shows the recommended entry and exit moves for short block Acc/Dec clamp disable mode.

Figure 17.14
Entry and Exit Move to/from Short Block



END OF CHAPTER

Dual Axis Operation

Overview

The Dual Axes feature lets the part programmer simultaneously control multiple axes while programming commands for only one. It differs from the split axis feature of the 9/PC control in that the split axis feature is used to control a **single axis** positioned by two servo motors.


This chapter reviews the following major dual axis operations:

Topic:	On page:
Parking a dual axis	18-3
Homing a dual axis	18-4
Programming a dual axis	18-5
Offset management	18-7

The dual axes feature is especially useful for lathes with dual turrets and other machines running with parallel cutting tools. Figure 18.1 shows a typical configuration for dual axes.

Implementation of the dual axis feature can require significant logic modification as well as proper AMP configuration. The dual axis feature is an option. Refer to your system installer's documentation to see if the dual axis option has been purchased for your machine.

Figure 18.1
Dual Axis Configuration



The 9/PC control can support two dual axis groups. A dual axis group consists of two or more axes coupled through AMP and commanded by a master axis name. The master axis name is used by the part programmer or operator when commanding the dual axis group in part programs or for jog moves.

Each axis that makes up a dual group is controlled by a separate positioning command from the servo module. This dual group command is based on the move generated by the control when the master axis is commanded to a position.


All axes that make up a dual group reach end-points at the same time. This requires that all axes that make up a dual axis group share the same feedrate parameters, acc/dec ramps, and other axes specific data for the group.

This section requires that you understand these terms:

- **Master Axis** - A master axis is the name used to command the axes in a dual group.
- **Dual Group** - A dual group is a set of axes that are coupled together in AMP and commanded by a single master axis name.

Figure 18.2 shows the position display for a system that contains a dual axis group containing two axes with a master axis name of X. Whether or not all axes of a dual group show up on the position display is determined in logic by your system installer.

Figure 18.2
Axis Position Display for Dual X Axis



Parking a Dual Axis

This feature allows you or the programmer to disable selected axes of the dual group. Any axis that is a member of a dual axis group can be parked. Axes in the dual group may be parked simultaneously. If all axes in the group are parked, no motion can take place in the dual axis group.

Once parked, no motion is allowed on the parked axis. Programmed and jog commands (including any homing requests) made to the dual axis group are ignored by the parked axes.

Axes in the dual group may only be parked or unparked when the control is in cycle stop and end-of-block state. The control cannot be in the process of completing any jog request or logic axis mover request. If an attempt is made to park/unpark an axis, and if any one of the above requirements is not true, the control ignores the request to park/unpark the axis.



ATTENTION: Be careful when an axis is unparked. Any incremental positioning requests you make to the dual axis group are referenced from the current location of all axes in the dual group. This includes any manual jogging or any incremental part program moves. When an axis is unparked, we recommend you make the next command the dual axis group be an absolute command to **realign** the axes in the dual group to the same position.

Perform an axis park in a dual group through logic. Refer to your system installer's documentation for details on how axes are parked.

Important: Some systems can have special parking requirements when homing axes in a dual group. Refer to page 18-4, *Homing a Dual Axis*, for details on homing dual axes.

Homing a Dual Axis

There are two methods to home axes in a dual axis group. Your system installer determines through logic which method is available. The two methods are:

- home each axis in the dual group individually
- home all axes in the dual group simultaneously

Both of these homing methods can be available for automatic (G28) as well as manual homing operations.

Your system installer can also define independent speeds and home positions for each axis in a dual group through AMP. This applies to both homing methods. Refer to your system installer's documentation for details on these speeds and locations.

Homing Axes Individually

This method requires that each axis be homed individually. When a manual home operation is performed, a home request must be made to each axis in the dual group on an individual method. Refer to chapter 4 for details on how to request a manual home operation.

When you use automatic homing (G28), the axes must be homed one at a time. This is accomplished by parking all other axes in the dual axis group except the axis that is to be homed and requesting that the AMP-assigned master axis name be homed in the G28 block. Once homed, that axis should be parked, the next axis to be homed should be unparked, and the homing procedure repeated. Refer to chapter 13 for details on how to request an automatic homing operation (G28).

Homing Axes Simultaneously

This method allows a request for all axes in the dual group to be homed at the same time. This does not mean that all axes reach home at the same time. Keep in mind that your system installer can define different feedrates and different home positions for each axis in the dual group.

With proper logic programming, your system installer can configure all axes in the dual axis group to home when the request is made to the master axis. If you use this homing method, all unparked axes home together. Refer to chapter 4 for details on how to request a manual home operation and chapter 13 on how to request an automatic home operation (G28).

Programming a Dual Axis

You can position axes in a dual axis group using any of the normal programming or manual motion operations. Only the master axis name can be requested to position a dual axis. Requests to position a dual axis can be made in manual, automatic, or MDI mode.

For absolute and incremental moves, regardless of the start-point, each axis in the dual group reaches the requested position (or travel the requested distance) at the same time. For absolute moves, this means individual axis feedrates can be modified, depending on the distance each axis must travel from start to end of the requested move.

Your system installer can assign different maximum cutting, external decel, and rapid feedrate limitations for each axis in a dual axis group. The control uses the slowest feedrate for each of these features from any axis in the dual axis group.

Special consideration must be given when programming these features:

Feature:	Consideration:
Mirror Imaging	Programmable mirror image is applied to all axes in the dual group. Manual mirror image, however, can be applied to each axis in the dual group individually. When manual mirroring is performed on selected axes in the dual group, positioning commands are in effect reversed from the programmed commands to the master axis. Manual mirror image is selected through logic. Refer to the system installer's documentation and chapter 13 for details.
Scaling	When scaling, specify the scale factor for the master axis of the dual group. All other axes in the dual group are then scaled using the master axis scale factor. Refer to chapter 12 for details.

Important: You can use the Logic Axis Mover feature if it is necessary to position dual axis group members separately without requiring any parking. Refer to the logic manual and the system installer's documentation for details.

Invalid Operations on a Dual Axis

Table 18.A lists the features that are not compatible with dual axes. If you must execute one of these features on a dual axis, only the AMP master axis can be used. **All other axes in the dual group must be parked.** Refer to your system installer's documentation to determine which axis has been assigned in AMP as the master axis.

Table 18.A
Features Not Compatible With Dual Axes

G-code	Feature
G16.1	Virtual C Cylindrical Interpolation
G16.2	Virtual C Cylindrical End Face Milling
G20, G24	Single Pass Roughing
G21	Single Pass Threading
G31-G31.4	External Skip Functions
G33, G34	Thread Cutting Mode
G37-G37.4	Automatic Tool Gauging Skip Functions
G72-G75	Roughing Cycles
G76	Face Grooving Cycle
G77	Grooving Cycle
G78	Multi-Pass Threading Cycle
G84.2, G84.3	Solid Tapping
G86.1	Boring Cycle w/Shift
G87	Back Boring Cycle

Offset Management for a Dual Axis

Give consideration to offsets used for a dual axis. In most cases, each axis can have independent offset values assigned to it. This section describes the difference in dual axis operation when it concerns offsets. How to activate/deactivate and enter these offset values is not described here unless some change specific to a dual axis occurs. See chapter 3 for implementation details about the offset you are using.

Preset Work Coordinate Systems (G54-G59.3)

The operation of the work coordinate systems is functionally the same for a dual axis as any other axis. Each axis in the dual group can have its own independent value entered into the offset table. If you want all axes in the dual group to have the same offset values, you must manually enter the same value for each axis in the dual group.

G52 Offsets

All axes in the dual group use the same value for the G52 offset regardless of whether they are parked. When you specify a G52 offset value using the master axis name, each axis offsets its coordinate system incrementally by the G52 amount.

G92 Offsets

When a G92 offset value is specified using the master axis name, the current position of all axes in the dual group takes on the location of the specified value.

For example, if you have a dual axis named X, and it consists of two axes, X1 and X2, when programming the following:

```
G92X10;
```

the control causes the current positions of X1 and X2 to become 10 regardless of their current positions when the G92 offset is executed.

Different G92 offset values can be created for each axis if necessary. This is accomplished by performing a jog offset or by using the logic axis mover to change the position of the dual axes relative to each other before the G92 block is executed.

Set Zero

You can perform a set zero operation on the axes in a dual group on an individual basis. For example, if you have a dual axis named X and it consists of two axes, X1 and X2, when the set zero operation is executed through logic, you must specify which axis in the dual group to set zero. When the set zero operation is performed on an axis, the current axis location becomes the new zero point of the coordinate system.

Cutter Compensation

Only one tool diameter can be active at any one time. Any offset created by cutter compensation affects all axes in the dual group.

Tool Length Offsets

Functionality is the same as for any other axis; independent values can be entered for each axis in the dual group. A T-word selects the length offset number, and the tool length offset is activated for each axis. Refer to chapter 19 for details on activating tool length offsets.

Additional programming for the G10L10 and G10L11 codes are available when a dual axis is the tool length axis. Since each axis in the dual group can have separate offset values, the G10 block must contain an individual name for each axis being assigned a value. Just programming the master axis name assigns values only to the master axis. Your system installer assigns axis names to all axes in the dual group in AMP. Refer to your system installer's documentation for details.

END OF CHAPTER

Tool Control Functions

Chapter Overview

This chapter describes these tool control functions:

Topic:	On page:
Programming a T-word	19-2
Entering tool offset data	19-5
Tool management	19-12


- **Programming a T-word** -- Different formats available for selecting a tool number and tool offsets
- **Tool length offsets** -- Compensate for the difference between the tool length assumed while programming, and the actual length of the tool used for cutting. This feature can offset up to 4 axes.
- **Tool Management and Random Tool** -- Tool life monitoring and tool changer pocket control

Important: Tool Tip Radius Compensation compensates for the difference between the tool diameter assumed while programming and the actual diameter of the tool used for cutting (eliminates overcutting or uncut portions of a workpiece due to differences in tool orientations and tip radius) as described in chapter 20.

T-words and Tool Length Offsets

Modern machining processes usually require a machine that is capable of selecting different tools. Typically tools are mounted in a turret and assigned tool numbers as illustrated in Figure 19.1. The tool length offset data, tool tip radius data, tool wear compensation data and tool orientation data are set in the offset table corresponding to different offset numbers. See chapter 3.

Figure 19.1
Typical Lathe Tool Turret



The selection of a tool number and an offset number for that tool is done by programming a T-word. A T-word can be programmed at any location in a part program.

Important: When you activate the MISCELLANEOUS FUNCTION LOCK feature, the control displays M-, B-, S-, and T-words in the part program with the exception of M00, M01, M02, M30, M98, and M99. Activate this feature through the front panel screen (as described in chapter 2) or by an optional switch installed by your system installer.

Programming a T-word and Tool Offsets

Important: If tool life management is being used on the system, see the tool management section in this chapter for details on programming a T-word. This section assumes that the tool life management feature is not being used.

Your system installer determines the format for a T-word in AMP. Table 19.A shows the 6 available format selections.

Table 19.A
T-word Formats

* FORMAT TYPE	WEAR OFFSET #	GEOMETRY OFFSET #
(1) 1 DGT GEOM + WEAR	last digit	same as wear
(2) 2 DGT GEOM + WEAR	last two digits	same as wear #
(3) 3 DGT GEOM + WEAR	last three digits	same as wear #
(4) 1 DGT WEAR	last digit	same as tool #
(5) 2 DGT WEAR	last two digits	same as tool #
(6) 3 DGT WEAR	last three digits	same as tool #

* For details on which format is being used on a specific control refer to documentation prepared by the system installer.

To use Table 19.A find the format being used on your system. Then go down the wear offset # column and find which digits of the T-word are used as the wear offset number. Any other digits to the left of the wear number are used as the tool number. If there are no digits remaining to the left of the wear number, the control uses tool number 0. The third column, geometry offset #, tells if the geometry number is the same number as the number used for wear or tool. Just because geometry may use the same offset number as wear it is not necessarily calling the same offset value.

Example 19.1
Using T-word Format #5

T213;

This T-word first calls for tool number 2 to be rotated into position, then data is accessed from the offset tables (chapter 3) for values under tool geometry offset number 2, and tool wear offset number 13.

Example 19.2
Using T-word Format #3

T2013;

This example first calls for tool number 2 to be rotated into position, then data is accessed from the offset tables (chapter 3) for values under tool geometry offset number 13, and tool wear offset number 13.

From these simple examples translation to the other formats should be relatively easy. The tool number is always the digits closest to the T-word. The maximum value that a tool number can have is determined by the system installer in AMP.

To cancel the tool length offset, program a T-word with a geometry and wear offset number of 0. The control does not cancel the active tool number since a tool number of 0 is invalid. If the wear or geometry offset number is the same as the tool number, a T-word of 0 cancels the offsets but not the tool number.

Example 19.3
Canceling Tool Offsets (Any T-word Format)

Assume that tool number 1 is the active tool number.

T0 ;

This example cancels all offsets and keeps tool number 1 in the turret. The system installer has the ability to force a tool change when T0 is programmed if he desire with a specific logic program. Refer to your system installers documentation for details.

Important: Your system installer determines in AMP whether or not all tool length offsets are canceled when the control is reset or an M02 or M30 end of program block is read.

Important: A T-word also calls up geometry and wear radius data for use in TTTC. See chapter 21.

Activating Tool Length Offsets

Your system installer has the option in AMP to determine exactly when the geometry and wear offsets take effect and when the tool position changes to the new shifted location. This manual makes the assumption that the system is configured to immediately shift the coordinate system by the geometry and wear amounts, and delay the move that re-positions the tool to the same coordinate position in the current work coordinate system. See the documentation prepared by your system installer to determine the application in a specific system.

Provided your system is configured as described above, the control activates a tool offset as described below:

- The control reads a block that activates or deactivates a tool length offset. This is a block that contains a T-word for the above configuration.
- The control immediately shifts the work coordinate system the amount of the tool geometry and tool wear amounts called by the T-word. Different values can be entered for the offsets for each axis in the offset table. The tool position display changes reflecting this shift. The absolute position display does not change.
- The offset is interpolated into the next move that generates axis motion on the offset axis, unless you are in incremental mode. If you are in incremental mode, the offset is not interpolated into the next move of the axis.

Example 19.4
Immediate Shift/Delay Move in Incremental and Absolute Modes

Absolute Mode		Incremental Mode	
G00Z0	Rapid Mode	G00Z0	Rapid Mode
G90	Absolute Mode	G91	Incremental Mode
T01	Activate tool 1. Program display changes Z position to -3.	T01	Activate tool 1. Program display changes Z position to -3.
Z1	Axis moves to +1	Z1	Axis moves to -2

If immediate shift, immediate move is selected in AMP, the control generates its own linear block to create the offset and positions the tool to the coordinates in the shifted work coordinate system as they were before the system was shifted. If axis words are present in the block that activates or deactivates a tool length offset, the control adds this generated move to the programmed move.

Important: A T-word cannot be programmed in a block that generates a circular motion (G02 or G03). If you want to change tools during circular blocks the T-word must be programmed in its own block where no axis motion takes place.

Entering Tool Offset Data Using (G10L10, G10L11)

You can enter data in the tool offset tables by programming the correct G10 command. This section describes the use of the G10 commands for the lathe tool offset table.

Important: Only the value in the offset table value changes when a G10 code modifies a tool offset table value. If the changed offset value is currently being used by the control, the active offset value is not changed until it is called again from the offset table using a T-word.

When the control is in incremental mode (G91), any values entered in an offset table using the G10 command are added to the currently existing offset values. When the control is in absolute mode (G90), any values entered in an offset table using the G10 command replace the currently existing offset values.

This is a representation of the basic format for modifying the offset tables.

```
G10 L(10-11)P__ X__ Z__ R__ Q__ T__ O__
```

Where :	Is :
L (10-11)	Designates which offset table is being modified. L10-Modifies the tool geometry table. L11-Modifies the tool wear table.
P	The tool offset number that is having its values changed is specified following the P address.
X	The value to add to (in G91 mode) or replace (in G90 mode) the tool length offset for the X axis. This value may be a diameter or radius value as determined with the O-word.
Z	The value to add to (in G91 mode) or replace (in G90 mode) the tool length offset for the Z axis.
R	The value to add to (in G91 mode) or replace (in G90 mode) the tool tip radius amount.
Q	The value to add to or replace the tool orientation amount (valid only when setting data for the geometry table).
T	A T-word that corresponds to the tool number that is being changed.
O	Determines if the value being entered into the offset table is a radius or diameter value. This only applies when setting data for the controls diameter axis (typically the axis perpendicular to the spindle). If no O-word is programmed the control uses the current radius/diameter mode active on the control. O1-indicates a radius value O2-indicates a diameter value

Important: Any axis word may be entered here along with/without the X- or Z-words. The lathe offset table allows the entry of offsets for up to four different axis, tool radius, and tool orientation for each offset number. Any values not specified in the G10 block remain unchanged.

Example 19.5 Using G10 to Change The Tool Offset Table

N00001 G90;

N00002 G10 L10 P4 Z2.1 Q1;

Offset number 4 has a new value of 2.1 for tool offset in the Z direction and new orientation value of 1 in geometry table. The current value for any axis not specified and for the tool radius remain unchanged.

N00003 G10 P4 L11 Z1.1;

Offset number 4 has a new value of 1.1 for tool offset in the Z direction in the wear table.

N00004 G91;

N00005 G10 L10 P4Z-1 Q1;

Offset number 4 has a new value of 0.1 (1.1 - 1.) for tool offset in the Z direction and new orientation value of 2 (1 + 1). The current value for any axis not specified and for the tool radius remain unchanged.

Important: G10 blocks cannot be programmed when TTRC is active.

Random Tool

Use the random tool feature to speed up production by saving cycle time when a tool is returned to the tool changing device. This is done by allowing the tool changer to randomly return the cutting tool to the most convenient pocket in the tool changing device. The control remembers what pocket the tool is returned to, and it is able to call the same tool from the new pocket at any time.

Important: This feature can be used with normal tool selection or the tool life management feature.

This feature has no effect on tool length offsets or cutter compensation. These features must still be activated correctly as described in their individual sections.

The random tool feature automatically decides the pocket that contains the requested tool based on the information in the pocket assignment table. If the requested tool has not been assigned to a pocket, the control generates an error.

Based on the current pocket number, which is maintained by logic, the control tells logic which pocket to move to, and how far, and in which direction to move. The control also tells logic where the tool currently in use can fit in the tool turret.

Important: This feature is very logic dependant. Before using this feature make sure your system installer has written the logic program to allow the use of Random Tool.

The control automatically updates the tool pocket assignment table when you make tool changes. The control indicates to logic the best location to return the tool to. Logic then decides where the tool gets placed in the tool holder. The pocket that is vacated by the new tool is marked as empty.


Manually Entering Random Tool Data

Data can be entered into the random tool table either manually, as described here, by programming, or by running a backup program of the tool data. These other methods are described later in this section.

To manually enter the random tool data, follow these steps:


1. Press the **{OFFSET}** softkey.

(softkey level 1)



- Press the **{RANDOM TOOL}** softkey. The pocket assignment table screen is displayed as shown below. This screen shows the current tool to pocket assignments. Your system installer designates the number of tool pockets available on a system in AMP.

(softkey level 2)



The columns labeled PKT give the tool changer pocket numbers. The columns labeled TOOL give the tool number of the tool in the corresponding pocket. Pockets with no tools assigned to them show no information next to the pocket number. Pockets with tools shown as XXXX indicate that a custom tool (tool that requires more than one pocket) has been assigned to use that pocket.

- Move the cursor to the pocket number with the assignment or change is to be made. Press the up, down, right, or left cursor keys on the operator panel. Move the cursor full pages by holding down the **[SHIFT]** key while pressing the up or down cursor keys. The selected pocket appears in reverse video.

Important: If random tool is not to be used for your system, make sure that none of the tool pockets have tool numbers assigned to them.

4. To modify tool data there are three choices:

- To remove a tool assigned to a pocket, press the {CLEAR VALUE} softkey. The selected tool is deleted from the table.
- To enter a tool number for the pocket, press the {REPLCE VALUE} softkey, key in the new tool number, and press the [ENTER] key. The old tool value is replaced with the new value just keyed in.
- To enter a custom tool (a tool that requires more than one tool pocket) enter the tool number of the custom tool in the pocket that is to be used as the “shaft pocket”. The shaft pocket is where the tool changer is positioned when the particular custom tool is to be used. Enter the number of pockets needed (to a max of 9), a comma, followed by the position of the shaft pocket in this group of pockets. Press the [ENTER] key enters the data into the table.

The screen shows XXXX for the tool number of any pockets that have been configured as part of a custom tool, and show the tool number in the pocket where logic is told to go in order to find the tool.

For example, in the pocket assignment screen, pocket number 19 is a shaft pocket for custom tool number 6. This custom tool requires 3 pockets, pockets 18, 19, and 20. When the {CUSTOM} softkey was pressed for pocket number 19, a value of 3,2 was entered.

Programming Random Tool Data

This feature is available so that it is not necessary to always manually enter the data into the pocket assignment table. By programming the correct G10.1 blocks all information may be entered into the tool pocket table. Note the control may automatically generate a G10.1 program by using the backup softkey as described later in this section.

Important: G10 blocks cannot be programmed when TTRC is active.

Programming of random tool data can only be done on a tool pocket if data has not already been configured for that pocket. If you need to make changes to a tool pocket that already has a tool assigned to it, you must either clear and re-load the entire random tool table as discussed below (you can not use a G10.1 to clear individual pocket data), or use the softkeys to manually access the random tool table and change the data using the keyboard.

Clearing the Random Tool Table

This block clears all information in the random tool table:

```
G10.1 L20 P0 Q0 O0 R0;
```


Format for Programming Random Tool Table

Use this block to set data for the random tool pocket assignment table:

```
G10.1 L20 P__ Q__ O__ R__;
```

Where :	Is :
G10.1 L20	This tells the control that the block will be setting data for the random tool pocket table. The G10.1 L20 is not modal, it must be programmed in every block that sets data for the random tool pocket assignment table.
P__	The value following the P-word determines the pocket number that is being set.
Q__	The value following the Q-word determines the tool number of the tool that is in the pocket determined with the P-word.
O__	The value following the O-word enters the number of pockets that are needed for the tool. Normally a value of one is entered here however, for custom tools that require more than one pocket, program the number of pockets that are required.
R__	The value following the R-word enters the pocket number of the shaft pocket for the tool. Normally a value of one is entered here. However, for custom tools that require more than one pocket, program the location relative to the other pockets for that tool that the tool changer goes to to access that tool.

For example, this block

```
G10.1L20P1Q20O1R1;
```

tells the control that tool number 20 is in pocket number 1;

```
G10.1L20P3Q23O4R2;
```

tells the control that tool number 23 has its shaft pocket as pocket number 3, four pockets are required for the custom tool and the second of these four pockets is the shaft pocket. This means that pockets 2, 3, 4, and 5 are used for the custom tool number 23.

Backup Random Tool Table

The control has a feature that allows you to back up (save) the information in the random tool table. The control generates a G10.1 program from the information already in the table. To do this follow these steps:


1. Press the **{OFFSET}** softkey.

(softkey level 1)

	PRGRAM MANAGE	OFFSET	MACRO PARAM	PRGRAM CHECK	SYSTEM SUPORT	→
F2	F3	F4	F5	F6	F7	F8
		ERROR MESAGE	PASS- WORD	SWITCH LANG		→
F2	F3	F4	F5	F6	F7	F8

2. Press the **{RANDOM TOOL}** softkey.

(softkey level 2)



3. Press the **{BACKUP}** softkey. The control prompts you for a program name. Key in the program name that is to contain the information from the random tool table and press the **[ENTER]** key. This program name cannot already exist in control memory.

This allows the control to generate a program that automatically loads the necessary data into the random tool table. This program can be edited as changes to tool table are needed.

The control automatically places this G10.1 program in the control's memory.

Starting a Program with a Tool Already Active

You can begin a part program with a tool already active in the chuck. In order for random tool to be able to properly handle that tool, it must enter information about that tool in the random tool table.

Important: If you use random tool when the tool was loaded into the chuck, it do not need to enter any data since random tool remembers what tool is loaded even after power is turned off. This procedure is only necessary if a tool is loaded manually or if random tool was not used when the tool was loaded.

The control needs the following information to properly handle a tool that is already active in the chuck. Tool number, number of pockets the tool uses, and position of the shaft pocket relative to these other pockets (refer to the section on manual entry of data for details on shaft pocket and custom tool data). Do this in the following way:

1. Press the **{ACTIVE}** softkey. The control prompts you for the tool number, the number of pockets, and the position of the shaft pocket relative to these other pockets all separated by commas.

(softkey level 2)

↑	WORK CO-ORD	TOOL WEAR	TOOL GEOMET	TOOL MANAGE	RANDOM TOOL	→
F2	F3	F4	F5	F6	F7	F8

↑		BACKUP OFFSET	SCALNG			→
F2	F3	F4	F5	F6	F7	F8

(softkey level 3)

↑	REPLCE VALUE	CLEAR VALUE	CUSTOM	ACTIVE	BACKUP	
F2	F3	F4	F5	F6	F7	F8

2. The control displays the configuration of the tool that it thinks is currently loaded into the chuck. If these values are incorrect, replace them using the correct tool information. Enter a value for tool number, number of pockets, and position of the shaft pocket all separated by commas on the input line. Data can be edited on the input line as described in chapter 2.
3. When the data for the tool that is currently in the chuck is correct, press the **[ENTER]** key. The control is now able to return the tool that is in the chuck to the best location in the tool changer at the proper time.

Important: You can also use the **{ACTIVE}** softkey to clear the currently active tool and specify no tool is currently in the spindle. To specify no tool is in the spindle press the **{ACTIVE}** softkey and delete any information that appears at the prompt. When the **[ENTER]** key is pressed, the active tool is cleared and the random tool assumes no tool is in the spindle.

Automatic Tool Life Management

Use the automatic tool management feature to monitor the life of a tool, determine when the tool should be replaced, and provide a replacement tool when that tool is requested in a program.

Tools are assigned to selected groups. Instead of calling a specific tool in a program, the programmer calls a tool group. The control then selects the first tool assigned to that group. If that tool has exceeded its entered tool life, then a replacement tool is selected from the next tool number assigned to that group. If that tool has exceeded its expected tool life, then the next tool in the group is selected. This continues until no more tools are available in that tool group. When a group is called that no longer has any available tools, an error is generated.

The correct tool length and tool radius offsets are assigned independently for each tool in the group.

Tool Directory Data

This section describes how to set up the tool groups and the information that must be entered for each tool group. This section described the manual method of entering this information. Page 19-23 describes a method of entering all information into the tables by programming.

Assigning Tool Numbers to Groups

Normally tools that are assigned to the same group have similar characteristics (such as a boring tool or a drilling tool). If one tool in the group is worn, the control should be allowed to select any tool in the same group and still be able to cut the same part using the same program.

Your system installer determines in AMP the usable range of tool group numbers by determining a boundary. Any tool number that is programmed above this boundary is used as a tool group number (the value of the boundary is subtracted from the tool number programmed). Any tool number that is programmed below this boundary is used as a normal tool number. A maximum of 200 group numbers are available.

Enter different tool length offset numbers, and radius offset numbers into the tool management table with the tool numbers in each group. When you select a tool from a group by the control, the tool length and radius offset numbers are activated with them getting the data for the tools radius, length's for each axis, and orientation from the tool offset tables. See chapter 3 on entering tool data for details.

Tool Life Measurement Type

The control can measure the life of a tool using one of three possible methods:

Tool Life Type	Method Selected	Meaning
0	time	<p>This is selected by choosing 0 as the type of tool life measurement.</p> <p>Time measures tool life as the length of time that a cutting tool is operated at a cutting feedrate.</p> <p>The value for the expected tool life is entered in units of minutes.</p>
1	number of times used	<p>This is selected by choosing 1 as the type of tool life measurement.</p> <p>Number of times used measures tool life as the number of times that the tool is selected as the active tool.</p> <p>The value for the expected tool life is entered as the number of times the tool may be used to cut parts; this number is per program.</p> <p>Regardless of the number of times that a tool is selected as active in a specific program, it only counts as one use each time the program is executed.</p>
2	distance	<p>This is selected by choosing 2 as the type of tool life measurement.</p> <p>Distance measures tool life as the distance that the tool has been moved using a cutting feedrate.</p> <p>The value for the expected tool life is entered in units of inches or millimeters depending on the mode that the control is operating in at the time.</p> <p>For multi-axis moves, the vectorial distance traveled by the tool is the distance used for tool life measurement.</p>

Select the tool life type (selected as either 0, 1, or 2) on a per-group basis. Different groups may use different tool life types, however, each tool in the group uses the same tool life type.

Tool Life Threshold Percentage

A threshold level may also be assigned to a tool group. The threshold level is assigned as a percentage of the total expected life of the tool. When a tool reaches this threshold level, it is classified as old for that tool group. A tool is classified as old only to allow the operator to see that a tool is close to expiration. If the tool is being used when it reaches the threshold level, it continues to be used as normal until the tool reaches the “expired state” (100% of the expected tool life).

The tool life threshold percentage is selected on a per-group basis. Different groups can use different threshold percentage, however each tool in the group uses the same threshold percentage.

Entering Tool Group Data

To enter tool group data, you must create the tool groups. This is done automatically when the group is selected to edit. To enter tools into groups and enter other tool group data follow these steps:

1. Press the {**OFFSET**} softkey.

(softkey level 1)

	PRGRAM MANAGE	OFFSET	MACRO PARAM	PRGRAM CHECK	SYSTEM SUPT	→
F2	F3	F4	F5	F6	F7	F8
		ERROR MESSAGE	PASS- WORD	SWITCH LANG		→
F2	F3	F4	F5	F6	F7	F8

2. Press the {**TOOL MANAGE**} softkey.

(softkey level 2)


↑	WORK CO-ORD	TOOL WEAR	TOOL GEOMET	TOOL MANAGE	RANDOM TOOL	→
F2	F3	F4	F5	F6	F7	F8
↑		BACKUP OFFSET	SCALNG			→
F2	F3	F4	F5	F6	F7	F8

3. Press the {**TOOL DIR**} softkey. The control displays the current tool directory screen showing all of the current tools and the groups that they have been assigned to (see the following figure). The control displays the prompt “EDIT GROUP:”.

(softkey level 3)

↑	TOOL DIR	TOOL DATA	BACKUP DATA			
F2	F3	F4	F5	F6	F7	F8

Figure 19.2
Typical Tool Group Directory Screen




At this point, you can delete any or all tool groups that already exist for some reason follow these steps:

To delete:	Press:
select tool group	the {DELETE GROUP} softkey. Key in the desired group number to delete and press the [ENTER] key. This deletes all information in the tool group including the tool offset numbers, threshold rate, tool numbers, etc.
all of the tool groups	the {DELETE ALL} softkey. The control prompts "DELETE ALL TOOL MANAGEMENT DATA? (Y/N):". Entering "Y" deletes all tool management data that has been entered into the management tables (this does not delete any G10 programs that are backups or used to set the tool management tables). Entering "N" aborts the delete operation.

- Key in the group number that is to be edited. When you select the correct group, press the **[EDIT GROUP]** key. Figure 19.3 shows all of the information for that tool group that is displayed.

Figure 19.3
Typical Tool Group Data Screen



- From this screen, you can:

Operation:	Description:
Change tools	Alter one of the tool numbers that has already been entered in the group. Move the cursor to the tool number to be changed by pressing the up or down cursor keys (move the cursor full pages by holding down the shift key while pressing a cursor key). Press the {CHANGE TOOL} softkey. Key in the new tool number and press the [ENTER] key.
Insert tools	Insert a new tool number for that group. Move the cursor to the location to insert a new tool number at by pressing the up or down cursor keys (move the cursor full pages by holding down the shift key while pressing a cursor key). Press the {INSERT TOOL} softkey. Key in the new tool number and press the [ENTER] key. The actual range of allowable tool numbers is 1 to 9999.
Delete tool	Remove a tool number from that group. Move the cursor to the tool number to be removed by pressing the up or down cursor keys (move the cursor full pages by holding down the shift key while pressing a cursor key). Press the {DELETE TOOL} softkey. Respond yes or no and press [ENTER] .

Change life type	Alter how the control records and measures tool life for that group. Press the { CHANGE TYPE } softkey. The prompt "LIFE TYPE..." is displayed on line 2 of the CRT. The same life type is assigned to all tools in any one tool group. Key in the number of the desired tool life measurement type for that group and press the [ENTER] key. 0 for "time," 1 for "number of tool uses," and 2 for "distance."
Change life threshold rate	Alter the percentage of a tool's expected life so that a tool is labeled as old. This percentage applies to all tools in the selected group. To alter the threshold percentage (the percentage of total tool life that has been used before a tool will be classified as old) press the { CHANGE T RATE } softkey. Key in the percentage of the total tool's life so that the tool is classified as old and press the [ENTER] key. Tool life threshold rate is explained earlier in this section.

The application of these operations was described in detail earlier in this section. All of this information can be entered into the tool groups using the programming method described on page 19-20.

Assigning Detailed Tool Data

This section assumes that tools have already been assigned to their specific groups. This section describes specific information that is to be entered into the tool life management tables for the individual tools. This information may also be entered into the tool management tables using the programming method described on page 19-20. This information includes:

- Tool length offset number
- Tool diameter/radius offset number
- Expected life of a tool

Tool Length and Diameter/Radius Offset Number

Use this feature of tool life management so the programmer does not need to know what tool has been called by tool life management and still have the correct tool offsets and cutter compensation activated.

Important: The control only automatically enters the tool length and cutter compensation offset numbers. This may or may not activate the tool length offset or cutter compensation features. These features must still be activated as normal.

Expected Tool Life

Use this feature of tool life management to set the expected life of a tool. The type of tool measurement used is assigned to the tool group as described on page 19-12. This tool measurement type determines the units that are used for the expected tool life.

As a tool is used the amount of usage is recorded and displayed as the accumulated tool life (the amount of the expected tool life that has been used). This is displayed individually for each tool on the tool data display screen. The accumulated tool life can be reset to zero by pressing the {**RENEW TOOL**} softkey.

The following is a description of the units that should be entered for the different tool life measurement types:

- If tool life is measured in units of time (0 is selected as tool life type), then the units for the expected tool life is minutes. Enter the minutes of operation that the tool is expected to operate and still be within the tolerance required for the part being cut. The accumulated life of a tool is only measured when that tool is the active tool, and it is performing a cutting operation. Moves that are rapid, or blocks that do not produce axis motion are not added to the accumulated tool life.
- If tool life is measured by the number of uses (1 is selected as tool life type), then the units for the expected tool is the number of programs that the tool may be selected as an active tool in. The accumulated life of a tool is increased by one if that tool is selected in a program as the active tool. Remember that the same tool may be active more than once in a program, however its accumulated life only increments by one. Enter the total number of program executions that can use the tool before the tool no longer meets the required tolerance for the part being cut.
- If tool life is measured in units of distance (2 is selected as tool life type), then the units for the expected tool life is either inches or millimeters (depending on the current operating mode of the tool). Enter the distance of travel that the tool is expected to cut and still be within the tolerance required for the part being cut. The accumulated life of a tool is only measured when that tool is the active tool, and it is performing a cutting operation. Moves that are are rapid, or blocks that do not produce axis motion are not added to the accumulated tool life. For multi-axis moves (including arcs and helices) the distance added to the accumulated life is the vectorial distance, not necessarily the distance traveled on each axes.

During turning cycles only the distance that the tool travels along the workpiece contour is added to the accumulated life. The other three moves of the cycle are not added regardless of if they are executed at cutting speed. The entire finishing pass for the contouring routine (if any) is used to increase the accumulated tool life.


Entering Specific Tool Data

The following steps describe the method of entering specific tool data for tool management. This includes tool offset numbers, and expected tool life:

Important: This section assumes that the steps required to assign tools to specific groups has been performed as described in *Assigning Tool Numbers to Groups*.


1. Press the {**OFFSET**} softkey.

(softkey level 1)




2. Press the {**TOOL MANAGE**} softkey.

(softkey level 2)




3. Press the {**TOOL DATA**} softkey. The control displays the prompt “EDIT GROUP:”.

(softkey level 3)



4. Key in the group number to edit using your keyboard and press the [ENTER] key. Figure 19.4 shows all of the information for that tool group that is displayed.

Figure 19.4
Typical Tool Data Screen



5. From this screen it is possible to perform the following operations. The application of these operations was described in detail earlier in this section.

Operation:	Description:
Enter or alter the tool length offset number	To enter or alter a value for the tool length offset number, move the cursor to the tool number of the tool to alter and press the {EDIT LN OFF} softkey. Key in the new offset number that calls the correct data from the offset tables for that tool for its tool length offset number and press the [ENTER] key. The old value for tool length (if any) is discarded and the new value replaces it.
Enter or alter the tool radius offset number	To enter or alter a value for the tool radius offset number, move the cursor to the tool number of the tool to alter and press the {EDIT CT CMP} softkey. Key in the new offset number that calls the correct data from the offset tables for that tool for its radius and press the [ENTER] key. The old value for radius offset numbers (if any) is discarded and the new value replaces it.
Enter or alter the expected life of a tool	To enter or alter a value for the expected life of a tool, move the cursor to the tool number of the tool to alter and press the {EDIT LIFE} softkey. Key in the new expected life of the tool (in units as determined by the tool life type) and press the [ENTER] key. The old value for expected life (if any) is discarded and the new value replaces it.
Reset the accumulated tool life to zero	To reset the accumulated tool life to zero, move the cursor to the tool number of the tool to alter and press the {RENEW TOOL} softkey. The old accumulated life of the tool is discarded and a value of zero is entered as the new accumulated tool life. This is normally performed after an old or expired tool has been replaced with a new tool. This updates the status of the tool and remove any "OLD," or "EXPIRED" status.

Programming Data and Backing Up Tool Management Tables (G10L3, G11)

This feature allows the rapid loading of information into the tool management tables. This is done by executing a program that automatically loads the tool management tables. This program can also be generated automatically when the tool management tables are backed up as described later in this section.

Data is sent to the tool management tables when the control executes this G10 block:

```
G10L3;
```

This block indicates to the control that any information following this block is to be used to set the tool management tables.

Important: G10 blocks may not be programmed when TTRC is active.



ATTENTION: Any time that a G10L3; block is executed the control automatically clears all information that is in the management tables for all tools and tool groups.

Any time after the G10L3 command, parameters may be programmed to enter what tool group is being entered, the type of tool life measurement that is being used, and the tool life threshold percentage. The format for this block is:

P__I__Q__;

Where :	Is :
P__	The value entered with the P-word is used to program what tool group number is being edited. The following blocks assign tools to that tool group.
I__	The value entered with the I-word is used to program the type of tool life measurement that is to be used for all the tools in that group. I0 sets a type of time, I1 sets a type of number of uses, and I2 sets a type of distance. Refer to page 19-12 for details. If more than one I-word is programmed for a tool group the control uses the last programmed I-word for that group. If no I-word is programmed for a group the control uses I1 as a default value.
Q__	The value entered with the Q-word is used to program the threshold percentage for that tool group. Enter the percentage of the total expected tool life that causes the tools in the group to be classified as old. Refer to page 19-12 for details on threshold percentage. If the Q-word is not programmed in a block the control uses a default value of 80%. If more than one Q-word is programmed for a tool group the control uses the last programmed Q-word for that group. If no Q-word is programmed for a tool group the control uses Q80 as the default value.

The following program blocks assign tools to groups, length and cutter compensation offset numbers, and expected tool life to specific tools. This information is assigned to the last group number programmed in a block using the P-word. The format for these blocks is:

T__H__D__L__;

Where :	Is :
T__	The value entered with the T-word is the tool number of the tool to be assigned to that group.
H__	The value entered with the H-word is the tool length offset number from the tool geometry and wear tables that is to be assigned to this tool. The H-word is only valid if programmed in the same block as a T-word.
D__	The value entered with the D-word is the tool radius number from the tool geometry and wear tables that is to be assigned to this tool. The D-word is only valid if programmed in the same block as a D-word.
L__	The value entered with the L-word is used to program the value of the expected tool life for that tool. The controls interpretation of this is dependant on the value set with the I-word in this program block. The value programmed with the L-word remains active for all following tools in that group until replaced with a different L-word, or a new tool group is programmed with a P-word.

All of the tools should then be programmed for that group in individual blocks. When all of the tools for that group have been entered, change groups by programming a different P-word in a block.

When all of the tools for all of the different groups have been entered, end the execution of editing the tool life management table by programming either a M02 or M30 end of program blocks or by entering this block:

G11;

This cancels the G10 data setting mode for tool management.

Important: Any information that was contained for a specific tool group that has been written to using a G10L3 command as described above is overwritten by the information programmed with the G10 blocks. All previous data for tool management for any of the groups is lost.

Example 19.6 Programming Tool Life Management Data

Program Block	Description
G10L3;	Starts loading tables.
P1I1Q60;	Begins loading data for tool group 1. Type 1 (number of uses) measurement. Threshold 60%.
T1H5D7L25;	Places tool 1 in group 1 with length offset number of 5, cutter radius offset number 7, and expected life of 25 uses.
T2H2;	Places tool 2 in group 1 with length offset number of 2, no cutter radius offset number and expected life of 25 uses.
T15H7;	Places tool 15 in group 1 with length offset number of 7, no cutter radius offset number and expected life of 25 uses.
P2;	Begins loading data for tool group 2. Type 0 measurement (default). Threshold at 80% (default).
T12H3D6L40;	Places tool 12 in group 2 with length offset number of 3, cutter radius offset number of 6, and expected life of 40 minutes.
T13;	Places tool 13 in group 2 with length and radius offset numbers of 0 and expected life of 40 minutes.
P4I0Q90;	Begins loading data for tool group 4. Type 0 (time) measurement. Threshold at 90%.
T20H3D6;	Places tool 20 in group 4 with length offset number of 3, cutter radius offset number of 6, and expected life of 0 minutes.
Q50;	Resets the threshold at 50% for group 4.
G11;	Ends the loading operation.
M02;	

Backing Up Tool Management Tables

This feature causes the control to automatically generate a G10L3 program that stores all of the information that it finds in the current tool management table. Any time that this G10 program is executed, it clears any information that is currently in the management tables and replaces it with the information that is in the G10 program.

To generate the G10L3 backup program of the tool management tables, follow these steps:

1. Press the **{OFFSET}** softkey.

(softkey level 1)

	PROGRAM MANAGE	OFFSET	MACRO PARAM	PROGRAM CHECK	SYSTEM SUPPORT	→
F2	F3	F4	F5	F6	F7	F8

		ERROR MESSAGE	PASS- WORD	SWITCH LANG		→
F2	F3	F4	F5	F6	F7	F8

2. Press the **{TOOL MANAGE}** softkey.

(softkey level 2)

↑	WORK CO-ORD	TOOL WEAR	TOOL GEOMET	TOOL MANAGE	RANDOM TOOL	→
F2	F3	F4	F5	F6	F7	F8

↑		BACKUP OFFSET	SCALNG			→
F2	F3	F4	F5	F6	F7	F8

3. Press the **{BACKUP DATA}** softkey. The prompt "BACKUP FILENAME:" is displayed on the input line.

(softkey level 3)

↑	REPLCE VALUE	CLEAR VALUE	CUSTOM	ACTIVE	BACKUP	
F2	F3	F4	F5	F6	F7	F8

4. Key in any legal program name and press the **[ENTER]** key. This program name is used as the program that stores all of the backed up tool management data. The control generates the tool management G10 program.

Programming a T-word Using Tool Management

This section describes how to activate a tool using tool life management. When using tool life management, remember:

- Your system installer sets up a boundary for T-words used with tool life management in AMP. Any T-word programmed that calls a tool number less than, or equal to, this boundary is used as a normal tool number. Any T-word programmed that calls a tool number greater than this boundary is used as a tool group number for tool management.

- When a T-word is programmed using tool life management, the group that is called with the T-word is equal to the programmed T-word, minus the value of the boundary set in AMP by your system installer. This boundary does not include any offset number normally attached to the T-word. Place holder digits for tool offsets must be programmed, although their values are ignored. See Example 19.7.
- Your system installer must have altered AMP parameters from their default condition to use tool management. The default condition sets a tool boundary at 100 and a T-word format of 3 digit geometry + wear. This default configuration requires a minimum six digit T-word be programmed to activate any tool group in tool life management. This configuration does not work if the AMP parameter **maximum allowable T-word** remains set to its default of only 5 digits.

Example 19.7

Assume your system installer has set the following constraints in AMP:

- the tool group boundary is set as 100
- the T-word format is configured as 2-digit geometry and wear (refer to page 19-1)
- the maximum allowable T-word is configured as a 5-digit number

To use tool management program for these constraints:

```
Tttt00;
```

Where :	Is :
Tttt	-- the group number (if greater than the group boundary) -- a tool number (if less than the group boundary)
00	the place holder for the tool offset number

Table 19.B**Result of Different T-words for Example 19.7**

T-word	Result
T12;	Since tool number is below boundary and two digits are necessary for offset with this T-word format, no tool is programmed here. Instead tool geometry and tool wear offset number 12 is selected.
T1201;	Tool 12 and geometry and wear offset number 1 is selected. Tool life management is not used because tool number 12 is below the group boundary of 100.
T10100;	The first available tool assigned to group 1 is selected along with the offset numbers assigned to that tool in the tool management table.
T10201;	The first available tool assigned to group 2 is selected along with the offset numbers assigned to that tool in the tool management table. The geometry and wear offset number of 01 programmed here is ignored.
T123456;	Error occurs because maximum allowable T-word of 5 digits has been exceeded.

Example 19.8
Programming Tool Changes Using Tool Life Management.

Example 19.8 assumes that:

- your system installer has configured in AMP the boundary for tool life management at 100
- the tool changer is located at the secondary machine home point called by a G30; this is not necessarily true for different machine applications
- the T-word format is configured as 3 digit geometry + wear
- the maximum allowable T-word format has been set to allow 6-digit T-words.

Program Block	Description
G30X10Z10F.1;	Return to secondary home position.
T101000;	Change to a group 1 tool.
G29;	Return from secondary home position. Activate tool length offset using the offset number for the tool as assigned in the tool management table.
G42;	Activate TTRC right using the offset number for the tool as assigned in the tool management table.

END OF CHAPTER

Tool Tip Radius Compensation (TTRC) Function

Chapter Overview

This chapter describes Tool Tip Radius Compensation function. Major topics include:


Topic:	On page:
Programming TTRC	20-4
Generation blocks	20-7
Tool paths (Type A)	20-9
Tool paths (Type B)	20-18
Tool path during TTRC	20-29
Special cases	20-34
Error detection	20-49

Generally, cutting tools used on lathes have a rounded cutting edge which often results in a difference between the cutting tool tip position assumed in writing a part program, and the actual cutting tool tip position. This inevitably causes a difference between the programmed shape and the actual shape cut on the workpiece in taper and arc cutting operations. See Figure 20.1.

For reference, the term “tool tip radius compensation” has been shortened to TTRC and is referred to as such in the following sections.

The TTRC functions allows you to use tools with different radii without requiring a modification of the part program.

Figure 20.1
Taper and Arc Cutting Without TTRC



Put the radius of the tool and tool orientation data into the offset tables in advance. This function lets the control use the same program to produce the same workpiece, regardless of the radius of the tool that does the cutting.

This feature also uses tool orientation data taken from the tool geometry table. You need this tool orientation to compensate for inaccuracies that can occur from difficulties in measuring tool tip diameter because of a tool mounting position. If this is not a factor, make sure all tool orientations use an orientation of either 0 or 9.




ATTENTION: If you use a 2-turret lathe, be aware that the X tool offset and the tool orientation values will be opposite of the A turret values for the second mirrored (B).

We use these terms in this section:

- **inside** -- Refer to an angle between two intersecting programmed tool paths as inside if, in the direction of travel, the angle measured clockwise from the second tool path into the first is **less than or equal to 180°**. See Figure 20.2. If one or both of the moves are circular, the angle is measured from a line tangent to the tool path at their point of intersection.

- **outside** -- Refer to an angle between two intersecting programmed tool paths outside if, in the direction of travel, the angle measured clockwise from the second tool path into the first is **greater than 180°**. See Figure 20.2. If one or both of the moves are circular, the angle is measured from a line tangent to the tool path at their point of intersection.
- **r** -- cutter radius
- **CR** -- cross-point between two programmed paths after you activate the TTRC

Figure 20.2
Definition of Inside and Outside



There are two types of cutter compensation available on the 9/PC control:

- type A (as described on page 20-9)
- type B (as described on page 20-18)

This table highlights the differences between the two types:

Type of Move	Type A	Type B
Entry Move Into TTRC	- The tool takes the shortest possible path to its offset position.	- The tool stays at least one radius away from the start-point of the next block at all times. - Extra motion blocks can be generated to attempt to prevent gouging of the part as may occur in Type A.
Tool Path	- Same as Type B.	- Same as Type A.
Exit Move From TTRC	- The tool takes the shortest path to the end-point of the exit move for both inside and outside corners.	- The tool takes the shortest path to the end-point of exit move for inside corners only . - For outside corners , the tool stays at least one radius away from the end-point.

Your system installer determines whether to use type A or type B by a control in AMP.

Programming TTRC

These G-codes are used for TTRC:


G-code:	TTRC, :
G41	left
G42	right
G40	cancel

Left or right is defined as offsetting the tool to the left or right of the programmed cutting path when facing the direction of cutter motion.

Important: If you set a negative value in the offset tables as the tool radius, this reverses compensation direction (tool left or right) for the G41 and G42 codes. G41 and G42 are also reversed during the mirroring operation. Refer to chapter 14.

All of these G-codes are modal and belong to the same modal group.

Figure 20.3
TTRC Direction



Important: The TTRC function is not available during any of the thread cutting cycles. TTRC must be canceled before any threading routine can be performed.

Program the TTRC function with this format:

```
G41(or G42)X ___ Z ___ T ___ ;
```

Where :	Is :
G41 (or G42)	TTRC direction, G41=left, G42=right
X, Z	End-point of entry move into TTRC. Program an entry move only on axes in the currently active plane. Axis motion must take place in order for TTRC to be active on an axis.
T	Designates the offset numbers and pulls data: 1) from the wear and geometry tables for the tool radius, and 2) from the geometry table for tool orientation. Refer to chapter 20 for information on programming a T-word. The T-word is optional in the G41 or G42 blocks. The T-word may also be designated in any previous or following program block.

You can program TTRC in various ways. Example 20.1 shows 1-, 2-, and 3-block programs activating TTRC with entry moves.

Example 20.1 Initializing TTRC

Assume: G18 (ZX Plane Selection)

Program Block	Comment
One Block	
G42 T0016 X1 Z1;	Sets compensation right, selects tool radius offset number, and activates move to X1 Z1
Two Blocks	
T0016;	Selects tool radius offset number
G42 X1 Z1;	Sets compensation right and activates move to X1 Z1
Three Blocks	
T0016;	Selects tool radius offset number
G42;	Sets compensation right
X1 Z1;	Activates move to X1 Z1

Important: Any entry move (refer to page 20-9 and 20-18) into TTRC must be a linear move. You cannot initially activate TTRC by programming either the G41 or G42 commands in a circular cutting mode (G02 or G03). However, if TTRC is already active, the G41 or G42 commands can be programmed in a circular block to change TTRC direction either left (G41) or right (G42).

The T-word calls this data from the offset tables:

- Initial cutter radius data (from geometry table)
- Cutter radius wear data (from wear table)
- Tool orientation data (from geometry table)


The control uses the sum of the cutter radius data from the geometry and wear tables as the data for the tool tip radius. The orientation data is used when determining tool positioning information relative to the part.

The designation of the T-word can be done in any block before the designation of the G42 or G41 commands or in any following block that contains axis motion in the plane selected for compensation. This is also provided that doing so will not generate the initialization of TTRC. If TTRC is initialized in the block containing a T-word, it must be a linear block.

Important: A T-word also calls up data from the geometry and wear tables for the tool length offset function described in chapter 19.

Important: The TTRC feature is not available for any motion blocks that are programmed in MDI mode. Refer to page 20-29. The TTRC mode can be altered by programming either G41, G42, or G40, or the tool radius can be changed in an MDI program. However, none of the tool paths executed in MDI will be compensated. Any changes made to TTRC are not applied until the next block executed in automatic mode.

Figure 20.4
Tool Radius Wear




G40 (TTRC cancel) is active when power is turned on, when E-STOP is reset, when the control is reset, or when an M02 or M30 end-of-program block is executed.

Example 20.2
Tool Tip Radius Compensation Sample Path

Assume: T01 = 5mm tool radius total from both geometry and wear tables. Also assume a tool orientation of 0.

Program Block	Comment
N1G00G42X30.Z35.T01;	rapid to start and set TTRC right
N2G01Z52.F.1.;	feed move to Z52
N3G03Z68.R15.;	arc of radius 15
N4G01.Z95.;	feed move to Z95
N5Z102.X18.;	feed move to Z102 X18
N6G40X0Z0;	exit TTRC
N7 M30	end of program

Figure 20.5
Results of TTRC Program Example



TTRC Generation Blocks
G39, G39.1

In certain instances, TTRC creates a nonprogrammed move called a generated block. These blocks improve cycle time and corner-cutting quality.

TTRC generates blocks for type A or B moves as follows:

Type of Move	Type A	Type B
Entry Move	No block is generated	Block is generated
Tool Path	Block is generated	Block is generated
Exit Move	No block is generated	Block is generated

Important: These blocks are created only if:


- G41 is active and cutting an inside angle that is less than 90°
- G42 is active and cutting an outside angle that is more than 270°

The generated block between the two tool paths can be programmed as linear or circular with these G-codes:

G39 (or G39.1);

Where :	Causes:
G39	linear transition blocks. If neither G39 or G39.1 is programmed, G39 is the default. This command is modal.
G39.1	circular transition blocks. When cutting straight line-to-arc or arc-to-straight line moves, the generated block will always be linear, and the G39.1 will be ignored. This command is modal.

Figure 20.6
TTRC Generated Blocks (G39 vs G39.1)



G39 or G39.1 can be programmed in any block. However, they must be programmed in or before the block that causes a TTRC generated block.

Important: For linear generated blocks, your system installer can define a minimum block length in AMP. If the generated move length is less than the system-defined minimum block length, no generated block is created. The tool path proceeds to the intersection of the two compensated paths. If the generated move length is equal to, or greater than, the system-defined minimum block length, a generated block is created.

Throughout this chapter, we show drawings where a generated block is created. Both G39 and G39.1 are shown in these drawings where applicable.


TTRC Tool Paths (Type A)

The easiest way to demonstrate the cutting tool's the actual tool paths when using TTRC type A is by pictorial representation. The following subsections describe the cutter path along with a figure to clarify the description:

TTRC Type A Entry Moves

An entry move is defined as the path that the cutting tool takes when the TTRC function first becomes activated in a program.

Figure 20.7 shows a typical entry move.




Important: Any entry move into TTRC must be a linear move. Initial activation of TTRC by designation of either the G41, G42, or T-word that initializes TTRC in a circular cutting mode (G02 or G03) is not allowed. The G41, G42, or T-word can be designated in a circular block to change TTRC direction or tool radius, as long as TTRC is already active.

The entry move of the cutting tool for type A TTRC takes the shortest possible path to its offset position. This position is at right angles to and on the left or right side of the next programmed move in the currently defined plane.


Figure 20.8 and Figure 20.9 show examples of typical entry moves using type A TTRC.

Figure 20.8
Tool Path for Entry Move Straight Line-to-Straight Line



If the next programmed move is circular (an arc), position the tool at right angles to a tangent line drawn from the start-point of that circular move.

Figure 20.9
Tool Path for Entry Move Straight Line-to-Arc



There is no limit to the number of blocks that can follow the programming of G41 or G42 before an entry move takes place. The entry move will always be the same regardless of the number of blocks that do not program motion in the current plane for compensation.

Example 20.3 Sample Entry Move After Nonmotion Blocks

Assume current compensation plane is the ZX plane.

N01X0Z0;	
N2G41T1;	This block commands compensation left
N3M02;	This is not the entry block since no axis motion takes place in the current plane.
N4...;	No axis motion in current plane.
N5...;	No axis motion in current plane.
N6...;	No axis motion in current plane.
"	"
"	"
"	"
N999X1Z1;	This is the entry move for the previously programmed G41.

Your system installer selects in AMP the allowable number of nonmotion blocks that is to be allowed during TTRC before the entry move must be re-initialized. Refer to page 20-29.

Important: The definition of a nonmotion block is any block within a program that does not actually generate the movement of one of the axes in the current compensated plane. Blocks that are skipped by the control because of the block skip feature (/) are also counted as a nonmotion block in TTRC, regardless of the content of the skipped block.


For example, assume that your system installer has designated that only two nonmotion blocks can be performed. Then, if more than two blocks following the entry move do not contain axis motion in the current plane, the entry move is performed again at the next block containing axis motion in the current plane.

Example 20.4 Too Many Nonmotion Blocks After Entry Block

Assume current plane to be the ZX plane.

N1X0.Z0.;	
N2G41T1X1.Z1.;	Entry move TTRC left.
N3;	No axis motion in current plane.
N4...;	No axis motion in current plane.
N5X4Z-4;	New entry move TTRC left.

Figure 20.10
Results of Example 20.4



TTRC Type A Exit Moves

Cancel the TTRC feature by programming G40. Refer to the path that is taken when the tool leaves TTRC as the exit move. The path that the tool follows during an exit move is dependant on:

- The direction of compensation (G41 or G42).
- The angle between the last motion made in TTRC (in the current compensation plane) and the motion of the exit move.

Designating a tool offset number T00 in a program does not cancel TTRC and does not generate an exit move. TTRC simply continues on as if a tool radius had been changed to a radius of zero. Refer to page 20-29 for information about changing cutter radius. The exit move, if T00 is the active tool radius, is the same path as the programmed tool path.

Important: An exit move cannot be a circular move (G02 or G03). Any exit move must be programmed on a linear path. Any attempt to generate an exit move by using a circular path generates a block-format error.

Example 20.5 gives some sample exit move program blocks.

Example 20.5
Type A Sample Exit Moves

Assume the current plane is the XZ plane and TTRC is already active before the execution of block N100 in these program segments.

N100X1.Z1.;	
N110X3.Z3.G40;	Exit move.
N100X1.Z1.;	
N110G40;	
N120X3.Z3.;	Exit move.
N100X1.Z1.;	
N110G40;	
N120;	No axis motion in the current plane.
N130...;	No axis motion in the current plane.
N140...;	No axis motion in the current plane.
"	"
"	"
N200X3.Z3.;	Exit move.
N100X1.Z1.;	
N110...;	No axis motion in the current plane.
N120...;	No axis motion in the current plane.
N130...;	No axis motion in the current plane.
"	"
"	"
N200G40X3.Z3.;	Exit move.

All of the program blocks in Example 20.5 produce the same exit move provided the number of nonmotion blocks in the compensation mode has not exceeded a value selected by your system installer in AMP.


Important: The definition of a nonmotion block is any block within a program that does not actually generate the movement of one of the axes in the current compensated plane. Blocks that are skipped by the control because of the block skip feature (/) are also counted as a nonmotion block in TTRC, regardless of the content of the skipped block.

The exit of the cutting tool for type A TTRC takes the shortest possible path to the endpoint of the exit move. This path starts at right angles to the left or right of the endpoint (depending on G41 or G42) of the last move in the currently defined plane. You can redefine this start-point by using an I- and/or K-word as described later in this section. The end-point of the exit move is no longer offset to the left or right.

Figure 20.11 through Figure 20.15 show examples of typical exit moves using type A TTRC. All examples assume that the number of nonmotion blocks before the designation of the G40 command have not exceeded the number allowed as determined by your system installer in AMP.


Important: The definition of a nonmotion block is any block within a program that does not actually generate the movement of one of the axes in the current compensated plane. Blocks that are skipped by the control because of the block skip feature (/) are also counted as a nonmotion block in TTRC, regardless of the content of the skipped block.

Figure 20.11
Tool Path for Exit Move Straight Line-to-Straight Line



If the last programmed move is circular (an arc), positioning the tool at right angles to a tangent line drawn from the end-point of that circular move.

Figure 20.12
Tool Path for Exit Move Arc-to-Straight Line



The examples in Figure 20.11 and Figure 20.12 assume that the number of blocks that do not contain axis motion, in the currently selected plane, follow the G40 programming before an exit move takes place and does not exceed an amount selected in AMP by your system installer. If the number of nonmotion blocks following G40 exceeds the limit, the control generates its own exit move. This may often cause overcutting of the part.

Important: The definition of a nonmotion block is any block within a program that does not actually generate the movement of one of the axes in the current compensated plane. Blocks that are skipped by the control because of the block skip feature (/) are also counted as a nonmotion block in TTRC, regardless of the content of the skipped block.

You can modify the path that the tool takes for an exit move by including an I- and/or K-word in the exit move. Only the I- or K-words that represent values in the current plane are programmed in the block containing the exit move. I and K correspond to the X and Z axes respectively.

The I- and K-words in the exit move block define a vector that is used by the control to redefine the end-point of the previously compensated move. I- and K-words are always programmed as incremental values regardless of the current mode (G90 or G91).

The vector defined by the I- and/or K-words is along a line drawn from the end-point of the programmed path to a point referenced from the end-point of the programmed path a distance along the axes in the current plane an amount as designated with the I- and/or K-words. A new vector is then defined parallel to the vector defined by the I- and/or K-word and offset from this vector in the direction and amount of the currently active offset (G41 or G42). The intersection of this new vector with the current compensated tool path defines a point which is the new end-point of the last programmed compensated move.

Figure 20.13
Exit Move Defined By An I, K Vector





Figure 20.13 is the exception. The change in length of the compensated path is more than one radius of the tool. In this special case, this offset is limited to one radius of the tool. The direction of the offset is towards the point of intersection of the I K vector and the current compensated tool path.

Example 20.6
Exit Move Defined By An I,K Vector But Limited To Tool Radius

Assume T1 radius is 3


```
N10 Z10.G41T1
N11 X10.Z2.I3K-10.G40;
```

Figure 20.14
Results of Example 20.6



If the vector defined by I and/or K is parallel to the programmed tool path, the resulting exit move is offset in the opposite direction of the I and/or K vector by one radius of the tool.

Figure 20.15
Exit Move When I, K Vector Is Parallel to Programmed Tool Path



Important: If one I and/or K value is programmed without the second one, the value of the second I- and/or K-word defaults to 0.

TTRC Tool Paths (Type B)


We demonstrate the actual tool paths taken by the cutting tool when using TTRC type B by pictorial representation. The following subsections describe the cutter path along with a figure to clarify the description.

TTRC Type B Entry Moves

An entry move is defined as the path that the cutting tool takes when the TTRC function first becomes activated in a program.

Figure 20.16 gives an example of a typical entry move.

Figure 20.16
TTRC Entry Move




Important: Any entry move into TTRC must be a linear move. Initial activation of TTRC by designation of either G41, G42, or T-word in a circular cutting mode (G02 or G03) is not allowed. The G41 or G42 commands can be designated in a circular block to change TTRC direction, or a new T-word can be designated to change cutter radius, as long as TTRC is already active.

The entry move of the cutting tool for type B TTRC can generate extra motion blocks to attempt to prevent gouging of the part as may sometimes occur using compensation type A. Type B TTRC keeps the cutting tool at least one radius away from the start-point of the next block at all times during an entry move. The final end-point of the entry move is a position at right angles to and on the left or right side of the next programmed move in the currently defined plane.


Figure 20.17 and Figure 20.18 show examples of typical entry moves using type B TTRC.

Figure 20.17
Tool Path for Entry Move Straight Line-to-Straight Line



If the next programmed move is circular (an arc), position the tool at right angles to a tangent line drawn from the start-point of that circular move.

Figure 20.18
Tool Path for Entry Move Straight Line-to-Arc



There is no limit to the number of blocks that can follow the programming of G41 or G42 before an entry move takes place. The entry move is always the same regardless of the number of blocks that do not program motion in the current plane for compensation.

In Example 20.7, assume current compensation plane is the ZX plane.

Example 20.7 Sample Entry Move After Nonmotion Blocks

```

N01X0Z0;
N2G41;           This block commands compensation left.
N3M02;           This is not the entry block since no axis
                  motion takes place in the current plane.
N4...;           No axis motion in current plane.
N5...;           No axis motion in current plane.
N6...;           No axis motion in current plane.
"               "
"               "
"               "
N999X1Z1;        This is the entry move for the previously
                  programmed G41.

```

Your system installer selects in AMP the allowable number of nonmotion blocks that are allowed during TTRC before the entry move must be reinitialized. Refer to page 20-29.

Important: The definition of a nonmotion block is any block within a program that does not actually generate the movement of one of the axes in the current compensated plane. Blocks that are skipped by the control because of the block skip feature (/) are also counted as a nonmotion block in TTRC, regardless of the content of the skipped block.

For example, assume that your system installer has designated that only two nonmotion blocks can be performed. Then, if more than two blocks during TTRC do not contain axis motion in the current plane, the entry move is re-performed at the next block containing axis motion in the current plane.

In Example 20.8, assume the current plane to be the ZX plane and the system installer has designated that only two nonmotion blocks can be performed before TTRC is reinitialized.


Example 20.8 Too Many Nonmotion Blocks During TTRC

```

N1X0Z0;
N2G41X1Z1;       Entry move TTRC left.
N3...;           No axis motion in current plane.
N4...;           No axis motion in current plane.
N5X4Z-4;         New entry move TTRC left.

```

Figure 20.19
Too Many Nonmotion Blocks



TTRC Type B Exit Moves

Program a G40 to cancel the TTRC feature. Refer to the path that is taken when the tool leaves TTRC is referred to as the exit move. The path that the tool follows during an exit move is dependant on:

- The direction of compensation (G41 or G42).
- The angle between the last motion made in TTRC (in the current compensation plane) and the motion of the of the exit move.

Designating a tool offset number T00 in a program does not cancel TTRC and does not generate an exit move. TTRC simply continues on as if a tool radius had been changed to a radius of zero. Refer to page 20-29 for information about changing cutter radius). The exit move (if T00 is the active tool radius) is then equal to the programmed tool path.

Important: An exit move cannot be a circular move (G02 or G03). Any exit move must be programmed on a linear path. Any attempt to generate an exit move by using a circular path generates an error.

Example 20.9 gives some sample exit move program blocks.

Example 20.9 Sample Exit Move Segments

Assume the current plane to be the ZX plane.

```

N100X1Z1;
N110X3Z3G40;   Exit move.

N100X1Z1;
N110G40;
N120X3Z3;      Exit move.

N100X1Z1;
N110G40;
N120...;       No axis motion in the current plane.
N130...;       No axis motion in the current plane.
N140...;       No axis motion in the current plane.
"              "
"              "
N200X3Z3;      Exit move.

N100X1Z1;
N110...;       No axis motion in the current plane.
N120...;       No axis motion in the current plane.
N130...;       No axis motion in the current plane.
"              "
"              "
200G40X3Z3;    Exit move.

```


Provided the number of nonmotion blocks in the compensation mode has not exceeded a value selected by your system installer in AMP, all of the program blocks in Example 20.9 produce the same exit move.

Important: The definition of a nonmotion block is any block within a program that does not actually generate the movement of one of the axes in the current compensated plane. Blocks that are skipped by the control because of the block skip feature (/) are also counted as a nonmotion block in TTRC, regardless of the content of the skipped block.

The exit of the cutting tool for type B TTRC takes the shortest possible path to the end-point of the exit move for inside corners only. For outside tool corners, the cutting tool always remains at least the radius of the cutting tool away from the end-point of the last move in compensation. You can redefine the start-point by using an I- and/or K-word as described later in this section. The endpoint of the exit move is no longer offset to the left or right.


Figure 20.20 and Figure 20.21 show examples of typical exit moves using type B TTRC. All examples assume that the number of nonmotion blocks before the designation of the G40 command has not exceeded the number allowed as determined by your system installer in AMP.

Figure 20.20
Tool Path for Exit Move Straight Line-to-Straight Line



If the last programmed move is circular (an arc), the tool is positioned at right angles to a tangent line drawn from the end-point of that circular move.

Figure 20.21
Tool Path for Exit Move Arc-to-Straight Line



12117-1

Important: The definition of a nonmotion block is any block within a program that does not actually generate the movement of one of the axes in the current compensated plane. Blocks that are skipped by the control because of the block skip feature (/) are also counted as a nonmotion block in TTRC, regardless of the content of the skipped block.

Figure 20.20 and Figure 20.21 assume that the number of blocks that do not contain axes motion in the currently selected plane, following G40 before the exit move takes place, do not exceed an amount selected in AMP by your system installer. If the number of nonmotion blocks following G40 exceeds the limit, the control generates its own exit move. This may often cause overcutting of the part, since this move is a linear path directly back to the programmed tool path.

You can modify the path that the tool takes for an exit move by including an I- and/or K-word in the exit move. Only the I- or K-words that represent values in the current plane are programmed in the block containing the exit move. I and K correspond to the X and Z axis respectively.

The I- and K-words in the exit move block define a vector that the control uses to redefine the end-point of the previously compensated move.

The vector defined by the I- and/or K-words is along a line drawn from the end-point of the programmed path through a point programmed with the I- or K-words. The I- and/or K-words must be in the currently defined plane. The point defined by I and K is always one incremental distance from the end-point of the last move measured parallel to the X and Z axis.

A new vector is then defined parallel to the vector defined by the I- and/or K-word and offset from this vector in the direction and amount of the currently active offset (G41 or G42). The intersection of this new vector with the current compensated tool path defines a point which is the new end-point of the last programmed compensation move.

Figure 20.22
Exit Move Defined By An I, K Vector





Figure 20.22 is the exception. The change in length of the compensated path is more than one radius of the tool. In this case, this offset is limited to one radius of the tool. The direction of the offset is towards the point of intersection of the I and/or K vector and the current compensated tool path.

Example 20.10
Exit Move Defined By An I, K Vector But Limited To Tool Radius
 Assume T1 radius is 3.

```


N10 Z10.G41T1;
N11 X10.Z2.I3K-10.G40;
    
```

Figure 20.23
Results of Example 20.10



If the vector defined by I and/or K is parallel to the programmed tool path, the resulting exit move is offset in the opposite direction of the I, K vector by one tool radius.

Figure 20.24
Exit Move When I, K Vector is Parallel to Programmed Tool Path.



Important: If one I and/or K value is programmed without the second one, the value of the second I- and/or K-word defaults to 0.

Tool Path During TTRC

Except for entry and exit moves, the basic tool path generated during TTRC is the same for types A and B TTRC. Whether tool left or tool right is specified, the path taken is a function of the angle between tool paths (G41 or G42) and the radius of the cutting tool.

Important: If at any time during the execution of TTRC blocks a block reset is performed, the TTRC function re-initializes and the next move acts as an entry move as described in an earlier section.


Important: When cutting arcs with TTRC active, the control may need to adjust the programmed feedrate to maintain cutting speed. Refer to chapter 17 for details on feedrates during TTRC.

The control generates extra motion blocks to keep the cutting tool in tolerance of the desired tool path. This becomes necessary when the intersection of tool paths is an outside tool path (as defined on page 20-4) that has an angle as follows:

- between 0° and 90° during TTRC left (G41)
- between 270° and 360° during TTRC right (G42)


Figure 20.25 through Figure 20.28 illustrate the basic motion of the cutting tool as it executes program blocks during TTRC.

Figure 20.25
TTRC Tool Paths Straight Line-to-Straight Line




12121-1

Figure 20.26
TTRC Tool Paths Straight Line-to-Arc




12122-1

Figure 20.27
TTRC Tool Paths Arc-to-Straight Line



12123-1

Figure 20.28
TTRC Tool Paths Arc-to-Arc



12124-1

TTRC Special Cases

The following subsections describe possible tool paths that can be generated when programming one of the following during TTRC:

- changing TTRC direction (cross-over tool paths)
- exceeding the allowable number of consecutive, nonmotion blocks during TTRC
- corner movement following a generated block
- changing cutter radius during TTRC
- effect on TTRC when interrupting a program to execute either a MDI program or a manual move
- changing or offsetting current work coordinate system during TTRC
- moving to and from machine home and secondary machine home

Changing TTRC Direction

This section describes the resulting tool path when a change in compensation direction (left or right) is programmed. This can result in the cutting tool crossing over the programmed tool path as compensation changes from left to right or right to left.

Linear Tool Path-to-Linear Tool Path.

The following figures show the tool path taken when TTRC is changed from G41 to G42 during the execution of two linear program moves.

The control generates two points when changing TTRC direction: point 1 and point 2.


- Point 1 is the final tool position before compensation direction is changed (at right angles to the end-point of the programmed tool path offset by one tool radius)
- Point 2 is the desired tool position for the start of the first block using the changed compensation direction (at right angles to the start-point of the motion block that changes compensation direction and offset by the tool radius)

The control generates the motion block that connects point 1 to point 2 as shown in these examples:

Example 20.11 **Linear-to-Linear Change in TTRC Direction (Reversing Tool Path)**

```
N10 Z10.G41;  
N11 Z20.;  
N12 Z10.G42;  
N13 Z0.;
```

Figure 20.29
Results of Example 20.11




Example 20.12
Linear-to-Linear Change in TTRC Direction (Continuing Tool Path)

```

N10 Z10.G41;
N11 Z20.;
N12 Z30.G42;
N13 Z35.;

```

Figure 20.30
Results of Example 20.12




Example 20.13
Linear-to-Linear Change in TTRC Direction (With Generated Blocks)

```

N10 X15.Z10.G41;
N11 X-5.Z8.;
N12 X0.Z35.G42;

```


Figure 20.31
Results of Example 20.13



Example 20.14
Linear-to-Linear Change in TTRC Direction (No Generated Blocks)

```
N20 X5Z10.G41;
N21 X-5.Z7.G42;
```

Figure 20.32
Results of Example 20.14




For one of these cases that changes the TTRC direction, the control attempts to find an intersection of the actual compensated tool paths:

Linear-to-Circular, Circular-to-Linear, or Circular-to-Circular Tool Paths


If the control finds an intersection, it modifies the end-point of the original compensated tool path and the start-point of the new compensated tool path to equal that intersection. See Figure 20.33.

Figure 20.33
Change in Compensation with Actual Tool Path Intersection



If no intersections of the actual tool paths exist, the compensated tool path is the same as if a linear-linear intersection had taken place. See Figure 20.34.

Figure 20.34
Change in Compensation With No Possible Tool Path Intersections



Too Many Nonmotion Blocks

The control always looks ahead to the next motion block to determine the actual tool path for a motion block in TTRC. If the next block is not a motion block, the control continues to scan ahead for a motion block until it either detects one or the allowable number of nonmotion blocks as set in AMP has been exceeded. Refer to documentation prepared by your system installer for the allowable number of nonmotion blocks allowed in a specific system.

Important: The definition of a nonmotion block is any block within a program that does not actually generate the movement of one of the axes in the current compensated plane. Blocks that are skipped by the control because of the block skip feature (/) are also counted as a nonmotion block in TTRC, regardless of the content of the skipped block.

When scanning ahead, if the control does not find a motion block before the number of nonmotion blocks has been exceeded, it does not generate the normal TTRC move. Instead the control sets up the compensation move with an end-point one-tool radius away from and at right angles to, the programmed end-point. In many cases this may cause unwanted overcutting of a work piece.

In many cases, this can cause unwanted overcutting of a work piece. Figure 20.35 and Figure 20.36 are example tool paths of programmed motion blocks followed by too many nonmotion blocks before the next move was made.

Figure 20.35
Too Many Nonmotion Blocks Following a Linear Move





Figure 20.36
Too Many Nonmotion Blocks Following a Circular Move




Corner Movement After Generated Blocks

Frequently the control must generate motion blocks to position the cutting tool in the proper alignment for a following compensated cutting move. These blocks are generated to make certain that the cutting tool remains at least one radius of the cutting tool away from the programmed cutting path at all times.


When the control generates two motion blocks, the length of the first generated block is checked against a minimum allowable length as determined in AMP by your system installer. The coordinate values for the current axes in the compensation plane are compared to the minimum allowed value. If both are less than the allowed value, then the control does not execute the first generated block. The path of the second generated block is then altered to position the cutting tool along a linear path to the original end-point of the second generated block. See Figure 20.37 for a pictorial representation.

Figure 20.37
Compensation Corner Movement for Two Generated Blocks



When the control generates 3 motion blocks, the length of the second generated block is checked against a minimum allowable length, determined in AMP by your system installer. The amount of motion of the second move on the two axes in the compensation plane is compared to the minimum allowed value for each axis. If both are less than the allowed value, then the control does not execute the second generated block. The path of the third generated block is then altered to position the cutting tool along a linear path to the original end-point of the third generated block. See Figure 20.38 for a pictorial representation.

Figure 20.38
Compensation Corner Movement for 3 Generated Blocks



Changing Cutter Radius During Compensation

If a tool becomes excessively worn, broken, or for any other reason requires the changing of the programmed tool tip radius, TTRC should be cancelled and reinitialized after the tool has been changed. Refer to page 3-14 on changing the tool offset and page on changing the active tool offset number.

Important: Slight overcutting may occur during Cutter Compensation, depending on the programmed path at the point where the change in cutter radius was made. To avoid overcutting, we recommend that you use a Mid-Start Program until the point of tool breakage.

Figure 20.39 through Figure 20.41 are representations of the resulting tool paths after the programming of a change in the radius of the cutting tool. Assume in these figures that the programmed change to the tool radius is entered in block N11 which also contains the motion as described in the figure.

The tool path taken when changing tool radius is dependant on the move immediately before the change in radius was programmed, the move that the change in radius was programmed in, and whether any generated motion blocks were made between these tool paths.

Figure 20.39 gives a description of the tool path when the programmed moves are linear-to-linear.

Example 20.15
Linear-to-Linear Change in Cutter Radius

When the control generates blocks	When the control does not generate blocks
N10 X10.Z5.G1T1;	N10 X10.Z10.G1T1;
N11 X-5.Z3.T2;	N11 Z20.T2;
N12 Z20.G42;	N12 X0.Z30.;

Figure 20.39
Linear-to-Linear Change in Cutter Radius During Compensation




Figure 20.40 describes the tool path when the programmed moves are linear-to-circular.

Figure 20.40
Linear-to-Circular Change in Cutter Radius During Compensation





Figure 20.41 describes the tool path when the programmed moves are circular-to-circular.

Figure 20.41
Circular to Circular Change in Cutter Radius During Compensation



Change in Cutter Radius During Jog Retract.

This section concerns a change in the cutter radius during a jog retract operation. The jog retract feature is often used when a tool becomes very worn or is broken. It can be necessary to replace the tool with a tool of a slightly different diameter. TTRC is able to adjust to the new tool diameter.

Typically when the jog retract operation is performed, the tool is jogged away from the workpiece and then replaced. After it is replaced, you need to activate a different tool diameter offset value. This is done in either of two methods:

- The new offset number is activated by programming a new D-word in an MDI block.
- The new offset number is activated by using the **{ACTIVE OFFSET}** softkey found on the offset table screen. This feature is described in chapter 3.

The new offset is activated. TTRC is able to compensate for this new diameter by modifying the saved jogged path. This path is modified so that the new tool cuts the same part as the old tool. The absolute position of the machine will, therefore, be different on the return path from what it was when jogging away from the part.


This jogged path is adjusted when you press the <CYCLE STOP> button to return from the jog retract. As soon as you press the <CYCLE STOP> button, the control generates a move that offsets the current tool position by the necessary distance. This distance is determined as the necessary distance the tool where would have to be positioned so that the exact same jog return paths can be used to return to the part and still have the end-point be offset from the original position by the difference in the cutter diameter.



ATTENTION: Make sure that this offset path will not cause any collisions with the part or the machine fixtures. The position of the tool when the tool change in jog retract is made should be a safe distance from the part and machine fixtures.

Figure 20.42 shows an example of a typical change in tool radius during jog retract with TTRC active:

Figure 20.42
Change in Cutter Radius During a Jog Retract




MDI or Manual Motion During TTRC

If exiting automatic mode and either a MDI motion block is executed or a manual jog motion is made, the TTRC feature, if active, will be re-initialized when the next motion block is executed. The compensation feature compensates the cutting tool one tool radius perpendicular to the tool path of the next motion block that is executed in automatic mode. In effect, the control generates its own entry move for compensation with the first compensated block being the next block executed in automatic operation.

Important: The TTRC feature is not available for any motion blocks that are programmed in MDI mode. The TTRC mode may be altered by programming either G41, G42, or G40, or the tool radius can be changed in an MDI program. However, none of the tool paths executed in MDI will be compensated. Any changes made to TTRC will not be applied until the next block executed in automatic mode.

Figure 20.43 is an example of the possible tool path taken when interrupting automatic operation during TTRC to execute MDI motion blocks. The same tool path would apply if interrupting TTRC to perform a manual jog move.

Figure 20.43
TTRC Interrupted with MDI Blocks



Important: If during cutter compensation, you switch out of automatic mode and either:


- generate axis motion in manual mode on an axis in the cutter compensation plane, or
- execute any block in MDI mode,

cutter compensation is re-initialized when you return to automatic mode.

This produces a path that is different from the path that would have been produced had the manual or MDI operation not been done, even if you returned the tool to the point of interrupt. In absolute mode the control returns to the originally compensated path after it executes a block that contains both axes in the compensation plane. In incremental mode, the compensated path remains offset by the additional tool radius. Figure 20.44 illustrates these conditions.

Figure 20.44
Cutter Compensation Re-Initialized after a Manual or MDI Operation.

Cutter Compensation is reinitialized here. The control assumes that the current position is a programmed position at the point of re-initialization. Consequently, after the initialization, tool compensation is offset by twice the tool radius.



Use the Jog Retract feature if you must jog the axes away from a compensated path. Jog retract prevents the overcompensation from occurring.

If you interrupt cutter compensation with a manual or MDI operation and the next programmed block is a circular block, the control generates an error when it tries to re-initialize cutter compensation. You can avoid this by using the jog retract feature instead of manual or MDI when you need to interrupt cutter compensation.

Unless **Cutter Compensation** is active, when a program recover is performed, the control automatically returns the program to the beginning of the block that was interrupted. In the case of power failure, the control will even reselect the program that was active prior to the interruption.

Moving to/from Machine Home

We recommend that you cancel TTRC by using a G40 command before executing a return to, or from, machine home, or a return to or from the secondary machine home. This refers to the operations performed when the control executes either the G28, G29, or G30 commands as described in chapter 14.


If compensation is not cancelled by using a G40 command, the control automatically, temporarily cancels compensation for the return to machine home or secondary machine home operations. This is done by using the move to the intermediate point, as designated when the operation was performed, as an exit move for compensation.

Important: An intermediate point should always be programmed for a return to home operation if TTRC is active. If no intermediate point is specified, the control executes the move prior to the return to home operation as an exit move. This can cause undesired overcutting of the part.

If compensation was not cancelled using a G40 command before returning to machine or secondary home points, the control automatically re-initializes TTRC for the return from machine or secondary home points. This is done by using the move to the intermediate point, as designated when the operation was performed as an entry move for compensation.

Figure 20.45 shows either a G28 or G30 block followed by a G29 block:

Figure 20.45
TTRC During G28, G30, and G29 Blocks



Changing or Offsetting Work Coordinate System in TTRC


We recommend that you cancel TTRC by using a G40 command before any modifications to the current work coordinate system are made, including any offsets or any change of the coordinate system (G54-G59.3).

If compensation is not cancelled using a G40 command, the control automatically, temporarily cancels compensation for the change in work coordinate system. This is done by using the last compensated move in the current coordinate system as an exit move for compensation.

If compensation was not cancelled by using a G40 command before a change in the work coordinate system was performed, the control automatically re-initializes TTRC after the new work coordinate system is established. This is done by using the first move in the new coordinate system that is in the compensation plane as an entry move for compensation.

Figure 20.46 gives an example of programming a G92; however, this would apply to any change in the work coordinate system.

Figure 20.46
TTRC During G92 Offset to Work Coordinate System



Block Look-ahead

During normal program execution, the control is constantly scanning ahead several blocks to set up the necessary motions to correctly execute the current block. This is called Block Look-ahead.

The 9/PC control has 21 set-up buffers. Different features require the use of some of these setup buffers. One is always used for the currently executing block. TTRC requires at least 3 of these buffers. Any remaining setup buffers are used for block look-ahead, with one buffer used for each block.

At times (especially during TTRC) the control may not have enough look-ahead blocks to correctly execute the current block. When this happens, the control automatically starts disabling the block retrace feature.

The block retrace feature uses one setup buffer for every re-traceable block. The number of retraceable blocks is set in AMP by your system installer (a maximum of 15 is possible).

If necessary, the control decreases the number of available retraceable blocks until either there are sufficient setup buffers available to successfully execute the current program, or until there are no more block retrace blocks left. The control displays a message on line 2 of the CRT if it has to eliminate some of the block retrace blocks.

Avoid using too many buffers for block retrace. The larger the number of look-ahead blocks that the control has available to set up future part program motion requests, the more efficiently the control executes programs. We recommend that you keep the number of setup buffers available to the block retrace feature as low as possible.

Error Detection


Error detection for TTRC blocks can be separated into 3 categories:

- Backwards motion detection
- Circular departure too small
- Interference

Backwards Motion Detection

The compensated tool path is parallel to but in the opposite direction of the programmed tool path.


Figure 20.47
Typical Backwards Motion Error



Circular Departure Too Small

No intersection can be generated between two consecutive compensated tool paths.


Figure 20.48
Typical Circular Departure Error



Interference

This error occurs when compensation vectors intersect. Normally when this intersection occurs, a backwards motion error is generated; however, a few special cases exist that are caught only by interference error detection.

Figure 20.49
Typical Interference Error



Disabling Error Detection

You can disable all of the above error detection (with the exception of circular departure too small cases) for a specific block or portion of a part program. To disable the error detection for a specific block, your system installer must have defined an M-code in AMP. By programming this M-code in a block, all error detection for TTRC can be disabled. Error detection is disabled until another M-code defined in AMP to re-enable error detection is programmed in a block.

Important: Circular departure too small cases cannot be disabled. The control cannot execute a compensated path when this error occurs.

The default condition is error detection enabled. Default values for these M-codes are:

M-code:	Error detection:
M800	disables
M801	enables

Error detection M-codes are only functional when TTRC is active. TTRC is active when the control is in G41 or G42 mode **and has already made the entry move into compensation**. If an M800 or M801 is programmed in G40 mode or before the entry move into TTRC takes place, the M code is ignored.

If error detection is disabled in TTRC, and TTRC is exited (G40 programmed), the next time TTRC is re-activated error detection will be reactivated automatically. Error detection is always automatically enabled when cutter compensation is activated.

Refer to documentation prepared by your system installer for the M-codes used on your specific system.

END OF CHAPTER

Single-pass Turning Cycles

Chapter Overview

Single-pass turning cycles consist of these cycles:

- G20 Single-pass O.D. and I.D. roughing cycle
- G24 Single-pass rough facing cycle
- G21 Simple threading cycle

This chapter describes the following major topics:

Topic:	On page:
G20	21-1
G24	21-7

These cycles are called single-pass cycles because each time the cycle is executed, it makes only one cutting pass over the workpiece. Typically single-pass cycles are modal and repeat after any block that commands axis motion.

It is possible for the system installer to select in AMP the option to repeat the cycle after **every** block following the single-pass cycle block. If your control is configured this way, the motions of the last executed single-pass cycle repeat after every program block until the cycle is cancelled.

This manual assumes that the system is configured to repeat the cycle only after blocks commanding axis motion (very similar to the drilling cycles described in chapter 25).

Cancel single-pass cycles by programming a different G-code in the same modal group. See G-code table in appendix C. G-codes in the same group include G00, G01, G02, G03, G33, and G34.

Single-pass cycles can be programmed in either diameter or radius mode. For the purpose of explanation, examples in this section are given in the radius programming mode. When programming in diameter mode, remember that the value entered for the X axis is half the actual motion for that axis. Single-pass cycle examples in this manual are programmed in absolute programming mode. Incremental mode may be used if desired.

Use the G20 cycle to cut the diameter of a part while using the G24 cycle to cut the part's face.


Important: Descriptions in this chapter are written assuming the control is in the G18 plane and that plane has been defined as the ZX plane. If your system has a different plane active, operation of these features is different. Parameters are defined here assuming Z is the first axis in the plane, and X is the second axis in the plane. If, for example, the XZ plane is the currently active plane, descriptions in this document should be interpreted accordingly (i.e., Z axis description applies for X axis and X axis description applies to Z axis. See your system installer's documentation for details on the plane definitions on your system.

Single-pass O.D. and I.D. Roughing Cycle (G20)

G20 calls either a straight or a taper cutting cycle. This cycle is a single-pass cycle.

Use the G20 cycle to cut along the diameter of a workpiece (in this manual that means cuts parallel to the Z axis). The G20 cycle basically consists of the moves shown in Figure 21.1.

Figure 21.1
G20 Straight Cutting Cycle



1. Rapid approach to the part
2. Cutting feed into the part
3. Cutting feed out of the part
4. Rapid return to the start point



ATTENTION: When programming the single-pass cycle, the first move to the depth of cut is a rapid move. Make sure that the tool does not contact the part on this initial move.

The feedrate used in the single-pass cycle is the currently active programmed cutting feedrate. If desired, a different cutting feedrate may be specified in the single-pass cycle block.

The rapid feedrate (for the axis in motion as assigned in AMP) is used for the approach to the part and the return to start point.

G20 Straight O.D. and I.D. Roughing

The format for the G20 straight cutting cycle is as follows:

G20X__ Z__;


Where :	Is :
x__	is the depth of cut for the X axis. In incremental mode, specify the amount of infeed. In absolute mode, specify the coordinate position at the desired depth of cut. X may be programmed as either a diameter or radius value.
z__	is the length of cut along the Z axis. In incremental, specify the amount of feed across the part. In absolute, specify the coordinate position of the end point of the cutting stroke.

After the G20 block is executed, the control re-executes the cycle for any following block that commands axis motion (until the cycle is cancelled). The value of the axis word in that block is used to replace the parameter determined with that axis word in the original G20 block and the cycle is re-executed using these new parameters.

Example 21.1 Straight Cutting Cycle

```
G90G00X40.Z60.;
G20X28.Z25.F10.;
X24.;
X20.;
G00;
```


Figure 21.2
Results of Example 21.1



G20 Taper O.D. and I.D. Roughing

A G20 block that includes an I-word generates a turning pass that produces a taper.

Figure 21.3
G20 Taper Cutting Cycle



The format for the G20 single-pass cycle to cut a taper is:


G20X Z I ;

Where :	Is :
x <u> </u>	the depth of cut for the X axis at the end point of the cutting move into the part. In incremental mode specify the amount of infeed, in absolute mode specify the coordinate position at the desired depth of cut. X may be programmed as either a diameter or radius value.
z <u> </u>	the length of cut along the Z axis. In incremental mode specify the amount of feed across the part, in absolute mode specify the coordinate position of the end point of the cutting stroke.
I <u> </u>	the amount of change in the depth of cut for the X axis. I is always an incremental radius value. Figure 21.4 shows the relationship between the sign of the I value and the way that the cycle is performed. The control adds the value of I to the X depth to determine the start point of the cutting pass.

After the G20 block is executed, the control re-executes the cycle for any following block that commands axis motion (until the cycle is cancelled). The value of the axis word in that block is used to replace the parameter determined with that axis word in the original G20 block and the cycle is re-executed using these new parameters.

Figure 21.4 applies only if programming X and Z as incremental values. If programming X and Z as absolute values, the depth of taper I is added or subtracted (depending on its sign) to the absolute X axis position.


Figure 21.4
Effect of Positive and Negative Parameters in a G20 Block



Example 21.2
Taper Cutting

```
G90G00X50.Z106.;
G20X38.Z46.I-11.F.5;
X32.;
X26.;
X20.;
```

Figure 21.5
Results of Example 21.2




Single-pass Rough Facing Cycle (G24)

G24 calls either a straight or a tapered facing cycle. This cycle is a single-pass cycle (makes only one cutting pass over the workpiece each time it is called).

Use the G24 cycle to cut along the face of a workpiece (in this manual that means it cuts along the X axis). The G24 cycle basically consists of the moves shown in Figure 21.6.

1. Rapid approach to the part
2. Cutting feed into the part
3. Cutting feed out of the part
4. Rapid return to the start point

Figure 21.6
G24 Straight Facing Cycle



ATTENTION: When programming the single-pass cycle, the first move to the depth of cut is a rapid move. Make sure that the tool does not contact the part on this initial move.

The feedrate used in the single-pass cycle is the currently active programmed cutting feedrate. If desired, a different cutting feedrate may be specified in the single-pass cycle block.

The rapid feedrate (for the axis in motion as assigned in AMP) is used for the approach to the part and the return to start point.

G24 Straight Facing

The format for the G24 straight facing cycle is:


```
G24X__ Z__;
```

Where :	Is :
x__	the length of cut along the X axis. In incremental mode, specify the amount of feed across the part. In absolute mode, specify the coordinate position of the end point of the cutting stroke. X may be programmed as either a diameter or radius value.
z__	the depth of cut for the Z axis. In incremental mode, specify the amount of infeed. In absolute mode, specify the coordinate position at the desired depth of cut.

After the G24 block is executed, the control re-executes the cycle for any following block that commands axis motion (until the cycle is cancelled). The value of the axis word in that block is used to replace the parameter determined with that axis word in the original G24 block and the cycle is re-executed using these new parameters.

Example 21.3
Straight Facing Cycle


```
G90G00X30.Z22.;  
G24X10.Z15.F10.  
Z13.;  
Z11.;  
G00;
```

Figure 21.7
Results of Example 21.3

G24 Tapered Facing

A G24 block that includes a K-word generates a facing pass that produces a taper.

Figure 21.8
G24 Face Taper Cutting Cycle



The format for the G24 single-pass cycle to cut a taper on a face is:


```
G24X__Z__K__;
```

Where :	Is :
x__	the length of cut along the X axis. In incremental mode specify the amount of feed across the part, in absolute mode specify the coordinate position of the end point of the cutting stroke. X maybe programmed as either a diameter or radius value.
z__	the depth of cut for the Z axis at the end point of the cutting move into the part. In incremental mode specify the amount of infeed, in absolute mode specify the coordinate position at the desired depth of cut.
K__	the amount of change in the depth of cut for the Z axis. K is always an incremental value. Figure 21.9 shows the relationship between the sign of the K value and the way that the cycle is performed. The control adds the value of K to the Z depth to determine the start point of the cutting pass.

After the G24 block is executed the control re-executes the cycle for any following block that commands axis motion (until the cycle is cancelled). The value of the axis word in that block is used to replace the parameter determined with that axis word in the original G24 block and the cycle is re-executed using these new parameters.

Figure 21.9 applies only if programming X and Z as incremental values. If programming X and Z as absolute values, the depth of taper K is added or subtracted (depending on its sign) to the absolute Z axis position.

Figure 21.9
Effect of Positive and Negative Parameter Values in a G24 Block
(incremental X and X only)




After this G24 block is executed, the control re-executes the cycle for any following block that contains an axis word (until the cycle is cancelled). The value of this axis word is used to replace the parameter determined with that axis word in the original G24 block and the cycle is re-executed using these new parameters.

Example 21.4
Tapered Face Cutting

```
G90G00X43.Z55.;
G24X10.Z50.K-10.F10.;
Z45.;
Z40.;
G00;
```

Figure 21.10
Results of Example 21.4



END OF CHAPTER

Grooving/Cutoff Cycles

Chapter Overview

These two cycles are provided to perform grooving or cutoff operations:

G76 Face Grooving Cycle

G77 O.D. & I.D. Grooving Cycle

This chapter reviews the following major topics:

Topic:	On page:
Face grooving cycle	22-3
O.D. & I.D. cycle	22-6

Important: Descriptions in this chapter are written assuming the control is in the G18 plane and that plane has been defined as the ZX plane. If your system has a different plane active, operation of these features is different. Parameters are defined here assuming Z is the first axis in the plane, and X is the second axis in the plane. If, for example, the XZ plane is the currently active plane, descriptions in this document should be interpreted accordingly (i.e., Z axis description applies for X axis and X axis description applies to Z axis. See your system installer's documentation for details on the plane definitions on your system.

Figure 22.1 shows the tool path during a typical G76 Face Grooving Cycle. Figure 22.2 shows the tool path during a typical G77 O.D. Grooving Cycle.

Multiple grooves at a programmed distance and depth are cut by a single G76 or G77 block.

Figure 22.1
Tool Path during a G76 Face Grooving Cycle





Figure 22.2
Tool Path during a G77 O.D. Grooving Cycle



These cycles may also be used as cut off cycles. The tool infeeds into a piece of stock, as in grooving, except that it cuts all the way through the part. Then, instead of retracting the cutting tool straight out of the part, the tool is shifted a predetermined direction and amount before retracting. This shifting helps attain a good finish on the end of the part that has been cut.

Face Grooving Cycle (G76)

The G76 Face Grooving grooving cycle is typically used to cut multiple grooves in a workpiece or as a cut off cycle. When the cycle is executed the groove or cutoff is made by infeeding the tool into the workpiece in steps to allow the removal of chips. The initial groove width (or width of material removed during the infeed) is determined by the tool dimensions.

The first groove is cut from the X coordinate position of the tool prior to the execution of the G76 block.

The format for this cycle is:


G76X__Z__I__K__F__D__;

Where :	Is :
X__	the location where the last groove is cut. If only one groove is to be cut do not program X. This may be programmed as either an incremental or absolute value. Remember that its value is also affected by diameter or radius modes (G07 and G08).
Z__	the total depth of the groove from the Z coordinate position of the tool prior to the execution of the G76 block. If this cycle is to be used as a cut off cycle the depth programmed here should drive the tool through the face of the part. This value represents the location of the bottom of the groove cut. This may be programmed as either an incremental or absolute value.
I__	the distance between each groove. If the distance between the location of the last groove (programmed with X) and the next to the last groove is less than the value programmed with I, then the I value is not used to determine the position of the last groove. The last groove is always cut at the location programmed with X. The I parameter is always programmed as an incremental, radius value regardless of the current mode of the control.
K__	the amount that the cutting tool infeeds into the workpiece with each step. The step is followed by a retract of amount e (set in AMP by the system installer). The cutting tool then infeeds into the workpiece an amount K + e, retracts an amount e, infeeds K + e, retracts e, etc. This repeats until the total programmed depth of the groove Z is reached. When this depth is reached the cutting tool stops infeeding and either shifts an amount D (if programmed) or retracts to the starting coordinate at rapid feedrate. The K-word is always programmed as an incremental value regardless of the current mode of the control.
F__	the desired feedrate for the grooving infeed moves. The value entered with this parameter replaces the currently active feedrate. It is optional in the grooving block. If F is not programmed the currently active feedrate is used.
D__	the size of the incremental shift move made by the tool when the full depth of a cut off has been reached. This parameter must be programmed even if its value is zero when not using this cycle as a cutoff. A value other than zero is assigned to D only if the grooving cycle is being used as a cut off cycle. It is always an incremental value regardless of the current mode. The sign of the value programmed with the D parameter determines the shift direction and should move the tool away from the part. Programming this shift move helps to provide a good finish since the cutting tool is not touching the part when it is retracted at the rapid feedrate.



ATTENTION: The shift programmed with a D parameter is executed as a rapid move. Make sure that the cutting tool is clear to shift at the end of the grooving cycle.

Figure 22.3
G76 Face Grooving Cycle Parameters



The retraction amount e is set in AMP by the system installer.

Example 22.1
G76 Grooving Cycle


Absolute Programming

G00X7.6Z5.3;
G76X2.0Z3.6I-2.8K-0.8D0;

Incremental Programming

G00X-1.8Z-1.2
G76X-5.6Z1.7I-2.8K-0.8D0;

Figure 22.4
Results of G76 Grooving Cycle Example



O.D. & I.D. Grooving Cycle (G77)

The G77 O.D. & I.D. grooving cycle is typically used to cut multiple grooves in a workpiece or as a cut off cycle. When the cycle is performed the groove or cutoff is cut by infeeding the tool into the workpiece in steps to allow the removal of chips. The initial groove width (or width of material removed during the infeed) is determined by the tool dimensions.

The first groove is cut from the Z coordinate position of the tool prior to the execution of the G77 block.

The format for this cycle is:


G77X__Z__I__K__F__D__;

Where :	Is :
Z__	the location where the last groove is cut. If only one groove is to be cut do not program Z. This may be programmed as either an incremental or absolute value.
X__	the total depth of the groove from the X coordinate position of the tool prior to the execution of the G77 block. If this cycle is to be used as a cut off cycle the depth programmed here should drive the tool through the center or inside diameter of the part. If a cut off is being made from the inside of the part, it should drive the tool beyond the outside diameter of the part. This value represents the location of the bottom of the groove cut. It may be programmed as either an incremental or absolute value and is also affected by radius or diameter mode (G07 or G08).
K__	the distance between each groove. If the distance between the location of the last groove (programmed with Z) and the next to the last groove is less than the value programmed with K, then the K value is not used to determine the position of the last groove. The last groove is always cut at the location programmed with Z. The K parameter is always programmed as an incremental value regardless of the current mode of the control.
I__	the amount that the cutting tool infeeds into the workpiece with each step. The step is followed by a retract of amount e (set in AMP by the system installer). The cutting tool then infeeds into the workpiece an amount I + e, retracts an amount e, infeeds I + e, retracts e, etc. This repeats until the total programmed depth of the groove X is reached. When this depth is reached the cutting tool stops infeeding and either shifts an amount D (if programmed) or retracts to the starting coordinate at rapid feedrate. The I-word is always programmed as an incremental value regardless of the current mode of the control.
F	optional in the grooving block. If programmed the value entered with this parameter replaces the currently active feedrate used when infeeding into the part. If F is not programmed the currently active feedrate is used.
D__	the size of the incremental shift move made by the tool when the full depth of a cut off has been reached. This parameter must be programmed even if its value is zero when not using this cycle as a cutoff. A value other than zero is assigned to D only if the grooving cycle is being used as a cut off cycle. It is always an incremental value regardless of the current mode. The sign of the value programmed with the D parameter determines the shift direction and should move the tool away from the part. Programming this shift during a cutoff move helps to provide a good finish since the cutting tool is not touching the part when it is retracted at the rapid feedrate.



ATTENTION: The shift programmed with a D parameter is executed as a rapid move. Make sure that the cutting tool is clear to shift at the end of the grooving cycle.

Figure 22.5
G77 O.D. & I.D. Grooving Cycle Parameters



Example 22.2
G77 O.D. & I.D. Grooving Cycle Used As a Cutoff Cycle

Absolute Programming

G00G90X42.Z56.;


G77X19.Z21.I-8.K-14.D2.;

Incremental Programming

G00G91X-36.Z-9.;

G77X-23.Z-35.I-8.K-14.D2.;

Figure 22.6
Results of G77 Used as a Cutoff Cycle Example



END OF CHAPTER

Compound Turning Routines

Chapter Overview

Compound turning routines are routines that make multiple passes across the workpiece to cut a specific contour into the workpiece. A set of blocks, called **contour blocks**, define the final contour shape of the workpiece. A calling block, containing one of the following G-codes, sets the parameters for the execution of the routine and defines what blocks are used as the contour blocks.

Topic:	On page:
G73 O.D. and I.D. Roughing Routine (along Z-axis)	23-2
G74 Rough Facing Routine (along X-axis)	23-14
G75 Casting/Forging Roughing routine (parallel to work shape)	23-27
G72 O.D. and I.D. Finishing Routine	23-34

Important: Descriptions in this chapter are written assuming the control is in the G18 plane and that plane has been defined as the ZX plane. If your system has a different plane active, operation of these features is different. Parameters are defined here assuming Z is the first axis in the plane, and X is the second axis in the plane. If, for example, the XZ plane is the currently active plane, descriptions in this document should be interpreted accordingly (i.e., Z axis description applies for X axis and X axis description applies to Z axis. Refer to your system installer's documentation for details on the plane definitions on your system.


Important: Any rapid motions that are generated by the execution of a compound turning routine are always performed using exponential ACC/DEC. Refer to chapter 17. Compound turning routines ignore the AMP parameter that determine the **ACC/DEC type** normally used for rapid moves. If AMP parameters have not been configured to properly allow rapid motions using exponential ACC/DEC, a SERVO AMPLIFIER FAULT error may be generated during the execution of these routines.

O.D. and I.D. Roughing Routine (G73)

The G73 contour turning routine is used to rough out the contour of a workpiece by making repetitive cuts parallel to the Z axis. A final pass may be made with this routine to cut parallel to the final contour of the workpiece. A finish allowance may be left on the workpiece to be removed later by a G72 finishing routine.

This routine may be used in conjunction with Tool Tip Radius Compensation (TTRC). If TTRC is active when the routine is executed, the tool radius is taken into consideration on each consecutive pass.

Figure 23.1
Stock Removal in G73 Roughing Routine



The G73 block has a P and a Q parameter that call out the sequence numbers (N-words) of the first and last blocks defining the final contour to be cut into the workpiece. This set of blocks may be located anywhere after the calling block (even after an end of program command), as long as the calling block is in the same program as the set of contour blocks. This means that contour blocks can not be called from a subprogram or a macro unless the calling block is in that subprogram or macro.

The control can handle two different cases of the G73 routine. It automatically recognizes them and adapts the tool path accordingly.

Case 1:

A Case 1 G73 roughing routine is defined when the workpiece contour has no pockets. The following constraints must be met in order to successfully perform a Case 1 contouring routine:


- The first block of the contour program must command motion in only the X axis. No Z axis motion is permitted in the first block of the contour program.
- The workpiece contour either continuously increases or continuously decreases in both the X and Z axis except for the first block of the workpiece contour program.
- The first contour point in the contour blocks must be closer to the spindle centerline than the last contour point.

Case 2:

A Case 2 G73 roughing routine is defined when a workpiece contour contains a pocket. The following constraints must be met in order to successfully perform a Case 2 contouring routine:

- The first block of the workpiece contour program must contain motion in both the X and Z axis (the move from the start point to the first contour point must have motion in both axes).
- The workpiece contour may increase or decrease along the X axis after the first contour block. The workpiece contour must either continuously increase or continuously decrease along the Z axis after the first contour block.
- The first contour point of the contour blocks must be farther away (or at least equidistant) from the spindle centerline than the last contour point
- The first and last contour blocks must define beginning and ending sides to the contour. The first programmed endpoint must be farther away from the spindle centerline than the second programmed endpoint. The last programmed endpoint must be farther away from the spindle centerline than the next to last programmed endpoint.

Figure 23.2
Workpiece Finish Contour Case 1 and Case 2 (G73)




The G73 block is programmed with this format:

```
G73P__Q__U__W__I__K__D__R__F__S__T__;
```

Where :	Is :
P__	the sequence number (N-word) of the first block in the set of contour blocks that define the final contour.
Q__	the sequence number (N-word) of the last block in the set of contour blocks that define the final contour.
U W	<p>determine the finishing allowance that is left on the part when the routine is completed. This finish allowance is typically removed later in the program when a G72 finishing routine block is executed. The actual value of the finish allowance is equal to the average of the U and W parameters $(U+W)/2$. It is not necessary to enter both of these parameters in the calling block. If only one is entered, the control uses half of the entered parameter value as the finish amount. The finish allowance is optional and does not need to be programmed. See Figure 23.3 to determine the sign of U and W. U and W are always programmed as incremental values.</p> <p>Important: This manual makes the assumption that U and W are assigned in AMP as the incremental axis names that correspond to the X and Z axes respectively.</p> <p>Important: The value assigned to U is affected by radius/diameter mode (G08/G09). W is not affected by radius diameter mode. If programming in diameter mode the value of the finish allowance is really $((U/2)+W)/2$.</p>
I K	<p>determine the amount of stock to be removed on the final pass of the routine. The actual amount of material removed on this final pass is equal to the average of the I and K parameters $(I+K)/2$. It is not necessary to enter both of these parameters in the calling block. If only one is entered the control uses half of the entered parameter value. The final pass is optional and does not need to be programmed. It is not a roughing pass and it does not remove the finish allowance. A final pass cuts tool paths that are parallel to the workpiece finish shape.</p> <p>Important: This manual makes the assumption that I and K are assigned in AMP as the integrand axis names that correspond to the X and Z axes respectively.</p> <p>Important: The value assigned to I and K are always incremental, radius values regardless of the current mode (radius/diameter or incremental/absolute).</p> <p>Important: The system installer has the option of forcing a final pass to be made by setting the proper AMP parameter. If this is the case, the control cuts the final pass regardless of whether I or K is programmed. When I and K are not programmed and the system installer has forced a final pass to be made, the control assumes I and K to be zero.</p>

Where :	Is :
D__	<p>the depth of cut for each pass except the final pass. No sign needs to be entered for this parameter. The depth of cut for the final pass is determined with the I and K parameters. D is always an incremental value regardless of the current mode.</p> <p>Important: It is possible to override the programmed depth of cut (D) using an AMP parameter. The override setting is made in increments of 1% ranging from 0 - 255%. See documentation prepared by the system installer for details. The system installer may also determine a maximum allowable value of D in AMP. If D is programmed larger than the AMP threshold for D, the control overrides the programmed depth and use the AMP assigned maximum depth.</p>
R__	<p>used to program the retract amount made after each roughing pass. This retract amount is an incremental, radius value measured parallel to the X axis. Case 1 operations retract at a 45 degree angle to the X axis and Case 2 operations retract parallel to the X axis. This does not affect the programmed value of R, as R is always measured parallel to X. If no value for R is programmed then the control uses the value for the retract amount set in AMP by the system installer.</p>
F__	Active feedrate during the routine only (see chapter 17)
S__	Spindle speed during the routine only (see chapter 16)
T__	Tool number and tool offset to be used during the routine only (see chapter 19)
	<p>Important: Any F-, S-, or T-words that are in the set of contour blocks are ignored when the routine is executed. If programmed in the G73 block these words replace any previously active modal F-, S- or T-words for the remainder of the G73 routine operation only. When the G73 routine is completed the previously active modal F-, S-, and T-words are reactivated.</p>

Figure 23.3
Parameters for G73 Roughing Routine



In Figure 23.3, the contour blocks for this routine must define all motions that would cut the workpiece finished shape. The first block of the contour blocks must be the tool path from the start point to the point where the initial roughing pass begins (point A to B in Figure 23.3).

The contour blocks can be programmed with or without a feedrate, or with a G00 (rapid) command. The control uses the feedrate specified by the F-word in the G73 block during all roughing portions of the routine. During the final contour pass of the roughing cycle, the control executes your feedrate programmed in your contour block (unless you do not use one, then it uses the F-word in the G73 block). This final contour can even contain rapid moves (G00).

Important: The blocks preceding the G73 roughing block must have positioned the cutting tool to a location above the part (start point in the above figure) from which it can safely move to begin the roughing passes.

If cutting a Case 1 contour, the first of the contour blocks must command X axis motion only (no Z axis motion). If cutting a Case 2 contour, the first of the contour blocks must command both an X and Z axis motion.

The G73 roughing routine activates the Tool Tip Radius Compensation (TTRC) function regardless of whether it was active prior to the roughing routine. If TTRC was not active, the roughing routine uses the tool tip radius data of the previously programmed T-word. At the end of the roughing routine, TTRC is cancelled unless it was active prior to the roughing routine.


In Example 23.1, the workpiece contour blocks are blocks N11 - N14.

Example 23.1
Typical G73 Block Followed By Blocks Defining Final Contour

```
N005 G73 P11 Q14 U.2 W.2 D.12 F10.S210;
.
.
N010 M30;
N011 X25;
N012 X55 Z40;
N013 X65 Z35;
N014 X70 Z5;
```


The finish allowance words (U and W) in the G73 block are signed values dependent on the workpiece contours. Figure 23.4 illustrates this with the workpiece contour blocks generating the motions from point A to point C.

Figure 23.4
Effect of Positive and Negative Finish Allowance Parameters



The workpiece contour in Figure 23.5 is illegal for the G73 roughing routine and may not be cut. When this routine is used to cut a contour the Z axis motion must either continuously increase or continuously decrease. No reversal is allowed on the Z axis.


Figure 23.5
Illegal Contour for G73 Roughing Routine



G73 Tool Paths, Case 1

When the control executes a Case 1 G73 contouring path, these tool paths are generated:


Figure 23.6
Tool Paths for Case 1 G73 Roughing Routine



In Figure 23.6:

1. The tool is moved from the start point parallel to the X axis, at a feedrate F, a distance D as programmed in the G73 block.
2. A rough cut is made parallel to the Z axis, at a feedrate F to a point that intersects the workpiece contour path, minus the finishing allowance and final pass allowance (if any).
3. Retract from this point at a 45 degree angle, at a feedrate F, a distance R measured parallel to the X axis. The R value may be entered as a parameter in the G73 block. If no value for R is programmed then the control uses the value for the retract amount set in AMP by the system installer.

Figure 23.7
Tool Retraction in Case 1 G73



4. Rapid traverse back along the X and Z axes to the coordinate that the last rough cut started from in step 2.
5. Move parallel to the X axis, at a feedrate F, a distance D as programmed in the G73 block.

Steps 2 - 5 continue to repeat until the operation is aborted or the rough contour shape is completed. The rough contour shape is completed when the thickness of the remaining material to be removed from the workpiece is equal to the sum of the finishing allowance $(U+W)/2$ and the final pass allowance $(I+K)/2$. If no final pass is to be cut (no I or K in the G73 block), skip to step 7.

6. The final pass is made at the feedrate programmed in your contour block including rapid (if the contour does not contain a programmed feedrate, then it uses the F-word in the G73 block). Only the amount of material specified with the final pass allowance $(I+K)/2$ is cut. This cut is made parallel to the exact contour of the final workpiece, it is not a roughing pass. After this cut is complete, the only remaining material on the workpiece contour is the finish amount (if any) programmed with U and W.
7. The control returns the cutting tool, at a rapid feedrate, to the start point of the cycle.


Example 23.2
Case 1 G73 Roughing Routine

```

N011 G00X80.Z150.;
N012 G73P14Q18U.8W.8I.6K.6D18.R7.F100;
N013 M30;
N014 X20.;
N015 Z110.;
N016 X40.Z80.;
N017 Z50.;
N018 X70.Z40.;

```

Figure 23.8
Results of Example 23.2




In Figure 23.8, the final pass over the workpiece does not remove all material from the final contour. A finishing pass is still required (typically a G72) to remove the finish amounts U and W .

G73 Tool Paths, Case 2

If a pocket or multiple pockets are present in a workpiece contour, it requires a Case 2 G73 contour turning routine.

For Case 2, the control cuts each pocket separately starting with the pocket closest to the beginning of the operation. Figure 23.9 shows the tool paths for a typical multiple pocket contour. The retract path used after each roughing pass is different than for Case 1 roughing.


Figure 23.9
Tool Paths for Case 2 G73 Roughing Routine (with pockets)



Important: Figure 23.9 does not show the optional final pass being made. This is for drawing clarity.

In Figure 23.9, after the roughing passes of one pocket have been completed, the control does not perform a normal retract move out of the pocket. Instead the control follows the contour out of the pocket and then proceeds on to the next pocket or finishes the routine.

Figure 23.10
Tool Motion in Case 2 G73



In Figure 23.10, these tool paths are made:

1. The tool is moved from the start point to first contour point at feedrate F . This move must generate motion in both the X and Z axes.
2. The control generates a rough cut towards the spindle centerline, parallel to the workpiece contour, and offset by the finish allowance amount and the final pass amount (if any). This rough cut continues until the X axis value has decreased an amount D as programmed in the $G73$ block.
3. A rough cut is made parallel to the Z axis, at a feedrate F , to a point that intersects with the workpiece contour path minus the finish allowance and final pass allowance (if any).
4. A rough cut is made away from the spindle's centerline, parallel to the workpiece contour, and offset by the finish allowance amount and the final pass amount (if any). This rough cut continues, at a feedrate F , until the X axis value has increased an amount D as programmed in the $G73$ block (or until the last contour point is reached).
5. The tool is retracted from this point, on the X axis only, a distance R as programmed in the $G73$ block (or the default distance R set in AMP) at a feedrate F (see Figure 23.10)
6. A rapid traverse is made back along the X and Z axes to the Z coordinate that the last rough cut started from (in step 3) and an X coordinate that is D distance above the X coordinate of the last rough cut.
7. A rough cut is made at feedrate F , into the workpiece parallel to the X axis to the X coordinate of the last rough cut.

Steps 2 - 7 continue to repeat until the operation is aborted or the rough contour shape is completed. The rough contour shape is completed when the thickness of the remaining material to be removed from the contour is equal to the sum of the finish allowance $(U+W)/2$ and the final pass allowance $(I+K)/2$. If no final pass is to be cut, skip to step 9.


If a final pass is programmed in the $G73$ block (I or K values in the $G73$ block) it is not executed until all of the workpiece pockets have been completely roughed out.

8. The final pass is made at the feedrate programmed in your contour block including rapid moves (if no feedrate is programmed in the contour blocks, the control uses the F-word in the G73 block). Only the amount of material specified with the final pass allowance $(I+K)/2$ is cut. This cut is made parallel to the exact contour of the final workpiece, it is not a roughing pass. After this cut is complete, the only remaining material on the workpiece contour is the finish amount (if any) as programmed with U and W.
9. The control returns the cutting tool, at a rapid feedrate, to the start point of the cycle.

Example 23.3
Case 2 G73 Roughing Routine

```
N010 G00X100.Z150.;
N011 G73P13Q20U.8W.8I.6K.6D10.R7.F100.;
N012 M30;
N013 X85.Z135.;
N014 X15.Z115.;
N015 Z82.;
N016 X45.Z72.;
N017 Z55.;
N018 X35.Z50.;
N019 Z22.;
N020 X80.Z7.;
```

Figure 23.11
Results of Example 23.3




Rough Facing Routine (G74)

The G74 rough facing routine is used to rough out the contour of a workpiece by making repetitive cuts parallel to the X axis. A final pass may be made with this routine to cut parallel to the final contour of the workpiece. At the completion of this routine a finish allowance may also be left on the workpiece to be removed later by a G72 finishing routine.

This routine may be used in conjunction with Tool Tip Radius Compensation (TTRC). If TTRC is active when the routine is executed the tool radius is taken into consideration on each consecutive pass.

Figure 23.12
Stock Removal in G74 Rough Facing



The G74 block has a P and Q parameter that call the sequence numbers (N-words) of the first and last blocks defining the final contour to be cut into the workpiece. This set of blocks may be located anywhere after the calling block (even after an end of program command), as long as the calling block is in the same program as the set of contour defining blocks. This means that contour blocks can not be called from a subprogram or a macro unless the calling block is in that subprogram or macro.

The control handles two different cases of the G74 routine and automatically recognizes them and adapts the tool path accordingly.

Case 1:

A Case 1 G74 rough facing routine is defined when the workpiece contour has no pockets. The following constraints must be met in order to successfully perform a Case 1 rough facing routine:

- The first block of the contour program must command motion in only the Z axis. No X axis motion is permitted in the first block of the contour program.
- The contour either continuously increases or continuously decreases in both the X and Z axis except for the first block of the contour program.


- The first contour point in the contour blocks must be closer to the spindle centerline than the last contour point.

Case 2:

A Case 2 G74 rough facing routine is defined when a workpiece contour contains a pocket. The following constraints must be met in order to successfully perform a Case 2 rough facing routine:

- The first block of the contour program must contain motion in both the X and Z axis (the move from the start point to the first contour point must have motion in both axes).
- The workpiece contour may increase or decrease along the Z axis after the first contour block. The workpiece contour must either continuously increase or continuously decrease along the X axis after the first contour block.
- The first contour point of the contour blocks must be farther away (or at least equidistant) from the spindle face than the last contour point.
- The first and last contour blocks must define beginning and ending sides to the contour. The first programmed endpoint must be farther away from the spindle face than the second programmed endpoint. The last programmed endpoint must be farther away from the spindle face than the next to last programmed endpoint.

Figure 23.13
Workpiece Finish Contour Case 1 and Case 2 (G74)



The G74 block is programmed with the following format:


```
G74P_Q_U_W_I_K_D_R_F_S_T_;
```

Where :	Is :
P__	the sequence number (N-word) of the first block in the set of contour blocks that define the final contour.
Q__	the sequence number (N-word) of the last block in the set of contour blocks that define the final contour.
U W	<p>determine the finishing allowance that is left on the part when the routine is completed. This finish allowance is typically removed later in the program when a G72 finishing routine block is executed. The actual value of the finish allowance is equal to the average of the U and W parameters $(U+W)/2$. It is not necessary to enter both of these parameters in the calling block. If only one is entered, the control uses half of the entered parameter value as the finish amount. The finish allowance is optional and does not need to be programmed. See Figure 23.15 to determine the sign of U and W. U and W are always programmed as incremental values.</p> <p>Important: This manual makes the assumption that W and U are assigned in AMP as the incremental axis names that correspond to the Z and X axes respectively.</p> <p>Important: The value assigned to U is affected by radius/diameter mode (G08/G09). W is not affected by radius diameter mode. If programming in diameter mode the value of the finish allowance is really $((U/2)+W)/2$.</p>
I K	<p>determine the amount of stock to be removed on the final pass of the routine. The actual amount of material removed on this final pass is equal to the average of the I and K parameters $(I+K)/2$. It is not necessary to enter both of these parameters in the calling block. If only one is entered the control uses half of the entered parameter value. The final pass is optional and does not need to be programmed. It is not a roughing pass and it does not remove the finish allowance. A final pass cuts tool paths that are parallel to the workpiece finish shape.</p> <p>Important: This manual makes the assumption that I and K are assigned in AMP as the integrand axis names that correspond to the X and Z axes respectively.</p> <p>Important: The value assigned to I is always an incremental, radius value regardless of the current mode (radius/diameter). K is always an incremental value and is not affected by radius/diameter mode.</p> <p>Important: The system installer has the option of forcing a final pass to be made by setting the proper AMP parameter. If this is the case the control cuts the final pass regardless of whether I or K is programmed. When I and K are not programmed and the system installer has forced a final pass to be made, the control assumes I and K to be zero.</p>
D__	<p>the depth of cut for each pass except the final pass. No sign needs to be entered for this parameter. The depth of cut for the final pass is determined with the I and K parameters. D is always an incremental value regardless of the current mode.</p> <p>Important: It is possible to override the programmed depth of cut (D) using an AMP parameter. The override setting is made in increments of 1% ranging from 0-255%. See documentation prepared by the system installer for details. The system installer may also determine a maximum allowable value of D in AMP. If the D value programmed is larger than the maximum allowed in AMP, the control overrides the programmed value and use the AMP assigned maximum value.</p>
R__	used to program the retract amount made after each rough facing pass. This retract amount is an incremental, radius value measured parallel to the Z axis. Case 1 operations retract at a 45 degree angle to the Z axis and Case 2 operations retract parallel to the Z axis. This does not affect the programmed value of R, as R is always measured parallel to Z. If no value for R is programmed then the control uses a value for the retract amount set in AMP by the system installer.

Where :	Is :
F :	Active feedrate during the routine only (see chapter 17)
S :	Spindle speed during the routine only (see chapter 16)
T :	Tool number and tool offset to be used during the routine only (see chapter 19)

Important: Any F-, S-, or T-words that are in the set of contour blocks are ignored when the routine is executed. If programmed in the G74 block these words replace any previously active modal F-, S-, or T-words for the remainder of G74 routine operation only. When the G74 routine is completed the previously active modal F-, S-, and T-words are reactivated.

Figure 23.14
Parameters for G74 Rough Facing



In Figure 23.14, the contour blocks for this routine must define all motions that would cut the workpiece finished shape. The first block of the contour blocks must be the tool path from the start point to the point where the initial roughing pass begins. The first block of the contour blocks may not be a rapid move (G00).

Important: The blocks preceding the G74 roughing block must have positioned the cutting tool to a location above the part (start point in the above figure) from which it can safely move to begin the roughing passes. If cutting a Case 1 contour, the first of the contour blocks must command Z axis motion only (no X axis motion). If cutting a Case 2 contour, the first of the contour blocks must command both an X and Z axis motion.

The G74 roughing routine activates the Tool Tip Radius Compensation (TTRC) function regardless of whether it was active prior to the roughing routine. If TTRC was not active, the roughing routine uses the tool tip radius data of the previously programmed T-word. At the end of the roughing routine, TTRC is cancelled unless it was active prior to the roughing routine.


In Example 23.4, the workpiece contour blocks are blocks N11 - N14.

Example 23.4
Typical G74 Block Followed by Blocks Defining Final Contour

```
N005 G74 P11 Q14 U.2 W.2 D1.2 F10. S210;  
.  
.  
N010 M30;  
N011 Z25;  
N012 X55 Z40;  
N013 X40 Z65;  
N014 X30 Z75;
```


The finish allowance words (U and W) in the G74 block are a signed value dependant on the workpiece contours. Figure 23.15 illustrates this with the workpiece contour blocks generating the motions from point A to C.

Figure 23.15
Effect of Positive and Negative Finish Allowance Parameters



In Figure 23.16, the workpiece contour is illegal for the G74 roughing routine and may not be cut. When this cycle is used to cut a contour the X axis motion must either constantly increase or constantly decrease. No reversal is allowed on the X axis.


Figure 23.16
Illegal Contour for G74 Rough Facing



G74 Tool Paths, Case 1

When the control executes a Case 1 G74 rough facing routine the following tool paths are generated:


Figure 23.17
Tool Paths for Case 1 G74 Rough Facing



In Figure 23.17:

1. The tool is moved from the start point parallel to the Z axis, at a feedrate F, a distance D as programmed in the G73 block.
2. A rough cut is made parallel to the X axis, at a feedrate F to a point that intersects the workpiece contour path, minus the finishing allowance and final pass allowance (if any).
3. Retract from this point at a 45 degree angle, at a feedrate F, a distance R measured parallel to the Z axis. The R value may be entered as a parameter in the G74 block. If no value for R is programmed then the control uses the value for the retract amount set in AMP by the system installer.

Figure 23.18
Tool Retraction in Case 1 G74



4. Rapid traverse back along the X and Z axes to the coordinate that the last rough cut started from (in step 2).
5. Move parallel to the Z axis, at a feedrate F, a distance D as programmed in the G74 block.

Steps 2 - 5 continue to repeat until the operation is aborted or the rough contour shape is completed. The rough contour shape is completed when the thickness of the remaining material to be removed from the workpiece is equal to the sum of the finishing allowance $(U+W)/2$ and the final pass allowance $(I+K)/2$. If no final pass is to be made skip to step 7.

6. The final pass is made at the feedrate programmed in your contour block including any rapid moves (if no feedrate is programmed in the contour blocks the control uses the F-word programmed in the G74 block). Only the amount of material specified with the final pass allowance $(I+K)/2$ is cut. This cut is made parallel to the exact contour of the final workpiece, it is not a roughing pass. After this cut is complete, the only remaining material on the workpiece contour is the finish amount (if any) programmed with U and W.

7. The control returns the cutting tool, at a rapid feedrate, to the start point of the cycle.


Example 23.5
Case 1 G74 Rough Facing Routine

```

N011 G00X80.Z130.;
N012 G74P14Q19U6.W6.I10.K10.D10.R8.F10.S60;
N013 M30;
N014 Z40.;
N015 X60.;
N016 X40.Z60.;
N017 Z80.;
N018 X30.Z90.;
N019 Z110.;
N020 X20.Z130.;

```

Figure 23.19
Results of Example 23.5




In Figure 23.19, the final pass over the workpieces does not remove all material from the final contour. A finishing pass is still required (typically a G72) to remove the finish amounts U and W.

G74 Tool Paths, Case 2

If a pocket or multiple pockets are present in a workpiece face, it requires a Case 2 G74 rough facing routine.

For Case 2, the control cuts each pocket separately, starting with the pocket closest to the beginning of the operation. Figure 23.20 shows the tool paths for a typical multiple pocket contour. The retract path used after each roughing pass is different than for Case 1 rough facing.


Figure 23.20
Tool Paths for Case 2 G74 Rough Facing Routine (with pockets)



Important: Figure 23.20 does not show the optional final pass being made. This is for drawing clarity.

In Figure 23.20, after the roughing passes of one pocket have been completed, the control does not perform a normal retract move out of the pocket. Instead the control follows the part contour out of the pocket and then proceeds on to the next pocket or finishes the routine.

Figure 23.21
Tool Motion in Case 2 G74



In Figure 23.21, these tool paths are made:

1. The tool is moved from the start point to the first contour point at feedrate F . This move must generate motion in both the X and Z axes.
2. The control generates a rough cut towards the spindle face, parallel to the workpiece contour, and offset by the finish allowance amount and the final pass amount (if any). This rough cut continues until the Z axis value has decreased an amount D as programmed in the $G74$ block.
3. A rough cut is made parallel to the X axis, at a feedrate F , to a point that intersects with the workpiece contour path minus the finish allowance and final pass allowance (if any).
4. A rough cut is made away from the spindle face, parallel to the workpiece contour, and offset by the finish allowance amount and the final pass amount (if any). This rough cut continues, at a feedrate F , until the Z axis value has increased an amount D as programmed in the $G74$ block.
5. The tool is retracted from this point, on the Z axis only, a distance R as programmed in the $G74$ block (or the default distance R set in AMP) at a feedrate F (see Figure 23.21).

6. A rapid traverse is made back along the X and Z axes to the X coordinate that the last rough cut started from (in step 3) and a Z coordinate that is D distance above the Z coordinate of the last rough cut.
7. A rough cut is made at feedrate F, into the workpiece parallel to the Z axis to the Z coordinate of the last rough cut.

Steps 2 - 7 continue to repeat until the operation is aborted or the contour shape is completed. The contour shape is completed when the thickness of the material remaining to be removed from the contour is equal to the sum of the finish allowance $(U+W)/2$ and the final pass allowance $(I+K)/2$. If no final pass is to be cut, skip to step 9.

If a final pass is programmed in the G74 block (I or K values in the G74 block) it is not executed until all of the workpiece pockets have been completely roughed out.

8. The final pass is made at the feedrate programmed in your contour block including any rapid moves (if no feedrate is programmed in the contour blocks, the control uses the F-word programmed in the G74 block). Only the amount of material specified with the final pass allowance $(I+K)/2$ is cut. This cut is made parallel to the exact contour of the final workpiece, it is not a roughing pass. After this cut is complete, the only material remaining on the workpiece contour is the finish amount (if any) as programmed with U and W.
9. The control returns the cutting tool, at a rapid feedrate, to the start point of the cycle.


Example 23.6 **Case 2 G74 Rough Facing Routine**

```

N011 G00X128.Z120.;
N012 G74P14Q21U.6W.6I.8K.8D10.R7.F10.S60;
N013 M30;
N014 X120.Z110.;
N015 X100.Z30.;
N016 X80.;
N017 X70.Z70.;
N018 X60.;
N019 X50.Z50.;
N020 X30.;
N021 X20.Z107.;

```

Figure 23.22
Results of Example 23.6




Casting/Forging Roughing Routine (G75)

In the G75 casting/forging roughing routine (also called pattern repeating routine), the control generates multiple cuts, each parallel to the workpiece final shape. Each cut is offset from the other an amount determined by the I, K and D parameters.

Through this process, a shape similar to the finished contour is obtained when the routine is completed. At the completion of this routine a finish allowance is usually left on the workpiece to be removed later by a G72 finishing routine.

Figure 23.23
Pattern Repeating Routine



The calling block references the sequence numbers (N-words) of the first and last blocks of the contour blocks defining the final contour of the workpiece. This set of blocks may be located anywhere after the calling block (even after an end of program command), as long as the calling block is in the same program as the set of contour defining blocks. Contour blocks cannot be in a subprogram or a macro unless the calling block is in that subprogram or macro.


The G75 block is programmed with this format:

G75 P__ Q__ I__ K__ U__ W__ D__ F__ S__ T__;

Where :	Is :
P__	The sequence number of the first block in the set of contour blocks that defines the finished workpiece shape.
Q__	The sequence number of the last block in the set of contour blocks that defines the finished workpiece shape.
U W	<p>Finish allowance. These parameters determine the finishing allowance that is left on the part when the routine is completed. This finish allowance is typically removed later in the program when a G72 finishing routine block is executed. The actual value of the finish allowance is equal to the average of the U and W parameters $((U+W)/2)$. It is not necessary to enter both of these parameters in the calling block. If only one is entered, the control uses half of the entered parameter value as the finish amount. The finish allowance is optional and does not need to be programmed. See Figure 23.25 to determine the sign of U and W. U and W are always programmed as incremental values.</p> <p>Important: This manual makes the assumption that W and U are assigned in AMP as the incremental axis names that correspond to the Z and X axes respectively.</p> <p>Important: The value assigned to U is affected by radius/diameter mode (G08/G09). W is not affected by radius diameter mode. If programming in diameter mode the value of the finish allowance is really $((U/2)+W)/2$.</p>
I K	<p>These parameters determine the incremental distance between the first and last pass of the routine. This distance is equal to the average of the I and K parameters $((I+K)/2)$. The location of the last pass is determined by the contour blocks and the finish amount $((U+W)/2)$, if any is programmed. I and K must be programmed. They are neither positive nor negative.</p> <p>Important: This total incremental distance should be less than one tool radius if cutter compensation is on when this cycle is executed.</p> <p>Important: This manual makes the assumption that K and I are assigned in AMP as the integrand axis names that correspond to the Z and X axes respectively.</p> <p>Important: The values assigned to I and K are always an incremental, radius value regardless of the current mode (radius/diameter or absolute/incremental).</p>
D__	Number of passes. The integer value entered with this parameter determines how many passes are made to reach the final pass. The depth of each pass is determined by dividing $(I+K)/2$ by D-1. The value entered with D must be an integer.
F__	Active feedrate during the routine only (see chapter 17)
S__	Spindle speed during the routine only (see chapter 16)
T__	Tool number and tool offset to be used during the routine only (see chapter 19)

Important: Any F-, S-, or T-words that are in the set of contour blocks are ignored when the routine is executed. If these words are to be changed from their current value, it is necessary to program an F-, S-, or T-word in the G75 block. If programmed in the G75 block these words replace any previously active modal F-, S-, or T-words for the remainder of G75 routine operation only. When the G75 routine is completed the previously active modal F-, S-, and T-words are reactivated.

Figure 23.24
Pattern Repeating Routine Parameters



In Figure 23.24, the contour blocks for this routine must define all motions that would cut the workpiece finished shape and the tool path that connects the start point of the routine to the first block of the workpiece finished shape. The first block of the contour blocks must be the tool path from the start point to the first block of the workpiece finished shape. It is assumed that some other blocks have positioned the cutting tool to a position above the part (start point in the above figure).

The arc and pocket in the example above get smaller and smaller as the passes get farther away from the final contour. If you specify passes very far from the final contour, the cutting tool can be too large to cut the resulting arc or pocket. When this occurs the control generates the error message "INVALID CYCLE PROFILE". Resolve this problem by making the distance from the final pass to the first pass smaller. This cycle was not designed to remove large amounts of material. Its intended design is to perform cleanup passes on castings or forgings. If you must remove large amounts of material you should use one of the roughing/facing routines discussed earlier in this chapter.

Prevent this invalid cycle profile error by keeping the right portion of the following equation less than the radius of any arcs in your cycle profile.

$$R \geq \sqrt{(I+U)^2 + (K+W)^2} + (\text{tool radius})$$

The same basic equation can apply to other contours. If the length of a block in the contour is less than the right portion of the above equation, you can get an “INVALID CYCLE PROFILE” error depending on your part contour. For contours with pockets, the width of the pocket must be at least twice the value of the right hand portion of the above equation. In general this error is a result of removing metal too far from the original part profile (I, K, U, or W too large) and reducing this distance typically resolves the error condition.

The workpiece contour blocks can be at any location within the same program containing the G75 block (even after an end of program block). They can not be resident in a subprogram or macro that is called by the program containing the G75 block. Contour blocks can be either circular or linear blocks. Any F-, S-, or T-words that are programmed in this set of contour blocks are ignored when they are executed as workpiece contour blocks in the G75 mode.

In Example 23.7, the workpiece contour blocks are blocks N11 - N14.

Example 23.7
Typical G75 Block Followed By Blocks Defining Final Contour

```
N005 G75P11Q14I2.W2.D3.F10.S210;
.
.
.
N010 M30.;
N011 X24.;
N012 X55.Z40.;
N013 X65.Z35.;
N014 X70.Z5.;
```


The control generates multiple passes each offset from the other by an amount equal to the total material to be removed $(I+K/2)$ divided by the number of passes (D) minus 1. The tool paths repeat until (D) tool paths have been made across the part. Each tool path is shifted sequentially by the distance obtained in this division to generate roughing paths. If a finishing allowance (U, W) was programmed in the block, it is left uncut. After the completion of the roughing routine, the cutting tool returns to the routines starting point.

The G75 routine can be programmed while the tool tip radius compensation mode (G41 or G42) is active. If tool tip radius compensation is active prior to the G75 block it remains active throughout the execution of the routine.

The G75 roughing routine activates the Tool Tip Radius Compensation (TTRC) function regardless of whether it was active prior to the roughing routine. If TTRC was active, the roughing routine uses the previously programmed T-word to compensate for the tool tip radius. At the end of the roughing routine, TTRC is cancelled unless it was active prior to the roughing routine.

The finish allowance words (U and W) in the G75 block are signed values dependant on the workpiece contours. Figure 23.25 illustrates this with the workpiece contour program generating the blocks from point A to C.

Figure 23.25
Effect of Positive and Negative Finish Allowance Parameters



The control generates multiple passes each offset from the other by an amount equal to the total material to be removed (I and K) divided by the number of passes (D) minus 1. These tool paths repeat until (D) tool paths have been made across the part. At completion of the last path the tool returns to the start point of the routine.

When the G75 routine is executed in single block mode, the execution of the routine stops after each complete iteration of the routine (a total of D iterations are made).


Example 23.8
G75 Casting/Forging Roughing Routine

```

N11 G00X100.Z175.;
N12 G75P14Q20I8.K12.U5.W5.D3F.1S100;
N13 M30;
N14 G00 X20.Z125;
N15 G01 Z85.;
N16 G02X30.Z75.R10.;
N17 G01X50.;
N18 Z55.;
N19 G02X60.Z35.R20.;
N20 G01X80.;

```

Figure 23.26
Results of G75 Casting/Forging Roughing Routine Example



O.D. and I.D. Finishing Routine (G72)

The G72 finish routine is normally executed after the completion of a contouring routine (G73, G74 or G75). With the G73, G74, and G75 routines a finish allowance is left on the workpiece if a U- and/or K-word is specified in the routine. The G72 routine is used to remove this finish allowance and cut the workpiece to within the specified tolerance of the actual workpiece finished shape.

The calling block references sequence numbers of the first and last blocks of the contour blocks defining the final contour of the workpiece. This set of blocks may be located anywhere after the calling block (even after an end of program command), as long as the calling block is in the same program as the set of contour defining blocks. This means that contour blocks can not be called from a subprogram or a macro unless the calling block is in that subprogram or macro. This routine actually executes the set of contour defining blocks as entered in the program.

The G72 finishing routine is usually performed at a lower feedrate to produce the desired finish results that are not necessary using the other rough contouring routines for rapid removal of material.

The program format for this finishing routine is indicated below:

```
G72 P__ Q__;
```

Where :	Is :
P__	The sequence number of the first block in the set of contour blocks that defines the finished workpiece shape.
Q__	The sequence number of the last block in the set of contour blocks that defines the finished workpiece shape.

In the G72 finishing routine, the contour of the finished workpiece can be described by a set of linear and/or circular blocks bounded by the sequence numbers specified with parameters P and Q. It is assumed that some other blocks have positioned the cutting tool to some position above the part. This position should be the start point of the workpiece contour blocks.

The workpiece contour blocks may be at any location within the same program containing the G72 block (even after an end of program M02 or M30). They may not be resident in a subprogram or macro that is called by the program containing the G72 block.

The control recognizes F-, S-, or T-words programmed in this set of contour blocks and uses these values for the routines execution. These values are not ignored as in the G73, G74, and G75 routines (F-words are used in the G73, G74, and G75 routines).

In Example 23.9, the workpiece contour blocks are blocks N11 - N14.

Example 23.9
Typical G72 Block Followed by Blocks Defining Final Contour

```
N005 G72P11Q14;  
.  
.  
.  
N010 M30.;  
N011 X24.;  
N012 X55.Z40.;  
N013 X65.Z35.;  
N014 X70.Z5.;
```

The G72 routine can be programmed while the tool tip radius compensation mode (G41 or G42) is active. If tool tip radius compensation is active prior to the G72 block, it remains active throughout the execution of this routine.

END OF CHAPTER

Thread Cutting

Chapter Overview

The 9/PC control provides two methods of thread cutting:

- **Single-pass thread cutting**
G33 and G34 blocks generate a single thread cutting pass. G33 can cut straight, tapered, face, multistart, and multiblock threads. G34 can cut thread passes of increasing or decreasing leads.
- **Automatic thread-cutting cycles**
G21 and G78 provide for fully automatic thread cutting with multiple passes at a programmed depth, including springing pass and clean-up pass options.

This chapter describes the following topics that relate to thread cutting:

Topic:	On page:
Considerations for thread cutting	24-2
Chamfering your threads	24-4
Single pass threading mode	24-6
Single pass variable lead thread cutting	24-12
Single pass threading cycle	24-15
O.D. & I.D. multipass threading routine	24-20

Important: Descriptions in this chapter are written assuming the control is in the G18 plane and that plane has been defined as the ZX plane. If your system has a different plane active, operation of these features is different. Parameters are defined here assuming Z is the first axis in the plane, and X is the second axis in the plane. If, for example, the XZ plane is the currently active plane, descriptions in this document should be interpreted accordingly (i.e., Z axis description applies for X axis and X axis description applies to Z axis. See your system installer's documentation for details on the plane definitions on your system.

Considerations for Thread Cutting

When performing threading operations, remember:

- **Emergency Stop** - Pressing the emergency stop during threading causes all axes to come to a rapid stop. This likely causes damage to the part or tool and resuming the threading moves is not possible.
- **<CYCLE STOP> (cycle suspend)** - A cycle stop does not occur if this button is pressed during a threading pass; instead the block executes in this manner:
If G33, or G34 threading is being executed then axis motion continues and cycle stop is ignored.
If G78 or G21 threading is being executed, one of two possible paths is taken by the control. If the threading retract feature has been enabled, the control immediately chamfers out of the thread, retracts the tool and then returns to the start point of the threading cycle. If no threading retract is enabled then the control continues execution until it has completed the entire pass of the threading cycle and returned to the start point of the move.
- **Overrides** - During the execution of any threading pass, all feedrate overrides are fixed at 100%.
- **Single Block** - In single block mode the entire cycle is executed for G21. For G78 one complete sub-cycle (including the return move to the initial point) is performed each time cycle start is pressed. When performing single pass threading (G33 or G34) motion stops at the end of the threading block typically resulting in a ringing of the thread.
- **Dry Run** - Whether or not the “dry run” and spindle speed override functions are operable during threading is determined by the system installer’s logic program.
- **Radius/Diameter Mode** - The control performs threading in either radius or diameter modes. Radius/Diameter mode only affects the controls interpretation of the X parameter.
- **Start point** - Due to axis acceleration and other machine dynamics, the threading cycles should be programmed such that the axes have room to attain speed prior to contacting the workpiece. Failure to do so may result in the initial thread lead being incorrect.
- **Controlling spindle** - On systems with multiple spindles, the controlling spindle (selected with G12) is the synchronized spindle used for thread cutting. The controlling spindle RPM, in conjunction with the programmed thread lead (F or E), determine the threading axis feedrate.

- **Axis feedrates** - When threading, the speed of the cutting axis is determined by the controlling spindle speed and the thread lead through this equation:


$$\begin{aligned} \text{axis feedrate} &= (S) / (F \text{ inches per revolution}) \\ &= (S) / (E \text{ threads per inch}) \\ &= (S)(E \text{ inches per thread}) \end{aligned}$$

Where :	Is :
S	the actual speed of the controlling spindle (programmed spindle speed times the spindle speed override switch setting in percent)
F	threads per revolution or degree depending on the current active mode
E	threads per inch or inches per revolution as determined in AMP by your system installer.

The programmer should use this equation to verify that the feedrate resulting from the thread parameters does not exceed the maximum allowable feedrate for the cutting axis. Otherwise an error results and axis motion stops. This equation can also be applied to face threads and tapered threads.

- **Pullout angles** - During threading cycles, the control synchronizes the moves of the X and Z axes with the spindle speed. This occasionally may force the X axis to move quite rapidly in order to produce the desired thread taper or pullout angles at the rates dictated by the active spindle speed. Compounded with the fact that many machines have X axis feedrate limits lower than those for the Z axis, the result may be velocity limitations. This is best prevented by first executing a Feed Check prior to actually cutting the threads and then reducing spindle speed or changing the pullout angle where necessary.
- **Tapered Thread Lead** - When cutting a tapered thread, the thread lead (E- or F-word) is applied to the axis that travels the greatest distance from the start to the end of the threading pass.
- **Infeed** - Plunge infeed relies on a sharp tool made at the exact thread angle that cuts on both sides of the tip as it is fed perpendicular to the work on successive passes. On larger threads, this type of infeed may cause vibration. In that case, angular infeed may be preferred. This results in the tool being fed along the thread flank with each successive pass, meaning only one side of the tip cuts. Figure 24.1 illustrates plunge and angular infeed.

Figure 24.1
Angular versus Plunge Infeed



The G78 threading pass allows the selection of different infeed types by programming a P-word. If you use any of the other threading methods, it is necessary to insert a small Z move to generate an angular feed.

- **Form Cut Threading** - The auto threading cycles (G21 and G78) assume a sharp triangular tool. If you use a shaped-tip tool, the tool loading is affected. Specifically, the first cut is loaded slightly less than successive cuts. Though generally insignificant, if this is a concern, we suggest that the initial cut depth be compromised as necessary to ensure that the tool is not overloaded on successive passes.

Chamfering Your Threads

Using Thread Chamfer

The thread chamfer feature, enabled in logic, cuts a chamfer at the end of a thread cutting pass. When the feature is activated, the control automatically cuts a chamfer at the end of each thread cutting pass to assure the tool is fully out of the thread before it is retracted.

This feature prevents the “ring” at the end of the thread that typically occurs when the control stops threading motion to retract the tool. This ring occurs when the threading axis reaches the endpoint of the thread and decelerates before executing the retract move. Typically spindle RPM does not compensate for this deceleration of the threading axis thus causing a ring at the end of the thread.

Both the thread retract and thread chamfer use the same values (set in AMP) for the pullout distance “r” and pullout angle “a” of the chamfer. “r” is entered as the number of threads to be chamfered, “a” is entered as the angle of the chamfer in degrees measured from the same axis as the thread lead.

Important: This feature may only be used with the G78 or G21 threading cycle. It is ignored if a G33 or G34 threading pass is being made.

Using Thread Retract


Enabled in logic, thread retract lets you interrupt a thread cutting operation without damaging the thread by pressing **<CYCLE STOP>**. When the operation is interrupted, the control automatically performs a retract (by cutting a chamfer) out of the thread to prevent damage to the thread due to ringing. Once free of the thread the control retracts the tool and returns it to the start point. Also, program execution stops at this point.

If you attempt to interrupt the thread cutting operation without thread retract active, the control does not interrupt the operation until the end of the currently executing threading pass.

Thread Chamfer and Thread Retract Parameters

Both the thread retract and thread chamfer use the same values (set in AMP) for the pullout distance “r” and pullout angle “a” of the chamfer. “r” is entered as the number of threads to be chamfered, “a” is entered as the angle of the chamfer in degrees measured from the same axis as the thread lead.


Figure 24.2
Ringing occurs when retracting from thread without using thread chamfer or thread retract.



Single Pass Threading Mode (G33)

The G33 thread cutting mode can cut straight, tapered, face, and multistart threads that have constant thread leads (use G34 to cut threads that do not have a constant lead). The G33 thread cutting mode is a mode, not a cycle and does not generate any extra motion blocks. This mode synchronizes the thread cutting tool motion with the spindle to allow programming multiple passes over the same threads.

Figure 24.3
Constant Lead Threads



The format for the G33 thread cutting operation is:


Parallel thread $G33Z_{\text{---}} \left\{ \begin{array}{l} F_{\text{---}} \\ E_{\text{---}} \end{array} \right\} Q_{\text{---}};$

Tapered thread $G33X_{\text{---}}Z_{\text{---}} \left\{ \begin{array}{l} F_{\text{---}} \\ E_{\text{---}} \end{array} \right\} Q_{\text{---}};$

Face thread $G33X_{\text{---}} \left\{ \begin{array}{l} F_{\text{---}} \\ E_{\text{---}} \end{array} \right\} Q_{\text{---}};$

Where :	Is :
x	This parameter is the end point of the thread cutting move in the X axis. This parameter may be an incremental or absolute and radius or diameter value. If not present there must be a Z parameter. If an X parameter is present, it indicates either a face, tapered, or lead-in thread. When used in a G33 block without a Z parameter, a facing thread is made parallel to the X-axis at the Z axis position prior to the G33 block. X values may be entered as a radius or a diameter value. X may also be programmed as an incremental or absolute value. The <u>initial</u> minor diameter of any straight or tapered thread is determined by the position of the X axis prior to the G33 block.
z	This parameter is the end point of the thread cutting move in the Z axis. This parameter may be an incremental or absolute value. If not present there must be an X parameter. When a Z parameter is used in a G33 block without an X parameter the threading pass is made parallel to the Z-axis at whatever X position the tool tip was at prior to the G33 block.
E F	This parameter may be entered by using either an E- or F-word. It represents the thread lead along the axis with the largest programmed distance to travel to make the thread cut. It is mandatory when cutting any threads. If the E-word is programmed, its value (sign ignored) is equal to the number of threads per inch or inches per thread (determined in AMP) regardless of whether inch or metric mode is active at the time. If the F-word is programmed, its value (sign ignored) is the thread lead in inches per revolution or millimeters per revolution, depending on the mode in which the control is operating.
Q	This optional parameter provides a relative value for the start offset angle of the thread. Its primary use is in cutting multistart threads. For example, if a threading pass were made with a value of zero here, and then followed by another pass with a value of 180 then the second cut would be started 180 degrees from the first resulting in a two start thread. If two more passes are then made, one with a parameter value of 90 and one with a value of 270, the result would be a four-start thread.

Figure 24.4
G33 Block Parameters



Important: Do not re-program the G33 command in consecutive threading blocks. Doing so will cause the control to pause axis motion (possibly damaging the thread) while the axis re-synchronizes with the spindle. Consecutive threading blocks in the following example are blocks N3 and N4, and blocks N8 and N9.

Example 24.1
Parallel Thread Cutting

Thread lead: 5 threads/inch (.20 inch pitch)

Depth of cut: .7 inch (after final pass)


Number of cutting passes: 2

```

N1 M03 S50;
N2 G00 X1.5 Z2.2;
N3 X.9;
N4 G33 Z.8 F.2;
N5 Z.5 X1.2
N6 G00 X1.5;
N7 Z2.2;
N8 X.7;
N9 G33 Z.8 F.2;
N10 Z.5 X1.2
N11 G00 X1.5;
N12 Z2.2;

```

Figure 24.5
Parallel Thread Cutting Results from Example 24.1




If both E and F are programmed in the same block the right-most parameter takes effect for that block.

The programmed lead remains in effect until another thread lead value is programmed, the control is reset, or an M02 or M30 end of program block is executed.

For tapered threads, the thread lead (determined by the F- or E-word) is applied along the axis that travels the greatest distance when cutting the thread. See Figure 24.6.

Figure 24.6
Lead Designation for Tapered Thread



When the X-axis is used as the thread lead axis for E or F, program thread leads as radial values.

Example 24.2
Tapered Thread Cutting

Thread lead: .125 threads/mm (8 mm pitch)

Depth of cut: 1 mm (X direction)


Number of cutting passes: 2

```

N1 M03 S30;
N2 G77 G00 X20. Z4.;
N3 G33 X48. Z-47. F8;
N4 X52 Z-55;
N5 G00 X60.;
N6 Z4.;
N7 X12.;
(second pass)
N8 G33 X40. Z-47.;
N9 X52 Z-55;
N10 G00 X60.;
N11 Z4.;

```

Figure 24.7
Results of Tapered Thread Cutting Example 24.2



Multiple-thread cutting can be programmed by assigning a thread cutting start shift angle using a Q-word. Omission of a Q-word indicates a shift angle of 0 (synchronizes at the spindle marker). Entering a Q word will offset the axis synchronization from the spindle marker position.

Example 24.3
Multistart Thread Cutting

Thread lead: 2 threads/inch (.50 inch pitch)

Depth of cut: .7 inch (after final pass)


Number of cutting passes: 2 at 180 degrees apart

```

N1 M03 S50;
N2 G00 X1.5 Z2.2;
N3 X.9;
N4 G33 Z.8 E2. Q0;
N5 Z.5 X1.2
N6 G00 X1.5;
N7 Z2.2;
N8 X.9;
N9 G33 Z.8 E2. Q180;
N10 Z.5 X1.2
N11 G00 X1.5;
N12 Z2.2;

```


Figure 24.8
Multistart Thread Cutting Results from Example 24.3



Single Pass Variable Lead Thread Cutting (G34)

The G34 code programs the variable lead thread cutting mode. It is programmed almost identically to the G33 thread cutting mode with the addition of a K-word used to program the amount of lead variation per revolution.

Figure 24.9
Variable Lead Thread



Important: Do not re-program the G34 command in consecutive threading blocks. Doing so will cause the control to pause axis motion (possibly damaging the thread) while the axis re-synchronizes with the spindle.

The format for the G34 threading mode is:

Parallel thread $G34Z_ \left\{ \begin{array}{l} F_ \\ E_ \end{array} \right\} Q_K_;$

Tapered thread $G34X_Z_ \left\{ \begin{array}{l} F_ \\ E_ \end{array} \right\} Q_K_;$


Face thread $G34X_ \left\{ \begin{array}{l} F_ \\ E_ \end{array} \right\} Q_K_;$

Where :	Is :
x	This parameter is the end-point of the thread cutting move in the X axis. This parameter may be an incremental or absolute and radius or diameter value. If not present, there must be a Z parameter. If an X parameter is present, it indicates either a face, tapered, or lead-in thread. When used in a G34 block without a Z parameter, a facing thread is made parallel to the X-axis at the Z axis position prior to the G34 block. The initial minor diameter of any straight or tapered thread is determined by the position of the X axis prior to the G34 block.
z	This parameter is the end-point of the thread cutting move in the Z axis. This parameter may be an incremental or absolute value. If not present, there must be an X parameter. When a Z parameter is used in a G34 block without an X parameter, the threading pass is made parallel to the Z-axis at whatever X position the tool tip was at prior to the G34 block.
E F	This parameter may be entered by using either an E- or F-word. It represents the thread lead along the axis with the largest programmed distance to travel to make the thread cut. It is mandatory when cutting any threads. If the E-word is programmed, its value (sign ignored) is equal to the number of threads per inch or inches per thread (determined in AMP) regardless of whether inch or metric mode is active at the time. If the F-word is programmed, its value (sign ignored) is the thread lead in inches per revolution or millimeters per revolution, depending on the mode in which the control is operating. In a G34 block, E or F indicates the <u>initial</u> thread lead used at the start of the threading pass.
Q	This optional parameter provides a relative value for the start offset angle of the thread. Its primary use is in cutting multistart threads. For example, if a threading pass were made with a value of zero here, and then followed by another pass with a value of 180°, then the second cut would be started 180° from the first resulting in a two-start thread. If two more passes are then made (one with an a parameter value of 90° and one with a value of 270°), the result would be a four-start thread.
K	Program the difference in the thread lead per spindle revolution (inch/rev/rev or mm/rev/rev). The amount of K is added to the thread lead (E or F) after each thread is cut. K may be programmed as a positive (increasing thread lead) or a negative (decreasing thread lead) value.

The lead changes continuously during the move. At any point during the move, you can calculate the lead with this formula:

$$\text{instantaneous lead} = F + (K * \text{number of revs since the start})$$

Figure 24.10
Instantaneous Lead



The actions of the G34 variable lead threading operation are identical to the G33 threading operation with the exception of the variable thread lead. Refer to the G33 threading section for details and examples of single-pass threading blocks that cut parallel, tapered, or face threads.

Metric and inch Lead variation limits are indicated below:

+/- 0.0001 to +/- 100.0000 mm/rev

+/- 0.000001 to +/- 1.000000 inch/rev

Example 24.4
Variable Lead Face Threading Using G34

N1G00G07X57.Z37.5F100;


N2G91;

N3G34X-47.5F.1K.071;

N4G00Z10.;

N5X47.5;

Figure 24.11
Results of Variable Lead Face Threading Example



Single Pass Threading Cycle (G21)

The G21 single pass threading cycle can be programmed to cut parallel or tapered fixed lead threads (variable lead threads may only be cut using a G34 block). This threading cycle performs a predetermined series of machining steps designated by a single program block.

The two chamfering features (threading retract and threading chamfer) described on page 24-4 can also be used with this threading cycle. The parameter to enable these and determine their angle and length is set in AMP. The thread chamfer feature must also be enabled through logic.

This threading cycle repeats automatically after every block that contains axis words until the cycle is cancelled. These axis words generate rapid moves. A G21 single pass threading cycle is canceled by programming any other G-code in modal group 1 (this includes G00, G01, etc.).

The conditions to be satisfied to execute this thread cutting cycle are described on page 24-2, thread cutting considerations.

Before programming the G21 threading cycle, the cutting tool must be positioned away from the part at a location that allows the control to execute the cycle correctly.

Straight Thread Cutting

This format is for programming a single pass straight threading cycle:

```
G21 X__ Z__ {F__};E
```

Where :	Is :
X	This parameter is the start-point of the thread cutting move in the X axis. This parameter may be an incremental or absolute and radius or diameter value. This is the depth that the X axis moves to before starting the thread cutting pass. This value may be replaced in any block following the G21 block while the G21 cycle is active. X may also be programmed as an incremental or absolute value.
Z	This parameter is the end-point of the thread cutting pass in the Z axis. This parameter may be an incremental or absolute value. Z parameters are always entered as a radius values regardless of the current mode.
E F	This parameter may be entered by using either an E- or F-word. It represents the thread lead along the axis with the largest programmed distance to travel to make the thread cut. It is mandatory when cutting any threads. If the E-word is programmed, its value (sign ignored) is equal to the number of threads per inch or inches per thread (determined in AMP) regardless of whether inch or metric mode is active at the time. If the F-word is programmed, its value (sign ignored) is the thread lead in inches per revolution or millimeters per revolution, depending on the mode in which the control is operating.

When this cycle is executed:


1. The cutting tool rapids to the depth programmed with the X-word.
2. The thread cutting pass is made to the position programmed with the Z-word using a feedrate that generates the required lead programmed with the E- or F-word. If the Thread Chamfering feature was enabled before the cycle began executing, the control performs a chamfer just before reaching the programmed Z position.
3. The cutting tool is retracted away from the part at a rapid feedrate to where the X axis was positioned prior to the G21 block.
4. The cutting tool is returned along the Z axis at a rapid feedrate to where the Z axis was positioned prior to the G21 block.
5. Program execution continues on to the next block.

G21 works like most fixed cycles in that it automatically repeats after every rapid move until canceled. Following passes need only contain a new value for the infeed (X value). The other parameters programmed in the G21 block remain in effect.

Example 24.5
G21 Straight Thread Cutting Cycle

G00X10.Z10.;	Rapid to the start point of the thread cutting cycle. This should be a point that allows a straight, <u>rapid</u> , X move to the depth that the thread is cut to.
S500.M03;	Starts the spindle turning at 500 RPM in the clockwise direction.
G21X4.8Z5.F.5;	This block makes a thread cutting pass with a lead of .5 and return the cutting tool to the start point of the thread cutting cycle (X10 Z10).
X4.5;	This block repeats the G21 thread cutting block using a new depth of cut to 4.5.
X4.3;	This block repeats the G21 thread cutting block using a new depth of cut to 4.3.
G00;	This block cancels the G21 thread cutting mode.

Figure 24.12
Results of G21 Straight Thread Cutting Example




Taper Thread Cutting

This format is for programming a single pass tapered threading cycle:

$$G21 X _ Z _ I _ \left\{ \begin{matrix} F \\ E \end{matrix} \right\};$$

Where :	Is :
X	This parameter is the end point of the thread cutting move in the X axis. This parameter may be an incremental or absolute and radius or diameter value. This is the depth that the X axis moves to before starting the thread cutting pass. This value may be replaced in any block following the G21 block while the G21 mode is active.
Z	This parameter is the end point of the thread cutting pass in the Z axis. This parameter may be an incremental or absolute value. Z parameters are always entered as radius values.
E F	This parameter may be entered by using either an E- or F-word. It represents the thread lead along the axis with the largest programmed distance to travel to make the thread cut. It is mandatory when cutting any threads. If the E-word is programmed, its value (sign ignored) is equal to the number of threads per inch or inches per thread (determined in AMP) regardless of whether inch or metric mode is active at the time. If the F-word is programmed, its value (sign ignored) is the thread lead in inches per revolution or millimeters per revolution, depending on the mode in which the control is operating.
I	This is the change in radius of the thread (on the X axis) that the threading pass makes as it reaches the end point of the thread cutting pass. The end point is the X position programmed with the X-word. I is an incremental, signed distance (+ or -) added to the X parameter to determine the start point of the threading pass on the X axis. If a chamfer is being cut at the end of the thread cutting pass, it does not affect the value programmed here. This parameter should be entered as if no chamfer was being cut. I parameters are always entered as radius values regardless of the current mode. I is always an incremental value regardless of the current mode.

Figure 24.13
G21 Taper Thread Cutting Parameters



When this cycle is executed:

1. The cutting tool rapids to the depth programmed with the X-word added to the I value.
2. The thread cutting pass is made to the position programmed with the X- and Z-words using a feedrate that generates the required lead programmed with the F- or E-word. As the tool moves along this threading pass, the taper distance programmed with the I parameter is interpolated along the X axis.

Important: If the Thread Chamfering feature was enabled before the cycle began execution, the control performs a chamfer before reaching the programmed Z position. The chamfer angle and length of are set in AMP.

3. The cutting tool is retracted away from the part at a rapid feedrate to the X axis position prior to the G21 block.
4. The cutting tool is returned along the Z axis at a rapid feedrate to the Z axis position prior to the G21 block.
5. Program execution continues on to the next block.

G21 is modal. Following passes need to contain only a new value for the infeed (X value). The other parameters programmed in the G21 block remains in effect.

O.D. & I.D. Multipass Threading Routine (G78)

The G78 multipass threading routine can be programmed to cut parallel, face, or tapered fixed lead threads (variable lead threads may only be cut using a G34 block). This routine performs a predetermined series of threading steps designated by a single program block. The G78 block contains all of the necessary information to cut the complete thread. When executed, the routine makes multiple passes over the thread until the programmed root depth is reached. The control automatically generates all threading passes necessary to reach the programmed root depth.

In effect, with the exception of the different infeed types, the multipass threading routine is executed as if many G21 single pass threading cycles were being executed. The key difference between the two features (aside from infeed types) is that the multiple pass cycle only requires one block to do the job of many single pass threading blocks. The G78 multipass threading routine is a nonmodal G-code (unlike G21). This routine is executed only when a block contains a G78.

A finishing pass is also available with the multipass threading routine. The size of the finishing pass, and whether a finishing pass is performed at all, is determined by the system installer in AMP. If a finishing pass is made, it is typically to improve final thread finish by removing a significantly smaller amount of material with the last pass executing across the thread by the G78 routine.

The two different chamfering features (threading retract and threading chamfer) described on page 24-2 may also be used with this multipass thread cutting routine. The parameters to enable these and to determine their angle and length are set in AMP. The thread chamfer feature must also be enabled through logic.

The conditions to be satisfied to execute this thread cutting routine are described on page 24-2, thread cutting considerations.

Programming Multipass Thread Cutting

Before programming the G78 threading routine, the cutting tool must be positioned to the point from which the routine is to be executed. This point is the end-point of each complete cycle of the threading routine's execution.

Use this format to program a multipass thread cutting routine:

$$G78X_Z_K_D_ \left\{ \begin{array}{c} F \\ E \end{array} \right\} A_P_I_;$$

Where :	Is :
X :	This parameter is the coordinate value of the root (depth) of the thread. If programming a tapered thread, it is the coordinate value to be attained at the <u>end</u> of the last threading pass (assume there is no chamfer cut at the end of the pass). X values may be entered as a radius or a diameter value. X may also be programmed as an incremental or absolute value.
Z :	This parameter is the Z coordinate value of the end of the thread cutting pass. Z parameters are always entered as a radius value regardless of the current mode. Z may also be programmed as an incremental or absolute value.
K :	This parameter is an unsigned value (always programmed as positive). It programs the distance from the thread root (as determined by the X parameter to the top of the thread. K is always programmed as a radius value.
D :	This parameter programs the depth of cut (designated in radius) for the first pass. It is an unsigned value (always programmed as positive). The depth of following passes is determined by this value and the type of infeed selected with the P parameter.
A :	This parameter programs the angle of the tool tip. It must be entered as an integer value from 0 to 120 (corresponding to 0-120 degrees). Not programming a value for A is the same as A0. A0 would be the same as a plunge type infeed. The value entered here determines the angle that the infeed moves makes, which also determines the final thread angle. See the tool infeed section (page 24-22) for details.
P :	This parameter determines the tool infeed. It must be entered as an integer value from one to four. See the tool infeed section (page 24-22) for details.
E, F :	This parameter may be entered by using either E or F for the thread lead (as in G33). If the E-word is programmed, its value (always unsigned) is equal to the number of threads per inch or inches per thread (determined in AMP) regardless of whether inch or metric mode is active at the time. If the F-word is programmed, its value (always unsigned) is the thread lead in inches per revolution or millimeters per revolution, depending on the mode in which the control is operating.
I :	This is the change in radius of the thread (on the X axis) that the threading pass makes as it reaches the end-point of the thread cutting pass. The end-point is the X position programmed with the X-word. I is an incremental, signed distance (+ or -) added to the X parameter to determine the start-point of the threading pass on the X axis. If a chamfer is being cut at the end of the thread cutting pass, it does not affect the value programmed here. This parameter should be entered as if no chamfer were being cut. I is always an incremental value regardless of the current mode. This parameter is always entered as a radius value regardless of the current mode.


If a straight thread is desired:

- enter a value of zero for this parameter
or
- do not program the I-word in the block

The control performs threading in either radius or diameter mode. Be aware that X values entered as a radius or a diameter value when entered. Z, I, K, and D, parameters are always entered as radius values regardless of the current mode. X and Z may also be programmed as incremental or absolute values. K, D, and I are always programmed as incremental values regardless of the current mode.

Figure 24.14 illustrates these parameters.

Figure 24.14
Multipass Thread Cutting Parameters



Tool Infeed

This multipass threading routine provides 4 different types of cutting tool infeed determined by a P-word in the threading block. These different infeeds are provided to allow operation with different types of cutting tools and materials. These different infeed types all move the end-point of the cutting tool when infeeding an amount referenced from the infeed reference point.

P1 - Constant cutting volume, angular infeed along thread face. A constant amount of material is removed in each pass (except possibly the last few passes). The last few passes may reach the minimum infeed amount set in AMP by the system installer. If the depth of cut is smaller than the minimum depth of cut set in AMP, it is increased to equal that minimum depth of cut. Only one edge of the cutting tool removes material.

P2 - Constant cutting volume, zigzag infeed. With this parameter, the control alternates the cutting edge of the tool after every pass. The amount of material that is removed is constant every two passes.

Important: If the user programs one pass, the control halves the programmed depth and makes two passes. Because of this, the number of passes programmed must always be even; and the depth of the pass cannot be too small. If it is too small, the cutting tool may only burnish the part, instead of cutting it.

To prevent burnishing, the system installer can program in AMP a minimum depth of cut. If the user then enters a depth of cut smaller than the minimum depth of cut in AMP, the entered value is disregarded, and the value in AMP replaces it.

P3 - Constant depth of cut, angular infeed along thread face. This method is the same as P1, except that the cutting depth is kept constant with each pass, and there is no minimum infeed applied. Only one edge of the cutting tool removes material.

P4 - Constant depth of cut, zigzag infeed. This method is the same as P2 except that the cutting depth is kept constant for each pass, and there is no minimum infeed applied. Each edge of the cutting tool removes material on alternate passes.

Figure 24.15
Multipass Thread Cutting Infeed Parameters





Figure 24.16
Sample Tool Paths for Multipass Threading Cycle (assumes P3)



END OF CHAPTER

Drilling Cycles

Chapter Overview

This chapter covers the G-word data blocks in the drilling cycle group. The operations of the drilling cycles are explained on these pages:

Topic:	Page:
Drilling cycles	25-1
Positioning and Hole Machining Axes	25-4
Parameters	25-7
Drilling Cycle Operations	25-8
Altering Drilling Cycle Operating Parameters	25-35
Fixed Drilling Cycle Examples	25-37



ATTENTION: The cycles described in this chapter can be used with live tooling. This application however requires proper logic control of the spindle, especially in cycles that perform spindle orients or change the spindle rotation direction. Failure to do this can result in injury to personal or damage to equipment.

Drilling Cycles

Drilling cycles, sometimes referred to as canned cycles or auto cycles, repeat a series of basic machining operations, such as boring, drilling, or tapping. These operations, designated by a single-block command, usually consist of a fixed series of steps that are dependent on the type of machining application.

For this chapter, as well as this manual, assume that the Z axis is the hole machining axis. The hole machining axis is established by the system installer.


The control provides the drilling cycles shown in Table 25.A.

Table 25.A
Drilling Cycles

G-code	Application	Tool Movement	Operation At Hole Bottom	Retraction Movement
G80	Cancel Or End Fixed Cycle	N/A	N/A	N/A
G81	Drilling Cycle, No Dwell/Rapid Out	Feed	Retract	Rapid Traverse
G82	Drilling Cycle, Dwell/Rapid Out	Feed	Dwell / Retract	Rapid Traverse
G83	Deep Hole Drilling Cycle	Intermittent Feed	Retract	Rapid Traverse
G83.1	Deep Hole Peck Drilling Cycle with Dwell	Intermittent Feed	Retract	Rapid Traverse
G84	Right-Hand Tapping Cycle	Feed	Spindle or Live Tool Reversed / Retract	Feed
G84.1	Left-Hand Tapping Cycle	Feed	Spindle or Live Tool Reversed / Retract	Feed
G84.2	Right-Hand Solid-Tapping Cycle	Feed	Spindle or Live Tool Reversed / Retract	Feed
G84.3	Left-Hand Solid-Tapping Cycle	Feed	Spindle or Live Tool Reversed / Retract	Feed
G85	Boring Cycle, No Dwell/Feed Out	Feed	Retract	Feed
G86	Boring Cycle, Tool Stop/Rapid Out	Feed	Spindle or Live Tool Stop / Retract	Rapid Traverse
G86.1	Boring Cycle, Tool Shift	Feed	Orient Spindle or Live Tool Stop / Retract	Rapid Traverse
G87	Back Boring Cycle	Feed	Oriented Spindle or Live Tool Stop / Retract	Rapid Traverse
G88	Boring Cycle Spindle or Live Tool Stop/ Manually Out	Feed	Dwell / Retract Spindle or Live Tool Stop / Retract	Manual/Rapid Traverse
G89	Boring Cycle, Dwell/Feed Out	Feed	Dwell/Retract	Feed

In general, drilling cycles consist of the following operations (see Figure 25.1):

Figure 25.1
Drilling Cycle Operations



The system installer determines if the positioning to initial point is always a rapid move, or if it is necessary to program a G00 or G01 to select a mode. This manual assumes rapid positioning.

Positioning and Hole Machining Axes

This section assumes that the programmer can determine the hole machining axis using the plane select G-codes (G17, G18, G19). Refer to the system installer's documentation to make sure that a specific axis has not been selected in AMP to be the hole machining axis.

G-codes G17, G18, or G19 determine the plane, the hole machining axis, and the positioning axes. The two axes that define the selected plane are used as positioning axes. The axis **perpendicular** to the plane is the hole machining axis.

Table 25.B assumes a specific plane definition. Refer to the system installer's documentation for the plane definitions on your system.

Table 25.B
Plane Selection vs Machining Axis

Plane	Hole Machining Axis	Positioning Axes
XU (G17)	Z axis or its parallel axis	X and U axes or their parallel axes
ZX (G18)	U axis or its parallel axis	Z and X axes or their parallel axes
UZ (G19)	X axis or its parallel axis	U and Z axes or their parallel axes

Example 25.1 shows you how to change the hole machining axis to a parallel axis. Prior to changing the hole machining axis, a G80 should be executed to cancel any active milling mode.

Example 25.1
Altering the Machining Axis to a Parallel Axis

Program Block	Comment
The W axis is parallel to the Z axis.	
G17;	XU plane active
G81X ___ U ___ ;	Drilling cycle, Z is the hole machining axis
.	
.	
G80;	Cancel drilling fixed cycle mode
G81X ___ U ___ W ___;	Drilling cycle, W is the hole machining axis
.	
.	

The plane selection codes (G17, G18, and G19) can be included in the drilling fixed cycle block, or can be programmed in a previous block.

Figure 25.2 shows typical drilling cycle motions in absolute (G90) or incremental (G91) mode. Note the changes in how the R point and Z level are referenced.

Figure 25.2
Drilling Cycle Parameters in G90 and G91 Modes

———— Cutting feed
 - - - - - Rapid feed





Figure 25.3 shows the two different modes available for selecting the return level in the Z axis after the hole has been drilled. These two modes are selected with G98 (which returns to the same level the cycle started at) and G99 (which returns to the level defined by the R point).

Figure 25.3
Drilling Cycle Parameters in G98 or G99 Modes



Important: If your system is configured to use lathe G code system “A” (selected in AMP), you can not program a G98 or G99 to change between initial and R point returns. Lathes with G code system “A” always use the R point return type (as if in G99 mode).

Important: In the **following sections**, figures and examples are assumed to be programmed in the incremental mode (G91) and initial point return mode (G98).

Parameters

This section provides a detailed explanation of each parameter you can program for the drilling cycles. Some parameters are not valid with all cycles; see the specific description of each cycle. To alter drilling cycle operation parameters, refer to page 25-35.

These drilling cycle parameters are described below:

$$X _ Y _ Z _ R _ \left\{ I _ J _ K _ \right\} P _ F _ L _ Q _ D _ S _ ;$$

Where :	Is :
X	specifies the location of the hole position in the selected plane. In the absolute mode (G90), program the hole position using the coordinate values in the active coordinate system. In incremental mode (G91), program the hole position using the distance from the current tool position to the required hole position. This parameter is affected by radius or diameter programming modes.
Z	defines the hole bottom. In absolute mode (G90), program the hole bottom level using the coordinate value in the active coordinate system. In the incremental mode (G91), program the distance from the R point level to the hole bottom level.
R	defines the R point level. In the absolute mode (G90), program the R point level as a coordinate value in the active coordinate system. In the incremental mode (G91), program the R point level by the distance from the initial point level to the R point level.
I, J, K	define the shift amount for G86.1 and G87.
P	defines the dwell period at hole bottom. P programs the dwell in the same way as G04: seconds if in feedrate mode (G94), spindle revolutions if in revolution mode (G95). (The allowable dwell time range in seconds is 0.001-99999.99. The allowable dwell range in revolutions is also 0.001-99999.999.) The P-word does not apply in all drilling cycles.
F	defines the cutting feedrate. If this parameter is not specified, the control uses the currently active feedrate for the cutting feedrate. For G84.2 and G84.3, F = tap thread lead in inches/mm per revolution.
L	defines the number of times the drilling cycle is repeated. The maximum number of repeats is 9999. <ul style="list-style-type: none"> • In absolute mode, the control drills in the same location the number of times specified by the L-word. • In incremental mode, the L-word drills the number of holes specified by the L-word at equally spaced positions, determined by axis positioning parameters X and Y. • If an L0 is programmed, the control decodes the milling cycle information, but does not execute the drilling cycle. If no L-word is programmed, the control defaults to L1.
Q	In G83, Q defines the infeed amount for each move made in the hole. In G86.1 and G87, Q defines the shift amount (as do I, J, and K). In G84.2 and G84.3, Q defines the angle at which to orient the spindle before starting the tap. If you don't program the Q-word, the spindle is not oriented before the tap begins. This means that the hole is not retappable unless a Q-word is programmed in the cycle block. The spindle is brought to a stop prior to the initiation of the tapping phase even if Q is <u>not</u> programmed; this happens after the move to the R-plane.
D	defines the return spindle speed so that, if you want, the tap-out move can be performed faster or slower than the tap-in. Tool selection by D-word is not possible while in the solid-tapping mode.
S	defines spindle speed in rpm.

Drilling Cycle Operations

Drilling cycles G83.1, G84.1, G86.1 and G81-G89 are modal, which means they remain active until you program a G-code that cancels the drilling cycle. Certain drilling cycles can, therefore, be repeated at different positions without having to reprogram all the parameters associated with a given operation.

Similarly, any parameters specified in the block calling the drilling cycle remain active until the cycle is cancelled, or until they are re-programmed in a following block. L-words do **not** remain active and, instead, designate the number of times the drilling cycle is repeated.

G00-G03, G33, G34 or G80 cancel drilling cycle mode.

Important: Start the tool rotating with appropriate programming before the control executes a drilling cycle block.



ATTENTION: On systems with more than one spindle, the controlling spindle code determines which spindle (and its related spindle modal M-codes) is active during drilling cycles. All references to spindle activities (orient, reversal, etc.) described in this chapter apply only to the controlling spindle. Refer chapter 16.

(G80): Cancel or End Fixed Cycles

The format for the G80 cancel or end fixed cycles is:

G80 ;

Programming a G80 cancels the currently active drilling cycle mode. G00, G01, G02, G03, G33 or G34 also cancel any active drilling cycle.

If drilling cycles are canceled with a G80, program execution returns to the mode which was in effect when the cycles were last turned on, for example, G00 - G03 or G33, G34.

(G81): Drilling Cycle, No Dwell/Rapid Out

The format for the G81 cycle is:


G81X_Z_R_F_L_;

Where :	Is :
X	specifies location of the hole.
Z	defines the hole bottom.
R	defines the R point level.
F	defines the cutting feedrate.
L	defines the number of times the drilling cycle is repeated.

See page 25-7 for a detailed description of these parameters.

Important: The programmer or operator must start spindle or live tool rotation.

Figure 25.4
G81: Drilling Cycle without Dwell



In the G81 drilling cycle, the control moves the axes in this manner:

1. The tool rapids to the initial point level above the hole location.
2. The drilling tool then rapids to the R point level, slows to the programmed cutting feedrate and begins the drilling operation.
3. The drilling tool continues to drill at the programmed feedrate until it reaches the depth of the hole as programmed with the Z-word.
4. The control retracts the drilling tool at a rapid feedrate to the initial point level as determined by G98.

When the **single block** function is active, the control stops axis motion after steps 1, 2 and 4.

(G82): Drill Cycle, Dwell/Rapid Out

The format for the G82 cycle is:


```
G82X__Z__R__P__F__L__;
```

Where :	Is :
X	specifies location of the hole.
Z	defines the hole bottom.
R	defines the R point level.
P	defines the dwell period at hole bottom.
F	defines the cutting feedrate.
L	defines the number of times the drilling cycle is repeated.

Refer to page 25-7 for a detailed explanation of these parameters.

Important: The programmer or operator must start spindle or live tool rotation.

Figure 25.5
G82: Drilling Cycle, Dwell/Rapid Out



In the G82 drilling cycle, the control moves the axes in this manner:

1. The tool rapids to initial point level point above the hole location.
2. The drilling tool then rapids to the R point level, slows to the programmed cutting feedrate and begins the drill operation.
3. The cutting tool drills at the programmed feedrate to the pre-programmed depth of the hole (defined by the Z-word in the boring cycle block).
4. If a value was programmed for the P parameter, the drilling tool dwells after it reaches the bottom of the hole.
5. After the drilling tool reaches the hole bottom and the dwell is completed, the drilling tool is retracted at a rapid feedrate to the initial point level as determined by G98.

When the **single block** function is active, the control stops axis motion after steps 1, 2 and 5.

(G83): Deep Hole Drilling Cycle

The format for the G83 cycle is:


```
G83X__Z__R__Q__F__L__;
```

Where :	Is :
X	specifies location of the hole.
Z	defines the hole bottom.
R	defines the R point level.
Q	defines the infeed amount for each step into the hole.
F	defines the cutting feedrate.
L	defines the number of times the drilling cycle is repeated.

See page 25-7 for a detailed description of these parameters.

Important: The programmer or operator must start spindle or live tool rotation.

Figure 25.6
G83: Deep Hole Drilling Cycle



In the G83 drilling cycle, the control moves the axes in this manner:

1. The tool rapids to initial point level above the hole location.
2. The drilling tool then rapids to the R point level, slows to the programmed cutting feedrate and begins the deep hole drilling operation.
3. During the drilling operation, the control infeeds the drilling tool by an amount Q , as programmed in the G83 block.
4. The drilling tool retracts at a rapid feedrate to the R point level.
5. The control feeds the drilling tool at rapid feedrate to a distance d above the level drilled in the previous infeed. The amount d is specified by the system installer, or can be set by the operator as described on page 25-35. This intermittent feed simplifies chip disposal and permits a very small retraction amount to be set in deep hole drilling.
6. The drilling tool slows to the cutting feedrate again and infeeds an amount $Q + d$.
7. The cutting tool is then retracted at a rapid feedrate to the initial point level as determined by G98.

When the **single block** function is active, the control stops axis motion after steps 1, 2 and 7.

(G83.1): Deep Hole Peck Drilling Cycle with Dwell

The format for the G83.1 cycle is:


G83.1X__Z__R__Q__P__F__L__;

Where :	Is :
X	specifies the location of the hole position in the selected plane.
Z	defines the hole bottom.
R	defines the R point level.
Q	defines the infeed amount for each step into the hole.
P	defines the dwell period at hole bottom.
F	defines the cutting feedrate.
L	defines the number of times the drilling cycle is repeated.

See page 25-7 for a detailed description of these parameters.

Important: The programmer or operator must start spindle or live tool rotation.

Figure 25.7
G83.1: Deep Hole Peck Drilling Cycle with Dwell



In the G83.1 peck drilling cycle, the control moves the axes in this manner:

1. The tool rapids to the initial point level above the hole location.
2. The drilling tool then rapids to the R point level, slows to the programmed cutting feedrate and begins the drilling operation.
3. During the drilling operation, the control infeeds the drilling tool by an amount Q, as programmed in the drilling cycle.
4. If a value was programmed for the P parameter, the drilling tool dwells after it reaches the bottom of the hole.
5. It then retracts by an amount d at a rapid feedrate. The amount d is specified by the system installer, or can be set by the operator as described on page 25-35. This intermittent feed simplifies chip disposal and permits a very small retraction amount to be set in peck drilling.
6. After the drilling tool retracts an amount d, it then resumes drilling at the cutting feedrate to a depth d + Q.

This retraction and extension continues until the drilling tool reaches the depth of the hole as programmed with the Z-word in the drilling cycle block.

7. The drilling tool then retracts at a rapid feedrate to the initial point level as determined by G98.

When the **single block** function is active, the control stops axis motion and awaits “cycle start” after steps 1, 2 and 7.

(G84): Right-Hand Tapping Cycle

Use this cycle to cut right-handed threads. The format for the G84 cycle is:

```
G84X _ Z _ R _ P _ F _ L _ ;
```


Where :	Is :
X	specifies location of the hole.
Z	defines the hole bottom.
R	defines the R point level.
P	defines the dwell period at hole bottom.
F	defines the cutting feedrate and represents the thread lead along the drilling axis (Z in this manual). It is mandatory when cutting any threads. The control interprets the F-word as the number of threads per inch or millimeter.
L	defines the number of times the drilling cycle is repeated.

Refer to page 25-7 for a detailed description of these parameters.

Important: When programming and executing a G84 tapping cycle, remember:

- the programmer or operator must start spindle or live tool rotation
- **override** usage - the control ignores the feedrate override switch and clamps override at 100 percent
- during tapping, the feedrate override switch and the feedhold feature are both disabled; cycle stop is not acknowledged until the end of the return operation

Figure 25.8
G84: Right-Hand Tapping Cycle



In the G84 right-hand tapping cycle, the control moves the axes in this manner:



ATTENTION: The programmer or operator must set the direction of spindle rotation for tap-in. The control forces the proper spindle direction for the tap-out, but uses the programmed spindle direction for the tap-in.

1. The tool rapids to initial point level above the hole location.
2. The threading tool then rapids to the R point level, slows to the programmed cutting feedrate and begins the tapping operation.
3. During the tapping operation, the control infeeds the threading tool to the depth and at the feedrate programmed in the tapping cycle.
4. If a value was programmed for the P parameter, the threading tool dwells after it reaches the bottom of the hole, and after the spindle has been commanded to reverse.

The spindle or live tool reverses to the counterclockwise direction.

5. The threading tool retracts at the cutting feedrate to the R point.
6. If a value was programmed for the P parameter, the threading tool dwells after it reaches the R point. Dwells may be ignored if the system installer has chosen to do so in AMP.

The spindle or live tool direction is reversed to clockwise.

7. With G98 active, the cutting tool then accelerates to the rapid feedrate and retracts to the initial point level.

When the **single block** function is active, the control stops axis motion after steps 1, 2 and 6.

If the operator activates a **feedhold** during steps 3, 4 or 5, axis motion stops after step 7. Axis motion also stops during steps 1, 2, and 7. However, if the operator activates a feedhold during step 7, axis motion stops immediately.

Important: Your system installer can enable a tap retract feature for this cycle through logic. Tap retract enables you to retract the tapping tool and resume the cycle, or completely abort the tapping operation. Refer to your system installers documentation for details.

(G84.1): Left-Hand Tapping Cycle

Use this cycle to cut left-handed threads.

The format for the G84.1 cycle is:

G84.1X__Z__R__P__F__L__;


Where :	Is :
X	specifies the location of the hole position in the selected plane.
Z	defines the hole bottom.
R	defines the R point level.
P	defines the dwell period at hole bottom.
F	defines the cutting feedrate and represents the thread lead along the drilling axis (Z in this manual). It is mandatory when cutting any threads. The control interprets the F-word as the number of threads per inch or millimeter.
L	defines the number of times the drilling cycle is repeated.

Refer to page 25-7 for a detailed description of these parameters.

Important: When programming a G84 tapping cycle, remember:

- the programmer or operator must start spindle or live tool rotation
- **override** usage - the control ignores the feedrate override switch and clamps override at 100 percent
- during tapping, the feedrate override switch and the feedhold feature are both disabled; cycle stop is not acknowledged until the end of the return operation

Figure 25.9
G84.1: Left-Hand Tapping Cycle



In the G84.1 left-hand tapping cycle, the control moves the axes in this manner:



ATTENTION: The programmer or operator must set the direction of spindle rotation for tap-in. The control forces the proper spindle direction for the tap-out, but uses the programmed spindle direction for the tap-in.

1. The tool rapids to the initial point level above the hole location.
2. The threading tool then rapids to the R point level, slows to the programmed cutting feedrate and begins the tapping operation.
3. During the tapping operation, the control infeeds the threading tool to the depth and at the feedrate programmed in the tapping cycle.
4. If a value was programmed for the P parameter, the threading tool dwells after it reaches the bottom of the hole, and after the spindle has been commanded to reverse.

The spindle or live tool reverses to the clockwise direction.

- 5. The threading tool retracts at the cutting feedrate to the R point.
- 6. If a value was programmed for the P parameter, the threading tool dwells after it reaches the R point. Dwells may be ignored if the system installer has chosen to do so in AMP.

The spindle or live tool direction is reversed to counterclockwise.

- 7. With G98 active, the cutting tool then accelerates to the rapid feedrate and retracts to the initial point level.

When the **single block** function is active, the control stops axis motion and awaits “cycle start” after steps 1, 2 and 7.

If the operator activates a **feedhold** during steps 3, 4 or 5, axis motion stops after step 7. Axis motion also stops during steps 1, 2 and 7. However, if feedhold is activated during step 7, axis motion stops immediately.

Important: Your system installer can enable a tap retract feature for this cycle through logic. Tap retract enables you to retract the tapping tool and resume the cycle, or completely abort the tapping operation. Refer to your system installers documentation for details.

(G84.2): Right-Hand Solid-Tapping Cycle

Use this cycle to cut right-handed threads.

The format for the G84.2 cycle is:

```
G84.2X__Z__R__F__L__Q__D__S__;
```


Where :	Is :
X	specifies location of the hole.
Z	defines the hole bottom.
R	defines the R point level.
F	defines the thread lead along the drilling axis (Z in this manual). It is mandatory and modal in any subsequent solid tapping cycle blocks until a new F-word is programmed. The control interprets the F-word as the thread lead in inches per revolution or millimeters per revolution, depending on the inch/metric mode active.
L	defines the number of times the drilling cycle is repeated.
Q	defines the angle at which to orient the spindle before starting the tap. It is modal in any subsequent solid tapping blocks until a new Q-word is programmed or the tapping cycle is cancelled by a G80. To retap a hole, a Q-word must have been programmed when the hole was originally tapped.
D	defines the return spindle speed, but cannot exceed the maximum tapping spindle speed set in AMP. This will adjust your Z-axis feedrate according to the thread lead defined in F.
S	defines spindle speed in rpm.

Refer to page 25-7 for a detailed description of these parameters.

Important: When programming and executing a G84.2 solid-tapping cycle, remember:

- the feedrate of the tapping phases is derived as
(spindle {RPM} * F-lead {IPR}) = IPM
- the spindle speed that is active at the start of the cycle determines the effective Z feedrate
- the direction of spindle rotation for tap-in and tap-out phases will be automatically generated by the control
- spindle speed override has no effect on the solid-tapping cycle; you can use feedrate override to adjust the tapping operation
- D cannot exceed the maximum tapping spindle speed set in AMP
- you cannot select tools via D-word while in solid-tapping mode
- gear changes are locked out
- you must disable CSS before performing solid tapping; an attempt to execute the tap phase of a solid-tapping cycle with CSS results in a decode error
- cycle stop and feedrate override are acknowledged throughout the cycle, but can be disabled by G63
- you can use active reset to abort the cycle after the cycle stop request has been acknowledged
- to retap a hole, a Q-word must have been programmed when the hole was originally tapped
- block retrace is possible during the tap-in portion of the cycle, but not during the tap-out

Figure 25.10
G84.2: Right-hand Solid-tapping Cycle



In the G84.2 right-hand solid-tapping cycle, the control moves the axes in this manner:

1. The tool rapids to the tapping position above the hole location.
2. The threading tool then rapids to the R point.
3. The control either orients or stops the spindle.

If a Q-word was programmed:	the control:
yes	orients the spindle
no	stops the spindle

4. *Tap-in:* The clockwise rotation of the spindle ramps up to the programmed S spindle speed and linear motion of the Z axis moves synchronously to reach the Z position.
5. *Tap-out:* The spindle and linear motion reverse to the counterclockwise direction and retract to the R point.

The tap-out speed is determined by $F * S$ unless you programmed D (tap-out rpm), in which case tap-out speed is $F * D$.

At the R point, spindle rotation has ramped to zero.

6. With G98 active, the cutting tool then accelerates to the rapid feedrate and retracts to the initial point level.

With G99 active, the cutting tool remains at R point; no movement occurs.

In single-block mode, the control stops axis motion after phases 1, 2, 3, and 6 of the cycle (Figure 25.10).

(G84.3): Left-Hand Solid-Tapping Cycle

Use this cycle to cut left-handed threads.

The format for the G84.3 cycle is:

```
G84.3X__Z__R__F__L__Q__D__S__;
```

Where :	Is :
X	specifies location of the hole.
Z	defines the hole bottom.
R	defines the R point level.
F	defines the thread lead along the drilling axis (Z in this manual). It is mandatory and modal in any subsequent solid tapping cycle blocks until a new F-word is programmed. The control interprets the F-word as the thread lead in inches per revolution or millimeters per revolution, depending on the inch/metric mode active.
L	defines the number of times the drilling cycle is repeated.
Q	defines the angle at which to orient the spindle before starting the tap. It is modal in any subsequent solid tapping blocks until a new Q-word is programmed or the tapping cycle is cancelled by a G80. To retap a hole, a Q-word must have been programmed when the hole was originally tapped.
D	defines the return spindle speed, but cannot exceed the maximum tapping spindle speed set in AMP. This will adjust your Z-axis feedrate according to the thread lead defined in F.
S	defines spindle speed in rpm.


Refer to page 25-7 for a detailed description of these parameters.

Important: When programming and executing a G84.3 solid-tapping cycle, remember:

- the feedrate of the tapping phases is derived as
(spindle {RPM} * F-lead {IPR}) = IPM
- the spindle speed that is active at the start of the cycle determines the effective Z feedrate
- the direction of spindle rotation for tap-in and tap-out phases will be automatically generated by the control
- spindle speed override has no effect on the solid-tapping cycle; you can use feedrate override to adjust the tapping operation
- D cannot exceed the maximum tapping spindle speed set in AMP
- you cannot select tools via D-word while in solid-tapping mode
- gear changes are locked out

- you must disable CSS before performing solid tapping; an attempt to execute the tap phase of a solid-tapping cycle with CSS results in a decode error
- cycle stop and feedrate override are acknowledged throughout the cycle, but can be disabled by G63
- you can use active reset to abort the cycle after the cycle stop request has been acknowledged
- to retap a hole, a Q-word must have been programmed when the hole was originally tapped
- block retrace is possible during the tap-in portion of the cycle, but not during the tap-out

Figure 25.11
G84.3: Left-hand Solid-tapping Cycle



In the G84.3 left-hand solid-tapping cycle, the control moves the axes in this manner:

1. The tool rapids to the tapping position above the hole location.
2. The threading tool then rapids to the R point.
3. The control either orients or stops the spindle.

If a Q-word was programmed:	the control:
yes	orients the spindle
no	stops the spindle

4. *Tap-in:* The counterclockwise rotation of the spindle ramps up to the programmed S spindle speed and linear motion of the Z axis moves synchronously to reach the Z position.
5. *Tap-out:* The spindle and linear motion reverse to the clockwise direction and retract to the R point.

The tap-out speed is determined by $F * S$ unless you programmed D (tap-out rpm), in which case tap-out speed is $F * D$.

At the R point, spindle rotation has ramped to zero.

6. With G98 active, the cutting tool then accelerates to the rapid feedrate and retracts to the initial point level.

With G99 active, the cutting tool remains at R point; no movement occurs.

In single-block mode, the control stops axis motion after phases 1, 2, 3, and 6 of the cycle (Figure 25.11).

(G85): Boring Cycle, No Dwell/Feed Out

The format for the G85 cycle is:


G85X_Z_R_F_L_;

Where :	Is :
X	specifies location of the hole.
Z	defines the hole bottom.
R	defines the R point level.
F	defines the cutting feedrate.
L	defines the number of times the drilling cycle is repeated.

See page 25-7 for a detailed description of these parameters.

Important: The programmer or operator must start spindle or live tool rotation.

Figure 25.12
G85: Boring Cycle (Without Dwell, Feed Out)



In the G85 boring cycle, the control moves the axis in this manner:

1. The tool rapids at the initial point level, to the hole location.
2. The boring tool then rapids to the R point level, slows to the programmed cutting feedrate and begins the boring operation.
3. The boring tool continues to drill at the programmed feedrate until it reaches the depth of the hole as programmed with the Z-word.
4. The control retracts the boring tool at the **cutting** feedrate to the R point.
5. The control retracts the drilling tool at a rapid feedrate to the initial point level, as determined by G98.

When the **single block** function is active, the control stops axis motion after steps 1, 2 and 5.

(G86): Boring Cycle, Spindle Stop/Rapid Out

The format for the G86 cycle is:


G86X__Z__R__P__F__L__;

Where :	Is :
X	specifies location of the hole.
Z	defines the hole bottom.
R	defines the R point level.
P	defines the dwell period at hole bottom.
F	defines the cutting feedrate.
L	defines the number of times the drilling cycle is repeated.

See page 25-7 for a detailed description of these parameters.

Important: The programmer or operator must start spindle or live tool rotation.

Figure 25.13
G86: Boring Cycle, Spindle Stop/Rapid Out



In the G86 drilling cycle, the control moves the axis in this manner:

1. The tool rapids to the initial point level above the hole location.
2. The cutting tool then rapids to the R point level, slows to the programmed cutting feedrate and begins the boring operation.
3. The cutting tool bores at the programmed feedrate until it reaches the depth of the hole as programmed with the Z-word.
4. If the user has entered a value for the P parameter, the cutting tool dwells after it reaches the bottom of the hole.
5. The spindle or live tool stops rotating.
6. The boring tool is then retracted at a rapid feedrate to the initial point level, as determined by G98. Spindle or live tool rotation continues forward.

When the **single block** function is active, the control stops axis motion after steps 1, 2 and 6.

(G86.1): Boring Cycle, Tool Shift

The format for the G86.1 cycle is:

$$G86.1X_Z_ \left\{ \begin{array}{l} I_K_ \\ Q_ \end{array} \right\} R_F_L_;$$

Where :	Is :
X	specifies location of the hole.
Z	defines the hole bottom.
Q or I, K	defines the tool shift amount.
R	defines the R point level.
F	defines the cutting feedrate.
L	defines the number of times the drilling cycle is repeated.

See page 25-7 for a detailed description of these parameters.

Important: The programmer or operator must start spindle or live tool rotation.

- the direction of the axis is specified as + or -.
- the feedrate using this shift method is always rapid traverse.
- the Q-word shift amount is always interpreted as a positive value; a negative Q-word is not allowed.

Method II

The direction of the shift using this method is programmed in the boring cycle block. Program a shift amount for axes in the current plane (G17, G18, or G19) by using only these words:

I__ programs an X axis move.

K__ programs a Z axis move.

Follow the I- and K-words (modal during drilling cycles) with incremental values in the block that programs the hole position.

When using Method II, remember:

- if both axes in the current plane are to be shifted, specify both words to move the axes
 - the generated move is a single linear move and executes at rapid traverse
6. The boring tool is then retracted at a rapid feedrate to the initial point level as determined by G98.
 7. After reaching initial point level, the control again positions the spindle or live tool at the bottom of the hole in a particular orientation as determined by the system installer in AMP.
 8. After reaching the initial point level, the boring tool is shifted back (in a manner previously explained and illustrated) and the spindle or live tool is re-started in the counterclockwise direction.

When the **single block** function is active, the control stops axis motion after steps 1, 2, 4, and 8.

When using Method II, remember:

- the generated move is a single linear move and executes at

(G87): Back Boring Cycle

The format for the G87 back boring cycle is:


$$G87 X_ Z_ \left\{ \begin{array}{l} I_ J_ K_ \\ Q_ \end{array} \right\} R_ F_ L_ ;$$

Where :	Is :
X	specifies location of the hole.

Z	defines the Z point level. The Z point level in this case is the top of the hole that is being cut by the back boring operation.
Q or I, J, K	defines the tool shift amount.
R	defines the position beyond the hole bottom so the tool can safely shift.
F	defines the cutting feedrate.
L	defines the number of times the drilling cycle is repeated.

Important: This cycle requires an existing hole through which the back boring tool can be safely lowered prior to the back boring operation.

Figure 25.15
G87: Back Boring Cycle



In the G87 back boring cycle, the control moves the axes in this manner:

1. The tool rapids to the initial point level above the hole location.
2. After the back boring tool is positioned, the control orients the tool to a position determined in AMP by the system installer.

The control shifts the boring tool by one of two possible methods as described on page 25-31. The shift method is determined in AMP by the system installer. Refer to the documentation supplied by your system installer for additional information.

Method I

This shift method is a single axis shift. The direction and axis for the shift is set in AMP by the system installer or can be altered using the drilling cycle parameter table. See page 25-35.

- the direction of the axis is specified as + or -
- the feedrate using this shift method is the programmed feedrate
- the Q-word shift amount is always interpreted as a positive value; a negative Q-word is not allowed

Method II

The direction of the shift using this method is programmed in the boring cycle block. Program a shift amount for axes in the current plane only (G17, G18, G19) by using these words:

I__ programs an X axis move.

K__ programs a Z axis move.

Follow the I- and K-words (modal during drilling cycles) with incremental values in the block that programs the hole position.

When using Method II, remember:

When using Method II, remember:

- if both axes in the current plane are to be shifted, specify both words to move the axes
 - the move generated is a single linear move and is executed at rapid traverse
3. The back boring tool moves at a rapid feedrate through the existing hole to the depth designated by the R-word.
 4. Once the designated depth is reached, the back boring tool shifts the same distance but in the opposite direction as the previous shift (the shift made in step 2).

After this shift, the programmer or operator must start the spindle or live tool. The spindle or live tool must rotate in the clockwise direction.

5. The control retracts the back boring tool at the cutting feedrate to a level specified by the Z-word.
6. After reaching the Z depth, the spindle or live tool rotation stops so that the control can re-orient the back boring tool to the position specified in AMP.

The back boring tool is shifted a third time, in the same manner as in step 2, so that it is again “off-center” and can be removed through the existing hole.

7. The back boring tool moves at a rapid feedrate to the initial point level regardless of whether G98 or G99 is active.
8. The back boring tool is shifted a fourth time, in the same manner as in step 2, returning to the initial X coordinates of the hole location.

(G88): Boring Cycle, Spindle Stop/Manual Out

The format for the G88 cycle is:

G88X__Z__R__P__F__L__;


Where :	Is :
X	specifies location of the hole.
Z	defines the hole bottom.
R	defines the R point level.
P	defines the dwell period at the hole bottom.
F	defines the cutting feedrate.
L	defines the number of times the drilling cycle is repeated.

See page 25-7 for a detailed description of these parameters.

Important: The programmer or operator must start spindle or live tool rotation.

Important: Setting the BW_EOBSTP (End-of-Block Stop Request) flag to true during a G88 fixed cycle causes the cycle to be executed in its entirety without user intervention. When this flag is set to true, the dwell occurs at the bottom of the hole, the spindle stops, and the control automatically retracts the Z axis.

Figure 25.16
G88: Boring Cycle, Spindle Stop/Manually Out



In the G88 boring cycle, the control moves the axis in this manner:

1. The tool rapids to the initial point level above the hole location.
2. The boring tool then rapids to the R point level, slows to the programmed cutting feedrate and begins the boring operation.
3. The boring tool bores at the programmed feedrate until it reaches the depth specified with the Z-word.
4. If the user has entered a value for the P parameter, the boring tool dwells after it reaches the bottom of the hole.
5. After the tool reaches the Z depth, the spindle or live tool stops revolving. At this point, the operator must perform a manual retraction of the drilling axis as described in chapter 4. (Press **<CYCLE START>** to return the control to automatic mode.)
6. The boring tool is then retracted at a rapid feedrate to initial point level, as determined by G98.
7. At this point, the rotation of the spindle or live tool changes to the clockwise direction.

When the **single block** function is active, the control stops axis motion after steps 1, 2 and 5.

(G89): Boring Cycle, Dwell/Feed Out

The operations in G89 are identical to as those of the G85 boring cycle with the exception that the control executes a dwell at hole bottom.

The format for the G89 cycle is:


```
G89X _Z _R _P _F _L _;
```

Where :	Is :
X	specifies location of the hole.
Z	defines the hole bottom.
R	defines the R point level.
P	defines the dwell period at hole bottom.
F	defines the cutting feedrate.
L	defines the number of times the drilling cycle is repeated.

See page 25-7 for a detailed description of these parameters.

Important: The programmer or operator must start spindle or live tool rotation.

Figure 25.17
G89: Boring Cycle, Dwell/Feed Out



In the G89 boring cycle, the control moves the axes in this manner:

1. The tool rapids to initial point level above the hole location.
2. The boring tool then rapids to the R point level, slows to the programmed cutting feedrate and begins the boring operation.
3. The boring tool bores at the programmed feedrate until it reaches the depth of the hole specified by the Z-word.
4. If the user has entered a value for the P parameter, the boring tool dwells after it reaches the bottom of the hole.
5. The control retracts the boring tool at the cutting feedrate to the R point level.
6. The boring tool accelerates to the rapid feedrate and retracts to the initial point level.

When the **single block** function is active, the control stops axis motion after steps 1, 2 and 5.

Altering Drilling Cycle Parameters


The system installer determines many parameter for the drilling cycles in AMP. For details on these cycles, see page 25-4 or chapters 21 - 24. These three parameters may also be changed by the operator by using the Drilling Cycle Parameter screen:

- G83.1 Deep Hole Peck Drilling Cycle retract amount - This parameter determines the value of “d.” “d” for this cycle is the distance above the last infeed step that the control retracts the tool from the part (normally to clear chips). Refer to the section on G83.1 Deep Hole Drilling cycle for details on this cycles operation.
- G83 Deep Hole Drilling Cycle clearance amount - This parameter determines the value of “d.” “d” for this cycle is the distance above the last infeed step that the feedrate is slowed at to cutting feedrate when infeeding during this cycle. Refer to the section on G83 Deep Hole Drilling for details on this cycles operation.
- G21 / G78 Threading Cycle
 - Pullout Distance - This parameter determines the value of “r.” “r” determines the pullout distance when a thread chamfer or thread retract operation is performed. This distance is in units of threads. Enter the number of threads to be chamfered when exiting the thread. This feature is enabled for threading in logic or in AMP.
 - Pullout Angle - This parameter determines the value of “a.” “a” determines the angle that the chamfer takes when it is performed. This angle is measure in units of degrees and measured from the same axis as the thread lead.

To alter these 3 parameters, follow these steps:


1. Press the {SYSTEM SUPORT} softkey.

(softkey level 1)



2. Press the {PRGRAM PARAM} softkey.

(softkey level 2)




3. Press the {DRLCYC PARAM} softkey. The Drilling Cycle Parameter screen is displayed. Figure 25.18 shows a typical Drilling Cycle Parameter screen.

(softkey level 3)



Figure 25.18
Drilling Cycle Parameter Screen



Important: Parameter values are displayed in inch or metric depending on which is the currently active program mode.

4. From this screen select the parameter that it is desired to change by pressing the up or down cursor keys. The selected parameter is shown in reverse video.
5. There are two options:
 - To replace the current value of the parameter with a new value, key in the new value on the input line of the CRT and press the **{REPLCE VALUE}** softkey. The new value replaces the old value.
 - To add an amount to the current value of the parameter, key in the amount to add to the current parameter value on the input line of the CRT and press the **{ADD TO VALUE}** softkey. The value just keyed in is then added to the old value for the selected parameter.
6. To leave the Drilling Cycle Parameter screen, there are two options:
 - To save the changes just made to the parameters and leave the Drilling Cycle Parameter screen press the **{UPDATE & EXIT}** softkey.
 - To discard any changes just made to the parameters and leave the Drilling Cycle Parameter screen, press the **{QUIT}** softkey.

(softkey level 4)

	REPLCE VALUE	ADD TO VALUE		UPDATE & EXIT	QUIT	
F2	F3	F4	F5	F6	F7	F8

Examples of Drilling Cycles

The following are example programs and an illustration of G83, deep hole drilling cycle. Example 25.2 is in incremental mode; Example 25.3 is in absolute. Figure 25.19 illustrates the result for both programs individually.

Example 25.2 Programming G83, Deep Hole Drilling Cycle in Incremental Mode

```

N10 M19 S0;
N20 G00 X5 Z0 G90;
N30 G83 X1 Z3 R5 Q1.5 F.1
N40 M19 S90;
N50 Z3;
N60 M30;

```


Example 25.3 Programming G83, Deep Hole Drilling Cycle in Absolute Mode

```

N10 G90 G00 X5 Y12 Z0 G17 F200;
N20 G83 X1 Y10 Z-5 R-2 Q1.5;
N30 X5 Y5 Z-8;
N40 X9 Y10 Z-5;
N50 M30;

```

Figure 25.19
Result of Example 25.2 and Example 25.3



END OF CHAPTER

Skip and Gauge Probing Cycles

Chapter Overview

This chapter describes the external skip and gauging functions available on the 9/PC control. External skip functions are motion generating G-code blocks that can be aborted when the control receives an external signal through the logic program. Gauging functions are similar to the external skip functions except that the axis coordinates (at the time the external signal is received) can be used to modify the tool offset table.

This chapter describes these major topics in detail.

Topic:	On page:
External skip functions	26-2
Tool gauging external skip function	26-3

Important: The G04 dwell feature may also be enabled as an external skip or tool gauging command. For details on programming a G04, see chapter 13.

The 9/PC control provides several means of triggering an external skip or gauging block:

- discrete inputs from logic
- a “probe” input that directly latches the feedback counters

These inputs, each with different degrees of precision, may be used to signal the control to store the current axes positions. See the documentation prepared by your system installer for details on your specific machine.

These conditions must be satisfied when an external skip or gauging block is executed:

- cutter compensation must be disabled (G40 mode) when the block is executed
- the block that contains the external skip G-code (excluding G04 as external skip) must be a linear block.



ATTENTION: We do not recommend using a skip block from any fixed cycle block (such as drilling or turning). If you do choose to execute a skip block in a fixed cycle mode, be aware that the block that is skipped when the trigger occurs can be a cycle generated block. If this is the case the cycle will continue normal execution skipping only the portion of the cycle that was executing when the trigger occurred. If the generated block skipped is a crucial portion of the cycle, damage to the part or machine tool can occur.

External Skip Functions (G31 codes)

Use external skip functions to terminate the execution of motion commands in a block when the control receives a signal through logic. When the program block is terminated any remaining axis motion generated by the block that has not been performed remains unexecuted (other non-motion commands are still performed). The control continues normal program execution at the beginning of the next block following the skipped block.

The external skip function is controlled by G31, G31.1, G31.2, G31.3, and G31.4. The system installer determines what signal (such as a touch probe, manual switch, etc.) corresponds to each G31 code in logic. The system installer can choose different signals to correspond to G31.2, G31.3, and G31.4. G31 and G31.1 are functionally the same, always using the same external signal and the same AMP defined feedrate. With proper logic programming, a G04 dwell in seconds may also be used as an external skip function.

Format for any G31 external skip blocks is:

```
G31 X__ Z__ F__;
```

Where :	Is :
G31	Any of the G-codes in the G31 series or G04. Use the one that is configured to respond to the current external skip signal device that is being used.
X, Z	The endpoint of the move if no external skip signal is received. These also determine the direction that the tool travels in.
F	The external skip function feedrate. If no value is entered here, the external skip function executes at either the currently active feedrate, or the feedrate defined for it in AMP (based on whether the AMP parameter Use AMP Skip Feedrate is set to "NO" or "YES"). A value entered here replaces the currently active feedrate and supersedes the AMP defined feedrate.

The G31 series of G-codes always produce linear motion regardless of the current mode active at their execution. After their completion the control returns to the operating mode active before the external skip block was read (G00, G01, G02, G03).

Important: The move that immediately follows a G31 series external skip block cannot be a circular move.

The coordinates of the axes when the external skip signal is received are available as the paramacro system parameters #5061-#5066 (work coordinate system) and #5071-#5076 (machine coordinate system). These values will have been adjusted to compensate for the probe tip radius if a radius compensation value was entered.

For example, assume you have entered a probe tip radius of .01. It is triggered as axis 2 approaches in the positive direction at the axis 2 coordinate of 1.1200. The value available for paramacro parameter #5072 would be 1.1300

Probe tip radius is defined by the system installer in AMP. This value may also be changed through the paramacro system parameter #5096.

See the chapter 27 for details on paramacro parameters.

Skip Function Application Example

A typical application for these G-codes would be to mount the probe as if it were a tool. When the probe contacts the part and triggers, coordinate data would be available in the paramacros for use in the remainder of the part program.

The probe tip radius would be significant for this application.

Tool Gauging External Skip Functions (G37 codes)

Tool gauging functions are similar to external skip functions. The key difference is that the tool gauging cycles use the actual tool position (when the external skip signal is received) to enter values in the tool offset table for the currently active offset.

Use tool gauging functions to terminate the execution of motion commands in a block and modify offset tables when the control receives a signal through logic. When the program block is terminated any remaining axis motion generated by the block that has not been performed remains unexecuted (other non-motion commands are still performed). The current tool position is stored, and the control continues program execution at the beginning of the next block following the skipped block.

The gauging function is controlled by G37, G37.1, G37.2, G37.3, and G37.4. The system installer determines what signal (such as a touch probe, manual switch, etc.) corresponds to each G37 code in logic. The system installer can choose different signals to correspond to G37, G37.1 G37.2, G37.3, and G37.4. G37 and G37.1 are functionally the same, always using the same external signal and the same AMP-defined feedrate.

The format for any G37 skip blocks is:

```
G37 Z__ F__;
```

Where :	Is :
G37	Corresponds to any of the G-codes in the G37 series. Use the one that is configured to respond to the current skip signal device that is being used.
X, Z	The axis on which the length offset measurement is to be taken is specified here as either X or Z. Only one axis may be specified in a G37 block. The numeric value following the axis name corresponds to the exact coordinate at which the skip signal is expected to occur. This value is a signed value (+ or -) and determines the initial direction of travel.
F	The tool gauging external skip function feedrate. If no value is entered here, the external skip function executes at either the currently active feedrate or at the feedrate defined for it in AMP (based on whether the AMP parameter Use AMP Skip Feedrate is set to "NO" or "YES"). A value entered here replaces the currently active feedrate and supersedes the AMP-defined feedrate.

Important: The G37 series G-codes cannot be used to modify the tool tip radius values. Only the tool length offset values can be modified.

The target offset value for these gauging operations is determined by the currently active tool offset number



ATTENTION: If modifying a tool length offset, the offset value generated with this gauging operation is immediately loaded into the offset table. Since this offset must be the currently active offset, it becomes effective either immediately when the next block is executed or delayed until the next block that contains motion on the tool length axis is executed (when an offset is activated is determined in AMP by the system installer).

The G37 series of G-codes always produce linear motion regardless of the current mode active at their execution. After their completion, the control returns to the operating mode active before the skip block was read (G00, G01, G02, G03).

The system installer determines (in AMP) a position tolerance for the G37 functions. This tolerance defines a legal range before and after the coordinate position programmed with the axis word in the G37 block.

If the skip signal is received before the tool enters **or** after the tool exits the position tolerance range, a PROBE ERROR occurs. This error appears on the screen as a warning but does not place the control in E-STOP. Instead the G37 block is aborted and program execution proceeds to the next block. No modification of the tool offset table is performed.

Important: The move that immediately follows a G37 series skip block cannot be a circular move.

The system installer determines in AMP if the new value is added to or replaces the old value in the table. The system installer also determines in AMP what gauge cycles alter which tool offset tables, geometry, or wear.

The control automatically compensates for probe radius and length when calculating tool offset changes if these probe parameters have been entered.

The coordinates of the axes when the external skip signal is received are available as the paramacro system parameters #5061-#5066 (work coordinate system) and #5071-#5076 (machine coordinate system). These values will have been adjusted to compensate for the probe tip radius and the probe length if radius and length compensation values were entered.

For example, assume you have entered a probe tip radius of .01. It is triggered as axis 2 approaches in the positive direction at the axis 2 coordinate of 1.1200. The value available for paramacro parameter #5072 would be 1.1300

Probe tip radius and probe length are defined by the system installer in AMP. These values may also be changed through the paramacro system parameters #5096 (for radius) and #5095 (for length).

Refer to chapter 27 for details on paramacro parameters.

Tool Gauging Application Example

A typical application for these G-codes in determining tool length offsets executes as follows:

1. When the control executes the G37 block, the tool is moved towards the triggering device using the axis specified in the block.
2. When the control receives the appropriate skip signal through logic, axis motion stops.
3. The control records the position when the skip signal is received. It determines the difference by subtracting the position specified with the axis word in the G37 block from this position. The difference is then added to or replaces the value in the appropriate geometry or wear table for the currently active tool offset number.

Figure 26.1
Typical Tool Gauging Configurations




Figure 26.1 illustrates 3 typical tool gauging configurations. All 3 cases assume that the probe is at a known, fixed point on the machine.

In Case 1, the Z axis tool offset length is being gauged, while in Case 2, the X axis tool offset length is being gauged. In both cases:

- only the probe tip radius is significant to the control in calculating the offset adjustment
- the reference position is the center of the probe ball

In Case 3, the X axis tool offset length is being gauged; and both the probe radius and the probe length are significant to the control's offset adjustment calculations. In this case, the reference position is the bottom of the probe.

Important: We do not recommend the tool gauging configuration Case 3 depicted in Figure 26.1 due to the risk of probe damage.

END OF CHAPTER

Paramacros

Chapter Overview

The Paramacro™ feature is similar to a subprogram with many added features. Special features available with a paramacro include:

- computable variables
- computable word address fields in any block type
- variable to and from logic
- access to certain modal system parameters for computations
- arithmetic operators and expressions for computations
- conditional branching, subroutines, and subprogram calls based upon logical function results
- parameter programs, subroutines, and subprograms
- parameter autocycles
- user-definable prompts to aid in program generation and execution
- prompting of parameters for main program execution
- calculator function under prompt edit

All of these features are valid in any block within a main program, subprogram, or paramacro program. Most are permitted in an MDI program unless otherwise stated; the only restriction being that no other program commands, except other paramacro commands, may exist in a block that contains paramacro commands. Macro and nonmacro commands may not exist in the same program block.

This chapter includes these major topics:

Topic	On page:
Transfer of control commands	27-6
Parameter assignments	27-11
Assigning parameter values	27-28
Macro call commands	27-35

Parametric Expressions

It may be necessary for mathematical expressions to be evaluated in a complex paramacro. This requires that some form of mathematical equation be written in a paramacro block. This section describes the operators and function commands available for use on the 9/PC control. These operators and function commands are valid in any block within a program, subprogram, paramacro, or MDI program.

Basic Mathematical Operators

This subsection lists the basic mathematical operators that are available on the 9/PC controller. Use these operators to accomplish mathematical operations that are necessary to evaluate the basic mathematical equation such as addition, multiplication, etc. Table 27.A lists the basic operators and their meanings.

Table 27.A
Mathematical Operators

Operator	Meaning
+	Addition
-	Subtraction
*	Multiplication
/	Division
[]	Brackets
OR	Logical OR
XOR	Logical Exclusive OR
AND	Logical AND
MOD	Modulus

The control executes a mathematical operation in this order:

1. Any part of the expression that is between the brackets [] is evaluated first.
2. Multiplication, division, and MOD are evaluated second.
3. All other operations are evaluated third.

If the same level of evaluation is performed, the left-most operation takes priority.

Example 27.1 Mathematical Operations

Expression entered	Result
$12/4*3$	9
$12/[4*3]$	1
$12+2/2$	13
$[12+2]/2$	7
$12-4+3$	11
$12-[4+3]$	5

All logical operators have the format of:

A logical operator B

where A and B are numerical data or a parameter with a value assigned to it.

If B is negative in the above format, an error occurs.

If A is negative, the absolute value of A is used in the operation and the sign is attached to the final result.

Before evaluation, A and B are made integers by rounding and truncating.

Example 27.2 Logical Operation Examples

Expression Entered	Result
$[16.2\text{MOD}3]$	1.0
$[-16.2\text{MOD}3]$	-1.0
$[-17.6\text{MOD}3]$	0.0
$[16.0\text{MOD}3]$	1.0
$[-5\text{AND}4]$	-4.0
$[4.4\text{AND}3.6]$	4.0
$[5\text{AND}-4]$	ERROR
$[83886079\text{AND}83886080]$	67108864

Mathematical Function Commands

This subsection lists the basic mathematical functions that are available on the 9/PC controller and their use. Use these functions to accomplish mathematical operations that are necessary to evaluate the trigonometric and other complex mathematical equation such as rounding off, square roots, logarithms, exponent, etc. Table 27.B lists the basic functions that are available and their meanings.

Table 27.B
Mathematical Functions

Function	Meaning
SIN	Sine (degrees)
COS	Cosine (degrees)
TAN	Tangent (degrees)
ATAN	Arc Tangent (degrees)
ASIN	Arc Sine (degrees)
ACOS	Arc Cosine (degrees)
SQRT	Square Root
ABS	Absolute Value
BIN	Conversion from BCD to Decimal
BCD	Conversion from Decimal to BCD
ROUND	Rounding Off (nearest whole number)
FIX	Truncation Down
FUP	Truncation Up
LN	Logarithms (base e)
EXP	Exponent

When programming these functions, the value on which that function is to be performed must be included in brackets: for example, SIN [10]. The exception to this is the arc tangent function. The format to ATAN requires the division of two values. For example, ATAN [10]/[2] is used to calculate the arc tangent of 5.

The functions in Table 27.B are executed from left to right in a program block. These functions are executed before the control executes any mathematical operators such as addition or subtraction. This order of execution can be changed only by enclosing operations in brackets []. Operations enclosed in brackets are executed first.

Example 27.3
Format for Functions

SIN[2]	This evaluates the sine of 2 degrees.
SQRT[14+2]	This evaluates the square root of 16.
SIN[SQRT[14+2]]	This evaluates the sine of the square root of 16.
LN[#2+4]	This evaluates the logarithm of the value of parameter #2 plus 4.

Example 27.4 Mathematical Function Examples

Expression Entered	Result
SIN[90]	1.0
SQRT[16]	4.0
ABS[-4]	4.0
BIN[855]	357
BCD[357]	855
ROUND[12.5]	13.0
ROUND[12.4]	12.0
FIX[12.7]	12.0
FUP[12.2]	13.0
FUP[12.0]	12.0
LN[9]	2.197225
EXP[2]	7.389056

Important: Precaution must be taken when performing calculations within the brackets [] following a mathematical function. The operations within the bracket are performed first, and then the function is performed on this resultant.

Example 27.5 Precaution for Order of Operation

N1#1=1.6;	Parameter #1 is set at 1.6
N2#2=2.8;	Parameter #2 is set at 2.8
N3#3=ROUND[#1+#2];	Parameter #3 is set at 4.0

The values composing parameter #3 are added together first and then rounded, not rounded and then added together.

Parametric Expressions as G- or M-codes

You can use parametric expressions to specify G-codes or M-codes in a program block.

For example:

```
G#1 G#100 G#500 M#1 M#100 M#500;
G#520 G[#521-1] G[#522+10] M#520 M[#522+1] M[#522+10];
```

When using a parametric expression to specify a G- or M-code, remember:

- When specifying more than one G- or M-code in a block from the same modal group, the G- or M-code closest to the End-of-Block of that block is the one activated. All others in that modal group are ignored.
- Parametric expressions that generate G- or M-codes used to call a paramacro are invalid. If the result of the paramacro expression for a G-code is 65, 66, 66.1, or any AMP-defined G-code, the error “ILLEGAL G-CODE” appears. If the result of the paramacro expression for an M-code is any AMP-defined M-code, the control will not execute the macro but interpret the M-code as either a system defined M-code or a user defined M-code. No error is generated.
- To get the G- or M-code value, the system will truncate, after the tenths position, the result of the mathematical expression. The following example assumes #1=37.0:

This Block	Generates This G-Code
G#1	G37.0
G[#1+0.32]	G37.3
G[#1+0.49]	G37.4

Transfer of Control Commands

Use transfer of control commands to alter the normal flow of program execution. Normally the 9/PC control executes program blocks sequentially. By using control commands, the programmer can alter this normal flow of execution and transfer execution to a specific block or begin looping (executing the same set of blocks repetitively).

Important: Transfer of control commands call a block by its N number. If more than one N number exists in a block, the control uses only the left-most N number in that block. If the same N number is used for more than one block, the control uses the first block it encounters with the correct N number (the control searches in the forward direction first, then starts at the top of the program).

Two types of transfer of control commands are available:

- Conditional -- The execution of a jump or loop is dependant on whether a mathematical condition is true.
- Nonconditional -- The execution of a jump or loop is always performed when that block is executed.

Conditional Operators

This section describes conditional operators that are available for paramacro programming. A conditional operator causes a comparison between two values and yields a result of true or false. Use conditional operators in “IF” or “WHILE” commands as described on pages 27-8 and 27-9.

Use the true or false condition to determine whether the “IF” or “WHILE” blocks are executed. Table 27.C lists the conditional operators available for paramacro programming:

Table 27.C
Conditional Operators

Operator	Condition Tested
EQ	Equal
NE	Not Equal
GT	Greater Than
LT	Less Than
GE	Greater Than or Equal
LE	Less Than or Equal

Program a condition between the [and] brackets in this format:

[A EQ B]

where A and B represent some numerical value. The values for A and B can be in the form of some mathematical equation or in the form of a paramacro parameter.

Example 27.6
Evaluation of Conditional Expressions

Expression	Evaluation
[6.03 EQ 6.0301]	FALSE
[6.03 NE 6.0301]	TRUE
[2.5 GT 2.5]	FALSE
[2.5 LT 2.51]	TRUE
[2.51 GE 2.5]	TRUE
[2.5 LE 2.5]	TRUE
[[2.5-3] LE 1]	TRUE
[#1 GT #2]	This depends on the value of the parameters #1 and #2

For details on the use of conditional expressions, see page 27-8 on “IF” statements and 27-9 on “WHILE” statements. For details on the use of paramacro parameters, see page 27-11.

GOTO and IF-GOTO Commands

Unconditional GOTO

Any time the control executes a GOTO block, the unconditional GOTO command automatically transfers control.

Use this format for the GOTO command:

```
GOTO n;
```

Where:	Is:
n	Execution is transferred to the block with the sequence number specified as n any time that the GOTO block is executed.

Example 27.7 Unconditional GOTO

```
N1...;
N2...;
N3GOTO5;
N4...;
N5...;
N6...;
/N7GOTO1;
```

In Example 27.7, execution continues sequentially until block N3 is read; then execution transfers to block N5 and again resumes sequential execution to block N6. If optional block skip 1 is off, block N7 transfers execution back to block N1.

Conditional IF-GOTO

The conditional IF-GOTO command is dependant on whether a mathematical condition is true. If this condition is true, execution transfers to the block specified.

Use this format for the IF-GOTO command:

```
IF [(condition)] GOTO n;
```

Where:	Is:
(condition)	some mathematical condition (refer to page 27-7). This condition is tested by the control to determine if it is true or false.
n	if the condition is tested as true, execution is transferred to the block specified as n

If the condition is tested as false, execution falls through the block and the GOTO is not executed. Program execution continues in a normal fashion.

Example 27.8 Conditional IF

```

N1...;
N2IF[#3EQ-1.5]GOTO5;
N3...;
N4...;
N5...;
N6IF[#4LT3]GOTO1;
N7...;

```

When block N2 is read, parameter #3 is compared to the value -1.5. If the comparison is true, then blocks N3 and N4 are skipped, and execution continues on from block N5. If the comparison is false, then execution continues to block N3. When block N6 is read, parameter #4 is compared to the value 3. If the comparison is true, then execution is transferred to block N1; if it is false, execution continues to block N7.

DO-END and WHILE-DO-END Commands

Unconditional DO-END

The unconditional DO-END command is rarely used. The lack of a condition here causes the control to loop indefinitely until reset or <CYCLE STOP> is pressed, or until some other transfer of control command forces execution out of the loop.

The format for the unconditional DO-END command is as follows:

```

DO m;
:
:
:
END m;

```

Where:	Is:
m	a loop identifier used to relate a DO block with an END block. The value of m must be the same for the DO as it is for the corresponding END. This value can be either 1, 2, or 3.

All blocks between the DO and the END command are executed indefinitely or until execution is stopped by some external operation such as by pressing <E-STOP> or <CYCLE STOP>, or when a block delete is performed if programmed.

Conditional WHILE-DO-END

The conditional WHILE-DO-END command is dependant on whether a mathematical condition is true. If this condition is false, execution transfers to the block immediately following the END statement block.

The following options are not available with OCI:

- software front panel
- standard 9/PC editor
- online search monitor utility
- tool path graphics
- encryption mode
- encryption setup

Use this format for the WHILE-DO-END command:

```
WHILE [ (condition) ] DO m;
;
;
;
END m;
```

Where:	Is:
(condition)	some mathematical condition (refer to page 27-7). This condition is tested by the control to determine if it is true or false.
m	an identifier used by the control to relate a DO block with an END block. The value of m must be the same for the DO as it is for the corresponding END. This value can be either 1, 2, or 3.

All blocks between the DO and the END command are executed until the condition is tested as false. This set of blocks is referred to as a WHILE-DO-END program segment.

When the condition for the WHILE-DO block is tested as false, execution is then transferred to the block immediately following the END statement block.

Example 27.9 WHILE-DO-END Program Segment

```
N1 #1=1;
N2WHILE[#1LT10]DO1
N3#1=[#1+1];
N4...;
N5...;
N6END1;
N7...;
```

In Example 27.9, blocks N2 through N6 are executed nine times. At that time, the condition in block N2 becomes false, and program execution is transferred to block N7.

Nesting is possible with a WHILE-DO-END command. Nesting is defined here as one WHILE-DO-END program segment executing within another WHILE-DO-END program segment.

WHILE-DO-END nesting is limited to three independent segments at one time.

Example 27.10 Nested WHILE DO Commands

```
N1#1=1;  
N2WHILE[#1LT10]DO1;  
N3#1=[#1+1];  
N4WHILE[#1EQ2]DO2;  
N5...;  
N6END2;  
N7END1;  
N8...;
```

In Example 27.10, blocks N2 through N7 are repeated until the condition in block N2 becomes false. Within DO loop 1, DO loop 2 repeats until the condition in block N4 becomes false.

Parameter Assignments

These subsections describe assigning paramacro parameter values and how these parameters are used in a paramacro. Use parameters for paramacros to replace a numeric value. They are used as a variable.

Five types of parameters can be called for use in a paramacro:

- local - independent set of variables assigned to each nested macro
- common - variables available to all programs
- system - variables that indicate specific system condition
- logic - provide variables shared between part programs and logic

The following sections describe these parameters independently. This in no way means that they are not interchangeable in the same macro program. Mixing the different types of parameters in the same paramacro is acceptable.

Local Parameter Assignments

Local parameters are #1 - #33. There are five sets of local parameters. The first set is reserved for use in the main program and any subprogram called by that main program with an M98. The remaining four sets are for each nested level of macro (four levels of nesting maximum).

Assigned parameter values are specific to the individual macro nesting levels. Local parameters are assigned as described on page 27-28.

Local parameters are used in a specific macro to perform calculations and axis motions. After their initial assignment, these parameters can be modified within any macro at the same nesting level. For example macro O11111 called from a main program has 33 local parameter values to work with (#1 to #33). All macros called from the main program, and nested at the same level, uses the same local parameters with the same values unless they are initialized in that macro.

For example macro O11111 called from a main program assigns a value to #1 = 1 and the macro returns execution to the main program with an M98. Later in the same main program (before executing an M99, M02, or M30) macro O11111 is called from the main program again. The value assigned to #1 (=1) remains from the previous macro that executed at that nesting level.

Important: Any local variables you intend to use in a macro we recommend you initialize them before you start using them unless you require values passed from a macro at the same nesting level. In our example above where macro O11111 assigns #1=1. The value of #1 is carried to any macro that is nested at the same nesting level. If for example after macro O11111 returns control to the main program a different macro O22222 is called, the same set of local variables is assigned to O11111 and O22222 because they are both nested at level 1. Confusion could be prevented if before macro O22222 uses #1 it initializes that variable using #1 = 0. All local variables are initialized when the control executes a end of program block (M99, M02, or M30).

Considerations for Local Parameters

When assigning values to local parameters, remember:

- All local variable assignments are reset to zero any time the control reads an M02, M99, or M30 in a part program.
- All local variable assignments are reset to zero any time that power is turned on, the control is reset, or an E-STOP reset operation is executed.
- If more than one I,J, or K set is programmed in an argument, use Table 27.H (B) on page 27-29 for the parameter assignment.

Example 27.11
Assigning Using More Than One I, J, K Set

```
G65P1001K1I2J3J4J5;
```

The above block sets the following parameters:

parameter #6 = 1
parameter #7 = 2
parameter #8 = 3
parameter #11 = 4
parameter #14 = 5

- If the same parameter is assigned more than one value in an argument, only the right-most value is stored for the parameter.

Example 27.12
Assigning the Same Parameter Twice

```
G65P1001R3.1A2R-0.5
```

The above block sets the following parameters:

parameter #1 = 2.0 As set by the A-word
parameter #18 = -0.5 As set by the last R-word.

The 1st value of 3.1, assigned to parameter #18 by the R-word, is replaced by the 2nd value set by the second R-word.

Example 27.13
Assigning The Same Parameter Twice Using I, J, and K

```
G65P1001R2I3.4D5I-0.6
```

The above blocks set the following parameters:

parameter #18 = 2 As set by the R-word.
parameter #4 = 3.4 As set by the 1st I-word.
parameter #7 = -0.6 As set by the 2nd I-word.

The 1st value of 5, assigned to parameter #7 by the D-word, is replaced by the 2nd value set by the second I-word.

Common Parameters

The common parameters refer to parameter numbers 100 to 199 and 500 to 999. The common parameters are assigned through the use of a common parameter table as described on page 27-28.

Common parameters are global in nature. This means that the same set of parameters can be called by any program, macro, subprogram, or MDI program.

Common parameters are divided in to two types: saved or unsaved.

- Saved common parameters refers to the common parameters that retain their value even after power to the control is lost. Saved common parameters are parameter numbers 500 - 999.
- Unsaved common parameters refers to the common parameters that do not retain their value after power to the control is lost. When power to the control is turned back on, these parameters reset their value to zero. Unsaved common parameters are numbers 100 - 199.

The logic programmer can use some of these parameters to check parametric values with the Paramacro Range Check feature. For more information refer to the description of BW_PRMQTY and BW_PRMERR in your 9/PC Logic Reference Manual (8520-9.2).

System Parameters

System parameters may be used by any part program, including paramacros and subprograms. All of these parameters may be used as data or may be changed by assignment (read and write) unless indicated differently in Table 27.D.

These system parameters are generated by the control and can be modified by operation or programming. They correspond to different control conditions such as current operating modes, offsets, etc.

Table 27.D lists the system parameters available on the 9/PC control.

Table 27.D
System Parameters

Parameter #	System Parameter	Page
2001 to 2999	Tool Offset Tables	27-16
3000	² Program Stop With Message (logic)	27-16
3001	System Timer (logic)	27-17
3002	System Clock	27-17
3003	² Block Execution Control 1	27-17
3004	² Block Execution Control 2	27-18
3006	² Program Stop With Message	27-18
3007	¹ Mirror Image	27-19
4001 to 4120	¹ Modal Information	27-19
5001 to 5008	¹ Coordinates of End Point	27-20
5021 to 5028	¹ Coordinates of Commanded Position	27-20
5041 to 5048	¹ Machine Coordinate Position	27-20
5061 to 5068	¹ Skip Signal Position (Work Coordinate)	27-21
5071 to 5078	¹ Skip Signal Position (Machine Coordinates)	27-21
5081 to 5088	¹ Active Tool Length Offsets	27-21
5095 to 5096	Probe stylus length and radius	27-22
5101 to 5108	¹ Current Following Error	27-22
5201 to 5208	External Offset amount	27-22
5221 to 5226	G54 Work Coordinate Table Value	27-23
5241 to 5246	G55 Work Coordinate Table Value	
5261 to 5266	G56 Work Coordinate Table Value	
5281 to 5286	G57 Work Coordinate Table Value	
5301 to 5306	G58 Work Coordinate Table Value	
5321 to 5326	G59 Work Coordinate Table Value	
5341 to 5346	G59.1 Work Coordinate Table Value	
5361 to 5366	G59.2 Work Coordinate Table Value	
5381 to 5386	G59.3 Work Coordinate Table Value	
5630	¹ S-Curve Time per Block	27-24
5661 to 5638	¹ Acceleration Ramps for Linear Acc/Dec Mode	27-24
5651 to 5658	¹ Deceleration Ramps for Linear Acc/Dec Mode	27-24
5671 to 5678	¹ Acceleration Ramps for S-Curve Acc/Dec Mode	27-25
5691 to 5798	¹ Deceleration Ramps for S-Curve Acc/Dec Mode	27-25
5711 to 5718	¹ Jerk	27-25

¹ These parameters may only have their value received (read-only)

² These parameters may only have their value changed (write only)

#2001 to 8801**Tool Offset Tables**

These parameters may be changed or simply read through programming. The values for these parameters are received or entered into the tool offset tables for geometry and wear (described in chapter 3). Table 27.E gives the parameter numbers associated with each table value.

Table 27.E
Tool Offset Table Parameters

	Offset Number	Parameter # for Geometry Table	Parameter # for Wear Table
Tool Length (Axis 1)	1 to 99	#2701 to 2799	#2001 to 2099
Tool Length (Axis 2)	1 to 99	#2801 to 2899	#2101 to 2199
Tool Length (Axis 3)	1 to 99	#8501 to 8599	#8101 to 8199
Tool Length (Axis 4)	1 to 99	#8601 to 8699	#8201 to 8299
Tool Length (Axis 5)	1 to 99	#8701 to 8799	#8301 to 8399
Tool Length (Axis 6)	1 to 99	#8801 to 8899	#8401 to 8499
Tool Radius	1 to 99	#2901 to 2999	#2201 to 2299
Tool Orientation	1 to 99	#2301 to 2399	N/A

#3000**Program Stop With Message (Logic)**

Use this parameter to cause a cycle stop operation and display a message on line 1 of the CRT. Any block that assigns any nonzero value to parameter 3000 results in a cycle stop. The actual value assigned to parameter 3000 is not used. Parameter 3000 is a write only parameter.

When the control executes this block, a cycle stop is performed and the message "SEE PART PROGRAM FOR MACRO STOP MESSAGE" is displayed on line 1 of the CRT. This is intended to point out to the operator an important comment in the program block that assigns a value to parameter 3000 (refer to chapter 9 on comment blocks).

For example, programming

```
#3000=.1 (TOOL NUMBER 6 IS WORN);
```

causes program execution to stop at the beginning of this block and displays a message telling the operator to read the comment in the block. A block reset must be performed before a cycle start resumes normal program execution.

When this block is executed, it also sets the paramacro alarm logic flag (BR_MCALRM) true. Refer to the system installer’s documentation for details on the effect of this logic flag.

**#3001
System Timer (Logic)**

This parameter is referred to as the timer parameter. It is a read-write parameter. Every 20ms a value of 20 is added to the value of parameter 3001. The value of this parameter is also stored by a logic flag (\$PM20MS) and may be modified or set by the system installers logic program. Refer to the system installer’s documentation for details on the use of this timer. The maximum value of this parameter is 32768ms. Any value greater than 32768 causes this parameter to “roll over” to zero and restart counting again. The value of this parameter is reset to zero every time power is lost.

**#3002
System Clock**

This parameter is referred to as a clock parameter and references an hour counter. It is a read-write parameter with negative value assignments being illegal. The maximum value for this parameter is 1 year (8760 hours). The parameter value is maintained when power is lost. It is incremented by .000005556 every 20 ms.

**#3003
Block Execution Control 1**

Use this parameter to control whether the control ignores single-block mode and to control when M-codes are executed in a block. The value of this parameter ranges from 0 to 3, and it is a write only parameter.

These results occur when parameter 3003 is set to the corresponding values:

Value:	Single-block mode:	M-codes are executed:
0	can be activated	at the beginning of the program blocks execution
1	requests are ignored	

Value:	Single-block mode:	M-codes are executed:
2	can be activated	after the complete execution of the other commands in the block
3	requests are ignored	

#3004**Block Execution Control 2**

This parameter determines whether a cycle stop request is recognized, whether the feedrate override switch is active, and whether exact stop mode is available (G61 mode). The range of this parameter is from 0 to 7 and it is a write only parameter.

Table 27.F shows the results of the different values for parameter number 3004. If they are ignored, the control does not let you use the feature. If they are recognized, you can activate the feature in the normal manner.

Table 27.F
Parameter 3004 Values

Value of Parameter	Cycle Stop	Feedrate Override	Exact Stop Mode
0	Recognized	Recognized	Recognized
1	Ignored	Recognized	Recognized
2	Recognized	Ignored	Recognized
3	Ignored	Ignored	Recognized
4	Recognized	Recognized	Ignored
5	Ignored	Recognized	Ignored
6	Recognized	Ignored	Ignored
7	Ignored	Ignored	Ignored

#3006**Program Stop With Message**

Use this parameter to cause a cycle stop operation and display a message on line 1 of the CRT. Any block that assigns a new value to the parameter 3006 results in a cycle stop. Any decimal value may be assigned to this parameter the value of which is not used.

When the control executes this block, a cycle stop is performed and the message "SEE (MESSAGE) IN PART PROGRAM BLOCK" is displayed on line 1 of the CRT. This is intended to point out to the operator an important comment in a program block (refer to chapter 9 on comment blocks). This parameter is a write only.


For example, programming:

```
#3006=.1 (Install Tool Number 6);
```

causes program execution to stop at the beginning of this block and displays a message telling the operator to read the comment in the block.

**#3007
Mirror Image**

This parameter is a read-only. It generates an integer that represents, in binary, what axes are mirrored. For example, if the value of this parameter was 3, the binary equivalent for this is 000011. The first digit of this binary equivalent (reading right to left) corresponds to axis 1, the second is axis 2, the third is axis 3, etc., up to the number of axes configured in your system. When a zero is in the binary location for an axis, it indicates that the axis is not mirrored. If a 1 is in that axis location, that axis is mirrored. For example, if the parameter #3007 is the integer 11 (binary 001011), it indicates axes 1, 2, and 4 are mirrored and axes 3, 5, and 6 are not mirrored.



Where:

- 0 indicates axis is not mirrored
- 1 indicates axis is mirrored

This parameter reflects both the programmed and front-panel (external mirror) status of mirroring on the axes.

**#4001 to 4120
Modal Information**

These are read-only parameters. They indicate the value of a modal program word. Table 27.G shows the modal program word that applies to the given parameter number.

**Table 27.G
Modal Data Parameters**

Parameter Number	Modal Data Value
4001 to 4025	These correspond to the different G-code Groups 1-25 (refer to chapter 9) and show what G-code from group is currently active.
4108	Current E-word value
4109	Current F-word value
4113	Most recently programmed M-code
4114	Most recently programmed N-word
4115	Current program number O-word
4119	Current S-word value
4120	Current T-word value

For example, if currently programming in G02 mode at a feedrate of 100, the parameters would be as follows:

G02 is a group 1 G-code, so its value of 02 is set to parameter number 4001.

The feedrate programmed with an F-word gives parameter number 4109 a value of 100.

#5001 to 5008 Coordinates of End Point

These parameters are read-only. They correspond to the coordinates of the end point (destination) of a programmed move. These are the coordinates in the work coordinate system.

5001	Axis 1 coordinate position	5005	Axis 5 coordinate position
5002	Axis 2 coordinate position	5006	Axis 6 coordinate position
5003	Axis 3 coordinate position	5007	Axis 7 coordinate position
5004	Axis 4 coordinate position	5008	Axis 8 coordinate position

The system installer determines in AMP the name (or word) that is used to define the axis.

#5021 to 5028 Coordinates of Commanded Position

These parameters are read-only. They correspond to the current coordinates of the cutting tool. These are the coordinates in the work coordinate system.

5021	Axis 1 coordinate position	5025	Axis 5 coordinate position
5022	Axis 2 coordinate position	5026	Axis 6 coordinate position
5023	Axis 3 coordinate position	5027	Axis 7 coordinate position
5024	Axis 4 coordinate position	5028	Axis 8 coordinate position

The system installer determines in AMP the name (or word) that is used to define the axis.

#5041 to 5048 Machine Coordinate Position

These parameters are read-only. They correspond to the coordinates of the cutting tool in the machine (absolute) coordinate system.

5041	Axis 1 coordinate position	5045	Axis 5 coordinate position
5042	Axis 2 coordinate position	5046	Axis 6 coordinate position
5043	Axis 3 coordinate position	5047	Axis 7 coordinate position
5044	Axis 4 coordinate position	5048	Axis 8 coordinate position

The system installer determines in AMP the name (or word) that is used to define the axis.

#5061 to 5068

Skip Signal Position Work Coordinate Position

These parameters are read-only. They correspond to the coordinates of the cutting tool when a skip signal is received to logic from a probe or other device such as a switch. These are the coordinates in the work coordinate system.

5061	Axis 1 coordinate position	5065	Axis 5 coordinate position
5062	Axis 2 coordinate position	5066	Axis 6 coordinate position
5063	Axis 3 coordinate position	5067	Axis 7 coordinate position
5064	Axis 4 coordinate position	5068	Axis 8 coordinate position

The system installer determines in AMP the name (or word) that is used to define the axis.

#5071 to 5078

Skip Signal Position Machine Coordinate System

These parameters are read-only. They correspond to the coordinates of the cutting tool when a skip signal is received to logic from a probe or other device such as a switch. These are the coordinates in the machine (absolute) coordinate system.

5071	Axis 1 coordinate position	5075	Axis 5 coordinate position
5072	Axis 2 coordinate position	5076	Axis 6 coordinate position
5073	Axis 3 coordinate position	5077	Axis 7 coordinate position
5074	Axis 4 coordinate position	5078	Axis 8 coordinate position

The system installer determines in AMP the name (or word) that is used to define the axis.

#5081 to 5088

Active Tool Length Offsets

These are read-only parameters. They correspond to the currently active tool length offsets (refer to chapter 19).

5081	Current axis 1 tool length offset.	5085	Current axis 5 tool length offset.
5082	Current axis 2 tool length offset.	5086	Current axis 6 tool length offset.
5083	Current axis 3 tool length offset.	5087	Current axis 7 tool length offset.
5084	Current axis 4 tool length offset.	5088	Current axis 8 tool length offset.

#5095 to 5096**Probe Stylus Length and Radius**

These parameters correspond to the values set in the probing cycle parameter table discussed in chapter 26. When values are assigned to these parameters, the current values in the probe table is replaced.

5095	Probe stylus Length
5096	Probe stylus Radius

For details on probe radius and length parameters, refer to chapter 26 on tool gauging.

#5101 to 5108**Current Following Error**

These parameters are read-only. They correspond to the current following error for an axis.

5101	Axis 1 following error	5105	Axis 5 following error
5102	Axis 2 following error	5106	Axis 6 following error
5103	Axis 3 following error	5107	Axis 7 following error
5104	Axis 4 following error	5108	Axis 8 following error

The system installer determines in AMP the name (or word) that is used to define the axis. The following error of a system constantly changes. You can use this parameter to take a “snapshot” of the following error, but the value that is read may not the current following error of the system.

#5201 to 5208**External Offset Amount**

These parameters are read or write. They correspond to the current value set in the work coordinate table for the external offset (refer to chapter 3). This allows the reading of data from the tables and also the setting of data into the table by assigning values to the parameters.

5201	Axis 1 offset amount	5205	Axis 5 offset amount
5202	Axis 2 offset amount	5206	Axis 6 offset amount
5203	Axis 3 offset amount	5207	Axis 7 offset amount
5204	Axis 4 offset amount	5208	Axis 8 offset amount

The system installer determines in AMP the name (or word) that is used to define the axis. Changes made to the external offset using this paramacro variable go into effect only after the axis has been rehomed, or power to the control has been cycled.

#5221 to 5386

Work Coordinate Table Value

These parameters are read or write. They correspond to the current value set in the work coordinate table for the G54 - G59 work coordinate systems (refer to chapter 3). This lets you read data from the tables and also set data into the table by assigning values to the parameters.

5221	G54 Axis 1 Coordinate
5222	G54 Axis 2 Coordinate
5223	G54 Axis 3 Coordinate
5224	G54 Axis 4 Coordinate
5225	G54 Axis 5 Coordinate
5226	G54 Axis 6 Coordinate

5241	G55 Axis 1 Coordinate
5242	G55 Axis 2 Coordinate
5243	G55 Axis 3 Coordinate
5244	G55 Axis 4 Coordinate
5245	G55 Axis 5 Coordinate
5246	G55 Axis 6 Coordinate

5261	G56 Axis 1 Coordinate
5262	G56 Axis 2 Coordinate
5263	G56 Axis 3 Coordinate
5264	G56 Axis 4 Coordinate
5265	G56 Axis 5 Coordinate
5266	G56 Axis 6 Coordinate

5281	G57 Axis 1 Coordinate
5282	G57 Axis 2 Coordinate
5283	G57 Axis 3 Coordinate
5284	G57 Axis 4 Coordinate
5285	G57 Axis 5 Coordinate
5286	G57 Axis 6 Coordinate

5301	G58 Axis 1 Coordinate
5302	G58 Axis 2 Coordinate
5303	G58 Axis 3 Coordinate
5304	G58 Axis 4 Coordinate
5305	G58 Axis 5 Coordinate
5306	G58 Axis 6 Coordinate

5321	G59 Axis 1 Coordinate
5322	G59 Axis 2 Coordinate
5323	G59 Axis 3 Coordinate
5324	G59 Axis 4 Coordinate
5325	G59 Axis 5 Coordinate
5326	G59 Axis 6 Coordinate

5341	G59.1 Axis 1 Coordinate
5342	G59.1 Axis 2 Coordinate
5343	G59.1 Axis 3 Coordinate
5344	G59.1 Axis 4 Coordinate
5345	G59.1 Axis 5 Coordinate
5346	G59.1 Axis 6 Coordinate

5361	G59.2 Axis 1 Coordinate
5362	G59.2 Axis 2 Coordinate
5363	G59.2 Axis 3 Coordinate
5364	G59.2 Axis 4 Coordinate
5365	G59.2 Axis 5 Coordinate
5366	G59.2 Axis 6 Coordinate

5381	G59.3 Axis 1 Coordinate
5382	G59.3 Axis 2 Coordinate
5383	G59.3 Axis 3 Coordinate
5384	G59.3 Axis 4 Coordinate
5385	G59.3 Axis 5 Coordinate
5386	G59.3 Axis 6 Coordinate

The system installer determines in AMP the name (or word) that is used to define the axis.

#5630**S-Curve Time per Block**

This parameter is read only. The value represents the amount of time (seconds converted to system scans) for a part program block's S-Curve filter where S-Curve Acc/Dec is applied during G47.1 mode. When it is multiplied by the scan time, the product equals the amount of time required by the acceleration.

This parameter is only calculated for blocks that have programmed motion with S-Curve Acc/Dec.

#5631 to 5638**Acceleration Ramps for Linear Acc/Dec Mode**

These parameters are read only. They correspond to the active acceleration ramps in Linear Acc/Dec mode. You can set these parameters by programming a G48.1 in your part program block. Control Reset, Program End (M02/M03), or G48 will reset these values to their default AMP values. For more information about programming G48.x codes, refer to chapter 17 in this manual.

5631	Axis 1 acceleration ramp	5635	Axis 5 acceleration ramp
5632	Axis 2 acceleration ramp	5636	Axis 6 acceleration ramp
5633	Axis 3 acceleration ramp	5637	Axis 7 acceleration ramp
5634	Axis 4 acceleration ramp	5638	Axis 8 acceleration ramp

#5651 to 5658**Deceleration Ramps for Linear Acc/Dec Mode**

These parameters are read only. They correspond to the active deceleration ramps in Linear Acc/Dec mode. You can set these parameters by programming a G48.2 in your part program block. Control Reset, Program End (M02/M03), or G48 will reset these values to their default AMP values. For more information about programming G48.x codes, refer to chapter 17 in this manual.

5651	Axis 1 deceleration ramp	5655	Axis 5 deceleration ramp
5652	Axis 2 deceleration ramp	5656	Axis 6 deceleration ramp
5653	Axis 3 deceleration ramp	5657	Axis 7 deceleration ramp
5654	Axis 4 deceleration ramp	5658	Axis 8 deceleration ramp

#5671 to 5678**Acceleration Ramps for S-Curve Acc/Dec Mode**

These parameters are read only. They correspond to the active acceleration ramps in S-Curve Acc/Dec mode. You can set these parameters by programming a G48.3 in your part program block. Control Reset, Program End (M02/M03), or G48 will reset these values to their default AMP values. For more information about programming G48.x codes, refer to chapter 17 in this manual.

5671	Axis 1 acceleration ramp	5675	Axis 5 acceleration ramp
5672	Axis 2 acceleration ramp	5676	Axis 6 acceleration ramp
5673	Axis 3 acceleration ramp	5677	Axis 7 acceleration ramp
5674	Axis 4 acceleration ramp	5678	Axis 8 acceleration ramp

#5691 to 5698**Deceleration Ramps for S-Curve Acc/Dec Mode**

These parameters are read only. They correspond to the active deceleration ramps in S-Curve Acc/Dec mode. You can set these parameters by programming a G48.4 in your part program block. Control Reset, Program End (M02/M03), or G48 will reset these values to their default AMP values. For more information about programming G48.x codes, refer to chapter 17 in this manual.

5691	Axis 1 deceleration ramp	5695	Axis 5 deceleration ramp
5692	Axis 2 deceleration ramp	5696	Axis 6 deceleration ramp
5693	Axis 3 deceleration ramp	5697	Axis 7 deceleration ramp
5694	Axis 4 deceleration ramp	5698	Axis 8 deceleration ramp

#5711 to 5718**Jerk**

These parameters are read only. They are only applicable to the current jerk values when S-Curve Acc/Dec mode is active. You can set these parameters by programming a G48.5 in your part program block. Control Reset, Program End (M02/M03), or G48 will reset these values to their default AMP values. For more information about programming G48.x codes, refer to chapter 17 in this manual.

5711	Axis 1 jerk	5715	Axis 5 jerk
5712	Axis 2 jerk	5716	Axis 6 jerk
5713	Axis 3 jerk	5717	Axis 7 jerk
5714	Axis 4 jerk	5718	Axis 8 jerk

Logic Parameters

Paramacro parameters are provided on the 9/PC control to allow a means of communicating values between the logic program and the part program. This is done by assigning values to specific paramacro parameters or logic flags. They are:

- Input parameters

Use these parameters to transfer data from logic to the part program

- Output parameters

Use these parameters to transfer data from the part program to logic. Some applications may, however, use the output flags transfer data from logic to the part program as needed.

Input Flags:

The paramacro input parameters available to the part programmer are:

These are 4-integer or 3-integer and 32-bit pattern input parameters available. The part program may only read the values assigned to these parameters; it may not write values to them. The paramacro input parameters available to the part programmer are:

- #1000 - #1031 and #1040 - #1071

These paramacro logic parameters are used to display the binary equivalent of the integer assigned to #1032. #1000 is the first bit, #1001 is the second bit, #1002 is the third bit, and so forth up to parameter #1031 (which is the 32nd bit).

The second set of parameters, #1040 - #1071, functions the same way.

- #1032 - #1035 and #1072 - #1075

The control always interprets parameter #1032, #1033, #1034, and #1035 as integer values regardless of how they are assigned in logic (as an integer or on a per bit basis). #1032 is the only parameter that may also be interpreted by the control on a per-bit basis using parameters #1000 - #1031. Logic may always interpret these values on either a per-bit basis or as integer values.

The second set of parameters, #1072 - #1075, functions the same way.

See the system installer's documentation for a detailed description of the use and operation of these input flags.

Output Flags:

Output flags function almost identically to input flag with one key difference. Where input flags may only be read by the part program, output flags may be both read and written to by the part program. Typically these are used only to output information to the logic program from the part program; however, if the available number of input flags is not sufficient for a given application, the Output flags may also be used to send information to the part program from logic.

Output flags should not be used as Input flags unless absolutely necessary. This is because the operator/programmer has the ability to inadvertently write data to the Output flags, whereas the Input flags cannot be written to from the control.

Output flags are broken into four 32-bit words. The part programmer can only assign or read the values of to these flags as integers with the exception of parameter #1032 which may be assigned as an integer or as a bit pattern. The paramacro output input parameters available to the part programmer are:

- #1100 - #1131 and #1140 - #1171

When the values of these parameters are assigned in the part program, they should be assigned values of 1 or 0 (as bit patterns). If any integer value other than zero is assigned to these parameters, logic interprets it as a 1. These paramacro logic parameters are used to pass the binary equivalent of the integer assigned to #1132. #1100 is the first bit, #1101 is the second bit, #1102 is the third bit, and so forth up to parameter #1131 (which is the 32nd bit). When a value is assigned to #1132, the values assigned to #1100 - #1131 are overwritten with the binary equivalent of #1132.

The second set of parameters, #1140 - #1171, functions the same way.

- #1132 - #1135 and #1172 - #1175

The control always interprets these parameters as **integer** values. #1132 is the only parameter that may also be interpreted by the part program on a per-bit basis using parameters #1100 - #1131.

The second set of parameters, #1172 - #1175, functions the same way.

See the system installer's documentation for a detailed description of the use and operation of these input flags.

Assigning Parameter Values

There are three methods for assigning parameters. They can be assigned by:

- using arguments (only available for local parameters)
- direct assignments
- using tables (view or set common parameters, view local parameters)

Assigning Parameters Using Arguments

Arguments may be used only to assign local parameter values. System, Common, and logic variables cannot be assigned by using arguments. Usually parameters assigned by using an argument are variables for a macro. They are usually specific to the part currently being cut (for example, the length and diameter of a shaft in a macro that turns a shaft).

The 9/PC control provides five sets of local parameters. The first set of local parameters (those that apply to the main program and any subprogram call) may not be assigned using arguments. The second through fifth sets may be assigned by their association to given words in an argument statement located in a paramacro calling block. Table 27.H gives a listing of arguments and their corresponding parameter numbers.

These arguments assign values to the local parameters associated with the paramacro called in the same block.

**Table 27.H
Argument Assignments**

(A)		(B)		
Word Address	Parameter Assigned	I, J, K Set #	Word Address	Parameter Assigned
A	#1	1	I	#4
B	#2		J	#5
C	#3		K	#6
D	#7	2	I	#7
E	#8		J	#8
F	#9		K	#9
H	#11	3	I	#10
I*	#4		J	#11
J*	#5		K	#12
K*	#6	4	I	#13
M	#13		J	#14
Q	#17		K	#15
R	#18	5	I	#16
S	#19		J	#17
T	#20		K	#18
U	#21	6	I	#19
V	#22		J	#20
W	#23		K	#21
X	#24	7	I	#22
Y	#25		J	#23
Z	#26		K	#24
		8	I	#25
			J	#26
			K	#27
		9	I	#28
			J	#29
			K	#30
		10	I	#31
			J	#32
			K	#33

* If more than one I, J, or K set is programmed in a block, use Table 27.H (B) for the parameter assignment.

To enter a value for a parameter # using an argument, enter the word corresponding to the desired parameter number in a block that calls a paramacro (for legal argument locations, see specific formats for calling the macro) followed by the value to assign that parameter. For example:

```
G65P1001A1.1 B19;
```

assigns the value of:

1.1 to local parameter #1 in paramacro 1001

19 to local parameter #2 in paramacro 1001

You can specify arguments as any valid parametric expression. For example:

```
G246A#100B[#500+10.0]C[SIN[#101]];
```

Direct Assignment Through Programming

This assignment method applies to Local, Common, System, and logic parameters. You can perform direct assignment in Main, Macro, or MDI programs. Direct assignment is done by setting the parameter equal to some value in an equation using the “ = ” operator. For example, to assign a value of 2 to parameter number 100, simply enter the following program block:

```
#100=2;
```

The value to the left of the equals sign must contain the # sign followed by a legal parameter number. This parameter number may also take on the form of:

```
#parameter expression = parameter expression
```

Example 27.14 Calling Parameter Numbers

```
#6=1;
#144=1;
#[SIN[#6]]=1;
#[148/2]=1;
#[#6]=1;
```

All of the above can be used as legal parameter numbers. Any time that a different parameter is used between the [] symbols, the current value of that parameter is used for evaluation. For example:

```
#1=4;
#1=#1+2;
```

The net result of the above two blocks would be the assignment of a value of 6 to parameter #1.

**Example 27.15
Assigning Parameters:**

```
#100=1+1;
#100=5-3;
#100=#3;
#100=#7+1;
#100=#100+1;
```

You can also assign multiple paramacro parameters in a single block. In a multiple assignment block, each assignment is separated by a comma. For example:

```
#1=10,#100=ROUND[#2+#3],#500=10.0*5;
```

If you use multiple assignments in the same block, remember:

- You can enter as many assignments as can be typed into one block (127 characters maximum).
- For local and common parameters, block execution is from left to right. For example:

```
#1 = 10,#2=#1+2;
```

When executed, #1 is 10 and #2 is 12

- Once the first paramacro parameter assignment is made in a block, only assignment syntax is allowed in that block. You cannot program other information in that block, including programming a G-code. For example:

```
#1 = 19.0,G1X10;
```

gets the error message, “PARAMETER ASSIGNMENT SYNTAX ERROR”

- Only assign the same parameter a value once in each block. For example:

```
#1=5,#2=4,#1=6;
```

causes the error message “PARAMETER ASSIGNMENT SYNTAX ERROR” to appear, since #1 is assigned a value twice in the same block (#1=5 and #1=6).

Direct Assignment Through Tables

Use this feature to view or set common parameters and view local parameters. Assignment through tables is generally used to edit common parameters.

Access the paramacro tables using the following steps:

1. Press the **{MACRO PARAM}** softkey.

(softkey level 1)

	PRGRAM MANAGE	OFFSET	MACRO PARAM	PRGRAM CHECK	SYSTEM SUPT	→
F2	F3	F4	F5	F6	F7	F8

		ERROR MESSAGE	PASS- WORD	SWITCH LANG		→
F2	F3	F4	F5	F6	F7	F8

2. Press the appropriate softkey for the table to be viewed. The macro parameters are separated in to 4 tables:

- **{LOCAL PARAM}** softkey - Use this softkey to view the local parameters of the currently active program (unless the block look ahead has scanned an upcoming paramacro call). This table includes parameters numbered 1 - 33. Only one of the five available sets can be viewed on this screen at any one time. The local parameters reset to zero at the end of program command (M02 or M30).
- **{COM-1 PARAM}** softkey - Use this softkey to view or edit the common parameters numbered 100 - 199 (available to any program, subprogram, or paramacro program). These common parameters lose their value and are reset to zero when power to the control is turned off.
- **{COM-2A PARAM}** softkey - Use this softkey to view or edit the common parameters (available to any program, subprogram, or paramacro program) numbered 500 - 519. Their value is retained even when power to the control is cycled off. In addition to being backed up, these parameters allow an alphanumeric name to be assigned to them. This alphanumeric name is only for the purpose of easy identification. It may not be used to call a common parameter in a program.
- **{COM-2B PARAM}** softkey - Use this softkey to view or edit the common parameters. Their value is retained even when power to the control is cycled off. They differ from common 2A parameters in that they do not allow an additional name to be stored in the table with their values.

If viewing the local parameter table, do not continue to step 3. If editing one of the common tables, move on to step 3.

(softkey level 2)

↑	LOCAL PARAM	COM-1 PARAM	COM-2A PARAM	COM-2B PARAM		→
F2	F3	F4	F5	F6	F7	F8

3. Select a parameter to change by moving the cursor to the desired parameter number. The selected parameter is shown in reverse video. Move the cursor by an entire page by pressing the up or down cursor key while holding down the [SHIFT] key.

Pressing the {SEARCH NUMBER} softkey allows a rapid search for the desired parameter number. To use this feature to position the cursor, press the {SEARCH NUMBER} softkey. Key in the desired parameter number and press the [ENTER] key. The entered parameter number is shown in reverse video.

4. Select and complete the appropriate step to alter the common parameter values. The three options include:
 - **To replace the current value of the selected parameter,** press the {REPLCE VALUE} softkey. Key in the new value for the parameter and press the [ENTER] key. The old value is replaced with the value just keyed in.
 - **To zero the current of a selected parameter,** press the {ZERO VALUE} softkey. The message "SELECT VALUE TO ZERO AND PRESS ENTER" appears. Select the parameter which is to be set to zero, and press the [ENTER] key. The current value of the selected parameter is replaced with zero.
 - **To zero all of the parameter values that are found in this parameter table,** press the {0 ALL VALUES} softkey. The control displays the prompt "OK TO ZERO ALL VALUES? (Y/N):" Press the Y character followed by the [ENTER] key to zero all parameter values in the table. Press the N character followed by the [ENTER] key to abort the operation.
 - While viewing one of the parameter screens during program execution, any changes to a parameter value on that screen that are made by the program are updated and displayed. By pressing the {REFRSH SCREEN} softkey, any parameters that have been changed by the program are updated to their current values.
5. If you pressed the {COM-2A PARAM} softkey (in step 2), additional softkeys are available to alter the parameter name. Select and complete the appropriate step to alter the common parameter names. The three options include:
 - **To edit an existing parameter name or enter a parameter name for the first time for a local parameter,** press the {REPLCE NAME} softkey. Key in a parameter name for the parameter. A name may be up to 8 characters long and include any alphanumeric character with the exception of a few of the special symbols. After the name is keyed in, press the [ENTER] key. The new parameter name is displayed next to the value of that parameter.

- **To clear a parameter name so that no name is displayed next to the parameter on the screen**, press the {CLEAR NAME} softkey. The message “SELECT NAME TO CLEAR AND PRESS ENTER” appears. Select the name to clear and press the [ENTER] key. The currently selected parameter name is deleted.
- **To clear all of the parameter names that are found on the {COMMON 2A} screen for all of the parameters**, press the {CLEAR ALL NM} softkey. The prompt “OK TO CLEAR ALL NAMES? (Y/N): ” appears. Press Y followed by the [ENTER] key if it is okay to delete all parameter names. Press N followed by the [ENTER] key if you want to abort the delete-all-name operation.
 - The parameter name is used only for display purposes. It has no real function other than to permanently label a parameter value. The parameter name is retained as is the parameter value for these parameters even after power is turned off. The softkeys used to edit the parameter name operate this way:

(softkey level 3)

↑	SEARCH NUMBER				REFRESH SCREEN	
F2	F3	F4	F5	F6	F7	F8

Addressing Assigned Parameters

Once you assign a parameter you can address it in a program:

Example 27.16 Addressing Assigned Parameters

```
#100=5;
#105=8;
G01X#100+5 ;   Axis moves to 10.
G01x[#100+5]   Axis moves to 8
```

You can also indirectly address parameters with other parameters

Example 27.17 Indirectly Addressing Parameters

```
#100=101
#101=2.345
G01 X#[#100]; X axis moves to the
                contents of #100 which
                is #101. #101 has the
                value of 2.345.
```

Backing Up Parameter Values

You can back up the contents of COM1, COM2A, or COM2B individually, or all of these simultaneously, by using the BACKUP softkeys.

(softkey level 2)

↑	LOCAL PARAM	COM-1 PARAM	COM-2A PARAM	COM-2B PARAM		→
F2	F3	F4	F5	F6	F7	F8
↑	BACKUP COM-1	BACKUP COM-2A	BACKUP COM-2B		BACKUP ALL	→
F2	F3	F4	F5	F6	F7	F8

To back up parameters:	Press this softkey:
#100 - 199	{ BACKUP COM1 }
#500 - 519	{ BACKUP COM2A }
#520 - 999	{ BACKUP COM2B }
all of the above	{ BACKUP ALL }

1. Press the appropriate BACKUP softkey.

The system prompts you for a file name.

2. Enter a name for the backup file and press [**ENTER**].

The system verifies the file name and backs up the selected parameters into the specified part program. You can restore these parameters by selecting and executing that part program.

Important: If part program calculations cause an overflow value, then the generated backup file contains an M00 and the parameter number followed by the word “OVERFLOW” as a comment.

Macro Call Commands

When a paramacro is called, execution of the currently active part program is halted, and execution is transferred to the macro program. Call paramacros in the following ways:

- Programming G65 in a part program
- Programming G66 or G66.1 in a part program
- Setting the proper AMP data can call a paramacro with the programming of specific G-, T-, S-, M-, and B-codes

You can use a paramacro call to call any program that has a program name of up to five numeric digits following the letter O (refer to chapter 9 on program names). This program must also contain an M99 end of subprogram or macro code somewhere in the program before an M02 or M30 is read. This M99 code causes control to return to the main program or restarts the paramacro if it is to be executed more than one time.

Important: The M99 code may be programmed anywhere in a paramacro program block provided no axis words are programmed to the left of the M99. Any information (other than axis words) programmed to the left of M99 is executed as part of the paramacro. Any information (including axis words) programmed in the block to the right of the M99 command is ignored.

M99X10;	X10 is ignored
X10M99;	Error is generated
M03M99;	M03 is executed

After the control has executed the macro the specified number of times (as specified by the L-word), execution is returned to the block following the paramacro call in the calling program.



ATTENTION: Any edits made to a subprogram, or to a paramacro program (as described in chapter 5) that has already been called for automatic execution, are ignored until the calling program is disabled and reactivated. Subprograms and paramacros are called for automatic execution the instant that the calling program is selected as active (refer to chapter 7).

Nonmodal Paramacro Call (G65)

Use this format for calling a paramacro using the G65 command:

G65 P_ L_ A_ B_ ;

Where:	Is:
P	Indicates the program number of the called macro. P ranges from 1 - 99999.
L	Programs the number of times the macro is executed. L ranges from 1 - 9999, and may be expressed as any valid parametric expression. If not specified, the control uses a default value of 1.
A-Z	Optional argument statements. May be programmed using any letter from A to Z excluding G, L, N, O, or P. Used to assign numeric values to parameters in the paramacro (see Table 27.H). Arguments may be specified as any valid parametric expression.

The G65 command is nonmodal. The macro is executed only at the time the control executes the G65 block. The control calls the macro specified by the G65 block as programmed by the P-word.

The control executes this macro until the control reaches an M99 macro return code. The macro then returns to the next unexecuted sequential block in the calling program unless the macro has not been repeated the number of times as determined by the L-word. If this is the case, the macro re-executes.

You can define the L-word or any optional argument statements in a G65 block by using any valid parametric expression. For example:

```
G65 P1002 L[#1+1] A[12*6] B[SIN[#101]];
```

Modal Paramacro Call (G66)

Use this format for calling a paramacro using the G66 command:

```
G66 P_ L_ A_ B_;
```

Where:	Is:
P	Indicates the program number of the called macro. P ranges from 1 - 99999.
L	Programs the number of times the macro is executed after each motion block that follows the G66. L ranges from 1 - 9999, and may be expressed as any valid parametric expression. If not specified, the control uses a default value of 1.
A-Z	Optional argument statements. May be programmed using any letter from A to Z excluding G, L, N, O, or P. Used to assign numeric values to parameters in the paramacro (see Table 27.H). Arguments may be specified as any valid parametric expression.

The G66 command is modal and remains in effect until canceled with a G67 block. The macro programmed by the P-word in the G66 block is not executed when the G66 block is read. The control delays macro execution to any block following the G66 command that contains a motion command.

When the control encounters a motion block (even if this block is contained in a different macro) following the G66 block, it executes the motions called for by that block first. After that block has been executed, the control then calls the macro specified by the G66 block.

The control executes this macro until the control reaches an M99 macro return code. The macro then returns to the next unexecuted sequential block in the calling program unless the macro has not been repeated the number of times as determined by the L-word. If this is the case, the macro re-executes.

Each time that a specific macro is called by a motion command, it is executed the number of times programmed with the L-word. All local variables remain at their current value throughout the program unless replaced, the control is reset, E-STOP is reset, or the control encounters an M02 or an M30 code in a program.

An L-word programmed with a G66 macro call cannot be replaced without re-programming the entire G66 block with the new L-word. An L-word is active each time the macro is called by the main program and causes the macro to be executed the number of times programmed with L.

You can define the L-word or any optional argument statements in a G66 block by using any valid parametric expression. For example:

```
G66 P1002 L[#1+1] A[12*6] B[SIN[#101]];
```

Unlike nonmodal macro calls, the G66 macro call repeats automatically after any axis move until cancelled by a G67 block. This also applies to nested macros. When the control begins execution of the nested macro 1002 in the program below, each axis move in the nested macro also calls for the execution of the macro 1001.

Example 27.18 Modal Macro Call

```
N0100G66P1001;
N0200G65P1002;
```

In Example 27.18, after the complete execution of the macro 1002, the macro 1001 is called. Any motion blocks in macro 1002 cause macro 1001 to be executed.

Example 27.19 Modal Macro Operation

(MAIN);

```
O1000;
N010G90;
N020G66P1001L2A1.1;
N030X1;

N040Z.25

N050G66P1002A2;
N060X1.;

N070G67;
N090G67;
N100M30;
```

Parameter #1 is set at 1.1 in macro 1001.
X Axis is moved 1 unit and then macro 1001 is called and executed 2 times.
Z Axis is moved .25 units and then macro 1001 is called and executed 2 times.
Parameter #1 is set at 2. in macro 1002.
X axis is moved 1 unit then macro 1002 is called and executed once.
Macro 1002 is canceled.
Macro 1001 is canceled.

(MACRO);

```
O1001;
N200Z#1;

N210#1=1.7
N220M99;
```

Z Axis moves an amount equal to the current value for parameter #1
Parameter #1 for macro 1001 is set at 1.7.
Macro end.

(MACRO);

```
O1002;
N300Z#1;

N310M99;
```

Z Axis moves an amount equal to the current value set parameter #1 (in this case always 2 units). Macro 1001 is called and executed twice.
Macro end.

Important: When the control executes block N040, the original value as set in block N020 for parameter number 1 is ignored, and the most current value (1.7) is used. The first time macro 1001 is executed, Z moves 1.1 units. The second time macro 1001 is executed, Z moves 1.7 units.

Modal Paramacro Call (G66.1)

Use this format for calling a paramacro using the G66.1 command:

```
G66.1 P_ L_ A_ B_;
```

Where:	Is:
P	Indicates the program number of the called macro. P ranges from 1 - 99999.
L	Programs the number of times the macro is executed. L ranges from 1 - 9999, and may be expressed as any valid parametric expression. If not specified, the control uses a default value of 1.
A-Z	Optional argument statements. May be programmed using any letter from A to Z excluding G, L, N, O, or P. Used to assign numeric values to parameters in the paramacro (see Table 27.H). Arguments may be specified as any valid parametric expression.

The G66.1 command is modal and is executed in the same manner as the G66 with these exceptions:

- The macro programmed by the P-word in the G66 block is not executed when the G66 block is read, whereas the macro programmed by the G66.1 is executed when G66.1 is read.
- The macro is executed in any and all blocks following the G66.1, not just after motion blocks, except for paramacro command blocks such as assignment, goto, etc.
- Axis motion cannot be generated by normal program blocks. Axis motion can be generated only in the program called by G66.1.
- The following words, when programmed after the G66.1 block, are used as argument assignments:

N: when programmed after a word other than N or O, is used as assignment #14.

G: The last G-code programmed in a block is used as an argument statement for parameter #10. All other G-codes are interpreted as normal.

L: Assigns value to parameter #12

P: Assigns value to parameter #16

All other argument assignments are interpreted as listed in Table 27.H.

The L-word or any optional argument statements following a G66.1 can contain any valid mathematical expression. For example:

```
G66.1 P1002 L[#1+1] A[12*6] B[SIN[#101]];
```

Example 27.20 G66.1 Macro Operation

N0100G90G17G00;	
N0110G66.1P9400;	Macro 9400 is executed.
N0120G91G18G01;	G91 and G18 become effective, 01 is assigned to parameter #10, macro 9400 is executed.
N0130G03X1.;	03 is assigned to parameter #10, 1. is assigned to parameter #24, macro 9400 is executed.
N0135;	Macro 9400 is executed.
N0140G67;	Macro 9400 is deactivated.
N0150M30;	program end.

Any time the macro is called (while executing the G66.1), the L-word programming the number of repetitions is in effect. Any attempt to re-program an L-word outside of a G66.1 block is interpreted as an argument assignment for parameter #12.

Important: When nesting a macro (any macro including G66.1) within a G66.1 macro, the outer G66.1 macro is executed after each individual block of the nested macro, except for paramacro command blocks such as assignment, goto, etc.

Example 27.21 Nesting a Modal Macro

```
N0100G66.1P1001;
N0200G65P1002;
```

After the execution of each individual block within the macro 1002, the macro 1001 is called.

You can define the L-word or any optional argument statements in a G66.1 block as any valid parametric expression. For example:

```
G66.1 P1002 L[#1+1] A[12*6] B[SIN[#101]];
```

AMP-defined G-code Macro Call

Use this format for calling an AMP-defined macro:

```
G_ A_ B_;
```

Where:	Is:
G_	Programs an AMP-defined G-code command (from G1 to G255.9).
A-Z	Optional argument statements. May be programmed using any letter from A to Z excluding G, L, N, O, or P. Used to assign numeric values to parameters in the paramacro (see Table 27.H). Arguments may be specified as any valid parametric expression.

An AMP-defined G-code macro is a G-code that is specified in AMP by the system installer. When one of these AMP-defined G-codes is executed in a part program, execution is transferred to the macro with the program number associated to that G-code.

G-code values for paramacro calls may range from 1 to 255.9. The system installer may define a maximum of 25 AMP-defined G-codes to call specific paramacro programs. The paramacro program name called with the AMP-defined G-code is a program number from 1 to 8999 or 9010 to 9019. Refer to the system installer's documentation for details.

Important: The system installer may disable the use of AMP-defined G and M-code macro calls when in MDI mode. Refer to the system installer's documentation to determine if this feature is functional in MDI.

AMP-defined G-code macros can be executed as either modal or nonmodal macros as selected in AMP. If selected as modal, they can be execute using either G66 modality (see page 27-37) or G66.1 modality (see page 27-39). This modality type for AMP defined G-codes is also determined by the system installer in AMP.

Any optional argument statements following an AMP-defined G-code may contain any valid parametric expression. For example:

```
G255A[12*6]B[SIN[#101]];
```

In a part program, if more than one digit is entered after the decimal point, the value is **truncated**. For example, 231.18 is 231.1, and 231.14 is 231.1.

Important: Certain AMP-defined G-code Macro calls cannot be called by any other AMP-defined macro call. For details, see page 27-43.

AMP-defined M-code Macro Call

Use this format for calling an AMP-defined M-code macro:

M255 A_B_

Where:	Is:
M255	Programs an AMP-defined M-code command.
A-Z	Optional argument statements. May be programmed using any letter from A to Z excluding G, L, N, O, or P. Used to assign numeric values to parameters in the paramacro (see Table 27.H). Arguments may be specified as any valid parametric expression.

These macros are executed only as nonmodal macro.

The term AMP-defined M-code macro comes from the fact that the M-code that calls a specific macro program is specified in AMP by the system installer. The system installer may define M-codes that calls paramacro programs with program names ranging from 9001 to 9009. Refer to the system installer's documentation to determine what M-codes are used to call what paramacro program name.

When one of these AMP assigned M-codes is specified in a part program, execution is transferred to the macro associated to that specific M-code.

M-code values for paramacro calls may range from -1 to 999. The system installer may define a maximum of 9 AMP-defined M-codes to call specific paramacro programs.

Important: The system installer may optionally disable the use of AMP-defined G and M-code macro calls when in MDI mode. See the system installer's documentation to determine if this feature is functional in MDI.

AMP-defined T-, S-, and B-code Macro Call

Use this format for calling an AMP-defined T-, S-, or B-code macro:

T t ;
S s ;
or
B b ;

Where:	Is equal to the value assigned to parameter:
t	#149
s	#147
b	#146

Important: Programming arguments are not allowed with the AMP-defined T-, S-, or B-code macro calls.

These macros are executed only as nonmodal macro.

The execution of the T-, S-, or B-code macro calls is the same as M-code macro calls with the following exceptions:

- the parameter # referenced when called
- the macro program called
 - T calls macro 9000
 - S calls macro 9029
 - B calls macro 9028

In order for the T-, S-, or B-words to call up a macro program, these prerequisites must be met:

1. The value following the word must be equal to the value stored for the specified parameter #.

For example:

T14;

The value of 14 must have been previously stored as the value for the parameter #149.

2. An AMP flag for that specific word must be turned on by the system installer to allow that word to call a macro.
3. The value for an AMP-defined T-, S-, or B-code command has the same format and range as an ordinary T-, S-, or B-code.

Nesting Macros

Nesting occurs when one program calls another program. A subprogram called by a main program is an example of nesting. (The “nested” program is the program called.)

Nesting applies to macros as well. When the main program calls a macro, the macro is said to be on nesting level 1. If this macro in turn calls another macro, this second macro is said to be in nesting level 2. Macros may be nested up to a maximum of 4 levels. However, if the maximum number of nested paramacros (4) is combined with up to 4 subprograms that end with M98, a maximum of 8 levels of nesting can be programmed.

What is **not** counted as an additional nested level? When a lower nested macro with a modal feature forces a higher nested macro to call it, the number of nested levels does not increase. Nor does it increase when a subprogram is called using M98.

Precautions must be taken when attempting to nest AMP assigned macro calls since many combinations of these calls may not be valid. The system installer determines in AMP the functionality of the AMP-defined macro call when nested. These two options are available (see the system installer's documentation to determine which applies to your system):

- Works as a macro call - When "works as a macro call" is selected, G-, M-, T-, S-, or B-code macro calls that are nested and called by other G-, M-, T-, S-, or B-code macro calls allow nesting as shown in Table 27.I.

Table 27.I
Works as a Macro Call

CALLING PROGRAM	TYPE OF MACRO NESTED ¹			
	G65, G66, or G66.1	AMP-G	AMP-M	AMP-T S or B
G65, G66 or G66.1	Yes	Yes	Yes	Yes
AMP G-code	Yes	No	Yes	Yes
AMP M-code	Yes	Yes	No	No
AMP T-, S- or B-code	Yes	yes	No	No

¹ What Yes/No means:

Yes -- the macro type across the top row may be called from the macro type down the left column.

No -- the macro type across the top row may **not** be called from the macro type down the left column. When this nesting is attempted, the control executes any other operation that would normally be performed by that G-, M-, T-, S-, or B-code (as defined by the 9/PC system as a standard code, logic, or some other AMP feature) and the paramacro call normally made by that code is not performed.

- Works as the system-defined code - When "works as the system defined code" is selected, G-, M-, T-, S-, or B-code macro calls that are nested and called by other G-, M-, T-, S-, or B-code macro calls allow nesting as shown in Table 27.J.

Table 27.J
Works as the System-defined Code

CALLING PROGRAM	TYPE OF MACRO NESTED ¹			
	G65, G66, or G66.1	AMP-G	AMP-M	AMP-T S or B
G65, G66 or G66.1	Yes	Yes	Yes	Yes
AMP G-code	Yes	No	No	No
AMP M-code	Yes	No	No	No
AMP T-, S- or B-code	Yes	No	No	No

¹ What Yes/No means:

Yes -- the macro type across the top row may be called from the macro type down the left column.

No -- the macro type across the top row may **not** be called from the macro type down the left column. When this nesting is attempted, the control executes any other operation that would normally be performed by that G-, M-, T-, S-, or B-code (as defined by the 9/PC system as a standard code, logic, or some other AMP feature) and the paramacro call normally made by that code is not performed.

Important: If the nesting is invalid (**No** in one of the above tables), the control executes the programmed code as some other function (as defined by the 9/PC system as a standard code, logic, or some other AMP feature) and the macro call is not made. If no other function is found that uses that G-, M-, T-, S-, or B-code, the control generates an error.

The rule to follow for Table 27.J is that an AMP-assigned macro may **not** call an AMP-assigned macro.

For example, if the calling program is an AMP-assigned M-code macro, then G65, G66 and G66.1 macro calls are allowed; but no other types of macro calls are allowed, including an M-code macro.

END OF CHAPTER

Softkey Tree

Appendix Overview

This appendix explains softkeys and includes maps of the softkey trees.

Understanding Softkeys

We use the term softkey to describe the row of 7 keys at the bottom of the screen. The function of each softkey is displayed on the screen directly above the softkey. Softkey names are shown in this manual between the { } symbols.

Softkeys are often described in this manual as being on a certain level, for example, softkey level 3. We use the level of the softkey to determine the location or necessary path to reach that particular softkey function. For example, to get to a softkey on level 3, you must press a specific softkey on level 1 followed by a specific softkey on level 2.


Specific softkeys for all levels change depending on the previous softkey pressed, with the exception of softkey level 1, which always remains the same. Softkey levels are all referenced from softkey level 1.

The softkeys on opposite ends of the softkey row have a specific use that remains standard throughout the different softkey levels. On the left is the exit softkey displayed with the up arrow {↑} and on the right is the continue softkey displayed with the right arrow {⇒}.

- Use the exit softkey {↑} on the far left to regress softkey levels. For example, if you are currently on softkey level 3 and you press the exit softkey, the softkeys change to the softkeys previously displayed on softkey level 2. When you press the {EXIT} softkey while holding down the [SHIFT] key, the softkey display returns to softkey level 1, regardless of the current softkey level.
- When more than 5 softkey functions are available on the same level, the control activates the continue {⇒} softkey at the far right of the softkey area. When you press the continue softkey, the softkey functions change to the next set of softkeys on that level.

The continue softkey is not available if there are 5 or fewer softkey functions on that level.

For example :



When softkey level 1 is reached, the previous set of softkeys is displayed. Press the continue softkey {⇒} to display the remaining softkey functions on softkey level 1.

(softkey level 1)

	PRGRAM MANAGE	OFFSET	MACRO PARAM	PRGRAM CHECK	SYSTEM SUPORT	→
F2	F3	F4	F5	F6	F7	F8

On softkey level 1, the exit softkey is not displayed since the softkeys are already on softkey level 1.

The softkey functions for level 1 softkeys are explained in this appendix. Softkey functions for level 2 or higher are explained in the sections that apply to specific operations. A “tree” of softkeys listing all the softkeys and their levels is included in the back of this appendix.

Important: Some of the softkey functions are purchased as optional features. This manual assumes that all available optional features have been purchased for the machine. If the feature has not been purchased, blank keys may appear.

Describing Level 1 Softkeys

The following section describes Level 1 softkeys and their prospective functions.

(softkey level 1)

	PRGRAM MANAGE	OFFSET	MACRO PARAM	PRGRAM CHECK	SYSTEM SUPORT	→
F2	F3	F4	F5	F6	F7	F8
		ERROR MESSAGE	PASS- WORD	SWITCH LANG		→
F2	F3	F4	F5	F6	F7	F8

If you want to:	Press:
edit, activate, or copy a program from control memory	{PRGRAM MANAGE}
display or enter tool offset data, the work coordinate system offset data, etc.	{OFFSET}
view and modify the local and global parameter assignments for paramacros	{MACRO PARAM}
check the part program, QuickCheck, and active program without actually moving an axis	{PRGRAM CHECK}
enter and display inhibit zone limits, canned cycle parameter data, AMP, etc.	{SYSTEM SUPORT}
display error messages, including an error log of old messages	{ERROR MESSAGE}
enter or assign passwords and access levels to selected features	{PASSWORD}
change the language displayed on the screen of the control	{SWITCH LANG}
display more softkeys on the same level when there are more softkeys on a level than can be displayed at once	{⇒}
display the previous level or previous row of softkeys	{↑}

Using the Softkey Tree

The remainder of this appendix shows the softkey tree. This tree illustrates the entire softkey layout on the control in an easy-to-use flow-chart type format. This flow chart has been drawn to have no 4-way intersections (no 4 lines connected at any one point). If you see what appears to be a 4-way intersection, it is really only a crossover point for lines that do not intersect.

AXIS POSITION DISPLAY FORMAT SOFTKEYS(access by pressing {F12})


PRGRAM
A B S
TARGET
D T G
AXIS SELECT
M CODE STATUS
PRGRAM D T G
A L L
G CODE STATUS

NOTE: The first four softkeys (from {PRGRM} to {DTG}) toggle between a small and large screen display.


THE FUNCTION SELECT SOFTKEYS LEVEL 1**WITH POWER UP (AXIS POSITION) DISPLAY SCREEN**

PRGRAM MANAGE	refer to page A-5
OFFSET	refer to page A-6
MACRO PARAM	refer to page A-7
PRGRAM CHECK	refer to page A-8
SYSTEM SUPORT	refer to page A-9
ERROR MESSAGE	refer to page A-10
PASS- WORD	refer to page A-11
SWITCH LANG	refer to page A-12


PROGRAM MANAGE




OFFSET




MACRO PARAM




BACKUP PARAM




PRGRAM CHECK




SYSTEM SUPORT




ERROR MESSAGE




PASSWORD




SWITCH LANG

This chart shows the order that the languages are changed.

ACTIVE PROGRAM



EDIT PRGRAM



NOTE: These keys are the layered softkeys available through the part program editor.

END OF APPENDIX

Error and System Messages

Overview

This appendix serves as a guide to error and system messages that can occur during programming and operation of your 9/PC control. We listed the messages in alphabetical order along with a brief description.

Important: To display both active and inactive messages, press the **{ERROR MESSAGE}** softkey found on softkey level 1. For details, refer to chapter 2.

Important: This appendix covers only error and system messages. Logic-generated operator messages generally appear on lines 21 and 22 of the BDS screen and should be described in documentation prepared by the machine tool builder.

Message	Description
Symbols	
(+) OVERTRAVEL PROGRAM ERROR	If axis motion continues along the programmed path, the indicated axis will reach or exceed the positive software overtravel limit (runtime error).
(-) OVERTRAVEL PROGRAM ERROR	If axis motion continues along the programmed path, the indicated axis will reach or exceed the negative software overtravel limit (runtime error).
(+) OVERTRVL PRGRAM ERROR:	The end-point of the commanded move will cause the indicated axis to reach or exceed the positive software overtravel limit (pre-execution error).
(-) OVERTRVL PRGRAM ERROR:	The end-point of the commanded move will cause the indicated axis to reach or exceed the negative software overtravel limit (pre-execution error).
+/- SIGN ERROR	A + or - sign was found out of place when a numeric value was being decoded. Check the active program block for programming format errors.
1	
1394 AXIS MODULE MISMATCH	At power turn on the system identified an axis module in the 1394 rack that is misconfigured in AMP. If an extra axis module is present in the 1394 rack it should either be fully configured or not configured at all in AMP even if that axis module is not used or detached.
1394 RING COMMUNICATIONS ERROR	At power up the internal communications ring which runs through the front of the 1394 system and drive modules was either not connected, a device on the ring experienced a hardware failure, or a device on the ring was discovered to be misconfigured once a command was sent to the device. Make sure all axis modules and the end terminator are properly connected to complete the communication ring. To clear this fault, you should: <ul style="list-style-type: none"> • determine the cause of the fault • stop the 9/PC main • turn off power to the 1394 • resolve the situation • turn on power to your 1394 drive • start the 9/PC main For more information regarding this fault, refer to the Troubleshooting chapter of the <i>1394 Digital AC Multi-Axis Motion Control System User Manual</i> .
15V SUPPLY FAILURE	15V dc is out of range on the main processor board. The System Ready Contacts open and the system goes into E-Stop. Check the wiring on the analog output circuits to make sure there is not a short.
1746 RACK CARDS MISMATCH	The I/O configuration for the 1746 I/O rack that was downloaded from ODS, or resides in the PAL PROMs, contradicts what is actually in the rack (devices must match slot-for-slot).
1771 RACK CARDS MISMATCH	The I/O configuration for the 1771 I/O rack that was downloaded from ODS, or resides in the PAL PROMs, contradicts what is actually in the rack (devices must match slot-for-slot).

Message	Description
2	
2MB RAM IS BAD/MISSING	The control has discovered the RAM SIMMs for the two megabyte extended storage option are either damaged or missing. The RAM SIMMs must be installed or replaced. Contact your Allen Bradley sales representative for assistance.
9	
9/SERIES LATHE - CANNOT USE MILL AMP	The control was powered up with a lathe software option chip installed, when the AMP file that was downloaded was configured for a mill.
9/SERIES MILL - CANNOT USE LATHE AMP	The control was powered up with a mill software option chip installed, when the AMP file that was downloaded was configured for a lathe.
7300	
7300 NAMES TABLE IS CORRUPTED	7300 program name doesn't match corresponding name in cross-reference table.
7300 PATTERN NAME TOO LONG	More than 5 digits have been used in the pattern name.
A	
A RETRACE BUFFER WAS DELETED	The control required one (or more) of the block retrace buffers to perform a necessary block look-ahead operation (refer to block look-ahead in the user's manual). When this occurs, less block retrace operations can be performed than AMP is configured to allow. If this error occurs, to improve control efficiency, it is recommended that the number of allowable block retrace blocks set in AMP be lowered or add additional RAM to your system.
ABS POSITION NOT INITIALIZED	This message indicates that axes with absolute encoders have not been homed. These axes require an initial homing operation to establish the absolute position.
ABSOLUTE FEEDBACK FAILURE	The control has detected a loss of feedback from the absolute encoder. The most likely cause of this error would be a broken or disconnected wire. Axis homing may be required after the error condition is corrected.
ACC/DEC CONFIGURATION ERROR	An axis configuration error was detected by the control when manual acc/dec was requested in a program block.
ACCUM. AND EXPECTED LIFE ARE 0	No tool life data was entered for the current tool selected by the tool life management feature. Tool life management will be disabled for this tool.
ACTIVE GROUP CANNOT BE DELETED	An attempt was made to delete a tool group in the tool life management feature that contains an active tool currently in the tool holder.
ACTIVE OFFSET CANNOT CHANGE	An attempt was made to alter a tool offset value of a tool offset that is currently the active tool offset on the control. The active tool offset is indicated with an * on the tool offset table.
ACTIVE TOOL CANNOT BE CHANGED	An attempt was made to edit tool data for the currently active tool. Deactivate the tool before editing.
ACTIVE TOOL CANNOT BE DELETED	An attempt was made to delete tool data for the currently active tool. Deactivate the tool before editing.
ADAPTIVE FEED MAX LIMIT	The actual torque is less than the desired programmed torque and the adaptive feed axis has reached the programmed maximum feed limit. Either raise the programmed maximum feed limit or lower the programmed desired torque.
ADAPTIVE FEED MIN LIMIT	This message indicates you are exceeding the programmed desired torque. The actual torque is greater than the desired programmed torque and the adaptive feed axis has reached the programmed minimum feed limit. Either raise the programmed desired torque or lower the minimum feed limit.
ADAPTIVE FEED PROGRAMMING ERROR	E and Q must both be programmed in every G25 block.
ALL DUAL AXES ARE PARKED	An attempt was made, while using dual axes, to move the dual group when all the axes of that group were parked.
AMP CHECKSUM ERROR - CNC STOPPING	The saved checksum that protects the AMP area of the executive does not match the computed checksum of the AMP data that the executive is operating with. AMP is corrupt and was not saved into the flash.
AMP FILE SIZE ERROR	The size of the AMP file being downloaded is incorrect. The file cannot be downloaded.

Message	Description
AMP IN BACKUP DOES NOT MATCH AMP IN RAM	This message always appears after a successful AMP download if the downloaded file is different from the one currently stored in backup memory. Its purpose is to remind the user to copy the downloaded AMP into backup memory after testing it.
AMP WAS MODIFIED BY PATCH AMP UTILITY	This message always appears after changes have been made to AMP using the patch AMP utility. Its purpose is to remind the user that the current AMP has not been verified by a cross-reference check normally performed by ODS. It is meant as a safety warning.
AMPED HOLDING OR DETECT TRQ OUT OF RANGE	This message is displayed when you have entered a value in AMP for either the holding torque or the detection torque, for the feed to hard stop feature, that is higher than the value entered for the servos available peak torque. You must change your AMP values.
ANALOG SERVO VOLTAGE FAILURE	A $\pm 15V$ to the servo cards has failed.
ANGLE WORD NOT ALLOWED	An angle word was programmed in a QPP block where it is not allowed, for example, programming an angle word in a circular QPP block.
ANGLED WHEEL AXES, JOG ONE AT A TIME	While in the angled wheel grinding mode you can not jog more than one axis in the angled wheel plane at any one time.
ANGLED WHEEL CONFIG ERROR	The angled-wheel grinder AMP downloaded to the control is not configured correctly. Make sure all necessary angled-wheel parameters are configured correctly and reupload AMP to the control.
ANGLED WHEEL NOT CONFIGURED	The user attempted to program an angled wheel grinder mode function and the angled wheel feature has not been correctly configured for your system. The angled wheel feature must be configured in AMP and is a purchased option for your CNC.
ARCTAN SYNTAX ERROR	An attempt was made to calculate or execute a paramacro block that calculates the arc tangent of an invalid or improperly entered number.
ARITHMETIC OVERFLOW ERROR	An internal math error has occurred; contact Allen-Bradley customer support service.
ARITHMETIC UNDERFLOW ERROR	An internal math error has occurred; contact Allen-Bradley customer support service.
AUX FB NOT ALLOWED WITH DEPTH PROBE	Your AMP file has a depth probe configured for an axis that also is configured to use an optional feedback device. A depth probe can not be configured to use any feedback device other than its depth probe for that depth probe axis. If a second feedback device is used it is configured in AMP as a separate logical axis.
AUXILIARY FEEDBACK DISCONNECTED	The digital servo module provides the capability to use two different feedback encoders with one servo (in the case where two encoders are used, the auxiliary encoder is used for the position feedback). If the servo processor detects that the auxiliary encoder has been disconnected, this message is displayed. <ul style="list-style-type: none"> • determine the cause of the fault • stop the 9/PC main • turn off power to the 1394 • resolve the situation • turn on power to your 1394 drive • start the 9/PC main For more information regarding this fault, refer to the Troubleshooting chapter of the <i>1394 Digital AC Multi-Axis Motion Control System User Manual</i> .
AUXILIARY FEEDBACK QUADRATURE FAULT	The digital servo module provides the capability to use two different feedback encoders with one servo (in the case where two encoders are used, the auxiliary encoder is used for the position feedback). If the servo processor detects a quadrature fault on the auxiliary encoder, this message is displayed.
AUXILIARY SPINDLE 2 NOT CONFIGURED	For aux spindle 2 to be programmable, it must be configured in AMP; a decode error.
AUXILIARY SPINDLE 3 NOT AVAILABLE	AMP configuration error; aux spindle 3 can be configured only on a 9/290.
AUXILIARY SPINDLE 3 NOT CONFIGURED	For aux spindle 3 to be programmable, it must be configured in AMP; a decode error.
AXES COLLISION	Two processes have collided. Interference checking has stopped all motion.
AXES CONFIGURED ON INACTIVE PROCESS	An AMP was loaded that contains an axis that was configured for an inactive process. Set the process axis in AMP to a process that has been configured.
AXES DATA MISSING	Expected axis data is missing in a program block.
AXIS AMPED AS NON-SCALING AXIS	The user attempted to scale an axis that was AMPed as nonscalable.

Message	Description
AXIS ASSIGNED TO LOGIC AXIS MOVER	The user attempted to move the axis configured as the logic axis mover axis by some means other than logic.
AXIS ASSIGNED TO PAL AXIS MOVER	The user attempted to move the axis configured as the logic axis mover axis by some means other than PAL.
AXIS DISPLAY DISABLED BY PAL	The position display for a selected axis has been turned off using the \$NODP flag.
AXIS IN PLANE DOES NOT EXIST	At least one of the axes assigned to a plane that was defined in AMP does not exist. An example of when this error would occur is if an axis was renamed in AMP, but that new name was not entered into the AMP plane definition. Another example would be if an unfitted axis was assigned to that plane.
AXIS INVALID FOR G24/G25	The programmed axis was not AMPed for software velocity loop operation, and can not be used in a G24 or G25 block. To use these features the axis programmed must be configured for tachless operation (or be a digital servo).
AXIS IS HARD STOPPED, CANT ADJUST SERVO	The torque limit of the servo can not be adjusted because, either the axis is in a hard-stopped state, or some other axis on the same servo card is in a hard-stopped state.
AXIS MODULE POWER FAULT	<p>The current through the power output transistors is monitored. If the current exceeds a fixed level (greater than 300% of controller rating) this fault will appear. Typical causes are a shorted lead, motor malfunction, or malfunctioning power IGBTs. To clear this fault, you should:</p> <ul style="list-style-type: none"> • determine the cause of the fault • resolve the situation • power cycle to your 1394 drive • turn your system back on <p>For more information regarding this fault, refer to the Troubleshooting chapter of the <i>1394 Digital AC Multi-Axis Motion Control System User Manual</i>.</p>
AXIS MODULE OVER CURRENT	<p>One of the axis modules of your 1394 drive has been requested to provide too much current. This is typically caused by the Acc/Dec command from the CNC requiring peak current for an excessive amount of time, the machine friction or inertial/viscous load is excessive, the motor has been improperly sized, a short circuit exists across the drive output terminals, logic supply circuits have malfunctioned, or AC input is incorrectly wired. To clear this fault, you should:</p> <ul style="list-style-type: none"> • determine the cause of the fault • resolve the situation • power cycle to your 1394 drive • turn your system back on <p>For more information regarding this fault, refer to the Troubleshooting chapter of the <i>1394 Digital AC Multi-Axis Motion Control System User Manual</i>.</p>
AXIS MODULE BUS VOLTAGE LOSS	<p>The DC bus supply was lost to the axis module. Check slider connections/termination strip or there could be a blown link fuse. To clear this fault, you should:</p> <ul style="list-style-type: none"> • determine the cause of the fault • resolve the situation • turn your system back on <p>For more information regarding this fault, refer to the Troubleshooting chapter of the <i>1394 Digital AC Multi-Axis Motion Control System User Manual</i>.</p>
AXIS MODULE OVER TEMP	<p>The 1394 contains a thermal sensor which senses the internal ambient temperature. Causes could be: that the cabinet ambient temperature is above rating. The machine duty cycle requires an RMS current exceeding the continuous rating of the controller. The airflow access to the 1394 is limited or blocked. This does not necessarily indicate a motor over temperature. Motor over temperature sensors should be wired directly into the E-Stop string. To clear this fault, you should:</p> <ul style="list-style-type: none"> • determine the cause of the fault • resolve the situation • power cycle to your 1394 drive • turn your system back on <p>For more information regarding this fault, refer to the Troubleshooting chapter of the <i>1394 Digital AC Multi-Axis Motion Control System User Manual</i>.</p>
AXIS MOVER CONFLICT WITH G16.3/G16.4	You requested a PAL or logic axis mover function on an angled wheel grinder. You can not use the PAL or logic axis mover in one of the angled wheel modes unless the PAL axis mover has control of both the axial and the wheel axes.

Message	Description
AXIS NAME DUPLICATE	Two or more axes have been assigned the same name in AMP.
AXIS NOT IN PROCESS	You attempted to read/write a paramacro parameter for an axis that is not currently in the process requesting the data. To access paramacro parameter data for an axis, that axis must be in the process making the request.
AXIS POSITION INCORRECT	Using the mid-start program function, you have searched to a block that does not create the programmed contour if started from your current axis position. Be aware the mid-start operation may have searched thru a offset operation that is not readily apparent to determine your axis position. The mid-start operation is aborted. You must re-perform the mid-start operation and either position the axes to the correct axis position, or use the {MOVE & EXIT} softkey to find the correct axis position.
AXIS SELECT NOT ALLOWED	The {AXIS SELECT} softkey was pressed when no axis select option is available. Axis select is only available on large screens and normal character size screen for systems that contain more than 9 axes total or dual process systems with more than 8 axes in a process. It is not available when the small screen (showing all system AMPed axes) is being viewed.
AXIS TYPE-POSITION LOOP ERROR	In patch AMP, an axis was assigned a position loop type that is illegal for the axis type assigned to that axis.
B	
BACKUP VERSION OF AMP WAS COPIED TO RAM	The AMP in RAM was erased (battery backup failed) or corrupted, so the control automatically copied the version of AMP in backup memory into RAM memory. (The control stores AMP in backup, but works from the copy of AMP in RAM memory.)
BAD DAC MONITOR PATCH AMP ENTRY	An invalid value was entered into patch AMP parameter #86 or #87. Either parameter allows the axes to be monitored through the servo module (DAC) analog output. See documentation provided by Allen-Bradley on patch AMP, or contact Allen-Bradley customer support service.
BAD FIRST POCKET BLOCK	When performing an irregular pocket cycle, the first pocket block should be away from the pocket start/end corner, not toward it. The move to the start/end corner is generated based on the coordinates programmed in the pocket definition block itself.
BAD PAL PROM	One of the PAL PROM chips (plugged into the main processor board) has failed or is not plugged in properly.
BAD RAM DISC SECTOR CHECKSUM ERROR	A RAM disk sector error was detected during the RAM checksum test at power-up. Attempt to power-up again. If the error remains, contact Allen-Bradley customer support services.
BAD RECORD IN PROGRAM	This indicates a serious problem with the program. Attempt to open the program a second time. If retry doesn't work, you may have to delete the program. Typically this error is not caused by a programmer or operator action. It is typically caused by an internal software error in the program.
BAD STATE/TOKEN COMBINATION (PROGRAM ERROR)	While attempting to decode the current block, a combination of characters caused a decode error to occur. Check the characters in the current block for an illegal combination.
BATTERY FAILURE	The battery that provides backup of the RAM memory is not functioning; the voltage may be low. The battery may be dead, removed, or poorly connected.
BAUD RATE MUST BE 4MHZ FOR 1394 DRIVES	The baud rate for 1394 SERCOS drives must be AMPed at 4MHz. For third-party drives (with no 1394 SERCOS drives in use), the baud rate must be AMPed at 2 MHz.
BBU SAVE FAILED, USING LAST VALID DATA	There was an improper shutdown of your 9/PC. This message appears when the save of BBU data (i.e., tool offsets, paramacros, axis calibration, work coordinates, and AMP data) failed to occur after the 9/PC executive was started.
BLK DELETE CHG IGNORED ON PREPARED BLKS	A block-delete was activated while a program was executing. This change is ignored by the control for blocks that have already been read into the control's set-up buffer (see block look-ahead in user's manual).
BLOCK LENGTH ERROR	A block that exceeds the allowable maximum block length was programmed.
BLOCK RETRACE ABORTED	The block retrace operation being performed has been canceled. When <CYCLE START> is pressed, the control will return the tool along a linear path back to the start-point of the block retrace operation.
BOOT CODE CRC ERROR - CNC STOPPING	A hardware failure occurred while the boot executive was performing a CRC test of the boot flash. During the CRC test, an error was detected in the boot flash CRC. This is basically a self-test to confirm that the boot flash that loads and runs the CNC executive is OK.

Message	Description
BOOT DIRECTORY IS MISSING	The update utility failed to properly create the system boot directory. Retry the update. If the error occurs again, contact your local Allen Bradley service.
BOOT RAM ACCESS ERROR - CNC STOPPING	A hardware failure occurred while the boot executive performed a RAM test of the memory where the executive will be loaded. An error reading/writing into the designated RAM area occurred.
BOOTSTRAP FAILED TO START	The bootstrap code did not send the "ok" signal to the main processor within the specified time.
BOTH AXES IN QPP PLANE NOT PRGMD	The second block of a currently executing QuickPath Plus two-block set does not contain both required axis words in the current plane. Both axis words are required to correctly identify the end-point of the second move.
BOTH LINES ARE PARALLEL	Both blocks of a two-block QPP sequence are parallel, and no mathematical intersection can be computed.
BOTH PORTS ARE BUSY	An attempt was made to use or monitor communication ports A or B when neither were available.
BUSY, REQUEST IGNORED	You have requested an operation while the control is currently executing some other higher priority function. The control must first complete the higher priority task before your new task can be performed.
C	
CALLED 7300 PATTERN NAME IS BAD	The 7300 pattern name that is called by a part program does not exist .
CANCEL/REMOVE OFFSET BEFORE AXIS CHANGE	You have attempted to change the active tool length axis while a length offset is currently active on that axis. You must cancel tool length offsets before you are allowed to change the active tool length axis.
CANNOT (GOTO) TO INSIDE A (DO)	A (GOTO) command cannot transfer execution to a block which is located within a (DO) loop.
CANNOT ACCESS REMOTE VARIABLE	Variable name is invalid. Check the fields for CNC name and remote name, and make sure they are in the correct format.
CANNOT ACTIVATE - OPEN PROGRAM	An attempt was made to activate a program for execution when it was still open for an editing operation. Before it can be activated for automatic execution, it is necessary to exit from the edit menu to close a program being edited.
CANNOT ACTIVATE RAM PARTITION	The RAM disk has been corrupted. Attempt to perform a "REFORMAT" operation. If this is unsuccessful, consult Allen-Bradley customer support services.
CANNOT ASSIGN IN CURRENT MODE	An attempt was made to modify a paramacro parameter that cannot be modified when the cutter compensation or TTRC feature is active.
CANNOT CALCULATE - PROMPT PRESENT	An attempt to perform a calculate operation was made when some other prompt was present on line 2 of the CRT. Before the control will allow a calculation to be made, it is necessary to remove any prompts from line 2 .
CANNOT COPY	The requested copying task cannot be performed due to an internal problem in the file or RAM disk. Contact Allen-Bradley customer support service.
CANNOT DELETE - OPEN PROGRAM	The selected program is either active or open for editing and cannot be deleted.
CANNOT DELETE ALL PROGRAMS	An attempt was made to delete all part programs or to reformat RAM while a program was being edited or was currently selected as the active program for execution.
CANNOT DELETE PROGRAM	The file selected cannot be deleted. This is caused by a major error being detected in the actual software file of the program. It may be necessary to "REFORMAT" RAM to remove the program. If this is unsuccessful, contact Allen-Bradley customer support service.
CANNOT DIVIDE BY ZERO	An attempt was made to divide a quantity by zero, either using the CALC functions or in an executing program with a paramacro operator.
CANNOT EDIT - FILE UPLOADING	The file you've tried to open is already open and is in the middle of a part program upload or download operation with ODS.
CANNOT EDIT - MUST BE IN CYCLE OR E-STOP	An attempt was made to edit a part program while another part program was currently being executed.
CANNOT EDIT - OPEN PROGRAM	The program that you have selected for editing is currently open for another feature.
CANNOT EDIT - OTHER FILE IS BEING EDITED	An attempt was made to edit a part program while another part program was currently being edited.

Message	Description
CANNOT EDIT ACTIVE PROGRAM	An attempt was made to edit a program that is currently selected as the active program for execution. Before it can be edited, the program must first be disabled.
CANNOT EXIT IN CYCLE	You cannot exit in the middle of a roughing cycle because it executes at runtime, not during setup.
CANNOT FIND CORRECT POSITION	The program-restart feature cannot locate the correct program block in the program at which automatic execution was interrupted. To position the program at the correct block, it will be necessary to perform one of the other search operations. The operator must know what this correct block is as the control has failed its recover operation.
CANNOT FIND PAL PAGE	PAL requested a PAL display page to be displayed that does not exist in the display page file.
CANNOT FORMAT - OPEN PROGRAM	A program was selected for automatic execution or was still in the edit mode when a request to format memory was made. The active program must be disabled by pressing the {CANCEL PROGRAM} softkey, and any program being edited must be closed by exiting before formatting memory.
CANNOT FORMAT RAM PARTITION	The control is unable to format memory due to open file conditions indicating a more serious problem. Consult Allen-Bradley customer support services.
CANNOT JOG - ALL AXES ARE PARKED	An attempt was made to jog a dual group when all the axes were parked.
CANNOT MERGE WITH SAME PROGRAM	An attempt was made to merge the same program that is being edited with itself. If this is desirable, first copy the original program, then merge the copy into the original.
CANNOT OPEN DIRECTORY	This indicates a serious RAM disk problem. If retry doesn't work, you may have to reformat.
CANNOT OPEN PROGRAM FOR READ	This indicates a serious problem with the program. If retry doesn't work, you may have to delete the program.
CANNOT OPEN PROGRAM FOR WRITE	An error occurred while attempting to open a file on the RAM disk. Either the RAM disk is full, or there is an internal problem with the file. The file may need to be deleted.
CANNOT OPEN SUBPROGRAM	An attempt to call a sub-program has failed. This is usually caused by the sub-program name (programmed in the calling block with a P-word) not existing in the current program directory.
CANNOT READ A WRITE-ONLY PARAMETER	An attempt was made to use the value of a paramacro system parameter that is a write-only parameter. This parameter may have only its value written to. It cannot be read.
CANNOT READ DIRECTORY	This indicates a serious RAM disk problem. If retry doesn't work, you may have to reformat.
CANNOT READ PROGRAM	This indicates a serious problem with the program. If retry doesn't work, you may have to delete the program.
CANNOT RENAME	When performing a rename of a program name, the new program name has not been correctly entered. The format is OLD PROGRAM NAME,NEW PROGRAM NAME.
CANNOT REPLACE START POINT	An illegal attempt was made to change the axis calibration start-point using the online AMP feature.
CANNOT RESTART G24 HARD STOP	An attempt was made to restart a part program on a block which would have an axis at the hard stop. You cannot restart or mid start a part program after if (at that blocks execution) any axis would be holding against a hard stop. You must either re-start/mid-start to a block before the G24 hard stop block or to a block after the hard stop is released.
CANNOT SEND AVAILABLE COMMAND	This displays when a nonprogrammed communications command is executed from "send" softkey.
CANNOT SET DATA WHEN TOOL IS ACTIVE	An attempt was made to manually (using the softkeys) change tool management data for the currently active tool. Tool management data can be changed only for a tool that is not currently selected as the active tool.
CANNOT TAP IN CSS	You must disable the CSS feature before you begin a tapping operation. Disable CSS using a G97 command.
CANNOT TAP IN VIRTUAL-C MODE	You attempted to use the solid tapping feature while cylindrical or end-face milling was active.
CANNOT UPLOAD - PAL NOT IN PROM	PAL can be uploaded only from the PAL PROMs. PAL in RAM memory cannot be uploaded.
CANNOT UPLOAD - PAL SOURCE NOT LOADED	When the source is loaded, PAL can be uploaded in the 9/240 only. The 9/260 and 9/290 always have PAL in flash.
CANNOT USE COPY WITH ACTIVE TOOL OFFSET	An attempt was made to copy offset data from one axis to another using the {COPY OFFSET} softkey. You cannot use this softkey if the tool offsets are active.

Message	Description
CANNOT USE EXIT - BLOCK NOT FOUND	An attempt was made to {EXIT} while searching for a block for a mid-program start. You cannot use {EXIT} until the block has been found. To abort the search, use {QUIT}.
CANNOT WRITE A READ-ONLY PARAMETER	An attempt was made to assign a value to a PAL or logic or system paramacro parameter that is a read-only parameter. The value of these parameters can be used only by the programmer; they cannot be altered in the program.
CANNOT WRITE TO PROGRAM	This indicates a serious problem with the program. Attempt to write to program a second time. If retry doesn't work, you may have to delete the program. Typically this error is not caused by a programmer or operator action, but rather by an internal program software error.
CAUTION! YOU ARE IN 7300 TAPE MODE TO RETURN TO STANDARD 9/240 MODE RESET THE 7300-COMPATIBILITY PAL FLAG	The operator is cautioned that the tape being copied is presumed to be a 7300 formatted tape. This message is displayed on the copy-tape set-up screen when the MCU is in 7300 compatibility mode.
CC/TTRC ON, CAN'T ASSIGN TIME DEP. PARAM	An attempt was made to assign a time-dependent paramacro system parameter while dresser/wheel radius compensation was active. Time-dependant parameters are any system parameters that record or reference a current axis position.
CHAMFER LENGTH/RADIUS TOO LARGE	A chamfer or radius value programmed with a ,C or ,R would generate a chamfer or radius that is larger than one or both of the two adjacent tool paths.
CHAMFER/RADIUS NOT ALLOWED	An attempt was made to perform a chamfer or radius cut (programmed with a ,R or ,C) in a block that does not allow these functions to be performed. For example, you cannot do a chamfer or radius cut in a non-motion block, in the last block on an MDI line, or in the last block of a part program.
CHANGE NOT MADE IN BUFFERED BLOCKS	Changes to the offset table did not affect those program blocks that were already in the control's current activation queue. Program blocks that call for offsets and which follow those already in the activation queue will call the updated offset tables.
CHANNEL NAME TOO LONG	There is an error in G05 DH+ communications block.
CHAR MUST BE _ , ., LETTER, DIGIT	You have used incorrect search string syntax in the PAL search monitor utility.
CHAR MUST BE LETTER,DIGIT, UNDERSCORE	You have used incorrect search string syntax in the PAL search monitor utility.
CHARACTERS MUST BE DIGIT	You have used incorrect search string syntax in the PAL search monitor utility.
CHARACTERS MUST FOLLOW WILDCARD	You have used incorrect search string syntax in the PAL search monitor utility.
CHECKSUM ERROR IN FILE	The file (AMP, logic) being downloaded from a storage device has a checksum error. The file cannot be used.
CIRCLE MID-POINT NOT ENTERED	The center-point of an arc is not entered in a circular programming block. Circular blocks require programming either an R or an I, J, K in the block.
CIRCULAR BLOCK NOT ALLOWED	When activating cutter compensation, you cannot program a circular block as the first block or as the last block prior to deactivating cutter compensation.
CIRCULAR NOT ALLOWED AFTER SKIP	A circular move cannot immediately follow a G31 or G37 series skip block. Only linear moves are permitted as the next move following a G31 or G37 type code.
CIRCULAR PROGRAMMING ERROR	A circular motion was programmed incorrectly. Typically this occurs from incorrectly programming an R or I, J or K value.
CODING ERROR	A system software error has occurred. Consult Allen-Bradley customer support services.
COM COMMAND TABLE IS CORRUPTED	Restore the flash version of the output command table.
COM CONFIGURATION TABLE IS CORRUPTED	Restore the flash version of the communication configuration table.
COMM ERROR WHILE PROCESSING HOST REQUEST	A communication error occurred between your PC and 9/PC while performing an update utility. Retry at a lower baud rate. If that does not work check communication ports, connections and cable wiring.
COMMUNICATION TIME-OUT	The time allowed for a peripheral device to respond has elapsed. Check cable connections and device set-up.
COMMUNICATIONS DISPLAY PAGE ENABLED	When a remote host enables the 9/Series remote operator display screen, this message is displayed.
COMMUNICATIONS LINK IS DOWN	A problem was detected in the communications line. Check the cables and retry the download/upload.

Message	Description
COMPLETED WITH ERROR(S)	A QuickCheck syntax check operation has completed the check of the currently active program and found one or more errors. Some editing of the program is required.
COMPLETED WITH NO ERRORS	A QuickCheck syntax check operation has completed the check of the currently active program and found no syntax errors.
CONFIGURATION ERROR	The master or slave processor detected an error in the configuration of your 9/PC system.
CONFIGURATION EXCEEDS AVAIL MEMORY	This error occurs when the amount of available control memory drops below what is required to maintain a minimum 5 block setup buffer for program execution. The system is held in E-Stop when this error occurs. You may either chose to add more memory to your system or reconfigure your system by decreasing the watch list allocation (in AMP) for OCI systems.
CONTINUE NOT ALLOWED	An attempt was made to continue a program search when no character string was entered. This can occur when an error is generated by the program being searched and the control cannot continue the search of the program correctly.
CONTROL RESET NOT ALLOWED	The Control Reset Request was not honored by the control (e.g., a Control Reset Request during Cycle Suspended state).
CORRUPTED PROGRAM FOUND & DELETED	Program was found to be corrupted and not usable. This program was deleted.
CPU #2 DUALPORT RAM FAILED	The DUALPORT RAM memory shared between the 68000 main processor and the Z80 I/O ring processor has failed. (two 98030's instead of the 68000 and Z80 on 9/230, 9/260, and 9/290 controls)
CPU #2 EXEC IS BAD/MISSING	CPU #2 exec is not in flash; you must use update utility to load it (9/290 only). Consult Allen-Bradley customer support services.
CPU #2 EXEC WILL NOT START	CPU #2 is halted and will not start to execute its exec (9/290 only). Consult Allen-Bradley customer support services.
CPU #2 HARDWARE ERROR #2	The 68030 main processor has detected a bus error. Consult Allen-Bradley customer support services (9/290 only).
CPU #2 HARDWARE ERROR #3	The 68030 main processor has detected a spurious interrupt. Consult Allen-Bradley customer support services (9/290 only).
CPU #2 HARDWARE ERROR #4	The 68030 main processor has detected an illegal address. Consult Allen-Bradley customer support services (9/290 only).
CPU #2 HARDWARE ERROR #6	The 68030 main processor has detected a privilege violation. Consult Allen-Bradley customer support services (9/290 only).
CPU #2 HARDWARE ERROR #8	CPU #2 has detected an unassigned vector interrupt. Consult Allen-Bradley customer support services (9/290 only).
CPU #2 HARDWARE ERROR #9	CPU #2 has detected an illegal instruction. Consult Allen-Bradley Customer Support Services (9/290 only).
CPU #2 LOCAL RAM FAILED	The RAM memory supporting the 68030 I/O ring processor has failed (Z80 I/O ring processor on 9/240 only). Consult Allen-Bradley customer support services.
CPU #2 PROM HAS FAILED	The PROM memory supporting the 68030 (Z80 9/240 only) I/O ring processor has failed its checksum test. Consult Allen-Bradley customer support services.
CPU #2 RAM HAS FAILED	The RAM memory supporting the 68030 (Z80 9/240 only) I/O ring processor has failed. Consult Allen-Bradley customer support services.
CPU #2 WATCHDOG ERROR	The 68030 (Z80 9/240 only) I/O ring processor has failed. Consult Allen-Bradley customer support services.
CREATING BACKUP FILE - PLEASE WAIT	A backup file for the current utility is being created. The message will clear when the backup is complete.
CREATING TOOL OFFSET FILE - PLEASE WAIT	The tool offset table (or tables) is currently being backed-up. The control is generating an executable G10 program and entering it into the control's program directory.
CREATING TOOL MGMT. FILE - PLEASE WAIT	The tool management tables are currently being backed-up. The control is generating an executable G10 program and entering it into the control's program directory.
CSS RPM LIMIT AUXILIARY SPINDLE 2	The aux spindle 2 RPM requested by CSS is greater than the maximum CSS RPM limit. This limit is set by the system installer in AMP or can be reduced by programming a G92 block.

Message	Description
CSS RPM LIMIT AUXILIARY SPINDLE 3	The aux spindle 3 RPM requested by CSS is greater than the maximum CSS RPM limit. This limit is set by the system installer in AMP or can be reduced by programming a G92 block.
CSS RPM LIMIT FIRST SPINDLE	The spindle 1 RPM requested by CSS is greater than the maximum CSS RPM limit. This limit is set by the system installer in AMP or can be reduced by programming a G92 block.
CSS RPM LIMIT PRIMARY SPINDLE	The primary spindle RPM requested by CSS is greater than the maximum CSS RPM limit. This limit is set by the system installer in AMP or can be reduced by programming a G92 block.
CSS RPM LIMIT SECOND SPINDLE	The spindle 2 RPM requested by CSS is greater than the maximum CSS RPM limit. This limit is set by the system installer in AMP or can be reduced by programming a G92 block.
CSS RPM LIMIT THIRD SPINDLE	The spindle 3 RPM requested by CSS is greater than the maximum CSS RPM limit. This limit is set by the system installer in AMP or can be reduced by programming a G92 block.
CUR LOOP G/A CLOCK LOST	This error was generated by a servo amplifier error. It can usually be corrected by turning off power to the amplifier, and then back on.
CURRENT FEEDBACK ERROR	The servo module has detected faulty or missing current feedback from the digital servo motor. The most likely cause of this error is be a broken or disconnected wire.
CURSORING NOT ALLOWED	While assigning a {CUSTOM TOOL} in {RANDOM TOOL}, you cannot cursor to select another tool position.
CUTTER COMP./TTRC INTERFERENCE	The cutter radius is too large, reverse motion is required, or some other cutter compensation interference exists. Either an alternate tool or an alternate tool path must be programmed. Another option would be to disable cutter compensation error detection.
CYCLE ALREADY ACTIVE	An attempt was made to start a cycle while another cycle was currently executing.
CYLINDER RADIUS IS ZERO	The cylinder radius was not programmed in a virtual C cylindrical interpolation (G16.1) cycle.
CYLINDRICAL AXIS NOT PRESENT	Cylindrical interpolation was programmed without at least one cylindrical interpolation axes present (rotary, park, or feed axes).
CYLIND/VIRTUAL CONFIGURATION ERROR	An axis configuration error was detected by the control when cylindrical interpolation or end face milling was requested in a program block. Some examples would include: <ul style="list-style-type: none"> • A cylindrical/virtual axis is named same as a real axis or is missing (for example on a lathe A, the cylindrical axis may have been named the same as a incremental axis name). • A cylindrical/virtual axis is named the same as another programing command (for example a secondary auxiliary word, the angle word, etc...).
D	
D-WORD IS GREATER THAN TOOL DIA.	The programmed D-word value is greater than the tool diameter of the current tool.
D-WORD IS LESS THAN AMP THRESHOLD	The D-word has been programmed with a value that is too small.
D-WORD OUT OF RANGE	More than 1000 auto-dress operations were specified by the D-word in a grinder fixed cycle.
DAC MONITOR CIPC ON	This message comes up on power-up, after patch AMP has been modified to invoke DAC monitoring of the coarse incremental position command.
DAC MONITOR F. E. ON	The axis-following error is being output to the DAC output port for monitoring and debugging. Turning parameters 86 or 87 ON through patch AMP enables this output.
DAC MONITOR FV ON	This message comes up on power-up, after patch AMP has been modified to invoke DAC monitoring of the fine interpolated final velocity for each fine iteration (20ms).
DAC MONITOR INTEGRATOR ON	This message comes up on power-up, after patch AMP has been modified to invoke DAC monitoring of the velocity error integrator accum.
DAC MONITOR VEL ERROR ON	This message comes up on power-up, after patch AMP has been modified to invoke DAC monitoring of the velocity error.
DAC MONITOR VELOCITY ON	The axis velocity command is being output to the DAC output port for monitoring and debugging. Turning ON parameters 86 or 87 through patch AMP enables this output.
DATA MAY BE OUTPUT TO PRINTER ONLY	The information being output by the control is intended to go to a printer. Make sure that the output port that is selected is properly connected to a printer and try again.

Message	Description
DATA STARVED	The control is waiting for the next program block to set up. Typically, this is the result of the control executing a part program faster than it can be read from a peripheral device such as a tape reader. This error often occurs immediately after the execution of several very short, rapidly executed blocks. To prevent this error from reoccurring, it is recommended that the program be loaded into control memory or to a faster peripheral device.
DECIMAL POINT ERROR	A word or parameter has been programmed with more than one decimal point.
DECIMAL POINT NOT ALLOWED	A word or parameter has been programmed with a decimal point when it can legally exist only as an integer value . For example, the number of repetitions (L) must be an integer value programmed without a decimal point.
DEFAULT AMP LOADED	This indicates that the default AMP values stored in the control's executive memory have been activated. AMP in RAM and AMP in Backup memory were either unavailable or corrupt. This message can also occur if the battery backup fails.
DEFAULTS LOADED	The default device set-up parameters were loaded into the current device.
DEPTH > PROGRAMMED ENDPOINT	This error occurs during a threading cycle when the depth of the cut exceeds the programmed final depth of thread.
DEPTH PROBE AXIS MUST BE LAST	Adaptive depth probe is not AMPed as the last axis in the system. It must be AMPed after all normal axis and after the deskew slave and before any spindles. Refer to your AMP reference manual for details.
DEPTH PROBE AXIS NOT AMPED	A G26 (adaptive depth probe) move was programmed but no adaptive depth probe axis has been specified in AMP. Refer to your AMP reference manual.
DEPTH PROBE FB GEARING NOT 1:1	The AMP configured gear ratio for the logical axis used as a depth probe must be a one to one ratio. "Reset Teeth on Motor Gear for Pos. FB" and "Teeth on Lead Screw Gear for Pos. FB".
DEPTH PROBE TRAVEL LIMIT	The adaptive depth probe has moved to its AMPed travel limit. Note the value entered in AMP is the adaptive depth probe deflection from the PAL- or logic-determined probe zero point. It may not be the actual total probe deflection.
DEPTH PROBE NOT SUPPORTED	A depth probe axis has been AMPed on an axis located on a servo card or a 9/230 that does not support the adaptive depth feature. (analog servo rev < rev 0.10 or 3 axis 9/260 9/290 digital servo cards)
DESKEW OPTION NOT INSTALLED	If the AMPed name specifying the deskew slave servo is not zero, or the AMPed name specifying the deskew master servo is not zero, and the option flag for deskew is zero, then the system is held in E-Stop.
DEVICE ALREADY OPENED	An attempt was made to open a device for download or upload from ports A or B when the device was already opened.
DEVICE NOT OPENED YET	The ready signal was not received when attempting to send data to or communicate with a peripheral device connected to communication ports A or B.
DIAMETER AXIS MISCONFIGURED	An invalid axis has been configured as the diameter axis.
DIRECTORY CHANGED TO MAIN DIRECTORY	When a password is entered that does not have access to the protectable part program directory and the protectable part program directory is currently selected, the control changes the selected directory to the main directory.
DISP SELECT NOT ALLOWED	You can not use the display select functions while the online PAL search monitor utility is active. Leave the search monitor utility before you try to select a display.
DIVIDE BY ZERO ERROR	A system software error has occurred. Consult Allen-Bradley customer support services.
DMA TRANSFER ERROR - CNC STOPPING	An error condition occurred as a result of a DMA transfer while the executive was running. The integrity of the data (logic PIT data or communication packets to the data server) is questionable. The CNC executive cannot continue operating.
(DO) NUMBER ALREADY USED	When executing a program, an attempt was made to activate a DO loop that has the same loop identifier (DO 1, 2, or 3) as an already active loop in the program. Provided they are not nested loops, the same loop identifier can be used more than once in a program .
(DO) RANGES INTERSECT	DO loops are improperly nested. A DO loop that is nested within another DO loop does not have an END command before the original DO loop END occurs.

Message	Description
DRESS CANCEL DEFERRED TO G40	The in-process dresser cannot be canceled (made inactive) while dresser/wheel radius compensation is active. If an attempt to cancel the in-process dresser is made, the control will postpone the request until dresser/wheel radius compensation is canceled with a G40 (note that M02, M30, and M99 can also cancel compensation).
DRESSER AXIS NOT ALLOWED	An attempt was made to program the dresser axis when the over the wheel dresser feature has been activated through PAL or logic. You cannot program the dresser axis when the over the wheel dresser feature is active.
DRESSER FLANGE LIMIT REACHED	While dressing the grinding wheel the wheel size reached the entered flange limit. You should stop dressing the wheel before damage to the wheel flange occurs.
DRESSER MINIMUM LIMIT REACHED	The current dressing operation would dress the grinding wheel below the minimum wheel diameter as specified on the dresser status screen. This dressing operation will not be performed.
DRESSER MISCONFIGURED	One of the AMP parameters for the dresser axis has not been configured properly. Either the dresser axis, the vertical axis, or some other axis name is not a valid axis in the system. You must reconfigure your AMP. Refer to your AMP manual for details.
DRESSER MIS-POSITIONED	Wheel re-enable was requested with IPD active and wheel is more than 4 inch-programming counts (hard-code amount) away from its previously active absolute position. Wheel dressing does not start.
DRESSER NOT INITIALIZED	This error is generated if an attempt is made to activate the in-process dresser before the dresser has been initialized through a wheel calibration operation.
DRESSER NOT/MIS CONFIGURED	The grinder over-the-wheel dresser feature issues this message when a wheel is initialized and the dresser parameters in AMP have been misconfigured. This message is issued when the dresser axis, dresser vertical axis, or dresser other axis has not been selected, or has been AMPed to have common axes, or has been AMPed to be a non-existent axis name.
DRESSER WARNING LIMIT REACHED	The axis specified as the dresser axis has been dressed smaller than the dresser warning limit value as specified on the dresser status page.
DRILL AXIS CONFIGURATION ERROR	The drilling axis is not a currently configured machine axis. On dual processing controls this message may result when the drilling axis is in another process. The drilling axis must be a configured axis in the current process and should not be the slave of a dual axis (drill axis should be the master axis for dual group). On machines with dual axes, this message can mean the axis configured in AMP as the fixed-drilling axis is a slave axis. The drill axis should be the master axis.
DUAL AXES MASTER&SLAVE PROCESS NOT SAME	When configuring a dual axis on a dual processing system, configure AMP so all axes in the dual axis group are in the same source process even if the dual axis group is shared.
DUAL AXES PARK LOGIC CANNOT CHANGE	An attempt was made, using dual axes, to change the current park status. At this point, the request will not be allowed.
DUAL GROUP AXES MUST HAVE SAME ROLLOVER	All rotary axes in a dual axes group must have the same rollover value. These rollover values are set in AMP.
DUAL LATHE-MUST USE PROCESS 1,2	Dual lathe must have the active processes be the first 2 available in AMP; 3 or 4 should not be configured as an active process.
DUAL MASTER&SLAVE RAD/DIAM CONFIG ERR	The slave of a dual group has been defined as a diameter axis. The OEM must define the master to be a diameter axis and the system will change the slave to be a diameter axis. When the group is decoupled the slave will continue to take on the master's rad/diam traits.
DUAL PLANE CONFIGURATION ERROR	In AMP you have defined a plane with an axis and a master and a slave in the wrong order. For example: If the system has 4 axes YXZU and ZU are duals, if an AMPed plane is ZX, then UX can not be and AMPed plane. It must be XU (refer to your AMP reference manual for details).
DUAL SLAVE OR SPLIT AXIS NOT ALLOWED	Neither a dual slave, nor a split axis (deskew axis) may be programmed in a G24, G25, or G26 block.
DUALS CANNOT CHANGE OFFSETS IN CIRCULAR	An attempt was made, using dual axes, to account for an offset change in a circular move. Dual offset changes can only be made in linear blocks.
DUALS ONLY ALLOWING SINGLE AXIS HOME	An attempt was made to home multiple axes in a dual group when PAL or logic only allows one axis at a time to be homed. PAL or logic can be changed to allow homing of multiple axes in a dual group.

Message	Description
DUALPORT PTO TEST FAILED	The Dualport failed the diagnostic test and the bootstrapping operation is skipped. Consult Allen-Bradley customer support services.
DUPLICATE 1394 SLOT	The 1394 rack ID and slot number AMP entries are the same for two or more servos. Each axis module in a 1394 rack must have an individual address.
DUPLICATE 7300 PATTERN NAME	An attempt was made to enter a 7300 pattern name that already exists.
DUPLICATE DUAL MASTER NAMES	Both dual master axes names have the same letter.
DUPLICATE I/O RING DEVICE	Two or more of the same type of device on the I/O ring have the same device address switch setting.
DUPLICATE PROGRAM	An attempt was made to rename a program in control memory using the same program name (or number) of another program already in memory.
DUPLICATE PROGRAM NAME	An attempt was made to store or copy a program in control memory using the same program name (or number) of another program already in memory.
DWELL VALUE NOT PROGRAMMED	A G04 Dwell or a parameter requesting a dwell at hole bottom in a fixed drilling cycle was programmed with no value assigned to the length of the dwell.
E	
(E) AND (F) IN SAME BLOCK	In a G32 block (Lathe A) or G33 block (Lathe B & C), both leads were programmed in the same block.
EMPTY PROGRAM WAS DELETED FROM DIRECTORY	The current program being edited was saved and contained no program blocks. This program was deleted from the control's program directory.
ENCODER QUADRATURE FAULT	An error has been detected in the encoder feedback signals. Likely causes are excessive noise, inadequate shielding, poor grounding, or encoder hardware failure.
END OF FILE	When transferring a file over the serial port, the control has reached the last block in the program.
END OF PROGRAM	When displaying a part program on the CRT, the control has reached the last block in the program.
END OF PROGRAM REACHED	When performing one of the program search features, the control has reached the last block in the program.
ENTER ALL REQUIRED PROMPT DATA	An attempt was made to create a transfer line part program from the quick view screen without entering all the required quick view screen prompt data. Optional data is shown in reverse video.
ENTRY OUT OF RANGE	A parameter value was entered that is larger or smaller than the usable range determined in AMP or allowed on the system.
ERASE PROMPT	The operator has data on the input line (line 2 of the CRT) that must be cleared or entered so that a new prompt can be displayed on the input line.
ERROR ACCESSING PROGRAM	A major software error was generated by the control's internal software when editing the program; the program should be deleted. If the error persists, contact Allen-Bradley customer service support.
ERROR FOUND	A QuickCheck syntax check operation has found an error in the currently displayed program block. This is the block after the block containing the block-completed symbol "@". Press <CYCLE START> to continue the program check.
ERROR IN CIRCLE DATA	This error can occur when digitizing a circular block, typically the result of entering positions that cannot be correctly connected with an arc.
ERROR INITIALIZING DMA - CNC STOPPING	When the CNC executive starts, it sets up the module DMA controller for transferring data to and from the PC. This error indicates that the DMA initialization sequence failed. Attempt to restart your 9/PC executive to recover from the error and to properly initialize the DMA.
ERROR LOOKING FOR (END) COMMAND	The control has found a paramacro END command that does not match one of the active paramacro DO loop ranges.
ERROR TRANSFERRING PAL TO CPU #2	An error occurred while PAL was being transferred to the I/O CPU at power-up. PAL is transferred to the I/O CPU at power-up on a 9/290. Consult Allen-Bradley customer support services.

Message	Description
ESTOP STRING FAILURE	Software detected an apparent problem with the E-Stop string. Although the servo is attempting to open it, the Drive_OK contact is being held closed.
EXACTLY 2 DIGITS MUST FOLLOW DECIMAL PT	You have used incorrect search string syntax in the PAL search monitor utility.
EXCESS FOLLOWING ERROR	The following error for an axis exceeds the allowable value as defined in AMP. Most likely cause is AMP servo related parameters are set too stringently for the hardware. Also caused by axis runaway.
EXCESS SKEW ON	The calculated skew is larger than the AMPed maximum allowable skew.
EXEC BOOTSTRAP FAILED	The bootstrapper failed to respond within the specified time for any code segment. Consult Allen-Bradley customer support services.
EXECUTIVE CHECKSUM ERROR - CNC STOPPING	The saved checksum that protects the CNC executive code does not match the computed checksum of the executive. The executive is corrupt and AMP will not be saved into the flash.
EXPRESSION INCOMPLETE	A syntax problem has been found in a paramacro expression. The control is unable to correctly evaluate the expression as entered.
EXTRA DATA IN INTERRUPT MACRO BLK	An attempt was made to program extra data (such as a G-code) in the M-code block that activates or deactivates an interrupt program. No extra commands can be programmed in this block.
EXTRA DATA IN QPP BLOCK	The QuickPath Plus block has been programmed with too many parameters. For example, you cannot program a G13 block with both axis data and an angle word or with an L or A word in the block.
EXTRA I/O RING DEVICE	An I/O device that has not been defined in the I/O assignment file is physically present on the I/O ring.
EXTRA KEYBOARD OR HPG ON I/O RING	The control detected a keyboard or HPG on the 9/Series fiber optic ring that was not configured as a ring device. The I/O ring will still function and the control will NOT be held in E-Stop. You may also use the keyboard or HPG by selecting it as the active device via the corresponding logic flags. You should configure the keyboard or HPG with the I/O assigner utility (refer to your <i>9/Series PAL Reference Manual</i> for details).
F	
FATAL FAULT OCCURRED - CNC STOPPING	A fatal fault occurred that did not report a specific error condition (e.g., an i960 internal NMI error). Contact your Allen-Bradley sales representative.
FCM DUALPORT RAM FAILURE	The FCM detected an error in dualport RAM.
FCM FLASH RAM FAILURE	The FCM detected an error in flash RAM.
FCM LOCAL RAM FAILURE	The FCM detected an error in local RAM at power-up or during the runtime diagnostics.
FCM PLUG CONFIGURE FAILED	The FCM card failed to configure correctly.
FCM PLUG FAULT	The plug on the FCM detected an error.
FCM PLUG NEGOTIATE FAILED	The FCM firmware could not communicate with the plug.
FCM POWER UP SEQUENCE FAILURE	Power-up failed. Try again. If error appears again, contact your Allen-Bradley sales representative.
FCM REVISION CHECK FAILURE	Revision on module is out-of-date. Contact Allen-Bradley sales representative to get latest revision of the module's firmware.
FCM ROM FAILURE	The FCM detected an error in ROM during runtime diagnostics.
FCM SHADOW RAM FAILURE	The FCM detected an error in shadow RAM.
FCM SPURIOUS INTERRUPT	A spurious interrupt occurred on the FCM card.
FCM VRTX ERROR	A call from VRTX from the FCM card firmware returned an error.
FCM WATCHDOG	The watchdog on the FCM card timed out.
FDBK NOT AVAILABLE ON 4TH AXIS OF BOARD	An attempt was made to receive feedback from the axis that is configured as the fourth axis on a servo board. You can only receive feedback from the first three axes on a servo board.

Message	Description
FEEDBACK DISCONNECTED	The control has detected a loss of feedback from the encoder. The most likely cause of this error would be a broken or disconnected wire. Axis homing will be required after the error condition is corrected. To clear this fault, you should: <ul style="list-style-type: none"> • determine the cause of the fault • resolve the situation • power cycle to your 1394 drive (for Stegmann devices only) • turn your system back on For more information regarding this fault, refer to the Troubleshooting chapter of the <i>1394 Digital AC Multi-Axis Motion Control System User Manual</i> .
FEED AXIS DATA NOT PROGRAMMED	Feed axis data required during a grinder fixed cycle was not programmed.
FEED AXIS MOTION NOT ALLOWED	During Virtual C programming, no axis motion is allowed on the axis specified as the feed axis in AMP.
FEED TO HARDSTOP PROGRAMMING ERROR	No axis, or more than one axis, was programmed in a G24 block. Or the programmed axis integrand was not programmed in the block.
FEEDBACK OPTION NOT INSTALLED	A PTO check determines the legal number of axes.
FILE CANNOT BE CONVERTED TO EIA FORMAT	The file requested to be output to a device has characters that cannot be converted to EIA.
FILE DOWNLOAD COMPLETE	Status message that means the download has completed.
FILE DOWNLOAD ERROR	Check file download and file download configuration screens to make sure all fields are entered correctly.
FILE DOWNLOAD IN PROGRESS	This status message means a file is being downloaded.
FIXED CYCLE ALREADY ACTIVE	You cannot program a fixed cycle with a fixed cycle already active.
FIXED CYCLE PROGRAMMING ERROR	A fixed cycle has been programmed incorrectly. Verify that the correct parameters have been used and that parameters restricted to integer or positive values are programmed as such.
FLASH IN USE - TRY AGAIN LATER	Only one task is allowed to write flash at a time. If a second task requests a flash write, you will see this message.
FLASH SIMMS ARE NOT INSTALLED	Install the flash SIMMs into the 9/Series mother board. Flash SIMMs must be installed. If a repaired system is being installed, you should have saved your flash SIMMs for re-installation before making the return.
FLASH SIMMS CONTAIN INVALID DATA	Flash SIMMs have become corrupted probably from a communication error during a system update. Retry the system executive update utility. If the situation persists, contact Allen-Bradley support.
FLASH SIMMS U10 AND U14 ARE EMPTY OR MISSING	Make sure your flash SIMMs are installed in the correct tracks. Refer to the <i>9/Series Installation and Integration Manual</i> section covering your processor for details on flash installation. Remove and reseat flash SIMMs.
FLASH SIMM U10 IS EMPTY OR MISSING	Make sure your flash SIMMs are installed in the correct tracks. If they appear to be installed correctly, remove and reseat SIMMs. If problem persists, contact Allen-Bradley support service.
FLASH SIMM U14 IS EMPTY OR MISSING	Make sure your flash SIMMs are installed in the correct tracks. If they appear to be installed correctly, remove and reseat SIMMs. If problem persists, contact Allen-Bradley support service.
FLASH WRITE ERROR	A problem occurred while writing to flash, for example bad flash, no flash, or no voltage.
BACKGROUND OVERLAP	The foreground tasks did not complete execution within the 20-millisecond period allocated. Foreground tasks include PAL foreground, axis interpolation, servo interface, and I/O ring scanning. Correct by reducing the PAL foreground program size or removing some devices from the I/O ring.
G	
G10 NOT ALLOWED DURING CYCLE	G10 code is not allowed to be used during the cycle. Cancel the fixed cycle.
G24 NOT ALLOWED	G24 is not allowed when any automatic G coded cycle is active (such as G81).
G24 PLANE INCOMPATIBILITY	The hard stop axis may not be in the active part rotation plane.
G25 NOT ALLOWED	G25 is not allowed when any automatic G coded cycle is active (such as G81).
G25 PLANE INCOMPATIBILITY	The adaptive feed axis may not be in the active part rotation plane.

Message	Description
G26 NOT ALLOWED	G26 (adaptive depth probe) can not be programmed when another modal group is active (such as a G81 fixed cycle).
G26 PLANE INCOMPATIBILITY	A conflict between a plane dependent feature and a G26 (depth probe). For example if part rotation is active and a G26 is programmed on an axis in the part rotation plane this error is generated. Refer to the G26 section of your operation and programming manual for details on incompatible planar features.
G28 BLOCK DOES NOT PRECEDE G29 BLOCK	A G29 block was programmed before a G28 block. During 7300 tape compatibility mode, the first automatic threading block must contain a G28 code; the next block must contain a G29 code.
G29 BLOCK DOES NOT FOLLOW G28 BLOCK	A G28 block was programmed without a following G29 block. During 7300 tape compatibility mode, the first automatic threading block must contain a G28 code; the next block must contain a G29 code.
G40 NOT ALLOWED IN CIRCULAR	An exit move from cutter compensation or TTRC was attempted in a circular block (G02 or G03). An exit move (programmed with a G40) must generate a linear move.
G53 NOT ALLOWED IN G91 MODE	An attempt was made to make an incremental move in the machine (absolute) coordinate system. Only absolute moves (G90) are permitted in the machine coordinate system.
G53 NOT ALLOWED IN INCREMENTAL MODE	A G53 move to absolute position was requested while in incremental mode.
G53 ON AN UNHOMED AXES	An attempt to program a move in the machine (absolute) coordinate system was made before the axis was homed. It is necessary to home the axes to establish the location of the machine coordinate system.
G91 MODE NOT ALLOWED IN QPP	Since QuickPath Plus is generally used to program blocks without knowing the intersection of the blocks, it is impossible to calculate a location for the end-point of the block when the move is incremental. QuickPath Plus must be programmed in absolute mode (G90).
(G-CODE) TABLE ERROR	There has been an internal software fault relative to the G-code table. Consult Allen-Bradley Customer Support Services.
(GOTO) SEQ. NUMBER NOT FOUND	The sequence number (N word) called by a GOTO command does not exist in the currently executing program.
GRAPHICS ACTIVE IN ANOTHER PROCESS	Graphics can only be active in one process at a time. You must turn graphics off in one process before you can activate them in another process.
H	
HARD STOP ACTIVATION ERROR	An attempt was made to (G24) hard stop an axis while a different axis was already holding against a hard stop.
HARD STOP AND/OR ADAPTIVE DATA CONFLICT	An attempt was made to create a transfer line part program from the quick view screen entering data for both hard stop (G24) and adaptive depth features (G26). You can select only one of these features.
HARD STOP AXIS NOT ALLOWED IN INTERRUPT	An axis which is still hard-stopped due to a previous G24 block may not be moved by any block inside an interrupt macro program.
HARD STOP DETECTION ERROR	A hard stop (G24) was detected outside of the programmed hard stop region. Or a hard stop was not detected before the hard stop axis reached its endpoint.
HARD STOP DIRECTION ERROR	The axis currently holding against a hard stop (G24) was programmed with a move further into the hard stop. You must program the move away from the hard stop in the direction opposite to the direction used to place the axis at the hard stop.
HARD STOP EXCESS ERROR	The hard stop axis (G24) was moving too fast when it encountered the hard stop. You must reduce the axis feedrate before contacting the hard stop.
HARDWARE ERROR #1	The 68030 (68000 on 9/240 only) main processor received an interrupt of unknown origin on level 6. Consult Allen-Bradley customer support services.
HARDWARE ERROR #2	The 68030 (68000 on 9/240 only) main processor has detected a bus error. Consult Allen-Bradley customer support services.
HARDWARE ERROR #3	The 68030 (68000 on 9/240 only) main processor has detected a spurious interrupt. Consult Allen-Bradley customer support services.
HARDWARE ERROR #4	The 68030 (68000 on 9/240 only) main processor has detected an illegal address. Consult Allen-Bradley customer support services.

Message	Description
HARDWARE ERROR #5	The PAL program residing in RAM memory has failed a checksum test. Attempt to download your PAL program to the control again. If the error remains, consult Allen-Bradley customer support services.
HARDWARE ERROR #6	The 68030 (68000 on 9/240 only) main processor has detected a privilege violation. Consult Allen-Bradley customer support services.
HARDWARE ERROR #7	The AMP data in Backup memory has failed a checksum test. Attempt to download your AMP program to the control again and again try to store it in Backup memory. If the error remains, consult Allen-Bradley customer support services.
HARDWARE ERROR #10	The servo processor RAM diagnostic test has failed. Consult Allen-Bradley customer support services.
HARDWARE ERROR #12	The servo communications timing diagnostic test between the main processor and the servo processor has failed. Consult Allen-Bradley customer support services.
HARDWARE ERROR #13	The main processor was not ready in time to send data to the servo processor. Consult Allen-Bradley customer support services.
HARDWARE ERROR #14	The servo processor sent an invalid error code to the main processor. Consult Allen-Bradley customer support services.
HARDWARE ERROR #15	The servo communications data echo diagnostic test between the main processor and the servo processor has failed. Consult Allen-Bradley customer support services.
HARDWARE OVERTRAVEL (+)	The indicated axis has reached a travel limit in the positive direction.
HARDWARE OVERTRAVEL (-)	The indicated axis has reached a travel limit in the negative direction.
HIPERFACE COMMUNICATION ERROR	A serial communications error (e.g., CHECKSUM, TIMEOUT) was detected within the SINCOS device during power-up. If this error occurs at PTO, check your feedback device to make sure it is not disconnected.
HIPERFACE PASSWORD FAILURE	During the SINCOS device's alignment procedure, the logic used to set the passwords detects an incorrect password. A section of the code will repeatedly attempt various combination of each of the passwords to correct the error condition.
HOME REQUEST ON A PARKED AXIS	An attempt was made, while using dual axes, to do a homing operation on a parked axis.
HOMING NOT COMPLETED	An attempt was made to execute a programmed axis move before the axes have been homed. Axes must be homed before they can be moved through part program or MDI commands. This message may also appear if there was an attempt to use switchless homing on an axis with distance coded marker (DCM) feedback.
I	
I/O RING COMMUNICATIONS ERROR	A communication error occurred in the fiber optic I/O ring. This is usually caused by a broken or disconnected fiber optic cable.
I/O RING NOISE WHILE IDLE	An illegal character was detected by an optical receiver while the I/O ring should have been idle. The system will try to reset itself. If it cannot reset itself, the system enters E-Stop.
I/O RING NOT CONFIGURED	The control cannot run the I/O ring if it was not configured and downloaded from ODS or resident in the PAL PROMs.
I/O RING TIME-OUT	A very large foreground PAL program, combined with a large number of I/O ring devices, has created timing problems for I/O ring communications. Reduce PAL program size by deleting unnecessary rungs and optimize the execution of others.
ILLEGAL (/) VALUE	A block delete slash value greater than /9 was programmed. There are only 9 block deletes available.
ILLEGAL (G) CODE	An illegal G-code value has been programmed.
ILLEGAL (M) CODE	An illegal M-code value has been programmed.
ILLEGAL ANGLE VALUE	A QuickPath Plus block has defined the angle of the next block incorrectly. There is no possible path that connects the two tool paths to the programmed end-point using the entered angle.
ILLEGAL APPLICATION COMMAND FROM TEACH	A non-recognized SD1-type packet was received in a CMD=61 DF1 packet from the teach pendant interface. Allowable SD1s are 1 - 5.

Message	Description
ILLEGAL AXIS DATA FORMAT	Digitized axis data does not fit within the allowable AMPed axis format. For example, if an axis inch format is set at 2.3 and a digitized position is recorded as 121.0, an error will be generated. The axis display will also show " _ . _ _ _".
ILLEGAL CHARACTER	An undefined character was entered in a program block and could not be executed. Certain characters cannot be recognized while in certain modes. Also verify that you are using the correct axis and integrand names as assigned in AMP.
ILLEGAL CODE DURING G41/G42	An illegal code was encountered during G41/G42 programming.
ILLEGAL CODE DURING VIRTUAL C	An illegal code was encountered during Virtual C programming.
ILLEGAL CODES IN RANDOM TOOL BLOCK	An invalid parameter was entered in a G10.1L20 block that loads data into the Random Tool table. P, Q, R, and O are the allowable parameters.
ILLEGAL COMMAND FROM ODS	A command was received from ODS that was not recognized by the control.
ILLEGAL COMMAND FROM TEACH PENDANT	A non-recognized CMD-type packet was received in a DF1 packet from the teach pendant interface. Allowable CMDs are 60 - 63.
ILLEGAL CONTROL TYPE	You have downloaded from a peripheral device an AMP that does not match your control hardware.
ILLEGAL CPU #2 COMMAND	The 68000 main processor sent incorrect data to the Z80 I/O ring processor. (two 98030's instead of the 68000 and Z80 on 9/230, 9/260, and 9/290 controls)
ILLEGAL CYLINDRICAL BLOCK	A G-code not allowed in a cylindrical entry block or during cylindrical programming mode was programmed.
ILLEGAL DUAL CONFIGURATION	Both dual master axes names have the same letter OR when assigning dual groups in AMP, dual groups must be assigned in contiguous order, starting with group 1, 2, 3, 4, and 5. You can not assign axes to dual group 3 without axes having been assigned to dual groups 1 and 2.
ILLEGAL DUAL LINEAR/ROTARY CONFIGURATION	The dual group cannot contain a mixture of linear and rotary axes.
ILLEGAL FILENAME	An attempt was made to create a program using a program name that contains illegal characters. A different program name must be used.
ILLEGAL G40 EXIT BLOCK	An illegal sequence of exit moves was programmed in a G40 exit block.
ILLEGAL G88.5 OR G88.6 PARAMETERS	Illegal parameters were entered in a G88.5 or a G88.6 programming block.
ILLEGAL G99	An illegal G99 was entered in a programming block.
ILLEGAL G-CODE IN INTERRUPT MACRO	An illegal G-code has been programmed in a program called by a program interrupt. G24, G25, G26, G40, G41, G42, G52, G92, and G92.1 cannot be programmed in an interrupt program.
ILLEGAL G-CODE IN POCKET	An illegal G-code was entered in a G88 or G89 pocket-programming block.
ILLEGAL I/O RING DEVICE CODE	There is a device on the I/O ring that cannot be identified.
ILLEGAL I/O RING RACK SLOT CODE	There is a card in the 1771 I/O rack that the I/O ring cannot use.
ILLEGAL INPUT	A number was input from the keyboard instead of a character, or a character was input instead of a number.
ILLEGAL MACRO CMD VIA MDI	A paramacro command that cannot be used in MDI mode was programmed. This also can include an illegal sub-program return M99 code.
ILLEGAL MASTER AXIS NAME	Slave axes that do not have a master have been configured for a dual group OR you have assigned a \$ axis name as a group master. Axis names beginning with a \$ can not be assigned as the master axis for a dual group (first logical axis assigned to the group).
ILLEGAL PASSWORD	A password was entered that was not assigned to one of the 8 different password levels. Make sure that no one has changed the passwords by using {ACCESS CONTRL}.
ILLEGAL PLANE - USING SLAVE AXIS	This is a power turn-on message. When using dual axes, one of the slave axes was AMPed as part of the plane configuration. Only master can be used in the plane configuration.
ILLEGAL PLANE DEFINITION	The axis plane assignment made in AMP is incorrect. It can also occur if the two axes assigned to a plane have the same axis name.
ILLEGAL PROGRAMMED RETURN GROUP	The tool group programmed in an M06 block must be the currently active tool group that is being replaced (not the tool group you are changing to). This requirement is configured in AMP by the system installer.

Message	Description
ILLEGAL PROGRAMMED RETURN TOOL	The tool number programmed in an M06 block must be the currently active tool number that is being replaced (not the tool number you are changing to). This requirement is configured in AMP by the system installer.
ILLEGAL RANDOM TOOL TABLE ASSIGNMENT	An attempt was made to program a G10.1L20 block that would assign a tool to a tool pocket that already has a tool assigned to it.
ILLEGAL RECIPROCATION INTERVAL	The programmed reciprocating interval is greater than the total rollover distance.
ILLEGAL ROTATION PLANE SELECTED	When using the external part rotation feature, the external part rotation plane selected on the rotation parameter screen is not the currently active plane in the program block being executed.
ILLEGAL SPINDLE PROCESS NUMBER	An illegal process number was used to indicate a process that uses one of the spindles.
INCOMPATIBLE PAL SOURCE	The PAL search monitor utility can not be accessed. The PAL search monitor utility requires PAL program built with a newer version of ODS.
INCOMPATIBLE TOOL ACTIVATION MODES	This message is displayed and the control is held in E-Stop at power up when the tool geometry offset mode is "Immediate Shift/Immediate Move" and the tool wear offset mode is "Immediate Shift/Delay Move" or when the tool geometry offset mode is "Immediate Shift/Delay Move" and the tool wear offset mode is "Immediate Shift/Immediate Move". These modes are incompatible. You must correct your AMP configuration and re-download AMP.
INCORRECT NUMBER OF SYMBOLS	An error occurred in G05 DH+ communications block.
INPUT DATA TOO LONG	The data input has a number of characters exceeding the allowable number of characters.
INPUT STRING SYNTAX ERROR	An attempt was made to search for an illegal character string, or no character string was entered.
INSUFFICIENT MEMORY FOR PART PROGRAM	There is not enough available memory for the current program to be stored. Any attempt to store the program in memory will be aborted by the control.
INTEGRANDS FOR DUALS MUST BE THE SAME	This is a power turn-on message. When using dual axes, all integrands of the dual group must use the same letter.
INTEGRANDS FOR NON-MASTER MUST BE NONE	An axis integrand name was configured in AMP that corresponds to an axis in a dual axis group that is not the master axis of that group. Only the master axis in a dual axis group can have a corresponding axis integrand name.
INTEGRANDS NOT AMPED PROPERLY	The axis integrand names were not configured properly in AMP. Refer to your AMP manual for additional details on axis integrand names.
INTERF CHECKING ZONE TABLE CORRUPTED	The zone tables used by interference checking have an invalid checksum and were cleared.
INTERNAL COMMUNICATIONS ERROR	Communication failed. Contact Allen-Bradley customer support services.
INTERRUPT NOT RECOGNIZED	An interrupt macro was not acted on for some reason. An example would be if an interrupt occurred in the middle of another interrupt.
INVAL LOOP BASE	An attempt was made to configure ports TB2 and TB3 as position/velocity loop or digital or digital spindle.
INVALID AMP-DEFINED G CODE	An attempt was made to assign the same G-code to different macro calls. This message appears after AMP is downloaded and the control does secondary calculations.
INVALID AMP LETTER FORMAT	The programmed word or parameter has an invalid letter format defined in AMP. Since ODS AMP detects and prohibits invalid formats, this error usually indicates that an invalid format was entered through patch AMP. Refer to your AMP reference manual for details.
INVALID ARC-COSINE ARGUMENT	An attempt was made to calculate or execute a paramacro block that calculates the arc cosine of an invalid or improperly entered number.
INVALID ARC-SINE ARGUMENT	An attempt was made to calculate or execute a paramacro block that calculates the arc sine of an invalid or improperly entered number. Change cosine to sine.
INVALID ARGUMENT ASSIGNMENT	An invalid argument assignment was programmed.
INVALID AXIS	The axis programmed in the adaptive depth (G26) or adaptive feedrate (G25) block is invalid. Valid axis names for programming these features are defined in AMP.
INVALID AXIS FOR CSS	The CSS axis (the axis that is perpendicular to the center-line of the rotating part) is not a valid axis on the control. This usually occurs when the CSS axis is changed from the default axis by programming a P-word in the G96 block that selects some other axis.

Message	Description
INVALID AXIS PROGRAMMING RESOLUTIONS	The axis resolutions set in AMP by the system installer are too far apart. The control is incapable of handling large differences in axis resolutions. For example, if the X axis has a resolution that allows .999999 and the Z axis allows a resolution of only .9, the control can have difficulty moving both axes simultaneously.
INVALID CCT INDEX	An error occurred in G05 DH+ communications block.
INVALID CHANNEL NAME	An error occurred in G05 DH+ communications block.
INVALID CHARACTER	A program name has been entered that contains an illegal special character.
INVALID CHECKSUM DETECTED	This error is common for several different situations. Most typically it results when writing or restoring invalid data to flash memory. For example if axis calibration data is being restored to flash and there was an error or invalid memory reference in the axis calibration data file. Typically this indicates a corrupt or invalid file.
INVALID CNC FILENAME	An error occurred in G05 DH+ communications block.
INVALID CODE PROGRAMMED FOR 7300	An invalid G or M code was programmed during 7300 tape compatibility mode.
INVALID COMMUNICATIONS PARAMETER	Parameters in G05 and/or G10.2 communication blocks are incorrect.
INVALID CONTROL FOR DUAL PROCESS SYS	The system executive downloaded to the control does not match the hardware configuration established by your option chip.
INVALID CUTTER COMPENSATION NUMBER	A compensation number (or TTRC number) out of the range of allowable compensation numbers (either too large or too small) was programmed.
INVALID CYCLE PROFILE	The path defining the cycle profile is not valid. This is typically caused by the cutter radius being set to the wrong sign, being set too large, or the values for U, W, I, K, and the cutter radius combined are not valid for the profile to be cut.
INVALID DATA AFTER A MACRO COMMAND	Typically caused by a non-paramacro command following a paramacro command. Macro and non-macro commands cannot exist in the same block.
INVALID DATA BEFORE A MACRO COMMAND	Typically caused by a non-paramacro command preceding a paramacro command. Macro and non-macro commands cannot exist in the same block.
INVALID DATA FORMAT MUST BE MM/DD/YY	An invalid date format was entered. The format must be Month / Day / Year (MM/DD/YY).
INVALID DEPTH PROBE CONTROLLING AXIS	The axis name which is AMPed as the controlling axis for the depth axis is not an axis that has been configured on the system or the adaptive depth controlling axis is configured as the same axis defined to have depth probe feedback. Refer to your AMP reference manual for details on axis configuration.
INVALID DESKEW MASTER	The AMPed name specifying the master deskew servo is not one of the AMPed axes.
INVALID DESKEW SLAVE	The AMPed name specifying the master deskew servo is not one of the AMPed axes, or it has already selected as a master axis.
INVALID DH COMMAND TYPE	An error occurred in G05 DH+ communications block.
INVALID (DO) COMMAND NUMBER	The specified loop number in a paramacro DO command is out of the legal range, or not found. DO commands must be followed by a 1, 2, or 3.
INVALID (END) COMMAND NUMBER	A paramacro END command has been encountered without a matching DO or WHILE, or outside the valid range. END commands must be followed by a 1, 2, or 3, as programmed with the corresponding DO command.
INVALID ENDPOINT IN G27 BLOCK	The position programmed in the G27 block is not the home position. The end-point of a G27 block must be the machine home position.
INVALID EXPECTED LIFE	The data just entered for the expected life of the cutting tool for tool management is invalid.
INVALID EXPECTED TOOL LIFE	The current program is attempting to enter an invalid value for the tool management expected life of a tool. Tool life is programmed in a G10 block with an L-word.
INVALID FB COUNTS	At power up the control checks the AMP configured position and velocity feedback counts per revolution. If either of these parameters are invalid (for this hardware type) this error appears and the control is held in E-Stop.
INVALID FDBK/MTR TYPE COMBO	When changing between an executive from system 9.xx to 10.xx some major changes occurred to how a servo is configured in AMP. When copying this AMP project from 9.xx to 10.xx you must open and reconfigure some of the AMP servo group parameters before saving and downloading to the control.

Message	Description
INVALID FILE TYPE	An error has occurred in a file that has been sent from the ODS workstation to the control. Typically it is the result of ODS sending the wrong file type to the control (for example, an AMP file is sent when a PAL download is taking place, etc.). Attempt to download the file again, making sure that the correct file type is selected when downloaded.
INVALID FIXED DRILLING AXIS	The axis selected as the drilling axis is an invalid axis for a drilling application.
INVALID FORMAT SPECIFIED IN B/DPRNT CMD	Improper format was used in the paramacro command (BPRNT or DPRNT) that outputs data to a peripheral device.
INVALID FUNCTION ARGUMENT	An invalid paramacro argument was used in a paramacro function. The argument contains either bad syntax or an illegal value.
INVALID G10 CODE	The format for a G10 block is not correct. Refer to your user manual for the correct format for the G10 block that is currently being programmed.
INVALID IN ANGLED WHEEL MODE	A feature that is not available in G16.3 mode, or G16.4 mode or both has been programmed. Refer to your grinder users manual angled-wheel grinder section for a description of features not available on an angled-wheel grinder.
INVALID INFEED (P WORD)	Infeed value (P-word) is not in valid range. The valid range for a P-word during a threading cycle is whole numbers 1 through 4.
INVALID INPUT VALUE	The data entered is invalid for the current operation being performed.
INVALID INTERFERENCE AREA	A G10 block has programmed a zone where the plus value is less than the minus value.
INVALID INTERFERENCE CHECK AXIS	An axis from the wrong process was AMPed. Unless a shared axis is used in the zone, the axis defined to make up an interference area must be in the process the zone is defined for.
INVALID LATHE AXIS	An illegal code was encountered during cylindrical interpolation programming.
INVALID LIFE TYPE	The current program is attempting to enter an invalid tool life type for a tool group in the tool management tables. Valid tool life types are type 0, 1, or 2. Tool life type is programmed in a G10 block following a I-word.
INVALID M99 IN MAIN PROGRAM	An M99 part program rewind and auto start was programmed in the middle of the main program. An M99 can be programmed only at the end of a part program.
INVALID MACRO COMMAND	The IS and IM commands are reserved for use by the control only for program interrupts. They cannot be entered in a part program or MDI program.
INVALID MACRO FROM TAPE	You have programmed a paramacro command that cannot be executed from tape.
INVALID NUMBER OF POCKETS	This error occurs when using G10 L20 to enter random tool data and the number of pockets needed for the tool is invalid.
INVALID OFFSET NUMBER	An offset number out of the range of allowable offset numbers (either too large or too small) was programmed.
INVALID OPERATOR IN EXPRESSION	Check expressions to make sure they are correct.
INVALID OPERATOR IN PARAMACRO EXPRESSION	The control has encountered a non-mathematical operator (character) in a paramacro expression or calculate operation.
INVALID OUTPUT FORMAT	An error occurred in G05 DH+ communications block.
INVALID PARAMACRO ARGUMENT ASSIGNMENT	An argument assignment in a block that calls a paramacro program contains either an invalid argument specification or a syntax error was made in the argument.
INVALID PARAMETER NUMBER	An attempt was made to assign or read the value of a paramacro parameter that does not exist.
INVALID PARAMETER VALUE	An attempt was made to assign an invalid value (typically too large or too small of a value) to a paramacro parameter.
INVALID POCKET NUMBER	An attempt was made to enter a tool pocket number that exceeds the allowable number of tool pockets in the random tool table. This error occurs when a P-word that is too large or too small is programmed in a G10.1L20 block.
INVALID POCKET PROFILE	An invalid pocket profile was programmed in a lathe roughing or finishing cycle.
INVALID POSITION FB TYPE	System was incorrectly AMPed with a Yaskawa type encoder (absolute or incremental) on the position feedback device when separate position and velocity feedback devices are used.

Message	Description
INVALID PROGRAM NUMBER (P)	A program number called by a sub-program or paramacro call is invalid. A P-word that calls a sub-program or paramacro can only be an all-numeric program name as many as 5 digits long. The O-word preceding the numeric program number in control memory cannot be entered with the P-word.
INVALID REMOTE NODE NAME	An error occurred in G05 DH+ communications block.
INVALID REMOTE STATION TYPE	An error occurred in G05 DH+ communications block.
INVALID REPEAT COUNT (L)	An L parameter that programs the number of times a paramacro or other operation is to be repeated was programmed incorrectly or out of the legal range. The L-word for repeat count must be a whole, positive number. Decimal values and negative values are invalid. The maximum value of an L-word is 9999.
INVALID ROUGHING CYCLE (P/Q) WORD VALUE	When executing a roughing cycle, the starting or ending sequence number of the contour defining blocks cannot be found in the currently executing program. The sequence number of the contour blocks is programmed using the P and Q words. These blocks can be anywhere in the program provided they are resident in the same program, sub-program, or paramacro program that contains the calling block.
INVALID SCALE FACTOR (P-WORD)	An invalid scale factor has been specified. The P-word has a range of 0.0001 to 999.99999.
INVALID SERVO HARDWARE TYPE	The AMP servo parameter that selects the servo type does not match the hardware found on the control when the AMP file is downloaded. Either AMP is misconfigured or the servo hardware installed on your system is not correctly installed or not of the correct type.
INVALID SHAFT POCKET	When entering a custom tool in the random tool table, an attempt was made to assign a shaft pocket position that is not in the range of the number of pockets assigned to the tool. The shaft pocket number must be equal to or less than the number assigned for the number of pockets.
INVALID SHAFT POCKET VALUE	A program is attempting to enter a custom tool in the random tool table with a invalid shaft pocket position (not in the range of the number of pockets assigned to the tool). The shaft pocket number must be equal to or less than the number assigned for the number of pockets. The shaft pocket value is assigned in a G10.1 block following the R-word.
INVALID SPCMD VALUE	A invalid special command error typically occurs when the servo PROMs are not compatible with the main processor PROMs. Check the software version numbers and contact Allen-Bradley customer support services.
INVALID SYMBOL NAME	An error occurred in G05 DH+ communications block.
INVALID T-CODE FORMAT	This is an invalid T-Code Format
INVALID_THREAD_ANGLE	An attempt was made to program an angle that is outside the allowable range, which is 0 through 120 degrees.
INVALID THRESHOLD RATE	An invalid threshold percentage was entered for a tool group while setting tool management data. The threshold percentage must range between 0 and 100 percent. Only whole positive numbers can be entered. If using a G10 block, the threshold percentage is entered with a Q-word.
INVALID TIME FORMAT MUST BE HH:MM:SS	An invalid time format was entered. The time format must be hour / minute / second (HH/MM/SS).
INVALID TOOL AXIS	This is an invalid Tool Axis.
INVALID TOOL CUTTER COMPENSATION NUMBER	An attempt was made to enter a tool radius offset number, for cutter compensation or TTRC, in the tool life management table that is larger than the maximum offset number allowed. If the tables are being loaded by a G10 program, the radius offset is entered with a D-word in the block.
INVALID TOOL DIAMETER VALUE	An invalid tool diameter value was entered in a program block.
INVALID TOOL GROUP	An attempt was made to create a tool group greater than 200 in the tool management tables. A maximum of 200 tool groups can be used. If loading the tables using a G10 program, the tool group number is entered using a P-word.
INVALID TOOL LENGTH OFFSET NUMBER	An attempt was made to enter a tool length offset number in the tool life management table that is larger than the maximum offset number allowed. If the tables are being loaded by a G10 program, the length offset number is entered with a H-word in the block.

Message	Description
INVALID TOOL LIFE TYPE	An attempt was made to enter an invalid tool life type for a tool group in the tool management tables. Valid tool life types are type 0, 1, or 2.
INVALID TOOL NUMBER	Either no tool or an invalid tool number was programmed in a random tool G10.1 block. Tools should be programmed with a Q-word in a G10.1 block or within a range determined by the system installer in AMP. An invalid tool number was entered into the tool management tables or was programmed in a part program block.
INVALID TOOL NUMBER FROM LOGIC	The logic offset change feature specified an invalid tool number to the control.
INVALID TOOL NUMBER FROM PAL	The PAL offset change feature specified an invalid tool number to the control.
INVALID TOOL ORIENTATION	This is an invalid tool orientation.
INVALID TOOL TABLE TYPE	This is an invalid tool table type.
INVALID VALUE ZONE 3	A zone 3 value was entered that is outside of the zone 3 limits.
INVALID VALUE ZONE 3:	The zone listed has values that are outside of the zone limits.
INVALID VELOCITY FDBK TYPE	AMP for your digital drive system has been configured for an invalid velocity loop hardware type. Valid values for digital systems are NO FEEDBACK, ABSOLUTE FEEDBACK, and INC ENCODER ON DIGITAL MODULE. Other selections are invalid on digital systems.
INVALID WHEEL ANGLE	An invalid wheel angle has been entered for the angled wheel grinder. Wheel angles must be entered between 0 and 180 degrees. Also wheel angles that approach 90 degrees are also invalid.
INVALID WORD IN G10L3 MODE	An attempt was made to assign a parameter that is not a legal parameter in the G10L3 mode. G10L3 assigns data to the tool management tables.
INVALID WORD IN G11 BLOCK	An invalid word was programmed in a G11 block that cancels the data setting mode for the tool management tables. The G11 code must be programmed in a block that contains no other data.
INVALID ZONE LIMIT	This is an invalid Zone Limit.
INVALID ',' WORD	A word other than a chamfering C-word, a radius R-word, or QPP angle word was programmed in a block with a comma ",". Only the radius and chamfer words can be preceded with a "," in a block.
IPD AND G16.3/G16.4 CANNOT BE CONCURRENT	This error message is issued when in-process dressing is on and a block containing a G16.3 or G16.4 is activated on a cylindrical grinder in angled wheel configurations.
J	
JOG WILL CAUSE (+) OVERTRAVEL	An attempt was made to execute an incremental jog that would move the indicated axis beyond its positive software overtravel limit.
JOG WILL CAUSE (-) OVERTRAVEL	An attempt was made to execute an incremental jog that would move the indicated axis beyond its negative software overtravel limit.
JOGGED HOME TOO FAST:	The speed selected for the move to the home limit switch is too fast and the homing operation has failed. Move the axes back to the other side of the limit switch (the side before the homing operation began), and re-execute the homing operation, this time slowing the speed using the <SPEED/MULTIPLY> switch or the <FEEDRATE OVERRIDE> switch.
L	
L VALUE OUT OF RANGE	An L-word repeat count was programmed larger than the system is capable of performing (typically a maximum L of 9999 is permitted). A second block will need to be programmed to duplicate the commands again. Enter a smaller L-word for both blocks.
L-WORD CANNOT BE GREATER THAN TOOL RADIUS	The programmed L-word value in a G88.5 or G88.6 hemispherical pocket cycle is greater than the programmed tool radius. The incremental plunge depth of a hemispherical pocket cycle cannot be greater than the tool radius.
L-WORD OUT OF RANGE	More than 1000 spark-out passes were specified by the L-word in a grinder fixed cycle.
LARGER MEMORY - REFORMAT	This message typically occurs after a new AMP or PAL has just been downloaded to the control. There is now more memory available for the RAM disk, but you need to reformat to use it. If desired, you do not have to reformat RAM and can continue to run the control with the RAM disk at its current size.

Message	Description
LEAD WORD FORMAT FINER THAN	The word format programmed is requesting a finer resolution than the axis word format for the corresponding axis allows. These word formats are set in AMP.
LENGTH OFFSET AXIS MISSING IN PROCESS	You have configured the tool length axis as a shared axis and it is currently not being controlled by the process requesting to activate a tool length offset. The shared length axis must be returned to the process attempting to activate the tool offset. Or tool offsets were programmed for an axis that is configured in AMP as unfitted.
LESS MEMORY - REFORMAT	This message typically occurs after a new AMP or PAL has just been downloaded to the control. There is now less memory available for the RAM disk, and you must reformat to use the RAM disk.
LETTER OR DIGIT MUST FOLLOW \$, %, !, &, OR #	You have used incorrect search string syntax in the PAL search monitor utility.
LETTER OR DIGIT MUST FOLLOW \$, %, ! OR #	You have used incorrect search string syntax in the PAL search monitor utility.
LETTER OR DIGIT MUST FOLLOW \$, % OR !	You have used incorrect search string syntax in the PAL search monitor utility.
LETTER OR DIGIT MUST FOLLOW \$, % OR !	You have used incorrect search string syntax in the PAL search monitor utility.
LETTER OR DIGIT MUST FOLLOW #	You have used incorrect search string syntax in the PAL search monitor utility.
LIMIT EXTRN DECEL SPEED ON	Dual axes have limited the external decel speed AMP value. An axis in the dual-axis group was AMPed with a lower value.
LIMIT MANUAL DLY CONSTNT ON	Dual axes have limited the manual delay constant AMP value. An axis in the dual-axis group was AMPed with a lower value.
LIMIT MAX CUTTING FEED ON	Dual axes have limited the maximum cutting feedrate AMP value. An axis in the dual-axis group was AMPed with a lower value.
LIMITED ACC/DEC RAMP ON	Dual axes have limited the acc/dec ramp AMP value. An axis in the dual-axis group was AMPed with a lower value.
LIMITED RAPID FEEDRATE ON	Dual axes have limited the rapid feedrate AMP value. An axis in the dual-axis group was AMPed with a lower value.
LIMITED VELOCITY STEP ON	If the velocity step AMP value is not the same for all axes of a dual group, the control will adjust them to the limiting axis.
LOGIC ANALOG PORT ILLEGAL CONFIGURATION	This is a power turn-on error that occurs when an AMP configuration error exists in the logic analog port configuration.
LOGIC ANALOG PORT/SERVO F-W INCOMPATIBLE	Logic-controlled analog output port feature requires the servo firmware (f-w) revisions: Analog servo f-w rev 0.06 or greater Digital servo f-w re. 2.03 or greater Consult Allen-Bradley customer support services about servo firmware updates.
LOGIC AXIS STATUS CANNOT CHANGE	You attempted to change the status of a logic axis (either to logic axis or to a system axis) when it is not allowed. Examples of when the transition is not allowed are when the axis is jogging, performing jog retract, performing block retrace, etc...
LOGIC INITIATED MOTION POSSIBLE	While in QuickCheck mode it is possible for logic to physically move axes. This includes any motion generated by logic including the logic axis mover, or jogs that can occur in automatic mode such as jog on the fly or manual gap elimination. This message is cleared after the first block is executed in QuickCheck mode.
LOGIC NOT RESPONDING - CNC STOPPING	The logic engine failed to send a logic completed reply to the PC within the allotted amount of time (300 msec).
LOGIC OVERLAP ERROR	During the first or last iteration of a block the control is forced into E-Stop because: • the logic processor did not finish executing the logic in the allotted AMPed time during synchronous mode or • the logic processor did not finish executing the logic in the allotted AMPed time executing a nonmotion block in autosynchronous mode. E-Stop is forced.
LOGIC OVERWRITING G54 → G59.3	Logic is overwriting the current G54 - G59.3 offset through logic offsets.
LOW VOLTAGE ON FLASH STICKS	Call Allen-Bradley Support Services.
LOWER > UPPER	A value entered in the programmable zone table for zone 2 or 3 results in a lower limit value being greater than the upper limit. The upper limit must always be greater than the lower limit.

Message	Description
M	
M02 OR M30 FOUND - REQUEST TERMINATED	This error occurs if an M02 or M30 is found before the requested block while searching during a mid-program start. The search will be terminated at the M02/M30 block.
MACHINE HOME REQUIRED OR G28	An attempt was made to program an axis move before the axes were homed. Axes can be homed manually or by programming a G28 block.
MASTER HAS TO BE AMPED FIRST	The dual master axis has to be configured first in the AMP data base.
MASTER ONLY G-CODE - MUST PARK SLAVES	An attempt was made to program a G-code that is not compatible with a dual axes. The programmed G-code can only be applied to the AMP defined master axis of the dual axis group. All other axes in the dual axis group must be parked.
MATH OVERFLOW	Your paramacro or calculator function is requiring a calculation with an excessively large or illegal value.
MAX SIZE EXCEEDED	The programmed number of symbols is too large (the communication data packet is too large).
MAX SOLID TAP RPM EXCEEDS MAX GEAR RPM	The resulting solid tapping RPM exceeds the spindles current RPM Maximum for the active gear range. Either change gear ranges, or reduce the tapping speed.
MAXIMUM BLOCK NUMBER REACHED	A renumber operation was performed to renumber block sequence numbers (N-words), and the control has exceeded a block number of N99999. Either the program is too large to renumber, or the parameters for the first sequence number, or the sequence number increment, are too large. When this error occurs, the renumber operation stops renumbering at the last block within the legal range of N-words.
MAXIMUM NUMBER OF AXES EXCEEDED	If the COCOM breakout is true, a maximum of 4 concurrent interpolated axes can be used.
MAXIMUM NUMBER OF PROGRAMS	The RAM disk directory for part program storage is full. You can store only 328 files on the system even when memory is available for part program storage.
MAXIMUM RETRACE COUNT REACHED	The limit (defined in AMP) for the amount of retrace blocks allowed was reached. No further retracing will be allowed.
MAXIMUM REVERSE PLANES EXCEEDED	The order that the axes are named in AMP is important. If, for example, axis one's name is assigned as X and axis three's name is assigned as Z, a reverse plane is defined if the G18 plane is assigned in AMP as the ZX plane. The G18 plane defines a plane consisting of axis 3 followed by axis 1, making it a reverse plane (axis 1 followed by axis 3 would be a normal plane since 1 is configured before 3 from the standpoint of ODS). This also pertains to parallel axes. A maximum of four reverse planes is allowed. If your system exceeds this number of reverse planes, you must re-configure your AMP.
MAXIMUM RPM LIMIT AUXILIARY SPINDLE 2	A request was made for the aux spindle 2 speed to exceed the AMPed maximum value. Reduce the programmed aux spindle 2 speed, or use the spindle speed override switch to reduce the RPM.
MAXIMUM RPM LIMIT AUXILIARY SPINDLE 3	A request was made for the aux spindle 3 speed to exceed the AMPed maximum value. Reduce the programmed aux spindle 3 speed, or use the spindle speed override switch to reduce the RPM.
MAXIMUM RPM LIMIT FIRST SPINDLE	A request was made for the spindle 1 speed to exceed the AMPed maximum value. Reduce the programmed spindle 1 speed, or use the spindle speed override switch to reduce the RPM.
MAXIMUM RPM LIMIT PRIMARY SPINDLE	A request was made for the primary spindle speed to exceed the AMPed maximum value. Reduce the programmed primary spindle speed, or use the spindle speed override switch to reduce the RPM.
MAXIMUM RPM LIMIT SECOND SPINDLE	A request was made for the spindle 2 speed to exceed the AMPed maximum value. Reduce the programmed spindle 2 speed, or use the spindle speed override switch to reduce the RPM.
MAXIMUM RPM LIMIT THIRD SPINDLE	A request was made for the spindle 3 speed to exceed the AMPed maximum value. Reduce the programmed spindle 3 speed, or use the spindle speed override switch to reduce the RPM.
MESSAGE PENDING, PRESS A KEY TO DISPLAY	The 9/Series screen saver is engaged and a system error message, logic error message, E-Stop condition, or PAL display page was activated. Press any key on the keyboard to disable the screen saver and view the error or PAL display page.
MDI INPUT COMMAND TOO LONG	The MDI input command string exceeds the maximum length allowed.
MDI NOT ALLOWED DURING INTERRUPT MACRO	An attempt was made to halt the execution of an interrupt program and execute a MDI command. MDI commands cannot be executed during the execution of an interrupt program.

Message	Description
MDI NOT ALLOWED DURING POCKET MILLING	An MDI command cannot be programmed while a G88 or G89 pocket milling cycle is executing.
MDI NOT ALLOWED DURING RETRACE	You cannot use MDI while a retrace operation is in progress.
MEASUREMENT POINT OVERFLOW	The user tried to enter more points into online AMP for axis calibration than are permitted.
MEMORY CRASH - REFORMAT	A major error has occurred within the system RAM memory. All part programs stored in memory will have to be deleted by performing a reformat operation. This will not remove the current versions of AMP or PAL from the system.
MEMORY FULL	There is no more RAM memory space for part program storage. If you are in the process of editing a part program, your changes cannot be saved.
MIDSTART NOT ALLOWED FROM TAPE	You cannot perform a mid-program start on a program that is stored on tape. The program must first be transferred to RAM memory.
MINIMUM RPM LIMIT AUXILIARY SPINDLE 2	The commanded aux spindle 2 speed requested by the control is less than the AMPed minimum aux spindle 2 speed for the current gear being used. This requires a gear change operation or a change in the programmed aux spindle 2 speed. In some cases, the <SPINDLE SPEED OVERRIDE> switch may be sufficient.
MINIMUM RPM LIMIT AUXILIARY SPINDLE 3	The commanded aux spindle 3 speed requested by the control is less than the AMPed minimum aux spindle 3 speed for the current gear being used. This requires a gear change operation or a change in the programmed aux spindle 3 speed. In some cases, the <SPINDLE SPEED OVERRIDE> switch may be sufficient.
MINIMUM RPM LIMIT FIRST SPINDLE	The commanded spindle 1 speed requested by the control is less than the AMPed minimum spindle 1 speed for the current gear being used. This requires a gear change operation or a change in the programmed spindle 1 speed. In some cases, the <SPINDLE SPEED OVERRIDE> switch may be sufficient.
MINIMUM RPM LIMIT PRIMARY SPINDLE	The commanded primary spindle speed requested by the control is less than the AMPed minimum primary spindle speed for the current gear being used. This requires a gear change operation or a change in the programmed primary spindle speed. In some cases, the <SPINDLE SPEED OVERRIDE> switch may be sufficient.
MINIMUM RPM LIMIT SECOND SPINDLE	The commanded spindle 2 speed requested by the control is less than the AMPed minimum spindle 2 speed for the current gear being used. This requires a gear change operation or a change in the programmed spindle 2 speed. In some cases, the <SPINDLE SPEED OVERRIDE> switch may be sufficient.
MINIMUM RPM LIMIT THIRD SPINDLE	The commanded spindle 3 speed requested by the control is less than the AMPed minimum spindle 3 speed for the current gear being used. This requires a gear change operation or a change in the programmed spindle 3 speed. In some cases, the <SPINDLE SPEED OVERRIDE> switch may be sufficient.
MIRROR NOT ALLOWED ON ROLLOVER AXIS	You cannot perform mirrored motion using an axis with rollover.
MISMATCHED SERCOS/1394 DRIVE REVISIONS	The 9/PC SERCOS master is incompatible with the 1394 SERCOS slave. You must either update your 9/PC software or your 1394 software. For assistance with this problem, contact your local Rockwell Automation support person.
MISSING 1394 I/O RING ADDR	This message indicates that a 1394 amplifier ID has been AMPed but not defined in I/O ring assignment from ODS. The 1394 amplifier must be a defined device on the 9/Series fiber optic I/O ring.
MISSING ([) AFTER FUNCTION NAME	Paramacro and calculator functions must have their values enclosed in [], for example, SIN[5].
MISSING (])	Paramacro and calculator functions must have their values enclosed in [], for example, SIN[5]. The control has found that a right bracket "]" is missing in the current operation.
MISSING (END) COMMAND	The control has found an end-of-program block (M02 or M30) before it has read the END command for a paramacro DO loop.
MISSING (F) IN INVERSE TIME	An F-word must be programmed in every motion block that is not rapid when in inverse time feed mode (G93). F is not modal in G93.
MISSING (GOTO) COMMAND	An IF paramacro condition does not have a GOTO with a sequence number following the condition.
MISSING A (DO) COMMAND	A WHILE paramacro condition does not have a DO with a loop identifier following the condition.

Message	Description
MISSING ADAPTIVE FEED DATA	An attempt was made to create a transfer line part program from the quick view screen with incomplete adaptive feedrate data.
MISSING COMMA	An error occurred in G05 DH+ communications block.
MISSING COMMA OR RIGHT PARENTHESIS	An error occurred in G05 DH+ communications block.
MISSING CUTTER COMP CODE	Cutter compensation must be activated before initiating a G89 irregular pocket cycle.
MISSING DATA FROM BLOCK	G89 irregular pocket cycle parameters are missing from a the G89 programming block.
MISSING END PARENTHESIS	An error occurred in G05 DH+ communications block.
MISSING G67	An active modal macro (G66 or G66.1) was not canceled by a G67 before the control read an M02 or M30 end-of-program command.
MISSING HPG FROM I/O RING	The I/O assignment file that was compiled and downloaded with PAL defines an HPG that is not physically present in the I/O ring. Verify that the HPG address settings are correct.
MISSING I/O RING DEVICE	The I/O assignment file that was compiled and downloaded with PAL defines an I/O ring device that is not physically present in the I/O ring. Verify that all device address settings are correct.
MISSING INTEGRAND/RADIUS WORD	A circular or helical block has been programmed with axis data and no radius (R) or integrand (I, J, or K) values. A radius or integrand must be programmed in a circular or helical block to define the location of the arc center.
MISSING KEYBOARD AND HPG FROM I/O RING	The I/O assignment file that was compiled and downloaded with PAL defines a keyboard and an HPG that is not physically present in the I/O ring. Also verify that the keyboard and HPG address settings are correct.
MISSING KEYBOARD FROM I/O RING	The I/O assignment file that was compiled and downloaded with PAL defines a keyboard that is not physically present in the I/O ring. Verify that the keyboard address settings are correct.
MISSING L-WORD	The L-word parameter is missing from the G88.5 or G88.6 hemispherical pocket programming block.
MISSING M02 OR M30	The control has executed through to the last block of a program and has not read an end-of-program command (M02 or M30).
MISSING MASTER AXIS NAME	Slave axes that do not have a master have been configured for a dual group.
MISSING OR ILLEGAL L-VALUE	An attempt was made to program an irregular pocket milling cycle (G89) with a missing or illegal L-word.
MISSING PROGRAM NAME	An operation, such as a copy or rename, was performed without the proper program names being specified. The proper format consists of the program performing the operation followed by a comma and the target program (OLD PROGRAM NAME,NEW PROGRAM NAME).
MISSING PROGRAM NUMBER (P)	No sub-program name was specified in a block that calls a sub-program or paramacro. A subprogram name must be programmed with a P-word in the calling block.
MISSING PROMPT DATA	The control is waiting for data to be entered on the input line (line 2 of the CRT) using the keys on the operator panel.
MISSING Q-WORD	The Q-word parameter is missing from the G88 or G89 programming block.
MISSING QPP ANGLE WORD	The second block of a two block QPP set does not contain the necessary angle word to define an intersection with the first block.
MISSING ROUGHING CYCLE (P/Q) WORD	A roughing cycle block was programmed that does not contain both a starting and ending sequence number for the contour blocks as programmed with the P- and Q-words.
MISSING ROUGHING CYCLE DEPTH (D) WORD	A roughing cycle block was programmed that does not contain the D parameter for depth of cut.
MISSING SHADOW RAM	Either your 9/290 control is missing the SIMMS necessary for shadow RAM, or your 9/260 control is not equipped with enough RAM to operate properly. If your 9/260 system contains both the DH+ module and the search monitor utility, additional RAM must be installed. All 9/290 controls must have this additional RAM. Refer to your <i>9/Series Installation and Integration Manual</i> for details on installing SIMMS.
MISSING SLAVE INCREMENTAL AXIS NAME	When using dual axes on Lathe A, all slave axes must have incremental axis names.
MISSING START PARENTHESIS	An error occurred in G05 DH+ communications blocks.
MISSING TOOL ENTRY	This is missing a tool entry.

Message	Description
MODULE(S) WITH INCONSISTENT REVISION LEVEL	Retry the update utility. If this does not work, call Allen-Bradley and request a new update utility that matches your hardware revision level.
MODULE(S) WITH INVALID CHECKSUM	Retry update.
MOTION IN DWELL BLOCK	An attempt was made to program axis motion in the same block that generates a dwell. No axis words can be programmed in a block that generates a dwell.
MOTION NOT ALLOWED	The block includes G-codes that must be programmed in a block without axis motion. For example, the G-codes that convert from inch to metric or metric to inch cannot have axis motion in the same block.
MOTOR SHAFT - LEAD SCREW RATIO TOO HIGH	The motor shaft to lead screw gear ratio is too high to achieve the rapid speed assigned in AMP.
MULTIPLE FUNCTIONS NOT ALLOWED	Multiple functions are not allowed.
MULTIPLE SPINDLE CONFIGURATION ERROR	Each multiple spindle must have a servo board identified in AMP to indicate to which board the spindle is connected. The spindle must be included in the number-of-motors AMP parameter for the board the spindle is on.
MUST ASSIGN TOOL NUMBER FIRST	In random tool, an attempt was made to customize a tool before the tool number was assigned.
MUST BE IN (AUTO)	It is necessary to place the control in auto mode to perform the requested operation.
MUST BE IN (AUTO) OR (MDI)	It is necessary to place the control in Auto or MDI mode to perform the requested operation.
MUST BE IN (CYCLE STOP)	It is necessary to place the control in cycle stop state to perform the requested operation. The control cannot be in cycle suspend, feed hold, or E-Stop.
MUST BE IN (CYCLE STOP) AND (EOB)	The control must be in cycle stop state and at the end-of-program block to perform the requested operation. The control cannot be executing a program, in cycle suspend, feed hold, or E-Stop.
MUST BE IN (E-STOP)	An attempt was made to perform an operation (such as, editing the reversal error parameters in online AMP) that must be performed in E-Stop. Place the control in E-Stop by pressing the <E-STOP> button.
MUST BE IN (LINEAR MODE)	An attempt was made to perform an operation (such as, exiting from cutter compensation) that must be performed in a linear block (G00 or G01).
MUST BE IN (MANUAL)	It is necessary to place the control in manual mode to perform the requested operation.
MUST BE IN (MDI)	It is necessary to place the control in MDI mode to perform the requested operation.
MUST BE IN E-STOP OR CYCLE STOPPED	It is necessary to place the control in E-Stop or cycle stop state to perform the requested operation. Place the control in E-Stop by pressing the <E-STOP> button. Place the control in cycle stop state by pressing the <SINGLE BLOCK> button. Simply pressing <CYCLE STOP> will not guarantee the control to be in cycle stop mode. Most likely a cycle stop request while executing a program will place the control in cycle suspend mode. If you get this error using the CALC function it indicates you may be asking the calculator function to access a paramacro variable (using the # sign) when a program is executing. You can not use a paramacro variable # sign in a calculator function when any part program is executing or suspended.
MUST BE IN MANUAL MODE TO HOME	To do a jog home operation (from jog retract) the control must be in manual mode.
MUST COMPLETE ACTIVE HOME OPERATION	An attempt was made to jog a dual group when one of the axes of the dual was homing.
MUST DISABLE RUN-TIME GRAPHICS	An attempt was made to call up one of the QuickView prompting options while the active graphics option was currently executing. Active graphics must be disabled before QuickView prompting can be performed.
MUST HOME ANGLE SOURCE AXIS FIRST	Before you can enter angled wheel grinding mode both the axial and wheel axes must be homed.
MUST HOME AXIS	An attempt was made to perform axis calibration before the axes were homed. Axes can be homed manually or by programming a G28 block.
MUST SETUP THE ENCRYPTION ARRAY	An attempt was made to encrypt a part program while uploading it to ODS or the mini-DNC package. The encryption array must be set up before you can encrypt a part program.
MUST START WITH \$, %, !, #, +, -, LTR, DIGIT	You have used incorrect search string syntax in the PAL search monitor utility.
MUST START WITH \$, %, !, #, OR LETTER	You have used incorrect search string syntax in the PAL search monitor utility.
MUST START WITH \$, %, !, OR LETTER	You have used incorrect search string syntax in the PAL search monitor utility.

Message	Description
MUST START WITH \$, !, OR LETTER	You have used incorrect search string syntax in the PAL search monitor utility.
MUST START WITH A LETTER	You have used incorrect search string syntax in the PAL search monitor utility.
MUST SWITCH PROCESS FOR SCREEN RESTORE	An attempt was made to 'restore screen' while the system was in Digitize, Graphics, Search, or while PAL was selecting a process. Any attempt to switch processes results in this message.
N	
NEED SHADOW RAM FOR ONLINE SEARCH	Your system contains the DH+ module and you have not installed the extra RAM SIMMS that are required to run the PAL online search monitor with the DH+ module installed. You must buy additional RAM for a system equipped with both of these features. Contact your Allen-Bradley Sales representative to purchase these SIMMS. Refer to your <i>9/Series Installation and Integration Manual</i> for details on installing additional SIMMS.
NEED SPINDLE FEEDBACK	You attempted to use the solid-tapping feature with a spindle that does not have feedback.
NEGATIVE DWELL VALUE	An attempt was made to execute a dwell with a negative value. Dwell values must be positive values.
NEGATIVE F-WORD PROGRAMMED	A negative feedrate was programmed in a program block. Negative feedrates are illegal.
NEGATIVE TO UNSIGNED LONG ERROR	Internal math error has occurred; contact Allen-Bradley customer support services.
NEGATIVE VALUE NOT ALLOWED	The minus (-) sign was used for an address which cannot be programmed with a negative value.
NET CORRECTION IS NOT ZERO	For a rotary axis, the net amount of correction for axis calibration should be zero for one complete revolution.
NET PICK/PLUNGE AWAY FROM ENDPOINT	The primary and secondary pick/plunge amounts, when added together, are in the direction away from the programmed endpoint.
NETWORK COMMUNICATION DISABLED	When editing or restoring communications configuration data, this message is displayed.
NETWORK PASSTHRU COMMUNICATIONS FAULT	A communication error has occurred between the control's ethernet module and the ODS passthrough device (typically a PLC).
NEVER OPENED THE PROGRAM	An attempt was made to edit a program that was not currently open.
NEW TOOL OFFSET SETUP BUT NOT ACTIVATED	The tool offsets for the active tool were changed, but not activated in the current block. These new tool offsets will not be activated until the set-up blocks are cleared of the old tool offsets and refilled with the new tool offsets.
NO ACTIVE PROCESS CONFIGURED	The AMP has been loaded into a multi-processing system that has no processes configured as active.
NO ACTIVE PROGRAM	An attempt was made to do a search when no part program is active.
NO AXIS CONFIGURED	The current active version of AMP does not have any axes configured as usable. All axes are configured as unfitted.
NO CHARACTERS ENTERED FOR SYMBOL	You have used incorrect search string syntax in the PAL search monitor utility.
NO DEPTH PROBE TRIP	A G26 block reached its programmed endpoint without the adaptive depth probe being tripped. The part surface was not detected by the adaptive depth probe before the G26 block completed.
NO FEEDRATE PROGRAMMED	A command for axis motion was executed when there was no active feedrate. Applies to non-rapid moves (G01, G02, or G03).
NO FURTHER RETRACE ALLOWED	The control has reached a block during retrace from which no further retrace is permitted.
NO INTERSECTION EXISTS	There is no mathematical intersection for the QPP blocks as programmed.
NO MARKER FOUND ON :	The encoder marker was not detected when homing the indicated axis. Homing was unsuccessful.
NO MORE MDI BLOCKS	Cycle start was requested during MDI mode when there were no MDI blocks present to be executed.
NO MORE MDI BLOCKS TO RESET	A reset was requested during MDI mode when there were no incomplete or unexecuted MDI blocks reset.
NO OFFSET ACTIVE	An offset must be active before the control will allow the offset to be changed. This check is used so that the control will no the method and direction of the offset will be the same as the previous offset.

Message	Description
NO OPTIONAL FB PORT ON ANALOG SERVO	The system was incorrectly AMPed with optional feedback module on an analog servo module.
NO PROGRAM TO RESTART	There is no program to restart. The previous program was either completed or cancelled.
NO RECIPROCATION DISTANCE	A reciprocation interval of zero (0) was programmed for a grinder reciprocation fixed cycle.
NO RECIPROCATION FEEDRATE	The reciprocation feedrate, E-word, required during a grinder reciprocation fixed cycle was not programmed.
NO SPINDLE ASSIGNED TO THIS PROCESS	A process attempted to activate virtual or cylindrical mode and that process has no spindle assigned to it via AMP.
NO STRING INPUT	A program search operation was requested and no string to search for has been entered. Key in the required search string, and press the [TRANSMIT] key to enter a search string.
NO TOOL GROUP PROGRAMMED	A block that loads data into the tool management table does not contain the parameter that determines the tool group number corresponding to the other data in the block. The group number is programmed using the P-word.
NO TOOL NUMBER PROGRAMMED	A block that loads data into the tool management table does not contain the parameter that determines the tool number corresponding to the other data in the block. The tool number is programmed using the T-word.
NO UNEXPIRED TOOL AVAILABLE	A request for a tool group was made, and all of the tools in that tool management group have expired their tool lives. Either reset the tool life for the tools, or install new tooling.
NON_CONSECUTIVE/TOO MANY FITTED AXES	More than the allowable number of axes may have been assigned in AMP or an unfitted axis was assigned between two fitted axes. You can assign only fitted axes consecutively in AMP.
NON-LINEAR AXIS IN PLANE DEFINITION	The current axis plane is illegal because a non-linear axis (rotary) has been assigned to the plane in AMP.
NOT ALIGNED	During the power-up alignment procedure, either the 1326 motor (connected to a 9/440HR) is misaligned or the SINCOS device's memory is corrupt.
NOT ALLOWED IN ANGLED WHEEL MODE	The axes can not be moving when you change to angled wheel mode. Also the axes involved in angled wheel motion must be homed before you can enter angled wheel mode. Other features, such as block retrace or jog retract also must not be active when changing mode.
NOT ALLOWED - G41/G42 ACTIVE	An attempt was made to perform some operation or program some feature that cannot be performed when cutter compensation or TTRC is active (G41 or G42). Cancel compensation by programming a G40 block before performing the operation.
NOT ALLOWED FROM MDI	Certain programming commands are not allowed from MDI (GOTO, WHILE, etc.).
NOT ALLOWED ON DUAL/SLAVE AXIS	A G26 was programmed on a dualed axis. The G26 feature is incompatible with the dual axis feature.
NOT ALLOWED - THREADING ACTIVE	An attempt was made to perform some operation (typically a spindle speed adjustment) that is not allowed when cutting a thread. This includes all forms of threading, including single pass or multiple pass threads.
NOT IN G10L3 MODE	A G11 block was programmed that cancels G10L3 data setting when the control is not in the G10L3 data setting mode. G10L3 is used to set the tool management table data.
NUMBER IS OUT OF RANGE	An attempt was made to perform a calculation using the paramacro features or the calculator features that contains a number longer than 11 characters.
NUMBER OF MOTORS/SPINDLE CONFIG ERROR	This error indicates AMP is incorrectly configured for your system. Typical AMP configuration errors that generate this error include: You have AMPed more motors than the current hardware supports. You have indicated there are servo motors attached to servo boards that don't exist (the 9/230 and 9/440 are configured as if they have only one servo card). You have configured too many spindles (1 on 9/230, 2 on 9/PC, 9/260, and 9/440, 3 on 9/290). Too few axes were configured for the indicated number of motors on the boards or too few servos were configured for indicated number of motors on the boards.
NUMERIC VALUE MISSING	The numeric value associated with the programmed word is missing. There is an AMP parameter that determines whether a missing numeric is assumed to be zero or if it will generate this error.

Message	Description
O	
OBJECT NOT FOUND IN PROGRAM	The object you are searching for in the search monitor utility does not exist in the current module, or does not exist in the program in the direction you are searching.
OCI ETHERNET CARD NOT INSTALLED	An OCI dual-process system has a standard CRT installed. The OCI Ethernet card has not been installed. This may happen if a dual-process OCI executive is loaded into a non-OCI system.
OCI SYSTEM ERROR	VRTX error. Contact Allen Bradley Support.
OCI PROCESSING TASK OVERLAP	The amount of time to process a new OCI request is taking longer than expected. This is an informational warning only. It is not critical to the CNC.
OCI WATCH LIST TASK OVERLAP	This message indicates that the watch list task was not running to completion in the AMPed allotted amount of time. This typically occurs when a large task is requested by an OCI station and the CNC takes longer than expected to complete.
ODS & 9/SERIES REVISIONS DIFFER	The version of AMP or PAL on the peripheral device does not match the control version.
ODS RUNG MONITOR ACTIVE	The online PAL search monitor utility can not be accessed. The online PAL search monitor utility requires the offline ODS PAL search monitor utility to not be running.
OFFSET EXCEEDS MAX CHANGE	You have attempted to modify an offset table by an amount that is larger than the allowable change to an offset table. Refer to your AMP reference manual for details on Maximum wear and geometry offset change.
OFFSET EXCEEDS MAX VALUE	You have attempted to modify an offset table by entering an offset amount that is larger than the allowable maximum offset selected in AMP. Refer to your AMP reference manual for details on Maximum offset table values.
OFFSET MOTION PENDING ON CYCLE START	After changing the active offset this message identifies that the control will move the axis to the new offset location the next time cycle start is pressed (this may or may not occur on a non-motion block depending on the AMP offset configuration).
OFFSET TABLE(S) CORRUPT/CLEARED	A bad offset table checksum value was detected by the control during PTO.
ONLY ONE DEPTH PROBE PER SERVO BOARD	The 1394 servo card firmware only supports one adaptive depth probe on each servo card. If your system requires more than one adaptive depth probe they must be attached to different servo cards (9/230 and 9/440 controls can only have one adaptive depth probe). AMP must be configured to indicate which port the adaptive depth probe is attached to.
ONLY ONE M19 ALLOWED PER BLOCK	For system configured with multiple spindles, only one spindle orient M-code (M19) is allowed per block.
ONLY REQUEST THE DUAL MASTER FOR JOGS	An attempt was made to jog a slave axis; you can jog a slave axis only when the master axis is parked.
OPTION NOT INSTALLED	An attempt was made to program an optional feature that has not been purchased from Allen-Bradley.
OPTION NOT INSTALLED (PAL DISPLAY PAGE)	The PAL display page option is not installed on your control.
OPTIONAL FEATURE IS NOT PROVIDED	An attempt was made to program an optional feature that has not been purchased from Allen-Bradley.
OPTIONAL RAM SIMM BAD/MISSING	The control has discovered the RAM SIMMs for the extended storage option are either damaged or missing. The RAM SIMMs must be installed or replaced. Contact your Allen Bradley sales representative for assistance.
OTHER PROCESS G CODE CONFLICT	On a dual processing system, one process has a conflicting G code active when you attempted to activate a G26 depth probe cycle. For example, process one executes a G26 while process two has an axis in feed to hard stop which is on the same servo card as the depth probe.
OVER SPEED	A servo motor is turning at an RPM that is greater than the maximum RPM allowed for that servo as defined in AMP by the system installer. For digital spindles this error can result from maximum RPM gear range 1 being set higher than your AMPed allowed Maximum Motor Speed.
OVER SPEED IN POCKET CYCLE	The programmed feedrate for an irregular pocket cycle (G89) was too high for the cycle to keep up. The part program stops at the endpoint of the block in which the error occurred. The cycle must be executed with a lower feedrate.

Message	Description
OVERTRAVEL (+)	The indicated axis has reached the positive software overtravel limit during an axis jog. This message can appear prior to reaching the overtravel limit in certain instances. For example, if a single pulse from the handwheel will result in a large incremental move beyond the overtravel limit, this error message will appear before the axis moves up to the limit.
OVERTRAVEL (-)	The indicated axis has reached the negative software overtravel limit during an axis jog. See OVERTRAVEL (+) for details.
P	
P VALUE OUT OF RANGE	An attempt was made to call a macro or sub-program using a program number, following the P-word, that is out of the valid range. Valid range for a P-word is 1 to 99999.
PAL & 9/SERIES REVISIONS DIFFER	Either the overall revision number of PAL does not match the software revision on the control, or the revision number of system symbols in PAL and the revision number of those on the control do not match.
PAL ANALOG PORT ILLEGAL CONFIGURATION	This is a power turn-on error that occurs when an AMP configuration error exists in the PAL analog port configuration.
PAL ANALOG PORT/SERVO F-W INCOMPATIBLE	PAL-controlled analog output port feature requires the servo firmware (f-w) revisions: Analog servo f-w rev 0.06 or greater Digital servo f-w re. 2.03 or greater Consult Allen-Bradley customer support services about servo firmware updates.
PAL AXIS STATUS CANNOT CHANGE	You attempted to change the status of a PAL axis (either to PAL axis or to a system axis) when it is not allowed. Examples of when the transition is not allowed are when the axis is jogging, performing jog retract, performing block retrace, etc...
PAL BACKGROUND TOOK TOO LONG	Background PAL was not completed in the time allocated to it in AMP. Background PAL will continue on to completion before restarting. If and when background PAL does complete in the allocated time, this message will disappear. If this message appears continuously, the PAL program should be rewritten, or else the AMP defined background PAL execution time should be increased. Refer to the AMP and PAL reference manuals for more details.
PAL DIVIDE BY ZERO ERROR	The PAL program tried to divide a value by zero. Check the PAL program for errors.
PAL DOES NOT EXIST	There is no PAL program in the system, either on EPROM or in RAM memory. EPROMs must be installed, or else PAL must be downloaded to RAM from ODS.
PAL INITIATED MOTION POSSIBLE	While in QuickCheck mode it is possible for PAL to physically move axes. This includes any motion generated by PAL including the PAL axis mover, or jogs that can occur in automatic mode such as jog on the fly or manual gap elimination. This message is cleared after the first block is executed in QuickCheck mode.
PAL OVERWRITING G54 → G59.3	PAL is overwriting the current G54 - G59.3 offset through PAL offsets.
PAL PAGE WAITING - EXIT DISPLAY SELECT	A PAL display page is being overwritten by the current screen. Pressing the {DISPLY SELECT} softkey will display the display page.
PAL PAGE WAITING - EXIT MONITOR	A PAL display page is being overwritten by the current screen. Exit the search monitor utility to see the screen PAL is attempting to display.
PAL PAGE WAITING - SCREEN HAS PROMPT	A PAL display page is being overwritten by the current screen.
PAL PROM CHECKSUM ERROR	Checksum error in the PAL PROM memory. This indicates PAL has been loaded successfully however it has failed to pass verification. Check if your flash sticks are installed properly and are not damaged. Attempt to download a copy of the same PAL image from another project.
PAL SOURCE NOT DOWNLOADED TO CNC	The PAL search monitor utility can not be accessed. The PAL search monitor utility requires the PAL source code be downloaded with the built PAL program.
PAL SOURCE NOT LOADED	The copy of PAL in flash does not contain source programs.
PAL SOURCE REV. MISMATCH - CAN'T MONITOR	PAL source code in the control does not match the revision of the CNC executive. The PAL code may execute if all of the PAL system flags exist but the monitor cannot be used.
PAL USING MEMORY - REFORMAT	The AMP parameter allowing PAL to be stored in RAM memory has been enabled. This changes the amount of RAM memory available for part program storage, requiring the RAM disk to be reformatted. Part programs should have been backed up prior to this.
PARAMETER ASSIGNMENT SYNTAX ERROR	A block that assigns Paramacro parameters has been entered incorrectly.

Message	Description
PARAMETER NUMBER NOT FOUND	The AMP parameter number being searched for through the control's patch AMP utility does not exist in the system.
PARAMETER VALUE OUT OF RANGE	The value entered for the selected AMP parameter or paramacro parameter is less than or greater than the allowed legal value.
PARENTHESIS INPUT ERROR	Parentheses have been entered incorrectly in a program block or calculation operation. Correct the use of the parenthesis; verify they are in matched pairs.
PARITY ERROR IN PROGRAM	A serial communications error occurred. A data parity error occurred while sending or receiving data. This can result in a corrupted file, or the entire data transfer operation may be aborted by the control.
PARK AXIS MOTION NOT ALLOWED	Axis motion was programmed for a parked axis in a dual axis group. When both master and slave axes are parked, no axis motion is allowed on a parked axis in a dual group.
PART PROGRAM NOT SELECTED	An attempt was made to execute a program or check a program before a program was selected for execution.
PART ROTATION FORMAT ERROR	In part rotation blocks (G68, G69), only plane changes and mode changes including inch/metric and absolute/incremental are permitted. Any commands other than normal motion commands and the motion G-codes (G00, G01, G02, and G03) are not permitted.
PASSWORD PROTECTED	When assigning password protectable features to an access level, an attempt was made to assign a feature to a different access level when the currently active password does not have access to the feature. You can assign features to other access levels only when you have access to that feature yourself.
PC COMMUNICATION LOST - CNC STOPPING	No communications between the CNC module and the PC occurred because the "heartbeat" signal was not established between the PC and the CNC module within the allotted time.
PEAK CURRENT NOT 300%	The axis for a 1394 or 9/440 is not AMPed to have the PEAK CURRENT set to 300%. This misconfiguration forces the control into E-Stop.
PERIPHERAL DEVICE ERROR	An illegal communication attempt was made with a peripheral device, for example, attempting to output to a tape reader or input from a tape punch.
PLANE SELECT ERROR	An attempt was made to change planes during cutter compensation (TTRC), between QPP blocks, or between chamfer and corner rounding blocks. This error also will occur if G17 or G19 planes are selected on a lathe.
PLEASE WAIT FOR CLEARING OF PAL MEMORY	PAL is being erased in preparation for a PAL download.
PLUNGE MOTION NOT ALLOWED	The final plunge position must be different from the start point of the cycle. This message can occur if the plunge axis is not programmed in the entry block to G89 mode, or if the plunge axis increment is zero, or if the final plunge axis position is the same as the start point of the cycle block during G89 mode.
PLUNGE MOTION NOT PROGRAMMED	In your pocket cycle you have either not programmed a final depth, or the final depth you have programmed is equal to the depth of the cutting tool at the starting point of the cycle. The location of the cutting tool when the pocket cycle is programmed must be at a different depth than the final programmed depth of the cycle.
PLUNGE NOT ALLOWED	A plunge that will cut into the pocket wall was requested in a G89 irregular pocket cycle.
PLUNGE STEPS MIS-PROGRAMMED	The rough, medium, and fine-feed depths in the cycle block are not programmed correctly. This is possible if the data in the block is incorrect or if the data in the modal values of the parameter not programmed in the block are incorrect.
POCKET END NOT SAME AS START	A pocket end-point that is not the same as the pocket start-point was programmed in a G89 irregular pocket cycle.
POCKET IS PART OF CUSTOM TOOL	An attempt was made to assign a tool to a tool pocket that is already used by a custom tool. Custom tools are assigned to tool pockets that are shown with an XXXX next to the pocket number on the random tool table.
POCKET MILLING SHAPE IS INVALID	A parameter is missing in the G88 programming block.
POINT ALREADY EXISTS	The point that you are trying to enter is already in the axis calibration table.
PORT B IS BUSY	This message appears when you press {SYSTEM SUPORT}, {MONITOR}, or {SERIAL I/O} and port B is busy.

Message	Description
PORT IS BUSY - REQUEST DENIED	An attempt was made to output or input information to or from a serial communications port that is already being used by some other device or is selected as the port that an active program is coming from.
PREVIOUS ABORT COMMAND NOT COMPLETE	This message is displayed when the communications "abort" key is entered before the last abort requested has completed.
PROBE/CONTROLLING AXIS CARD DIFFERENT	Both the adaptive depth probe and the adaptive depth probe controlling axis (typically the axis that positions the probe) must be attached to the same servo card. You must re-AMP your system and rearrange your servo wiring so that the adaptive depth probe and its corresponding servo are on the same servo card.
PROBE CYCLES CALCULATION ERROR	The servo module was unable to compute the probe position when the probe is fired. Make sure that all measurement points are within the programmed range entered for the probe cycle. Lower the feedrate during the probing operation and try again.
PROBE CYCLES PROGRAMMING ERROR	Either not enough or too many axes are programmed in a probing cycle block.
PROBE ERROR	A probing cycle has reached the outer limits of the tolerance band without firing the probe, or the probe has fired before entering the tolerance band.
PROBE IN USE BY OTHER PROCESS	On a dual processing control only one probing function is allowed at any one time. Probing can not be performed by both processes simultaneously. You must wait for probing to complete in one process before probing in the other process.
PROBE IS ARMED, CAN'T ADJUST SERVOS	With the probe armed through a probing operation, until the probe fires or the probe is disarmed, other online AMP servo parameters like torque, feedforward percentage, gain, etc., are not allowed to be changed.
PROBE TRIP DURING DECEL	An adaptive depth probe trip occurred after the program block reached endpoint. The trip was made while the control was waiting for the following error to collapse after interpolation is complete. Avoid this error by reducing axis speed (thus reducing following error) or by moving the adaptive depth block endpoint further into the part.
PROCESS SWITCH NOT CURRENTLY ALLOWED	On a dual-processing system, you cannot switch processes while in graphics or in digitize.
PROGRAM ACTIVE	An attempt has been made to delete or perform some other operation to a program that was activated for automatic execution. The program must be deactivated using the {CANCEL PROGRAM} softkey.
PROGRAM ACTIVE IN ANOTHER PROCESS	This dual lathe error appears when one process attempts to open a file for edit, deletion, etc., while that file is active in another process.
PROGRAM BEING EDITED	An attempt has been made to copy, verify, or perform some other operation on a program that is still in the edit mode. It is necessary to press the {EXIT EDITOR} softkey from the edit menu to properly end an editing operation.
PROGRAM BLOCK TOO LONG	More than 128 characters were entered into a single block.
PROGRAM CURRENTLY IN USE	A subprogram or paramacro program was called that is currently being used to perform some other operation (such as editing or copying). Typically, this message is the result of attempting to edit a program that was not properly closed. A program remains in the edit mode until the {EXIT EDITOR} softkey is pressed from the program edit menu.
PROGRAM NAME TOO LONG	An attempt was made to create a program with a program name longer than 8 alphanumeric characters. If a large, descriptive program name is desired, a comment may be added to the right of the program name using the {PROGRAM COMMENT} feature.
PROGRAM NOT FOUND	The program cannot be located in memory. Check to make sure the program name was correctly entered.
PROGRAM OPEN FOR EDIT IN ANOTHER PROCESS	On a dual-processing system, you cannot edit a program that is active in another process. You will need to switch processes if you want to edit the other program.
PROGRAM REWIND ERROR	An attempt to rewind the tape was not successful. Check to be sure that the tape reader is functioning properly and the tape is on the drive sprockets.
PROGRAM SHOULD START HERE	When performing a {MID ST PROGRAM} operation to restart a program, the control has found the block that the program execution should begin at, and selected that block as the next block to be executed. That block is the block immediately following the one containing an @.
PROGRAMMED AXIS IS OFF OR DETACHED	Part program blocks are attempting to program motions on an axis that has its servos either off or configured as detached in AMP.

Message	Description
PROGRAMMED G26 DEPTH < TRIGGER TOLERANCE	A G26 block is programmed with an integrand less than or equal to the AMPed Adaptive Depth Trigger Tolerance amount. A block decode error is given and the block will not execute until the integrand in the block is made larger or AMP is modified to reduce the trigger tolerance.
PROGRAMMED SPINDLE UNAVAILABLE	The programmer attempted to program the follower spindle independently (M03, M04, M05, or M19) while spindle synchronization was active.
PROGRAMS ARE DIFFERENT	A program verify operation has determined that the two selected programs are not identical.
PROGRAMS ARE IDENTICAL	A program verify operation has determined that the two selected programs are identical matches.
PROGRMABLE ZONE 2 VIOLATION	An attempt was made to move the indicated axis into the area defined by programmable zone 2.
PROGRMABLE ZONE 3 VIOLATION	An attempt was made to move the indicated axis into (or out of) the area defined by programmable zone 3.
PROGRMD G26 DEPTH < TRIGGER TOLERANCE	The programmed adaptive depth deflection (hole depth) is less than the probe tolerance value. You must either increase the programmed block depth, or decrease the AMPed probe tolerance value.
Q	
QPP ANGLE WORD SAME AS AXIS NAME	AMP downloaded an angle word for QuickPath Plus that is the same as an axis name. AMP must be reconfigured; the angle word cannot be the same as an axis name.
QPP ANGLE WRD SAME AS SECONDARY AUX. WRD	AMP downloaded an angle word for QuickPath Plus that is the same as the secondary auxiliary word. AMP must be reconfigured; the angle word cannot be the same as the secondary auxiliary word.
QPP BLOCK FORMAT ERROR	Data is incorrectly entered or insufficient data is entered for the control to correctly execute a QuickPath Plus block or pair of QuickPath Plus blocks.
QPP MDI BLOCK LOOKAHEAD ERROR	Only one of two necessary blocks was programmed in MDI using QuickPath Plus commands that require two blocks for proper execution.
QPP NOT ALLOWED DURING POLAR MODE	With polar coordinate programming active, you cannot use QPP.
R	
R WORD FORMAT FINER THAN	The word format programmed is requesting a finer resolution than the axis word format for the corresponding axis allows. These word formats are set in AMP.
RAMP/JERK OUT OF RANGE	There was an attempt to set an acceleration limit in a G48.n block that is outside the valid range. Check AMP for the allowable programmed range for the acceleration limit.
RAPID SPEED TOO HIGH FOR AMPED CONFIG	AMP configuration error. The axis resolutions and feedback device resolutions will not permit the rapid and maximum feedrates assigned in AMP.
RADIUS TOO SMALL	An arc (or helix) was programmed (G02 or G03) that defines a radius that is too small to connect the start-point of the arc to the end-point. The value of R is too small.
RAPID TOO HIGH FOR AMPED CONFIG	AMP configuration error. The axis and feedback device resolutions will not permit the rapid feedrates assigned in AMP.
RAPID TRAVERSE ERROR :	An attempt was made to jog an axis using rapid traverse when it is not permitted. Typically, to use the TRVRS function while jogging, the control must be in manual mode; continuous jog must be selected; and, if the axis being jogged has an overtravel value, that axis must first have been homed.
READ ERROR	An attempt to read a program from a tape or disk drive has failed.
RECIP AXIS IN WRONG PLANE	The reciprocation axis specified in a G81 or a G81.1 programming block is not in the currently selected plane.
RECIP AXIS NOT PROGRAMMED	No reciprocation axis was specified in a G81 or a G81.1 programming block.
RECIPROCATION NOT STOPPED	An attempt was made to deactivate the current part program while reciprocation is still active. You must deactivate reciprocation before deactivating the current part program.
REMOTE I/O COMMON RAM FAULT ON RESET	The RIO module tests the common RAM after reset and detects an error. The Interboard Communications Fault LED is turned ON.
REMOTE I/O CTC CHIP TEST FAULT	The RIO module tests the CTC chip after reset and detects a fault. The Processor Fault LED is turned ON.

Message	Description
REMOTE I/O DENIED COMMON ACCESS ON RESET	The RIO module was denied access to CRAM for more than 1 second after reset. The Interboard Communications Fault LED is turned ON.
REMOTE I/O EPROM INTEGRITY FAULT	The checksum test over the RIO program area in the EPROM chip found a fault. The Processor Fault LED is turned ON.
REMOTE I/O INCORRECT USER BT DATA AMOUNT	The RIO module attempted to read a block of data from one of the user output block transfer data buffers in common RAM and found the word count of the data to be outside of the range of 1 to 64. The Interboard Communications Fault LED is turned ON.
REMOTE I/O INITIALIZATION ERROR	Remote I/O hardware or network has failed to initialize. Cycle power to try to restart or check remote I/O hardware (9/290 only).
REMOTE I/O INTERNAL RAM FAULT	The RIO module tests its internal RAM chip after reset and during operation. A fault has been detected. The Processor Fault LED is turned ON.
REMOTE I/O INTERRUPT HARDWARE FAULT	The RIO module detects that its CPU was not interrupted by any expected external interrupts. This condition indicates a problem in recognizing interrupts. The Processor Fault LED is turned ON.
REMOTE I/O INVALID RACK ADDRESS SET UP	The RIO module's rack address is illegal. This fault is the result of the user setting the rack address, via the dip switches, to an invalid rack size and/or starting module group number.
REMOTE I/O INVALID USER BT DATA CHECKSUM	The 16-bit 2's complement checksum calculated by the RIO module using data from a user output block transfer data buffer does not match the checksum placed in the buffer by the user device. The Interboard Communications Fault LED is turned ON.
REMOTE I/O INVALID USER DATA CHECKSUM	The 16-bit 2's complement checksum calculated by the RIO module using data from the user output data table in common RAM does not match the checksum placed by the user in the user output data table in common RAM. The Interboard Communications Fault LED is turned ON.
REMOTE I/O MISSING USER OPERATIONAL CODE	The RIO module did not detect the user operational code after reset. This fault is displayed when the RIO module does not detect the user operational code in the user status register in common RAM within 100ms after the RIO module has set its operational code and released control of common RAM back to the user device. The Interboard Communications Fault LED is turned ON.
REMOTE I/O RIO DENIED COMMON RAM ACCESS	The RIO module was denied access to CRAM for longer than the specified interval. The RIO module failed to gain access to common RAM after attempting for the Accessing Time-out time period. The time-out is due to either the user device maintaining access for more than the Accessing Time-out interval. or to a hardware failure. The Interboard Communications Fault LED is turned ON.
REMOTE I/O SERIAL COMMUNICATIONS FAULT	The RIO module cannot communicate with the PLC processor. Either the PLC processor's power is OFF, the blue hose is not connected, or the PLC processor is in Edit mode.
REMOTE I/O SIO CHIP TEST FAULT	The RIO module tests the SIO chip after reset and detects a fault. The processor fault LED is turned ON.
REMOTE I/O UNABLE TO FIND BT DATA BUFFER	The RIO module was unable to detect the user block transfer data buffer. The interboard communications fault LED is turned ON.
REMOTE I/O UNRECOVERABLE ERROR	Remote I/O hardware or network has catastrophic failure. Cycle power to try to restart or check remote I/O hardware (9/920 only).
REMOTE I/O USER FAULT OCCURRED	The RIO module detected that the user fault bit was set. The interboard communications fault LED is flashing.
REMOTE I/O WATCHDOG TIMEOUT	The watchdog mechanism on the RIO module timed out, indicating that the RIO module has not operated in an expected manner for possibly 17ms. The processor fault LED is turned ON.
REMOTE IO INTERPROCESSOR HANDSHAKE FAULT	The RIO module failed to detect the complement of the user-handshake word, in the complement user-handshake word in common RAM, within the handshake interval. The user device has not shook hands with the RIO module. The interboard communications fault LED is flashing.
REPLACE ABSOLUTE FB BATTERY	The battery that attaches to the servo module and supplies power for the absolute encoders is under-voltage and must be replaced.
REPLACE MEMORY BACKUP BATTERY	The battery that attaches to the main processor board and supplies power for the control's RAM memory is under-voltage and must be replaced. If not replaced, AMP data cannot be copied to backup memory and part program data may be lost.

Message	Description
REQUESTED DATA TOO LARGE	The data you are trying to send or receive is too large.
REQUIRES AT LEAST TWO AXES	A transfer line quick view prompt was selected for a cycle which requires two or more axes. Your system is currently configured as a single axis system.
RESETTING E-STOP	Once you push the E-Stop Reset button to clear the E-Stop state, the Resetting E-Stop message displays to alert you that the control is attempting to come out of E-Stop. After the system is out of E-Stop and the drives are enabled, the control clears this message. If the error condition is not cleared, this message clears, but the "E-STOP" message continues to flash, as the control remains in the E-Stop state.
RETRACE NOT ALLOWED	A retrace is not allowed from the point in program execution.
RIGHT OPERAND MUST BE POSITIVE	The right operand of a logical operator must be a positive value. Negative values are illegal; for example, 1AND-2 is illegal because of the -2.
RIO COMMON RAM ACCESS NOT ACKNOWLEDGED	The control's request to use the RIO module was denied. The RIO module lost power, or the control was restarted, but the RIO module was not.
ROLLOVER/OVERTRAVEL INCOMPATIBLE	Overtravel limits were specified in AMP for an axis that is configured as a rollover axis. Rollover axes do not have overtravel limits.
ROTARY AXIS CANNOT BE SCALED	A rotary axis cannot be scaled.
ROTARY WORD OUT OF RANGE	A rotary axis was programmed to move to an absolute position that is greater than or equal to 360 degrees. In absolute mode, a rotary word must range between 0 and 360 degrees.
ROUGHING CYCLE NESTING ERROR	The contour blocks called by a roughing cycle to define the finished contour of a part contain a block that likewise calls for a roughing cycle. Contour blocks for a roughing cycle cannot contain a block that likewise calls for a roughing cycle.
ROUGHING CYCLE PROGRAMMING ERROR	A syntax error has been found in a roughing routine block (G72, G73, G74, or G75).
RUNG NUMBER NOT FOUND	The rung number you are searching for in the search monitor utility does not exist in the current module, or does not exist in the program in the direction you are searching.
S	
S-CURVE ACC/DEC CONFIGURATION ERROR	An axis configuration error was detected by the control when the programmed acc/dec ramp was out of range. An attempt to program an acceleration ramp value of 0 in a G48.3 or G48.4 block. An attempt was made to program another G-code in a block with a G48.x.
S-CURVE MIN PROG TOO SMALL	An attempt was made to select a jerk value below the allowable AMPed value.
S-CURVE MODE NOT ALLOWED	This message displays when an attempt was made to use a feature that is illegal in S-Curve Acc/Dec mode. The following can not be used with S-Curve Acc/Dec: 7300 Series Tape Compatibility, PAL Axis Mover, Circular Interpolation Mode (G02, G03), Feed to Hard Stop (G24), jogging, threading, and solid tapping.
S-CURVE OPTION NOT INSTALLED	An attempt was made to select S-Curve Acc/Dec (G47.1) when the S-Curve option bit was set to false. make sure your system includes the S-Curve option.
S NOT LEGAL PROGRAMMING AXIS NAME	This is displayed at power-up when the letter "S" is assigned to linear or rotary axis. Only the spindle(s) can be AMPed with "S" as the name; it cannot be assigned to a programmable axis.
S OVER SPEED	A servo motor is turning at an RPM that is greater than the maximum RPM allowed for that servo as defined in AMP by the system installer. For digital spindles this error can result from maximum RPM gear range 1 being set higher than your AMPed allowed Maximum Motor Speed.
SAVE COMPLETED	The changes made to the current device set-up have been saved.
SCALE FACTORS MUST BE EQUAL FOR PLANE	When performing circular motion or motion in certain cycles, keep the scale factors for the axes of the active plane equal.
SCALING INVALID DURING POLAR	Scaling cannot be used during polar programming.
SEARCH ALREADY IN PROGRESS	You cannot request a search operation while one is currently running. Complete or abort the current search before attempting another search.
SEARCH MONITOR SELECT NOT ALLOWED	You can not use the online PAL search monitor utility while the display select function softkeys are active. Leave the display select screens (press DISP SELECT) before you try to access the search monitor utility.

Message	Description
SEARCH REQUIRES AN ACTIVE PROGRAM	An attempt has been made to perform a search operation when no program was selected for execution. A program must be selected for automatic execution before a program search can be performed.
SEARCH STRING NOT FOUND	The character or character string designated in the search operation was not found.
SECOND SPINDLE NOT CONFIGURED	For spindle 2 to be programmable, it must be configured in AMP; a decode error.
SECONDARY AUX. WORD SAME AS AXIS NAME	The secondary auxiliary word (usually B) is the same as an axis name, causing an interpretation conflict for the control. This word and all axis names are assigned in AMP.
SEE (MESSAGE) IN PROGRAM BLOCK	The programmer has assigned a system parameter that generates this message, telling the operator to read the comment in the current part program block. Program execution will resume when cycle start is pressed.
SEQUENCE NUMBER OUT OF RANGE	A sequence number beyond the range of 1 - 99999 was programmed.
SEQUENCE STOP NUMBER FOUND	A sequence stop number has been activated, and that sequence number has been found in the currently executing program. Execution will stop after the block containing the sequence number corresponding to the sequence stop number is executed. Execution will resume when cycle start is pressed.
SERCOS COMMUNICATIONS LOST	Communications between the 9/PC SERCOS master and all devices in the fiber optic ring was not established. The SERCOS cable may be damaged, communications between one or more of the drives may be lost, or power to one or more of your drives may be off. The system remains in E-Stop until this condition is corrected.
SERCOS CYCLE TIME/FG SCAN TIME MISMATCH	An attempt was made to AMP a Fine Foreground Scan Time parameter that was not an integer multiple of the SERCOS Cycle Time parameter. Only integer multiples are permitted. To correct this error, reconfigure AMP so that the previously mentioned prerequisite is met. For more information regarding setting Cycle Time for SERCOS, refer to your <i>9/PC AMP Reference Manual</i> .
SERCOS MASTER-9PC HANDSHAKE FAULT	The handshake between the 9/PC SERCOS master and the 9/PC main that occurs each coarse foreground scan did not complete in the time allotted. This error may occur if there is an interruption in the execution of the 9/PC main. The system goes into E-Stop until you stop and restart your 9/PC main. In the event that this error persists, contact your Rockwell Automation support person for assistance.
SERCOS MEMORY FAILURE	A memory failure was detected in either the 9/PC SERCOS master or one of the 1394 serial drives connected on the fiber optic ring. This condition may occur if the size of the AMP image received by the 1394 CNC Serial Drive is larger than permitted. This condition may be the result of a mismatch between your ODS AMP version and the 1394 SERCOS slave software. In the event that this error occurs, contact your Rockwell Automation support person for assistance.
SERCOS NETWORK OVERLAP	The 9/PC SERCOS master did not complete processing the data for one communications cycle while in the cyclic phase (phase 4) of the SERCOS protocol before another communications cycle started. Until the error is cleared by the SERCOS master software, the 9/PC will remain in E-Stop. Check your system to make sure that there is not a misconfiguration of AMP or you do not have an incorrect version of the 9/PC SERCOS master software installed on your system. In the event that this problem occurs, contact your local Rockwell Automation support person for assistance.
SERCOS PHASE 1 NOT COMPLETED	An error occurred in the SERCOS protocol during phase 1 of the PTO run-up sequence. This error appears when communications between the 9/PC SERCOS master and all drives connected on the fiber optic ring failed to reach phase 1 of the protocol within 5s. This message may appear if: <ul style="list-style-type: none"> • power to the drive is lost or no power was applied • a power up or power down sequence interrupted phase 1 communications • there is a mismatch between the SERCOS node addresses configured in AMP and the actual 1394 CNC Serial Drive node addresses If this error occurs, the 9/PC SERCOS master initializes communications and reattempts to complete phase 1 of the SERCOS protocol. Verify that each AMPed device has a SERCOS address that matches the SERCOS address of the physical device located on the fiber optic ring. In the event that this problem persists, contact your local Rockwell Automation support person.

Message	Description
SERCOS PHASE 2 NOT COMPLETED	<p>An error occurred in the SERCOS protocol during phase 2 of the PTO run-up sequence. This message may appear if:</p> <ul style="list-style-type: none"> • power to the drive is lost • a power up or power down sequence interrupted phase 2 communications • there is a synchronization problem between the 9/PC SERCOS master and a drive on the fiber optic ring <p>If this error occurs, the 9/PC SERCOS master will attempt to restart communications beginning in phase 1 of the protocol. In order to clear this error, power cycle your drive. In the event that this problem persists, contact your local Rockwell Automation support person.</p>
SERCOS PHASE 3 NOT COMPLETED	<p>An error occurred in the SERCOS protocol during phase 3 of the PTO run-up sequence. This message may appear if:</p> <ul style="list-style-type: none"> • power to the drive is lost • a power up or power down sequence interrupted phase 3 communications • there is a synchronization problem between the 9/PC SERCOS master and a drive on the fiber optic ring <p>If this error occurs, the 9/PC SERCOS master will attempt to restart communications beginning in phase 1 of the protocol. In order to clear this error, power cycle your drive. In the event that this problem persists, contact your local Rockwell Automation support person.</p>
SERCOS PHASE 4 NOT COMPLETED	<p>An error occurred in SERCOS protocol during phase 4 of the PTO run-up sequence. This message may appear if:</p> <ul style="list-style-type: none"> • power to the drive is lost • a power up or power down sequence interrupted cyclic (phase 4) communications • the servo processor is indicating a fault • the SSRN is indicating a fault <p>If any of these conditions occur, the 9/PC will log a second message providing additional information in conjunction with the original message. In order to clear this error, correct any hardware or AMP configuration problems and power cycle your drive. In the event that this problem persists, contact your local Rockwell Automation support person.</p>
SERCOS RING LOST DATA	<p>The 9/PC SERCOS master detected data loss during communications in the cyclic phase (phase 4) of the SERCOS protocol. During cyclic communications, the SERCOS protocol requires the transaction of data between the master and slave to complete at specific, predefined intervals. If the master or slave detects an incomplete communications cycle, the 9/PC goes into E-Stop and the 9/PC attempts to restart SERCOS communications beginning in phase 1. This error may be caused by an interruption of power to one of the devices in the SERCOS ring or a break in the fiber optic cable. In the event that this problem persists, contact your local Rockwell Automation support person.</p>
SERCOS SERVO POWERUP FAULT	<p>An error occurred during 1394 DSP processor power-up. Possible causes are:</p> <ul style="list-style-type: none"> • the servo DSP processor did not initialize correctly • unable to set up AMP or flash SIMMS on the 1394 servo DSP loop processor <p>This error indicates a problem with the servo hardware or a compatibility problem between the 1394 SERCOS slave software and the servo software. In the event that this fault occurs, contact your local Rockwell Automation support person.</p>
SERCOS SLAVE POWER FAIL	<p>This condition occurred as a result of one of the following:</p> <ul style="list-style-type: none"> • power supply in the 1394 CNC Serial Drive failed • the 1394 CNC Serial Drive detected an interruption in power (+24V) • the +24V power supply fell below acceptable levels
SERCOS SLAVE POWERUP FAULT	<p>An error occurred during initialization of the slave 1394 DSP processor. This error indicates a problem with the 1394 SERCOS slave hardware or a compatibility problem between the 9/PC SERCOS master software and the 1394 SERCOS slave software. In the event that this problem persists, contact your local Rockwell Automation support person.</p>

Message	Description
SERCOS MS SYNCH LOST ON 1394	Clock synchronization between the 9/PC SERCOS master and 1394 SERCOS slave was lost. Data was not received or it was received at the wrong time. In order to clear this error, power cycle your drive. Excessive electrical noise or a hardware fault may be the cause of this problem. To correct this problem power down your PC and all devices in the fiber optic ring. Verify the fiber cables are securely fastened and if possible, eliminate any source of unnecessary noise that might trigger the problem. Without applying power to the machine tool, restart the 9/PC and apply power to each of the drives connected on the fiber optic ring. If the error is no longer apparent, restart your system. If this problem persists, contact your local Rockwell Automation support person.
SERCOS SS SYNCH LOST ON 1394	Clock synchronization between the 1394 SERCOS slave and the servo loop processor was lost. Data was not received or it was received at the wrong time. Excessive electrical noise or a hardware fault may be the cause of this problem. To correct this problem power down your PC and all devices in the fiber optic ring. Verify the fiber cables are securely fastened and if possible, eliminate any source of unnecessary noise that might trigger the problem. Without applying power to the machine tool, restart the 9/PC and apply power to each of the drives connected on the fiber optic ring. If the error is no longer apparent, restart your system. If this problem persists, contact your local Rockwell Automation support person.
SERIAL COMMUNICATIONS BUFFER OVERFLOW	A peripheral device communication error (such as a tape reader). The 512 character input (receive) buffer has overflowed. Data may have been lost. Check your configured communications protocol (flow control) and check for proper cabling/pin connections.
SERIAL COMMUNICATIONS ERROR #1	This is an internal software error. The control is unable to access DF1 Driver.
SERIAL COMMUNICATIONS ERROR #2	This is an internal software error. Check cables and try again.
SERIAL COMMUNICATIONS ERROR #3	This is an internal software error. This is an unknown DF1 Driver error.
SERIAL COMMUNICATIONS ERROR #4	This is an internal software error. The control is unable to access the serial communications port.; check cables and try again.
SERIAL COMMUNICATIONS ERROR #5	Serial communications port has not received the expected response in the time allowed.
SERIAL COMMUNICATIONS FRAMING ERROR	An incorrect number of bits was encountered during a read operation. Check your device setup.
SERIAL COMMUNICATIONS PARITY ERROR	Incorrect parity of data was received. Check your device setup.
SERIAL PORT IN USE	This message will appear if a serial communications port is busy when checked prior to transmission.
SERIAL UART BUFFER OVERFLOW	The 2 character buffer on the UART receiver has overflowed. A character has been lost. Check communications setup.
SERVO AMP C LOOP GAIN ERROR	One of the following AMP parameter errors exist: $\text{Current Prop. Gain} + \text{Current Integral Gain} < 4096$ or $\text{Current Prop. Gain} - \text{Current Integral Gain} > 0.$
SERVO AMP ERROR	There is an error in one or more of the AMP parameters relative to servo control or an absolute feedback encoder failed to initialize.
SERVO AMP FDBK PORT ERROR	The feedback port assignments in AMP are wrong; for example, two servos are using the same feedback port on the same servo module. Make sure to check the error log for additional messages that may appear in conjunction with this message.
SERVO AMP FE LIMITS CORRECT	One or more of the following AMP parameters were changed to satisfy the following equation: $\text{Inposition Band} \leq \text{Gain Break Point} \leq \text{Feedrate Suppression} \leq \text{Excess Error}$ The servo module would have disabled control operation if these parameters were not changed.
SERVO AMP ID SPEED CORRECT	One or more of the following AMP parameters were changed to satisfy the following equation: $0 / \leq \text{Motor speed at starting Id} \leq \text{Motor speed at Id Break Point} \leq \text{Max. Motor Speed}$ The servo module would have disabled control operation if these parameters were not changed.
SERVO AMP OUTPUT PORT ERROR	The output ports as assigned in AMP are wrong; for example, two servos on the same board are assigned to the same output port.

Message	Description
SERVO AMP V LOOP GAIN ERROR	One of the following AMP parameter errors exist: Velocity Prop. Gain + Velocity Integral Gain < 65536 or Velocity Prop. Gain - Velocity Integral Gain > 0
SERVO AMP, AMP TYPE ERROR	The AMP parameters specifying amplifier types and connectors are contradictory.
SERVO AMPLIFIER FAULT	This indicates that a fault signal has been received from a servo amplifier. It can usually be corrected by turning off power to the amplifier, and then back on.
SERVO BUSY DURING HOMING OPERATION	This error indicates that the servo processor was unable to respond during a homing operation. It can occur under the unusual condition resulting from two or more servo axes reaching their home point simultaneously. Generally, the axes can be re-homed with no problems.
SERVO CONFIGURATION ERROR	The AMP servo configuration is inconsistent. An example of this error would be if the downloaded AMP file were configured for only two axes, when the AMP parameter "Number of Motors on First Board" was set for three.
SERVO COMMUNICATIONS ERROR	A communications error occurred between the control and the servo module.
SERVO CURRENT LOOP ERROR	While running an axis, the allowable current loop proportional error or current loop integral error has gone out of range.
SERVO INTERFACE FAILURE	The servo interface diagnostics performed on power-up have failed. Attempt to power up again. If the error remains, contact Allen-Bradley customer support services.
SERVO POS & VEL FB SIGN ERR	This is a power turn-on error which occurs when the signs of the position and velocity feedback devices do not match when a common feedback port is used for both.
SERVO POWER UP SEQUENCE ERROR	The servo processor diagnostics performed on power-up have failed. Attempt to power up again. If the error remains, contact Allen-Bradley customer support services.
SERVO POWERUP DIAGNOSTICS FAILURE	The servo module diagnostics performed on power-up have failed. Possible causes include incorrect servo AMP parameters being downloaded. An example would be configuring AMP for five axes when there is only one servo module installed.
SERVO PROCESSOR ASSIGNMENT ERROR	Too many servos were AMPed or a servo was assigned to a non-existent servo processor. The system is held in E-Stop. The message indicates an error in the total number of fitted axes and spindles, or in the AMPed values of: Number of Motors on 1st board Number of Motors on 2nd board.
SERVO PROCESSOR OVERLAP	The analog version of the servo sub-system provides fine iteration overlap detection. This message is displayed if the fine iteration software on the DSP does not execute to completion in one fine iteration.
SERVO PROM CHECKSUM ERROR	The checksum test on the servo processor software stored in PROM memory has failed. This test is performed on power-up and periodically while the system is running. Contact Allen-Bradley customer support services.
SERVO PTO DIAGNOSTICS FAIL	The servo card has failed its power-up diagnostics. Consult Allen-Bradley customer support services.
SERVO PTO SEQUENCE ERROR	The servo card has failed its power-up diagnostics. Consult Allen-Bradley customer support services.
SERVO TIME-OUT READING ABSOLUTE ENCODER	During power-up initialization of the position registers or during a homing operation, the servo processor has failed to return a read within the required time after the absolute position has been requested by the main processor. Consult Allen-Bradley customer support services.
SERVO TIME-OUT READING FEEDBACK	During a homing operation, if there is an error reading feedback from the servo module, this message appears. This usually occurs when the system scan time is close to the threshold at which logic execution can just complete and when homing more than 3 axes at a time. This error can be avoided by homing axes individually or increasing the system scan time in AMP.
SET ZERO NOT ALLOWED ON:	A set zero operation on the specified axis is not permitted. Typically this is because either the control is not in manual mode, or the selected axis is in the process of being jogged.
SETUP BUFFER ALLOC ERROR - CNC STOPPING	The 9/PC executive was unable to allocate the setup buffers used for processing part program blocks.

Message	Description
SHAFT VALUE > NUMBER OF POCKETS	An attempt was made to assign a shaft pocket that is greater than the number of pockets assigned for that custom tool. The shaft pocket number must be a value between 1 and the number of pockets assigned to that tool.
SHARED AXIS CONFIGURATION ERROR	Either there are too many shared axes configured, a shared axis has the same name as some other axis in the system, the diameter axes on a lathe are shared axes, or some other miscellaneous configuration error occurred.
SHARED AXIS NOT IN PROCESS	You have attempted to position a shared axis (or recouple a shared dual axis) not currently available to the requesting process. A shared axis can only be positioned by the process currently controlling the shared axis.
SHARED SPINDLE CONTENTION	This is a run-time decode error. A process attempted to activate an exclusive-use spindle mode or change the spindle speed when another process was using it. The process goes into cycle stop.
SHIFT AWAY FROM ENDPOINT	When a cylindrical grinder cycle (G84 or G85) is programmed with a shift and plunge, and the shift increment does not move towards the cycle endpoint, this message is generated. The shift increment must move towards the cycle endpoint.
SHIFT VALUE HAS TOO MANY DIGITS	You have used incorrect search string syntax in the PAL search monitor utility.
SKIPPING SOURCE NOT INCLUDED MODULE(S)	When you downloaded your PAL program the source code for some modules was not included. The ODS software can decide to not include the source on selected modules when it determines there is not sufficient memory on the control to hold both the PAL image and the source code. The PAL search monitor utility will not monitor any PAL modules that do not have their source code downloaded.
SLASH NOT ALLOWED	An error occurred in G05 DH+ communications block.
SLAVE AXIS LETTER CANNOT BE PROGRAMMED	An attempt was made, when using dual axes, to program the slave's axis letter.
SPINDLE CONFIGURATION ERROR	An attempt to configure a spindle that did not have a servo board identified in AMP to indicate to which board the spindle is connected. The spindle must be included in the number-of-motors AMP parameter for the board the spindle is on.
SPINDLE ERROR, AMP FIRST SPINDLE 1ST	AMP order of spindles must be spindle 1, spindle 2, spindle 3.
SPINDLE ERROR, AMP SECOND SPINDLE 2ND	AMP order of spindles must be spindle 1, spindle 2, spindle 3.
SPINDLE ERROR, AMP THIRD SPINDLE 3RD	AMP order of spindles must be spindle 1, spindle 2, spindle 3.
SPINDLE IS CLAMPED	An attempt was made to program a block containing a spindle code other than an M05 while the PAL or logic servo clamp request flag for the spindle was set.
SPINDLE MODES INCOMPATIBLE	An attempt was made to enter virtual mode when the spindle that is used for this mode is synchronized as the follower spindle or an attempt was made to perform end face milling during synchronization.
SPINDLE MOTOR SPEED TOO HIGH	When using a 1326 motor as a spindle, feedback resolution combined with your configured maximum spindle speed would return feedback counts faster than the control can reliably decode. Either reduce the maximum configured spindle speed, or reduce the configured feedback counts for the spindle in AMP.
SPINDLE MUST BE THE LAST SERVO	When the system is AMPed, the spindle must be assigned to the first available port after all axes have been assigned.
SPINDLE NOT ASSIGNED	A spindle axis was AMPed, but not assigned to any process.
SPINDLE ORDER ERROR, AMP AUX. 2 SECOND	AMP order of spindles must be primary spindle, aux. spindle 2, aux. spindle 3.
SPINDLE ORDER ERROR, AMP AUX. 3 THIRD	AMP order of spindles must be primary spindle, aux. spindle 2, aux. spindle 3.
SPINDLE ORDER ERROR, AMP PRIMARY 1ST	AMP order of spindles must be primary spindle, aux. spindle 2, aux. spindle 3.
SPINDLE SYNC NOT CONFIGURED	The programmer attempted to enter synchronized spindle mode before it was configured in AMP.
SPINDLE SYNC UNAVAILABLE THIS PROCESS	An attempt was made to enter synchronized spindle mode on a dual-process control when the process was not yet configured for both spindles in the synchronized pair.
SQUARE ROOT OF NEGATIVE ERROR	Internal math error has occurred; contact Allen-Bradley customer support services.

Message	Description
SQUARE ROOT OF NEGATIVE INVALID	An attempt was made to determine the square root of a negative number using the calculator or through a paramacro SQRT command.
SSRN COMMUNICATIONS ERROR	A 1394 SERCOS drive reported an error with the system serial communications network (SSRN) that monitors hardware status. Excessive electrical noise could cause the SSRN in the drive to fault. This message may also appear if the terminator connector on the 1394 CNC Serial Drive is loosened or removed while the system is operating. To recover from this condition, remove power to the drive, verify that the terminating connector is attached, and power up the 1394 CNC Serial Drive. If the problem persists, contact your local Rockwell Automation support person.
SSRN NOT INITIALIZED (X)	An SSRN on a 1394 rack was not initialized properly. One possible cause for this message to appear during power-up is if the terminator connector on one of the 1394 CNC Serial drives (X = 0 or 1) is missing. The system remains in E-Stop until initialization is complete. To recover from the situation, plug the terminator and power cycle the drive.
STORED PASSWORD LIST TO BACKUP	This message appears after the password list has been successfully stored to the control's backup memory.
STORING TO BACKUP - PLEASE WAIT	This message appears whenever AMP or axis calibration data in RAM is being stored in backup memory.
SWITCHLESS HOME NOT ALLOWED WITH DCM	An attempt was made to execute a programmed axis move before the axes have been homed. Axes must be homed before they can be moved through part program or MDI commands. This message may also appear if there was an attempt to use switchless homing on an axis with distance coded marker (DCM) feedback.
SYMBOL NAME FORMAT ERROR	Check the remote symbol and CNC symbol to make sure they exist on both remote and CNC. Check the table of the read only or write only variables.
SYMBOL NOT FOUND	Check the remote symbol and CNC symbol to make sure they exist on both remote and CNC. Check the table of the read only or write only variables.
SYNCHRONIZATION DEADLOCK	A synchronization code is activated and caused the activating process to wait on a process that is already waiting.
SYNCH SPINDLES MISCONFIGURED	Causes for this could be: only one spindle (either controlling or follower) was defined in the synchronized spindle pair, you exceeded the simple feedback ratio limitation of 10 (e.g., 11:1 or 2:13), or on a multiprocess system, one (or both) of the spindles in the synch pair is currently not available to the process making the synchronization request.
SYNCH SPINDLES REQUIRE FEEDBACK	One or both of the spindles, configured in AMP as a member of a synchronized pair, did not have feedback. Both spindles in a synchronized pair must be equipped with an AMP configured feedback device.
SYNTAX ERROR (COMMA)	A missing comma or an extra comma was found in the program block.
SYSTEM DIAGNOSTIC #1	An illegal parameter was passed into a switch statement (mid-program start) in the control software. Contact Allen-Bradley customer support services.
SYSTEM DIAGNOSTIC #2	An illegal parameter was passed into a switch statement (ASCII buffer task) in the control software. Contact Allen-Bradley customer support services.
SYSTEM DIAGNOSTIC #3	An illegal parameter was passed into a switch statement (ASCII buffer task) in the control software. Contact Allen-Bradley customer support services.
SYSTEM MODULE GROUND FAULT	<p>The 1394 system module has detected a ground fault. The system generates a ground fault when there is an imbalance in the DC bus of greater than 5A. This drive error can be caused by incorrect wiring (verify motor and ground wiring), motor malfunction, or an axis module IGBT malfunction. To clear this fault, you should:</p> <ul style="list-style-type: none"> • determine the cause of the fault • resolve the situation • power cycle to your 1394 drive • turn your system back on <p>For more information regarding this fault, refer to the Troubleshooting chapter of the <i>1394 Digital AC Multi-Axis Motion Control System User Manual</i>.</p>

Message	Description
SYSTEM MODULE OVER TEMP	<p>The 1394 contains a thermal sensor which senses the internal ambient temperature. Causes could be: that the cabinet ambient temperature is above rating. The machine duty cycle requires an RMS current exceeding the continuous rating of the controller. The airflow access to the 1394 is limited or blocked. This does not necessarily indicate a motor over temperature. Motor over temperature sensors should be wired directly into the E-Stop string. To clear this fault, you should:</p> <ul style="list-style-type: none"> • stop the 9/PC main executive • determine the cause of the fault • resolve the situation • power cycle to your 1394 drive • restart the 9/PC main executive <p>For more information regarding this fault, refer to the Troubleshooting chapter of the <i>1394 Digital AC Multi-Axis Motion Control System User Manual</i>.</p>
SYSTEM MODULE OVER VOLTAGE	<p>The 1394 system module buss voltage exceeds the maximum operating voltage. The DC power bus is continuously monitored. If it exceeds a preset level (810 Vdc), a fault is sensed and the power supply is disabled. This can be caused by an under sized shunt requirement, shunt regulator fuse has blown, the shunt regulator transistor has malfunctioned, the power driver board is malfunctioning and incorrectly sensing the bus voltage, the CNC acc/dec rate is incorrectly set, the input line voltage is excessive, the system inertia is too high causing excessive energy to be returned to the power supply bus, or a vertical axis with insufficient counterbalancing is over driving the servomotor and causing excessive energy to be returned to the power supply bus. To clear this fault, you should:</p> <ul style="list-style-type: none"> • stop the 9/PC main executive • determine the cause of the fault • resolve the situation • restart the 9/PC main executive <p>For more information regarding this fault, refer to the Troubleshooting chapter of the <i>1394 Digital AC Multi-Axis Motion Control System User Manual</i>.</p>
SYSTEM MODULE PHASE LOSS	<p>The 1394 system module has detected a loss of one of the input power phases. The three-phase input line is monitored and a fault will be issued when a phase loss is detected. Typical causes include, one or more input line fuses have opened, contactor malfunction, or incorrect wiring. To clear this fault, you should:</p> <ul style="list-style-type: none"> • stop the 9/PC main executive • determine the cause of the fault • resolve the situation • restart the 9/PC main executive <p>For more information regarding this fault, refer to the Troubleshooting chapter of the <i>1394 Digital AC Multi-Axis Motion Control System User Manual</i>.</p>
SYSTEM MODULE UNDER VOLTAGE	<p>The 1394 system module voltage does not meet the minimum operating voltage. The DC power buss shall activate the under voltage limit when the bus drops to 275V dc or less. It will clear at 300V dc. Typical causes include low voltage on the three phase input.</p> <ul style="list-style-type: none"> • stop the 9/PC main executive • determine the cause of the fault • resolve the situation • restart the 9/PC main executive <p>For more information regarding this fault, refer to the Troubleshooting chapter of the <i>1394 Digital AC Multi-Axis Motion Control System User Manual</i>.</p>
T	
(T) WORD IN CIRCULAR MODE	<p>An attempt was made to activate a tool length offset in a block that generates a circular move. Tool length offsets can be activated only in linear blocks (or in non-motion blocks if AMP is so configured).</p>
T-WORD NOT ALLOWED WITH M06	<p>NEXT TOOL IN T WORD was selected as the tool-change type in AMP while a T-word is programmed in an M06 block.</p>
TAN CIRCLE NOT IN 1ST BLOCK	<p>When editing a program, an attempt was made to digitize an arc using {CIRCLE TANGNT} as the first block in the program. To use this digitizing format, the control must first have a tool path programmed to make the arc tangent.</p>

Message	Description
TEMPLATE PROGRAM NOT FOUND	A transfer line quick view item was selected without the correct part program template present in the protected directory. There are 19 transfer line cycles and there must be part program templates QV01 thru QV19 present in the protected directory. Refer to your T-LINE-9 Quick Start guide for details on replacing/restoring these part program templates.
THIRD SPINDLE NOT AVAILABLE	AMP configuration error; spindle 3 can be configured only on a 9/290.
THIRD SPINDLE NOT CONFIGURED	For spindle 3 to be programmable, it must be configured in AMP; a decode error.
THRDS/IN WORD FORMAT FINER THAN	The word format programmed is requesting a finer resolution than the axis word format for the corresponding axis allows. These word formats are set in AMP.
THREAD FEEDRATE TOO LARGE	The lead is too large in threading mode. Program slower spindle speed.
THREAD LEAD ERROR	The thread lead was too large or too small. This commonly occurs when cutting a variable thread lead and before the end of the threading pass is reached. Either the lead goes to zero for a decreasing lead thread, or an axis speed would exceed its maximum allowable cutting feedrate when cutting an increasing lead thread.
THREAD LEAD IS ZERO	No thread lead has been programmed in a block that calls for thread cutting. Thread lead is programmed with either an F- or an E-word.
THREAD PULLOUT DISTANCE TOO LARGE	The programmed threading pullout distance is larger than the programmed distance of the thread departure.
THREAD PULLOUT STOPPED AT I-PLANE	The chamfer block of a threading cycle is shortened so that the combination of pullout angle and pullout distance does not cause the retract in axis 1 to go beyond the I-plane. The AMP pullout angle is still used for the chamfer.
THREADING DISTANCE IS ZERO	A threading cycle has been programmed with no thread. Program an end-point or an end-point different from the start-point.
TIME-OUT OCCURRED WHILE WAITING FOR INPUT	When downloading AMP or PAL from the ODS workstation to the control, the message OKAY TO DOWNLOAD? (Y/N): appears on the control screen. If you do not respond within an allowed time, this error will appear.
TIMER MUST START WITH #	You have used incorrect search string syntax in the PAL search monitor utility.
TOO MANY ([] IN EXPRESSION	The control has found an unmatched number of [] in a program block or calculator operation. All left brackets “[” must have a corresponding right bracket “]”.
TOO MANY () IN EXPRESSION	The control has found an unmatched number of] in a program block or calculator operation. All right brackets “]” must have a corresponding left bracket “[”.
TOO MANY 1394 DRIVES AMPED	An attempt was made to AMP more than two 1394 SERCOS drives.
TOO MANY 7300 PATTERNS IN MEMORY	An attempt was made to enter a 7300 pattern into the control's memory when the internal cross-reference table of pattern repeat names was full. The internal cross-reference table of pattern repeat names can only hold 20 pattern repeat names.
TOO MANY ACTIVE PROCESSES CONFIGURED	An AMP has been loaded that has too many actively configured processes for this controller model. The 260 series and the dual lathe can have only 2 active processes.
TOO MANY AXES PROGRAMMED	Too many axis letters were programmed in a fixed cycle block.
TOO MANY AXES SELECTED FOR DISPLAY	When using the {AXIS SELECT} softkey, you can display only 6 axes. If you attempt to display more than 6 axes, this message is displayed.
TOO MANY CODES IN SYNCH BLOCK	Synch codes must be in a block by themselves, except for an N- or O-word. (9/260-9/290 dual lathe only)
TOO MANY DECIMAL POINTS	A word or parameter value has been programmed with two or more decimal points.
TOO MANY DEVICES ON I/O RING	The I/O ring cannot support the number of devices that has been connected.
TOO MANY EXPRESSION NESTS	The maximum number of nested expressions is 25; for example, [P3+[P4+[P5]]] has 3 expressions nests.
TOO MANY G67'S	A G67 cancel modal paramacro code was executed when no modal paramacro was active. This is typically caused when there are fewer nested modal paramacros than the programmer expected.
TOO MANY I-J-K SETS	An attempt was made to define a local paramacro parameter that is greater than #33 using I,J,K, argument sets. A maximum of 10 different I, J, K, sets may be programmed for each set of local parameters.

Message	Description
TOO MANY MACRO CALLS	The maximum number of nested paramacros was reached. Only 4 paramacros can be active at any one time.
TOO MANY MOTORS AMPED ON 1ST BOARD	The AMP parameter for the number of motors on the first servo board is larger than the number of axes in the system.
TOO MANY NESTED (DO) COMMANDS	More than the allowable number paramacro DO loops are active at one time. A maximum of 3 nested DO loops are allowed.
TOO MANY NONMOTION BLOCKS-DEADLOCK	There were too many non-motion blocks encountered during the look-ahead for cutter compensation or QPP. Consult Allen-Bradley customer support services.
TOO MANY NONMOTION CHAMFER/RADIUS BLOCKS	Too many non-motion blocks separate the first tool path that determines the chamfer or radius size (programmed with a ,R or ,C) from the second tool path. A maximum number of non-motion blocks is set in AMP by the system installer. A non-motion block is defined as any block that does not generate axis motion in the current plane.
TOO MANY POCKETS IN ROUGHING CYCLE	A maximum of 2 pockets can exist in a roughing cycle.
TOO MANY QPP NONMOTION BLOCKS	Too many nonmotion blocks separate the first and second tool paths with unknown intersections in QuickPath Plus. A maximum number of nonmotion blocks is set in AMP by the system installer. A nonmotion block is defined as any block that does not generate axis motion in the current plane.
TOO MANY SERCOS AXES FOR SCAN TIME	An attempt was made to AMP more SERCOS axes than was allowed by the SERCOS Scan Time. The AMPed foreground scan time must be increased for the number of AMPed 1394 axes.
TOO MANY SHARED SPINDLES	Too many spindles were specified as being shared by two or more processes.
TOO MANY SPINDLES	More than one spindle is configured on the control.
TOO MANY SUBPROGRAM CALLS	The maximum number of nested subprograms was reached. Only 4 sub-programs may be active at any one time.
TOOL CONFIGURATION WILL NOT FIT	When assigning a custom tool in the random tool table, the number of pockets assigned to the tool relative to the position of the selected shaft pocket will conflict with a different tool already assigned to a pocket. If the custom tool is to be assigned as entered, it must be assigned to a different shaft pocket, or the tool that conflicts with the custom tools location must be moved.
TOOL ENTRY EXCEEDS LIMIT	The selected tool number entered is greater than the AMPed maximum tool number entered by the system installer.
TOOL GROUP DOES NOT EXIST	An attempt was made to edit a tool group in the tool life management tables that does not yet exist in the tool directory. A group must be created by using the {TOOL DIR} softkey options.
TOOL OFFSET CHANGES NOT ALLOWED	During certain cycles, G10 tool change operations are not allowed.
TOOL OFFSET REQUIRES MOTION BLOCK	A tool offset cannot be changed in a non-motion block. A non-motion block is any block that does not generate axis motion in the current plane.
TOOL RADIUS TOO LARGE	The programmed tool radius in a G88 or G89 pocket cycle is too large for the pocket contour. A smaller radius tool must be used to machine out the current pocket contour.
TOOL RADIUS TOO SMALL FOR POCKET SIZE	The programmed tool radius in a G88 or G89 pocket cycle is too small for the pocket contour. Either select a larger tool for the pocket contour or reduce the amount of material to be removed each rough cut of the cycle.
TOP OF PROGRAM REACHED	When performing one of the program search operations, the first block in the program has been reached.
TRAVERSE NOT ALLOWED ON :	An attempt was made to move an axis at rapid traverse before it was homed. This only applies to axes that have software overtravel limits.
TYPE 1 INTERRUPT INCOMPATIBLE WITH G24	This message occurs when returning from a type 1 program interrupt that previously interrupted a G24 block. The interrupt is allowed however the return move is invalid since the axis was previously in the G24 mode. You must manually intervene to continue program execution. We recommend switching to a type 2 program interrupt.
U	
UART PORT IS ALREADY OPEN	The requested serial communications port has already been opened. This message will appear if an attempt is made to send data to a port that is currently being used.

Message	Description
UNABLE TO OPEN PROGRAM	The control cannot find the program that is requested. Make sure the program name is entered correctly or the peripheral device has the correct programs loaded in it.
UNABLE TO OPEN THE UART PORT	A serial communication port error has occurred; retry. The conditions that can lead to this error are unusual and generally will not exist when a second attempt is made to open the port. If this error is generated continuously, it indicates that there may be a communications port hardware failure.
UNABLE TO SYNCH IN CURRENT MODE	The control can not perform the request to synchronize spindles. Possible causes are: synchronization is already active; virtual/cylindrical programming or a threading operation is active on the primary or follower spindle when the synchronization request is made; or on a dual-process system, one of the requesting processes cannot gain control over both spindles.
UNABLE TO WRITE TO FLASH MEMORY	If flash SIMMs appear to be installed correctly, remove and reseal SIMMs. If problem persists, contact Allen-Bradley support service.
UNDEFINED INTERRUPT MACRO/SUBPROG	An interrupt program request was received by the control, but it cannot find the paramacro or sub-program with the corresponding program name in the program directory. The program name is defined in the enable block (M96) with a P-word.
UNEXPECTED DEPTH PROBE TRIP	G26 adaptive depth probe has fired unexpectedly. Either it has fired in a non-G26 block or it has fired before the programmed G26 contact range.
UNKNOWN ERROR - CNC STOPPING	An unknown error condition caused a fatal fault to occur. Contact Allen-Bradley Support Services.
UNSPECIFIED NETWORK ERROR	An error is being sent from another device that the module cannot interpret.
UNUSABLE WORDS IN ZONE BLOCK	An axis word or other data was programmed in a programmable zone block (G22, G22.1 G23, G23.1). These G-codes must be programmed in blocks containing no other data except a block delete /, N word, or comments.
UNRECOVERABLE ERROR	Can occur when updating flash SIMMs with new 9/Series firmware. Retry the update utility. If problem persists, call Allen-Bradley Support Services.
V	
VEL LOOP INVALID WITH DAC OUT	An attempt was made to select the position/velocity servo loop type on a 9/440HR system.
VIRTUAL AXIS NOT ALLOWED	The virtual axis can only be programmed when the control is in a virtual axis mode. You must place the control in G16.3 mode to program a virtual axis.
VIRTUAL C NEEDS SPINDLE WITH FDBK	When the spindle is the virtual C axis in a virtual C application, it must be configured to provide feedback to the servo module.
VIRTUAL/REAL AXIS NAME CONFLICT	The axis configured in AMP as the Virtual C axis was previously configured as a linear machine axis.
W	
WARNING - G10 OFFSETS ALTERED	This message warns that the offsets were changed by a G10 block during execution from a mid-program start.
WARNING - PROGRAM STARTING AT BEGINNING	An active program was edited and then the editor exited. This causes the active program to restart at the beginning of the program.
WARNING - VERIFY MODAL CODES	The MID START PROGRAM feature that activates modal codes for mid-program execution is requesting that these generated modal codes be checked before program execution is started. These modal codes can be checked on the G- and M-code status screens.
WARNING - WATCHDOG JUMPER IS INSTALLED	This error indicates that the watchdog has been bypassed on the control hardware and your system will not report watchdog errors. Call Allen-Bradley field service.
WATCHDOG TIMEOUT - CNC STOPPING	The watchdog timed out due to a possible failure in the 9/PC executive. Contact local Allen-Bradley Support Service.
WATCHLIST ALLOC ERROR - CNC STOPPING	The executive was unable to allocate sufficient memory for watchlists to run the CNC executive.
WHEEL AXIS MOTION INVALID IN G16.3/G16.4	While in the angled wheel grinding mode you have attempted to program the wheel axis directly. Only the virtual axis and the axial axis can be programmed in angled wheel mode.
WILDCARD MUST BE AT START/END OF SYMBOL	You have used incorrect search string syntax in the PAL search monitor utility.

Message	Description
WORK CO-ORD CHANGES NOT ALLOWED	You have attempted to make a change to the work coordinate system at an invalid time. Changes to the work coordinate system can not be performed when some features are active. Disable the offending feature before attempting to change coordinate systems.
Z	
Z-WORD CANNOT BE GREATER THAN R-WORD	The depth (Z-word) of a pocket formed using a G88.5 and G88.6 hemispherical pocket cycle cannot be greater than the radius (R-word) of that pocket.
ZONE 2 PROGRAM ERROR	The next block in the program or MDI entry would cause the specified axis to enter the restricted area of programmable zone 2.
ZONE 2 PROGRAM ERROR:	The current block in the program or MDI entry caused the specified axis to enter the restricted area of programmable zone 2.
ZONE 3 PROGRAM ERROR	The next block in the program or MDI entry would cause the specified axis to enter or exit the area defined as programmable zone 3.
ZONE 3 PROGRAM ERROR:	The current block in the program or MDI entry caused the specified axis to enter the restricted area of programmable zone 3.

END OF APPENDIX

G-code Tables

Appendix Overview

This appendix lists the G-codes for your CNC. They are listed numerically along with a brief description of their use. These G-codes are discussed in detail in the sections within this manual that refer to their specific usage.

G-code Tables

The group numbers given in the table refer to modality. Group 00 are not modal and are independent of other G-codes. The remaining G-code groups are modal with other G-codes with the same group number. This means programming a G-code in group 1 replaces any other active group 1 G-code but does not affect any G-codes in the other group numbers.

A	B	C	Modal	Function	Type
G00			01	Rapid Positioning	Modal
G01				Linear Interpolation	
G02				Circular Interpolation (Clockwise)	
G03				Circular Interpolation (Counterclockwise)	
G04			00	Dwell	Nonmodal
G07			18	Programming Using Radius Values	Modal
G08				Programming Using Diameter Values	
G09			00	Exact Stop	Nonmodal
G10L2				Setup Work Coordinate Offset Table	
G10L3				Setup Tool Management Table	
G10L10				Setup Tool Offset Values Geometry Table	
G10L11				Setup Tool Offset Values Wear Table	
G10.1				Setup Random Tool Table	
G11				Setup Tool Management Table (Cancel)	
G12.1			21	Spindle 1 Controlling	Modal
G12.2				Spindle 2 Controlling	
G14			19	Scaling (Disable)	Modal
G14.1				Scaling (Enable)	
G15			15	Virtual C (Cancel)	
G16.1				Virtual C Cylindrical Interpolation	
G16.2				Virtual C End Face Milling	
G17			02	Plane Selection	
G18				Plane Selection	
G19				Plane Selection	
G90	G77	G20	01	Single Pass O.D. and I.D. Roughing	
G92	G78	G21		Single Pass Thread Cycle	
G94	G79	G24		Single Pass Rough Facing Cycle	
G22			04	Programmable Zone 2 and 3 (On)	
G22.1				Programmable Zone 3 (On)	
G23				Programmable Zone 2 and 3 (Off)	
G23.1				Programmable Zone (Off)	

A	B	C	Modal	Function	Type
G27			00	Machine Home Return Check	Nonmodal
G28				Automatic Return to Machine Home	
G29				Automatic Return from Machine Home	
G30				Return to Secondary home	
G31				External Skip Function 1	
G31.1				External Skip Function 1	
G31.2				External Skip Function 2	
G31.3				External Skip Function 3	
G31.4				External Skip Function 4	
G32	G33	G33		01	
G34			Variable Lead Thread Cutting		
G36			22	Short Block Acc/Dec (Enable)	
G36.1				Short Block Acc/Dec (Disable)	
G37			00	Tool Gauging Skip Function 1	Nonmodal
G37.1				Tool Gauging Skip Function 1	
G37.2				Tool Gauging Skip Function 2	
G37.3				Tool Gauging Skip Function 3	
G37.4				Tool Gauging Skip Function 4	
G39			20	Tool Tip Radius Compensation (Linear Generated Block)	Modal
G39.1				Tool Tip Radius Compensation (Circular Generated Block)	
G40			07	Tool Tip Radius Compensation (Cancel)	
G41				Tool Tip Radius Compensation (Left)	
G42				Tool Tip Radius Compensation (Right)	
G45			23	Disable Spindle Synchronization	
G46				Set Spindle Positional Synchronization	
G46.1				Set Active Spindle Speed Synchronization	
G47			24	Linear Acc/Dec in All Modes	
G47.1				S-Curve Acc/Dec for Positioning and Exact Stop Mode	
G47.9				Infinite Acc/Dec (No Acc/Dec) (AMP-selectable only)	
G50.1			11	Programmable Mirror Image (Cancel)	Modal
G51.1				Programmable Mirror Image	
G52			00	Offset Coordinate Zero Points	Nonmodal
G53				Motion in Machine Coordinate System	
G54			12	Preset Work Coordinate System 1	Modal
G55				Preset Work Coordinate System 2	
G56				Preset Work Coordinate System 3	
G57				Preset Work Coordinate System 4	
G58				Preset Work Coordinate System 5	
G59				Preset Work Coordinate System 6	
G59.1				Preset Work Coordinate System 7	
G59.2				Preset Work Coordinate System 8	
G59.3				Preset Work Coordinate System 9	
G60			25	Synchronous Logic/Block Synchronization Mode	Modal
G60.1				Asynchronous Logic/Block Synchronization Mode	
G60.2				Autosynchronous Logic/Block Synchronization Mode	

A	B	C	Modal	Function	Type
G61			13	Exact Stop Mode	Modal
G62				Automatic Corner Override	
G63				Tapping Mode	
G64				Cutting Mode	
G65			00	Paramacro Call	Nonmodal
G66			14	Paramacro call	Modal
G66.1				Paramacro call	
G67				Paramacro call cancel	
G20	G20	G70	06	Inch system selection	
G21	G21	G71		Metric system selection	
G70	G70	G72	00	O.D. and I.D. Finishing Cycle	Nonmodal
G71	G71	G73		O.D. and I.D. Roughing Cycle	
G72	G72	G74		Rough facing cycle	
G73	G73	G75		Casting/forging roughing cycle	
G74	G74	G76		Face Grooving Cycle	
G75	G75	G77		O.D. and I.D. Grooving Cycle	
G76	G76	G78		O.D. and I.D. Multi-Pass Threading Routine	
G80				09	
G81			Drilling cycle (no dwell, rapid out)		
G82			Drilling cycle (dwell, rapid out)		
G83			Deep hole peck drilling cycle		
G83.1			Deep hole peck drilling cycle (dwell)		
G84			Right hand tapping cycle		
G84.1			Left hand tapping cycle		
G84.2			Right hand solid tapping cycle		
G84.3			Left hand solid tapping cycle		
G85			Boring cycle (no dwell, feed out)		
G86			Boring cycle (spindle stop, rapid out)		
G86.1			Boring cycle (spindle shift)		
G87			Back boring cycle		
G88			Boring cycle (spindle stop, manual out)		
G89			Boring cycle (dwell, feed out)		
--	G90	G90	03		Absolute mode
--	G91	G91		Incremental mode	
G50	G92	G92	00	Coordinate offset using tool positions	Nonmodal
G50	G92	G92		Maximum CSS Spindle RPM	
G92.1				Coordinate system offset cancel	
G92.2				Cancel select offsets	
G98	G94	G94	05	Feed per minute mode	Modal
G99	G95	G95		Feed per revolution mode	
G96			17	CSS ON	Modal
G97				RPM Spindle Speed Mode	

A	B	C	Modal	Function	Type
--	G98	G98	10	Initial level return drilling cycles	Modal
--	G99	G99		R-point level return drilling cycles	

END OF APPENDIX

Symbols

{CHANGE DIR} Softkey, 2-40
{CONFIG} Softkeys, 5-13
{COPY PROGRAM} Softkey, 2-40
{CUT & PASTE}, 5-6
{DEL-LINE} Softkey, 5-11
{DELETE} Softkey, 5-19
{EXIT} Softkey, 5-8
{INCLUDE} Softkey, 5-7
{SEARCH} Softkey, 5-12
{SEQUENCE}, 5-11

Numbers

9/PC
 Additional Publications, 1-5
 Shutdown, 2-2
 Starting and Stopping, 2-1
 Startup, 2-1

A

A-word, 9-15
Absolute Coordinates, 10-1
Absolute Mode, 12-2
Absolute Position Display, 8-4
Acceleration/Deceleration, for Short Blocks,
 17-18
Access Control, 2-23
 Assigning Access Levels and Passwords,
 2-23
 Passwords, entering, 2-28
 Protection of Passwords, 2-26
ACTIVE PROGRAM, SoftkeyTree, A-13
All Position Display, 8-9
AMP Feedrates, 17-8
Asynchronous Mode, 7-22
Automatic Acc/Dec, 17-9
Automatic Machine Home, 13-11
Automatic Mode, 7-19
Automatic Return from Machine Home
 (G29), 13-15
Automatic Tool Management, 19-12
Autosynchronous Mode, 7-23

Axis Detach, 2-35, 4-6
Axis Direction, 2-18
Axis Inhibit Mode, 7-17
Axis Motion, Axis Clamp, 13-22
Axis Names, 9-15
Axis Position Data Display, 8-1
Axis Select (Large Display Screens Only),
 8-7

B

B-word, 9-26
Backing Up Parameter Values, 27-34
Backup Memory, Setting
 power-on time/after reset, 2-38
 power-on time/overall, 2-37
BACKUP PARAM, Softkey Tree, A-7
Basic Display Set
 Accessing, 2-3
 Definition, 2-3
 Inputting Text, 2-10
 Powering Off, 2-20
 Tour, 2-5
Block Delete, 7-1, 9-5
Block Execution
 Asynchronous Mode, 7-22
 Autosynchronous Mode, 7-23
 Programmable, 7-21
 Synchronous Mode, 7-22
Block Look-Ahead, 20-49
Block Retrace, 7-30
Boring Cycles
 Back Boring Cycle (G87), 25-2
 Back Boring Cycles (G87), 25-30
 Feed Out (G85), 25-2, 25-24
 Spindle Shift (G86.1), 25-2, 25-27
 Spindle Stop, Rapid Out (G86), 25-2,
 25-26
 with Dwell, Feed Out (G89), 25-2,
 25-34
 with Dwell, Spindle Stop, Rapid Out
 (G86), 25-2, 25-26
 without Dwell, Rapid Out (G87), 25-2,
 25-30

C

- C Axis, Virtual, 16-11
- C-word, 9-15
- Cancel Fixed Cycle (G80), 25-8
- Casting/Forging Roughing Cycle Routine (G75), 23-27
- Chamfering, 15-2
- Changing Languages, 8-10
- Chinese, Language Display, 8-10
- Circular Interpolation Mode (G02, G03), 13-4
- Circular QuickPath Plus, 14-6
- Clock (System), Time-dependent parameters, 27-17
- Clock, System, 2-35
- CNC Functions
 - Backspace, 2-11
 - Calculator, 2-11
 - End-of-Block, 2-11
 - Performing from the PC Keyboard, 2-11
- Comment Blocks, 9-4
- Comment Display, 5-21
- Communications Module Installed, 8-11
- Conditional Operators, 27-7
- Configuration Manager, Shutdown of 9/PC via, 2-2
- Constant Surface Speed Mode, (G96), 16-3
- Contour Blocks, 23-1
- Controlling Spindles, (G12.1, G12.2, G12.3), 16-8
- Coordinate System, 10-1
- Coordinates of commanded position, Time-dependent Paramacros, 27-20
- Copying Programs, 5-23
- Corner Radius, 15-3
 - R Command, 15-3
- CRT Displays, 8-1
- CSS Mode, (G96), 16-3
- Current Following Error, Time-dependent paramacros, 27-22
- Cutter Compensation (G41, G42)
 - Error Detection, Disabling, 20-51
 - Type A, Overview, 20-3
 - Type B, Overview, 20-3

- Cycle Editor
 - Available Cycles, 5-18
 - Configuring, 5-13
 - Displaying Cycle Prompts, 5-15
 - Graphics Defined, 5-17
 - Keystroke, 5-14
 - Modifying an Exiting Block, 5-19
 - Quick View, 5-15
- Cycle Power, 2-42
- Cycle Start, 2-18
- Cycle Stop, 2-18

D

- Date, Setting, 2-35
- Deep Hole Drill Cycle (G83), 25-11
- Definitions, 1-4
- Deleting a Program, 5-19
- Device, for Program Execution, 7-4
- Diameter Mode (G08), 12-4
- Directories, 2-39
- Display Information, 2-16
- Display Screens, Scaling and Axis Position, 12-9
- Display Select, 8-1
- Displaying a Program {DISPLY PRGRAM}, 5-21
- Displaying Position
 - ABS, 8-4
 - ABS (Large Display), 8-4
 - ALL, 8-9
 - DTG, 8-6
 - DTG (Large Display), 8-6
 - G-code Status, 8-10
 - M-code Status, 8-7
 - PRGRAM, 8-3
 - PRGRAM (Large Display), 8-3
 - PRGRAM DTG, 8-8
 - Target, 8-5
 - Target (Large Display), 8-5
- Distance to Go Position Display, 8-6
- Documentation, Additional Manuals, 1-5
- Downloading Part Programs from ODS, 6-5
- Drilling Cycle Operations, 25-8
- Drilling Cycle Parameter, Altering, 25-35
- Drilling Cycle, Cancel, 25-8

Drilling Cycle, Dwell/Rapid Out (G82), 25-10

Drilling Fixed Cycle
 Drilling Cycle Operations, 25-8
 Drilling Cycle, No Dwell/Rapid Out (G81), 25-8
 Drilling Cycles, 25-1

Dry Run, 7-18

Dual Axis
 Configuration, 18-1
 Homing, 18-4
 Invalid Operations, 18-6
 Offsets for, 18-7
 Parking, 18-3
 Programming, 18-5
 Terms, 18-2

Dwell, 13-18
 Seconds, 13-18
 Spindle Revolutions, 13-18

E

EDIT PROGRAM, SoftkeyTree, A-14

Editing a Program
 Protectable Program Directory, 5-24
 Selecting, 5-4

Editing Part Programs Offline, 6-2

Emergency Stop Operations, 2-18, 2-21

Emergency Stop Reset, 2-18, 2-22

End Face Milling, 16-18

Energizing the Control, 2-18

English, Language Display, 8-10

Entering Part Programs Offline, 6-1

ERROR MESSAGE, SoftkeyTree, A-10

Error Messages, System, B-1

Exponential Acc/Dec, 17-10

External Offset, 10-9

External Offset, Altering, 10-10

F

F-words, 9-16

F1-F4, 2-18

Face Grooving Cycle (G76), 22-3

Feed Per Minute Mode (G94), 17-3

Feed Per Revolution Mode (G95), 17-4

Feedrate Limits, 17-7

Feedrate Override, 2-17, 17-6

Feedrate Switch, External Deceleration, 17-8

Feedrates, 9-16, 17-1

Firmware Revision, 8-11

Following Error, Time-dependent paramacros, 27-22

Format, RAM Disk, 2-34

French, Language Display, 8-10

G

G-Code, Table, 9-19

G-code Status, 8-10

G-Code, Lathe System A, 12-3

G-Code, Using LZS and TZS, 9-12

G-Codes
 G00, 13-1
 G01, 13-3
 G02, 13-4
 G03, 13-4
 G07, 12-4
 G08, 12-4
 G09, 17-16
 G10, 10-8, 10-10, 19-5, 19-20
 G12.1, 16-8
 G12.2, 16-8
 G13, 14-6
 G13.1, 14-6
 G14, 12-6, 12-8
 G14.1, 12-6
 G15, 16-13, 16-18
 G16.1, 16-13
 G16.2, 16-18
 G17, 12-1
 G18, 12-1
 G19, 12-1
 G20, 21-2
 G21, 24-15
 G22, 11-5
 G22.1, 11-7
 G23, 11-5
 G23.1, 11-7
 G24, 21-7
 G27, 13-16
 G28, 13-11, 13-13
 G29, 13-15
 G30, 13-17
 G31, 26-2
 G31.1, 26-2
 G31.2, 26-2
 G31.3, 26-2
 G31.4, 26-2

G33, 24-6
G34, 24-12
G36, 17-18
G36.1, 17-18
G37, 26-3
G37.1, 26-3
G37.2, 26-3
G37.3, 26-3
G37.4, 26-3
G39, 20-8
G39.1, 20-8
G40, 20-4
G41, 20-4
G42, 20-4
G47, 17-14
G48, 17-14
G52, 10-15
G53, 10-2
G60, 7-22
G60.1, 7-22
G60.2, 7-23
G61, 17-16
G62, 17-17
G63, 17-17
G64, 17-16
G65, 27-36
G66, 27-37
G66.1, 27-39
G67, 27-37
G70, 12-4
G71, 12-4
G72, 23-34
G73, 23-2
G74, 23-14
G75, 23-27
G76, 22-3
G77, 22-6
G78, 24-20
G80, 25-2, 25-8
G81, 25-2, 25-8
G82, 25-2, 25-10
G83, 25-2, 25-11
G83.1, 25-2, 25-13
G84, 25-2, 25-14
G84.1, 25-2, 25-17
G85, 25-2, 25-24
G86, 25-2, 25-26
G86.1, 25-2, 25-27
G87, 25-2, 25-30
G88, 25-2, 25-32
G89, 25-2, 25-34
G90, 12-2
G91, 12-2
G92, 10-12
G92.1, 10-18
G92.2, 10-20
G93, 13-18
G94, 17-3

G95, 17-4
Table of, C-1

G-words, 9-17

German, Language Display, 8-10

Grinder Cycles, 5-18

Group Number for M-codes, 9-23

H

Hardware Installed, 8-11

Hardware Overtravel, 11-2

Help, 5-3

Technical, 1-5

Hole Machining Axes, 25-4

Homing a Dual Axis, 18-4

Homing the Axis

Automatic Homing, 13-11

Automatic Return from Machine Home
(G29), 13-15

Machine Home Check (G27), 13-16

Homing, Manual Machine, 4-7

I

I-word, 9-22

Inch Mode (G70), 12-4

Incremental Mode, 12-2

Incremental/Absolute Mode, 10-8
G54-59.3, 10-4

Input Cursor, 2-10

Input Device, for Part Programs, 7-4

Installing BDS, 2-4

Integrand Words, 9-22

Interrupted Program Recover, {MID ST
PROGRAM}, 7-24

Italian, Language Display, 8-10

J

J-word, 9-22

Japanese, Language Display, 8-10

Jog Offset, 10-17

Jog Offset Function, 4-4

Jog Retract, 7-27

Jog Select, 2-17

Jogging

- Continuous Jog, 4-3
- Incremental Jog, 4-3
- Jogging an Axis, 4-2
- Jogging an Offset, 4-4
- Jogging at Rapid (TRVRS), 2-18

K

K-word, 9-22

Keyboard, Performing CNC Functions with,
2-11

L

L-words, 9-15, 9-27

Languages, Changing, 8-10

Lathe Cycles, 5-18

Left-hand Tapping Cycle (G84.1), 25-17

Limits

- Hardware, 11-2
- Resetting, 11-12
- Software, 11-3

Line Display, 2-16

Line Editor

- Creating a Blank Line, 5-10
- Creating a New Line, 5-10
- Cut & Paste, 5-6
- Deleting Lines, 5-11
- Dimensions, 5-8
- Entering Blocks, 5-10
- Including a Part Program, 5-7
- Navigating Through, 5-8
- Numbering Lines, 5-11
- Recovering Lines, 5-11
- Saving and Exiting, 5-8
- Search Softkey, 5-12

Linear Acc/Dec, 17-11

Linear Interpolation Mode (G01), 13-3

Local Parameters, 27-11

Logic, Offsets, 10-20

Logic Execution

- Asynchronous Mode, 7-22
- Autosynchronous Mode, 7-23
- Synchronous Mode, 7-22

LZS, Using, 9-12

M

M-code Status Display, 8-7

M-code Table, 9-23

M-Codes

- M00 Program Stop, 27-35
- M01 Optional Program Stop, 9-24
- M03 Primary Spindle Clockwise, 16-11
- M04 Primary Spindle Counterclockwise,
16-11
- M05 Primary Spindle Stop, 16-11
- M19 First Spindle Orient, 16-9
- M19.2 Spindle 2 Orient, 16-9

M-codes

- group number, 9-23
- M00 Program Stop, 9-24
- M02 End of Program, 9-24
- M30 End of Program with Tape Rewind,
9-24
- M48 Overrides Enabled, 9-24
- M49 Override Disabled, 9-25
- M58 Constant Surface Speed Enable,
9-25
- M59 Constant Surface Speed Disable,
9-25
- M98 Subprogram Call, 9-25
- M99 End of Main Program with Auto
Start, 9-25
- M99 End of Subprogram or Paramacro,
9-25
- Table of, 9-23

M-Word

- M98, 9-7
- M99, 9-8

Machine (Absolute) Coordinate System,
10-1

Machine Coordinate Position,

Time-dependent Paramacros, 27-20

Machine Coordinate System, Motion in the
Machine Coordinate (G53), 10-2

Machine Home Return (G27), 13-16

Machine Messages, 2-31

Clearing Active Messages, 2-33

Macro

- Call Commands, 27-35
- Nesting, 27-43

MACRO PARAM, SoftkeyTree, A-7

Magnification Data Screen, 12-9

- Main Program Jumps, 9-27
 - Main Program Returns, 9-8
 - Manual (Operator's), Design, 1-1
 - Manual Operating Mode, 4-1
 - Manuals, Other, 1-5
 - Mathematical
 - Function Commands, 27-3
 - Operators, 27-2
 - MDI Basic Operation, 4-10
 - MDI Mode, 4-9
 - Memory, Search with Recall, 7-10
 - Message, at PTO, 8-11
 - Metric Mode (G71), 12-4
 - Mid-start Program, 7-10
 - Mill Cycles, 5-18
 - Mirror Image, 13-19
 - Mirroring on a Dual Axis, 18-6
 - Mirroring, Manual and Programmed, 13-19
 - Miscellaneous Function, 9-26
 - Miscellaneous Function Lock, 7-1
 - Modal Paramacro Call
 - G66, 27-37
 - G66.1, 27-39
 - Mode, G-code Display, 8-10
 - Move to Alternate Home (G30), 13-17
 - MTB Panel, 2-16
 - Function of Buttons or Switches, 2-17
 - Push-button, 2-17
 - defaults at power turn on, 2-16
 - Multilevel Delete, 9-5
- N**
- N-word, 9-27
 - Naming Part Programs, 5-2
- O**
- O.D. & I.D. Finishing Routine (G72), 23-34
 - O.D. & I.D. Grooving Cycle (G77), 22-6
 - O.D. & I.D. Multipass Threading Routine (G78), 24-20
 - O.D. & I.D. Roughing Routine (G73), 23-2
 - O-words, 9-27
 - OCI
 - Editor, 5-1
 - Starting, 2-3
 - OCI Terms, 1-4
 - ODS, Downloading Part Programs, 6-5
 - ODS, Uploading Part Programs to, 6-9
 - OFFSET, SoftkeyTree, A-6
 - Offset
 - Alternating Using G10, 10-10
 - Coordinate Zero Points, 10-15
 - External, 10-9
 - Jog Offset, 10-17
 - Set Zero, 10-16
 - Work Coordinate System, 10-12
 - Offset Management for Dual Axis, 18-5
 - Offset Tables, 3-1
 - Backing up the Tool Offset Tables, 3-18
 - Setting Offset Tables, 3-8
 - Offsets
 - Cancel, 10-18
 - Cancel, Selectively, 10-20
 - Logic, 10-20
 - Offsets for Dual Axis, 18-7
 - Online Help, 5-3
 - Operating Modes, Changing, 2-29
 - Operator Messages, B-1
 - Operator Panel, Calculator Function, 2-12
 - Overflow Value, 27-35
 - Overtravel
 - Hardware, 11-2
 - Reset, 11-12
 - Software, 11-3
 - Zones, 11-1
 - Overtravels, 4-5
 - Overview, OCI vs. Standard Front Panel, 1-1, 18-1, 19-1
- P**
- P-words, 9-27
 - Panel, MTB Panel, 2-16
 - Paramacro Commands
 - AMP-defined
 - G macro call, 27-5, 27-41
 - M macro call, 27-42
 - T, S, B code macro call, 27-42
 - Block Look-Ahead, 20-49
 - Common Parameters, 27-14

- Control Commands, Transfers, 27-6
- DO-END, 27-9
- GOTO, 27-8
- IF GOTO, 27-8
- Local Parameter Assignments, 27-11
- Logic Parameters, 27-26
 - input flags, 27-26
 - Logic parameters, output flags, 27-27
- Nonmodal Paramacro Call (G65), 27-36
- Parameter Value Assignment, 27-28
 - through programming, 27-30
 - through tables, 27-31
 - using arguments, 27-28
- System Parameters, 27-14
- WHILE-DO-END, 27-9
- Parameters, Single-Pass Turning Cycles, 21-1
- Parametric Expressions, 27-2
- Parking a Dual Axis, 18-3
- Part Production/Automatic Mode, 7-19
- Part Program, Editing, 5-5
- Part Programs
 - Choosing a Directory, 2-40
 - Connecting to, 2-42
 - Copying, 2-40
 - Creating, 5-2
 - File Size, 2-42
 - Format, 2-42
 - Moving, 2-42
 - Numbered Part Programs, 5-2
 - Paramacros, 5-2
 - Storing, 2-39
 - Subprograms, 5-2
- Part Programs, Editing Offline, 6-2
- Parts Count Display, 2-35
- PASSWORD, SoftkeyTree, A-11
- Passwords, Entering, 2-28
- PC Keyboard, Performing CNC Functions with, 2-11
- Pecking Drill Cycle (G83.1), 25-13
- Personal Computers, for Part Programming, 6-1
- Plane Select
 - (G17, G18, G19), 25-4
 - Power-up Condition, 2-20
 - TTRC Initializing, 20-5
- Plane Selection, (G17, G18, G19), 12-1
- Position Display, 8-1
- Positioning a Dual Axis, 18-1
- Positioning and Hole Machining Axes, 25-4
- Positioning Axes, 13-1
- Power Loss, 2-3, 2-42
- Power Off, 2-18
- Power On, 2-18
- Power Up Conditions, 2-6
- Power Up Display, 8-11
- Power-Up Conditions, 2-20
- Preparatory Functions, 9-17
- Preset Work Coordinate Systems, 10-4
- PRGRAM CHECK, Softkey Tree, A-8
- PRGRAM MANAGE, SoftkeyTree, A-5
- Probing
 - Applications (G31), 26-3
 - Applications (G37), 26-5
 - Skip Function (G31), 26-2
 - Time-dependent Paramacros, 27-21
 - Tool Gauging, 26-3
- Program DTG Display, 8-8
- Program Names, 9-27
- Program Names, Entering, 9-3
- Program Position Display, 8-3
- Program Recover, 7-24
- Program Search, {SEARCH}, 7-8
- Program, Selecting, 7-5
- Programmable Acc/Dec, 17-13
- Programmable Synchronous/Asynchronous Block Execution, 7-21
- Programmable Zone 3, 11-7
- Programmable Zone Table, 3-20
- Programmable Zones, 11-1
- Programming Configuration, 9-1
- Programming Data and Backing up Tool Management Tables, 19-20
- Programs, Selecting an Input Device, 7-4
- PTO Message, 8-11
- PTO Screen, 8-11
- Publications, Additional, 1-5
- Pulldown Menus
 - Accessing, 2-6
 - File, 2-7
 - Options, 2-7

Select CNC, 2-8
Size, 2-8
Push-button MTB Panel, 2-16

Q

Quick Check, {QUICK CHECK}, 7-16
QuickPath Plus Words, 9-15

R

R-word, 9-15
Corner Radius, 15-3
Radius Mode (G07), 12-4
Random Tool, 19-7
Rapid Feedrate, 17-5
Rapid Feedrate Override, 2-18, 17-6
Rapid Positioning Mode (G00), 13-1
Recall, Search with Memory, 7-10
Resizing the Window, 2-8
Restarting BDS, 2-42
Revision, of software, 8-11
Right-hand Tapping Cycle (G84), 25-14
Rotary Axes, 13-8
Rough Facing Cycle (G24), 21-7
RPM Spindle Speed Mode, (G97), 16-7

S

S-Curve Acc/Dec, 17-12
S-words, 9-28
Saving Part Programs, 2-39
Scaling
(G14.1), 12-6
Axis Position, 12-9
Cancel (G14), 12-6
Display Screen, 12-9
Magnification Data Screen, 12-9
Restrictions, 12-11
Search
Program Search, 7-8
Search with Recall, 7-10
Selecting a Part Program Input Device, 7-4
Selecting Linear Acc/Dec Modes, Using
G47, 17-14

Selecting Linear Acc/Dec Values, Using
G48, 17-14
Sequence Numbers, 9-4, 9-27
Sequence Stop, {SEQ STOP}, 7-2
Servo Firmware Revision, 8-11
Servo Modules Installed, 8-11
Short Block Acc/Dec
Activate/Cancel (G36, G36.1), 17-18
Entry and Exit, 17-20
Shutdown
9/PC, 2-2
Uncontrolled, 2-2
Single Block, 7-3
Single Pass Rough Facing Cycle (G24),
21-7
Single Pass Threading Cycle (G21), 24-15
Single Pass Threading Mode (G33), 24-6
Single Pass Variable Lead Thread Cutting
(G34), 24-12
Skip and Gauging Functions, 26-1
Skip Signal Position Machine Coordinate
Position, Time-dependent
Paramacros, 27-21
Skip Signal Position Work Coordinate
Position, Time-dependent
Paramacros, 27-21
SoftkeyTree
Active Program, A-13
Axis Position Display Format, A-3
Backup Parameters, A-7
Edit Program, A-14
Error Message, A-10
Function Select, A-4
Macro Parameters, A-7
Offset, A-6
Password, A-11
Program Check, A-8
Program Manage, A-5
Switch Language, A-12
System Support, A-9
Softkeys, A-1
{CHANGE DIR}, 2-40
{CONFIG}, 5-13
{COPY PROGRAM}, 2-40
{CUT & PASTE}, 5-6
{DEL-LINE}, 5-11
{EXIT}, 5-8
{INCLUDE}, 5-7
{SEARCH}, 5-12
{SEQUENCE}, 5-11

- {SWITCH LANG}, 8-10
- ABS, 8-1, 8-4
- ACCESS CONTROL, 2-23
- ACTIVE OFFSET, 3-14
- ALL, 8-1, 8-9
- AXIS SELECT, 8-1
- BACKUP ALL, 27-34
- BACKUP COM1, 27-34
- BACKUP COM2A, 27-34
- BACKUP COM2B, 27-34
- BACKUP OFFSET, 3-19
- BLOCK DELETE, 7-1
- CHANGE DIR, 5-25
- COMMENT, 5-21
- COPY PROGRAM, 5-23
- DE-ACT PROGRAM, 7-7
- Definition, 2-8
- DELETE, 5-19
- DISPLY PROGRAM, 5-21
- DTG, 8-1, 8-6
- EDIT PROGRAM, 5-5
- ENTER MESSAGE, 8-12
- ERROR MESSAGE, 2-31
- G CODE, 8-1
- G CODE STATUS, 8-10
- GEOMET, 3-1
 - Layered, 5-3
- M CODE, 8-1
- M CODE STATUS, 8-7
- MACRO PARAM, 27-32
- MEASURE, 3-11
- MID ST PROGRAM, 7-10, 7-24
- MORE LIMITS, 3-21
- MORE OFFSET, 3-9
- PASSWORD, 2-24
- PLANE SELECT, 12-1
- PROGRAM, 8-1, 8-3
- PROGRAM CHECK, 7-16
- PROGRAM DTG, 8-8
- PROGRAM MANAGE, 5-25
- PROGRAM PARAM, 25-36
- PROGRAM DTG, 8-1
- PTOM SI/OEM, 8-11
- QUICK CHECK, 7-16
- RANDOM TOOL, 19-7
- REFORM MEMORY, 2-34
- RENAME, 5-20
- SEARCH, 7-8
- SELECT PROGRAM, 7-5
- SEQ STOP, 7-2
- SET ZERO, 10-16
- STRING SEARCH, 7-9, 7-12
- SYNTAX ONLY, 7-16
- TARGET, 8-1, 8-5
- TOOL GEOMET, 3-1
- TOOL MANAGE, 19-23
- TOOL WEAR, 3-1
- WEAR, 3-1
- WORK CO-ORD, 3-15
- ZONE LIMITS, 3-21
- Software Overtravel, 11-3
- Spanish, Language Display, 8-10
- Speed Multiply Switch, 2-17
- Spindle Acceleration, 17-18
- Spindle Button, 2-17
- Spindle Direction, 2-17
 - (M03, M04, M05), 16-11
- Spindle Orientation, (M19, M19.2, M19.3), 16-9
- Spindle Speed, 9-28
 - (S-word), 16-2
- Spindle Speed Control, 16-1
- Spindle Speed Override, 2-17
- Spindle Synchronization, 16-21, 16-22, 16-24
- Standard MTB Panel, 2-16
- Start-up Message, 8-11
- Starting and Stopping, 9/PC, 2-1
- Startup, 9/PC, 2-1
- Subprogram Call, 9-7
- Subprogram Calls, 9-27
- Subprogram Nesting, 9-9
- Subprogram Return, 9-8
- Subprogram, Using, 9-6
- Subprograms and Paramacros, 5-2
- Support, 1-5
- SWITCH LANG, SoftkeyTree, A-12
- Synchronized Spindle, 16-21, 16-22, 16-24
- Synchronous Mode, 7-22
- System A, G-Code, 12-3
- System Clock, Time-dependent parameters, 27-17
- System Error Messages, B-1
- System Integrator Message, 8-11
- System Requirements, 2-4
- System Startup Screen, 8-11
- SYSTEM SUPORT, SoftkeyTree, A-9
- System Timing Screen, 8-11

T

- T-Word, Programming T-word, 19-2
- T-word, 19-1
- T-words, 9-29
- Table of G-Codes, C-1
- Tape, Program Name for, 9-27
- Tapping Cycle Left and Right Hand, 25-14, 25-17
- Tapping Mode (G63), 17-17
- Target Position Display, 8-5
- Technical Support, 1-5
- Text, Changing Language, 8-10
- Text, Language Mode, 8-10
- Thread Cutting, 24-1
- Thread Cutting Cycle, Considerations, 24-2
- Threading
 - O.D. & I.D. Multipass Threading Cycle (G78), 24-20
 - Single Pass Threading Cycle (G21), 24-15
 - Single Pass Threading Mode (G33), 24-6
 - Single Pass Variable Lead Thread Cutting (G34), 24-12
- Time and Parts Count Display, 2-35
- Time-dependent Paramacros
 - Coordinates of commanded position, 27-20
 - Current following error, 27-22
 - Digital inputs, 27-26
 - Logic parameters, 27-26
 - input flags, 27-26
 - Machine coordinate position, 27-20
 - Skip Signal Position Machine Coordinate Position, 27-21
 - Skip Signal Position Work Coordinate Position, 27-21
 - System clock, 27-17
- Tool, Gauging (G37), 26-3
- Tool Directory Data, 19-13
- Tool Length Offset, 9-29
- Tool Management, Automatic, 19-12
- Tool Management, Programming, 19-23
- Tool Offset Table, 3-1
 - Tool Offset Dimensional Parameters, 3-3
- Tool Offsets, Activation, 19-4
- Tool Orientation Parameter, 3-5
- Tool Position, Coordinate Offset, 10-12
- Tool Selection, 9-29
- Tool Tip Radius Compensation (TTRC)
 - Block Generation, (G39, G39.1), 20-7
 - Block Look-Ahead, 20-49
 - Circular Transition (G39.1), 20-7
 - Corner Movement after Generated Blocks, 20-39
 - Cutter Radius Changes, 20-41
 - Cutting Tool Path, 20-29
 - Direction Changes, 20-34
 - Entry Moves
 - Type A, 20-9
 - Type B, 20-19
 - Error Detection, 20-49
 - Exit Moves
 - Type A, 20-13
 - Type B, 20-23
- G-Codes
 - Circular Transition (G39.1), 20-8
 - Linear Transition (G39), 20-8
 - Linear Transition (G39), 20-7
 - Machine Home (To/From), 20-47
 - MDI or Manual Motion, 20-45
 - Minimum Block Length, 20-8
 - Nonmotion Blocks, 20-38
 - Overview, 20-1
 - Programming Instruction, 20-4
 - Special Cases, 20-34
 - Work Coordinate System, Offsetting, 20-48
- TRVRS, 2-18
- Turing Cycle Operations, O.D. & I.D.
 - Finishing Routine (G72), 23-34
- Turning Cycle Operations
 - Casting/Forging Roughing Routine (G75), 23-27
 - Face Grooving Cycle (G76), 22-3
 - O.D. & I.D. Grooving Cycle (G77), 22-6
 - O.D. & I.D. Multipass Threading Cycle (G78), 24-20
 - O.D. & I.D. Roughing Routine (G73), 23-2
 - Roughing Facing Routine (G74), 23-14
 - Single Pass O.D. & I.D. Roughing Cycle (G20), 21-2
 - Single Pass Roughing Facing Cycle (G24), 21-7
 - Single Pass Threading Cycle (G21), 24-15
 - Single Pass Threading Mode (G33), 24-6
 - Single Pass Variable Lead Thread Cutting (G34), 24-12

Turning Operations, 21-1, 23-1, 24-1
Turning Routines, 23-1
TZS, Using, 9-12

U

Uncontrolled Shutdowns, 2-2
Uniform Acc/Dec, 17-11
Uninterruptible Power Supply, 2-2
Uploading Part Programs to ODS, 6-9
UPS, 2-2

V

Virtual C Axis, 16-11
 Cylindrical Interpolation, 16-13
 End Face Milling, 16-18

W

Window Resizing, 2-8
Windows NT, Shutdown of 9/PC via, 2-2
Word Descriptions, 9-15
Word Format, 9-10
Word Functions, 9-10
Work Coordinate System, 10-4
Work Coordinate System Data, 3-16
Work Coordinate System Offset Table,
 3-15
Work Coordinate System, Definition, 10-5

Z

Zones, 11-1
 Programmable Zone 2, 11-5
 Programmable Zone 3, 11-7
 Resetting, 11-12

www.rockwellautomation.com

Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe/Middle East/Africa: Rockwell Automation, Vorstlaan/Boulevard du Souverain 36, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846