



# **Portable Plasma / Flame CNC Cutting Machine**

USER MANUAL

SNR-BD

**Neri Machine Tools Pvt Ltd.**

[www.nerigroup.in](http://www.nerigroup.in)

**WE THANK YOU VERY MUCH FOR YOUR INTEREST SHOWN  
IN OUR PRODUCT.**

Before using this machine, please read the instruction carefully.


1. Open the package, please check the center unit, make sure it is not be broken, and make sure the packing list conform to the article.
2. Please make the voltage is ( AC220V±10%, and use the isolation transformer or other isolation voltage regulator device to make sure the system work stably. The machine must be grounded reliably when it is working.
3. Clean up dust on a regular basis to ensure the rail and rack clean.
4. The display screen of CNC system is easily broken, pay attention to protect it.
5. This machine should be operated by professional, with some operation and safety train information.
6. If there is something unclear, please contact with the local dealer or call the manufactures.

Content

1 Machinery part-----	3
2 CNC control system part-----	8

## Machinery Part

1 Put the crossed beam on the center unit, connect the line with the motor.




2. put the motor into the center unit.



3. Fix the four screws.



4. Put the security cover on the beam.





5. Fixed the screw of the security cover.



6. Install the anti-fire plate.



## How to use the special crossed beam trunkings?

- ① Loosen the screw, remove the anti-fire plate.
- ② Take the security cover from the center unit.
- ③ Loosen the screw of the trunking, take it out, put the plasma cable into the trunking, and cover it. Then install security cover and the anti-fire plate as following picture.





Ports details

**Parameter**

Input voltage	220V
Power frequently	50HZ
Rated power	180W
Display	5.7 inch
Effective cutting range	X-axis: 2000mm Y-axis: 1200mm
Speed	Flame cutting: 0-1000mm/min unload>8m Plasma cutting: 0-4000mm/min unload>8m
Cutting thickness	Flame cutting: 0-150mm Plasma cutting: 6-150mm
Transversal beam length (Y-axis)	1500mm
Longitudinal rails frame (X-axis)	2500mm
Total weight	80Kg
Gas depression	Max 0.1Mpa
Oxygen depression	Max 1.5Mpa
Befitting gas	Ethane, propane, methane

## CNC system part

### Chapter One Summarize

#### 1.1 System features

- 1) 5.7 high-definition lattice LCD, Small volume, Structure compact.
- 2) Processing graphics dynamic/static display.
- 3) High speed 16-bit and 8-bit single-chip microcomputer and hardware interpolator control. High speed running by 0.5 $\mu$  equivalent 6 meters/minute.
- 4) Step motor high subdivision control the driver , move smoothly, low noise, the quality improved clearly.
- 5) You can set begin speed and the time of rising/falling arbitrarily.
- 6) Supplying multiple constant loops to program simply.
- 7) Directly diagnose all input information of system, Convenience for you to check.
- 8) Multi-settings of parameter, can suit different requires.

#### 1.2 Technology norm

- 1) Pulse equivalent : X-axis 0.5 $\mu$  ( diameter ) Z-axis 1 $\mu$  ( or X axis 0.25 $\mu$ diameter )  
Z-axis 0.5 $\mu$  )
- 2) G00 Max-speed :  $\geq$  6 meter/minute(X-axis 0.25 $\mu$  ( diameter ) Z-axis 0.5 $\mu$ )
- 3) Number of connected shaft : 2 axis
- 4) Input coordinate scope : +/- 9999. 999mm
- 5) Maximum lines of user program : 540 line
- 6) User program space : 60K
- 7) Number of user program : 64
- 8) Dimension : 300\*200\*85



## Chapter Two System Operation and Function


### 2.1 Operate panel keyboard illustration



【F1】 - 【F6】 Function keys: Under different operate mode, they have different definition.

【 ◀ 】, 【 ▶ 】 Triangle sign Give up and quit : Definition of the left and right key is

same.



**【INS】** :Insert key under program state. Under others, it is used for increasing LCD brightness.

**【DEL】** :Delete key under program state. Under others, it is used for decreasing LCD brightness.

**【Pgup/ S↑】** :Page-up key under program state. Under automatic and manual function, it is used for adjust cutting-gun, when press/loosen the key, cutting-gun rising/stopping.

**【Pgdn/ S↓】** : Page-down key under program state. Under automatic and manual function, it is used for adjust cutting-gun, when press/loosen the key, cutting-gun falling/stopping.

**【Shift】** :Space key. It is used for distinguish between upper case and lower case under program editing state.

**【】** : Enter/Effective key

**【F↑】** :It is used for increase speed under automatic and manual control state, increase 1%/press once

**【F↓】** :It is used for decrease speed under automatic and manual control state, decrease 1%/press once



Strong current control :

Ignition automatically key under manual control state.



Strong current control :

Preheat oxygen key under manual control state



Strong current control :

Acetylene open key under manual control state



Strong current control :

Cutting oxygen key under manual control state




Strong current control :

Perforation key under manual control state

Strong current control :

Close all states under automatic and manual control state

## 2.2 Main interface of system working



Automatic	Manual	Editor	Parameter	Diagnosis	Return
-----------	--------	--------	-----------	-----------	--------

After power on , enter into main interface , please press **【F1】** — **【F6】** key and select function as follow:

**【F1】** Auto : Machining program automatically.

**【F2】** Manual: Manual adjusting the position of lathe.

**【F3】** Editor : Edit/modify machining program

**【F4】** Parameter : Parameter setting

**【F5】** Diagnosis : Checking input/output information of lathe.

**【F6】** Return : Lathe return to origin ( the position set by proximity switch )

Press **【G】 【G】 【3】** key , System will clear all contents of user program..

### 2.3 Auto function

Under main interface ,press **【F1】** key, System will enter into auto function and display as follow:

Speed : F* 100%=00000	Program : 0001	Number : 0000
<p style="font-size: 2em; margin: 0;">X +0000. 000</p>		Machining automatically Acetylene closed Preheat closed Cutting closed Cutting tip stop

Preheat : 0850

▶G92 X100YZ0  
G00 Y100

U +0000.000  
V +0000.000

Single segment	Manual	Free play	Graphics	Select segment	Return reference point
----------------	--------	-----------	----------	----------------	------------------------

\*The first line display : F× 〈magnification〉 %= 〈current speed〉 , current program name and the number of machining.

\*The medium display the current coordinate of X and Y by big character.

\*Under the coordinate the two lines are current continuous program, use '▶' indication.

\*Above line of the right indicate the state is automatic machining.

\*Under line of the right ,indicate current system state respectively ,including :Acetylene( switch ) ,

Preheat oxygen ( switch ) , Cutting oxygen ( switch ) , Cutting tip ( rising/falling/stopping ) .

\*Others indication :

M—Latest instruction M.

U , V—Increment coordinate.




## Operate under automatic function

- 1 . Press **【F1】** , System select single segment machining , Press **【F1】** again, give up. Under this state, Press **【Startup】** key once , System will run one instruction. Press **【Quit】** key , give up this function.
- 2 . Press **【F2】** ,System enter into manual state, concrete function refer manual function section.
- 3 . Press **【F3】** ,System enter into free play state , Press **【Startup】** system working, display the moving trace of cutting tip, But the operation of driver and I/O all closed to check whether program is correct.
- 4 . Press **【F4】** ,System enter into graphics machining tracking state. (referring the picture below)
- 5 . Press **【F5】** ,System select arbitrary segment to machining , '▶' represent the first line program that current running. Press **【↑】** and **【↓】** key ,you can select orderly the current program. Press **【Startup】** ,System will run from the selected program. Press **【Quit】** will give up select segment machining. Attention: Under select segment machining state, firstly, you should aim the cutting-gun to initiation position of program (easy aim). Press **【Startup】** begin to select segment machining. When appear 'Pause' sign, you can manual control the strong current switch to finish the prepare working, then press **【Startup】** ,System will begin to run from the selected segment.
- 6 . Press **【F6】** ,System will return automatically to reference point.
- 7 . When lathes are not running, you can select strong current key to control **Ignition, Acetylene opened/closed ,Preheat oxygen opened/closed, Cutting oxygen opened/closed** and **Cutting tip rising/falling/stopping**. Under normal machining state, the strong current keys are locked. Attention: Press ignition key , if acetylene key is not open , please open acetylene valve firstly ,then open ignition switch, after one ignition delay ( refer Parameter - **Control - Ignition delay** ) , close ignition switch. Press **【K1】** key will run a preheat perforation

procedure. ( refer M50 preheat perforation fixed cycle ) .Press **【K2】** key is general switch.

- 8 . Press **【F↑】** and **【F↓】** , you can increase or decrease speed magnification. Note: Manual and automatic magnification are saved respectively. The value immune to influence of power on/off.
- 9 . Press **【Pgup/S↑】** and **【Pgdn/S↓】** ,This two keys are compound. Under edition state, they are turn to page up and down.. Under this state they are used to control move up and down of cutting tip. Press **【Pgup/S↑】** ( or **【Pgdn/S↓】** ) cutting tip moving up ( or down ) ,loose it will stop.

#### Automatic graphics track



Under graphics mode, press **【F】** , the picture will double its size, Press **【F】** again , come back. Press **【↑】** , **【↓】** , **【→】** , **【←】** key will move the display window , you can observe every segment in detail.

- 10 . Press **【DEL】** key to clear counter.

## Reference point under automatic machining

**Reference point** is initial point of machining program ( set by G92 ) .One program run once ( include free play ) , Reference point will be saved automatically ( Also set by parameter ) .

Once reference point is set, orientation of reference point is very easy, as follows:

- 1 ) Please aim the knifepoint to special position of steel plate that waiting for cut ( know coordinate ) , set the current coordinate.
- 2 ) Under automatic or manual mode, if select return reference point function, system will automatically return to reference point.

## Startup under automatic machining

After all prepare work is ok, there are two means to startup the automatic machining program.

1. Press **【Startup】** .
2. Press outside "startup" button. ( refer chapter 6.1 "outside input interface" )

## Control and error compensate under automatic machining

After automatic machining beginning, only these keys are effect:

- 1 . **【Pause】** : Press this , system will decrease speed till stop. Execute instruction M according to the set of G61 to keep the current display contents. If press **【Startup】**, system will keep on running. Under pause state, if find deviation of dimension, you can press **【F2】** key to enter into manual state ( in inch state automatically, increment is 0.01mm ) , Operator press direction key to adjust the position of knifepoint, its move be considered compensation. Adjustment finished, press **【Startup】** system will neglect compensation movement and keep on running according to before adjustment. If press **【Quit】** , system will return to main picture.

Error compensation under pause state is reference point's compensation in fact.

- 2 . **【F↑】**, **【F↓】** Moving axis adjust speed key: Increase or decrease speed magnification, change 1% once.

3 . **【Pgup/S↑】** , **【Pgdn/S↓】** Control cutting gun rising or falling ,Press key, cutting gun rising or falling, loose it will stop.

4 . **【Stop】** : Outside button ( refer chapter 6.1 “outside input interface” ) , Signal can derive from input port. All stop when this key is effect.

### **Return and renew machining according to original track**

During machining, because of cutting incompletely, need return and renew machining, You can deal with as follow:

1 . Press **【Pause】** , system will decrease speed till stop and display " pause " sign. Prompt ( Graphics mode ) " F 2 manual F 6 return " ,Press **【F2】** can enter into manual compensation function ( refer below ) , press **【F6】** can enter into return and renew machining function.

If select **【F6】** , System will hint:

**Return < - - - > forward**

Indication: Press **【←】** , System will return along original trace. Press **【→】** , System will forward along original trace base of return. During return, if reach position that want to return, You can press **【Pause】** again, repeat the above-mentioned procedure, select again keep on returning or forward.

2 . You may press **【Pause】** again when system get to the return position , After system stop Steady, you can press the strong current key correspondingly ( like Preheat perforation, open cutting oxygen etc. ) , Press **【→】** again, and select machining forward.

3 . Above-mentioned operate can run repeatedly till get the satisfactory effect.

### **Break recover and power cut disposal**

When system pause by man-made, it will save automatically the current working trace (cutting tip's position) as a break. This break will be saved forever, regardless power off. Power on again or enter into automatic mode, if only the current program is not changed you can press **【G】** key to resume break. When find the break, system will hint " pause " state, You can press the strong current function key correspondingly (such as preheat perforation, open cutting oxygen etc.), Press **【Startup】** again, system will keep on running from break's position.



After machining pause, if you want to quit automatic state and enter into manual state to move cutting tip(whatever how much) , When press **【G】** key to begin resuming break, system will move the cutting tip to the position of break firstly, then resume break. Of course, if you changed the current coordinates by hand, the break will not be resumed normally.

If during machining, you encounter failure of electricity, you can enter into automatic mode firstly after get back electric power. Press **【F3】** key will set the current coordinate as break and recover like above-mentioned. Attention: This moment you must not move the cutting tip or set the current coordinate.

Only pause operation can generate break.

## 2.4 Manual function

Under main picture, press **【F2】** enter into manual mode, display:

Speed: F×100%=0000		Program : 0001		Number : 0000	
<p><b>X +00000.000</b></p> <p><b>Y +00000.000</b></p>		Manual operating			
		Acetylene closed			
<p>Preheat : 0850</p>		Preheat closed			
		Cutting closed			
		Cutting tip stop			
		M00			
		U 0000.000			
		V 0000.000			
		XY coordinate			
		G inch increment			
Inch moving	Manual Pulse		MDI	Return parameter	Test position

### Display under manual function

Like automatic mode , but have any distinction:

- 1 . Under left of the menu display the current increment value.
- 2 . Under right hint : Press **【G】** , you can modify the inch increment.
- 3 . Press **【X】** , you can modify the X value. Press **【Y】** , you can modify the Y value.

## Operate under manual function

- 1 . Press **【↑】** and **【↓】** to adjust the position of X axis ,Press direction- key correspondingly. The X axis will run by speed *the maximum speed limit* Manual magnification. Press **【→】** and **【←】** to adjust the position of Y axis. Press direction-key correspondingly, The Y axis will run by speed *the maximum speed limit* Manual magnification.
- 2 . Press **【F1】** , system will enter into **inch moving** state, Press the direction-key once, Motor will move one inch increment correspondingly. Press **【F1】** again, return to continue state. Press **【G】** key can change the inch increment.
- 3 . Press **【F2】** , system will enter into manual pulse mode, display as follow:

Speed : F×100%=0000		Program : 0001		Number : 0000	
X +00000.000		Manual operating			
		Acetylene closed			
Y +00000.000		Preheat closed			
		Cutting closed			
		Cutting tip stop			
		M05			
		U 0000.000			
		V 0000.000			
		XY coordinate			
X axis	Y axis	1.00	0.10	0.01	0.002

Enter into manual pulse mode,  
Press **【F1】** and **【F2】** to select  
X or Y axis.  
Select valid weight:  
**【F3】** - 1.00mm / pulse  
**【F4】** - 0.10mm / pulse  
**【F5】** - 0.01mm / pulse

- 4.Press **【F4】** ,system will select **MDI** function , Under this mode , You can directly input single segment program, such as :

G01 X100 Y200


After input one line, press **【Enter】** key to run at once. Press **【Quit】** key to cancel. **MDI** mode supports various G、 M、 S instructions. Note: The MDI instruction inputted will be saved till modified or power off.

5. Press **【F5】** ,System will control cutting tip return to reference point.
6. Press **【G】** will change the value of inch increment, hint: input increment value, then press enter key, this value will be saved till changed or power off.
7. Press **【X】** key to change value of X .hint: input coordinate of X ( Y ) axis, then press enter key, the coordinate of X and Y are changed at once; Press **【Y】** key to change value of Y .hint: input coordinate of Y axis, then press enter key, the coordinate of Y are changed at once
8. Press **【F6】** key , system enters into test-position function. Test-position is testing the precision distance from the current position of cutting tip to the origin of machine tool. Concrete usage: Firstly, You should aim the cutting tip to a special point ( such as reference point ) , test the current coordinate and modified ( press“X/Y” ) , Press **【F6】** key, cutting tip begin to return to origin of machine tool and save it as machine’s origin of parameter. Return-position is same to test-position from shape, but their results are not same: Return-position is that send the origin value of machine tool to current coordinates , but test-position is that send the current coordinate to origin of machine tool.
9. Press **【F↑】** and **【F↓】** ,you can adjust the manual magnification. Note: Manual and automatic magnification are saved respectively till changed and the value immune to influence of power off.
10. Press **【Pgup/S↑】** , **【Pgdn/S↓】** and strong-current key ,their usage is same to auto mode.

## 2.5 Parameter set

Under main working picture, Press **【F4】** can enter into parameter set function.

Displaying:



Every function item save parameter as follow:

**Speed**---- Start speed, Adjust time , Max speed.

**Adjustment**---- Software limit position , Origin , reverse clearance , reference point

**Control**----Machining speed limit, Ignition delay, Preheat delay, Cutting gun rising delay, Cutting gun falling delay, Perforation cutting gun rising delay, Perforation cutting gun falling delay.

**System**----Each axis's electric gear, Driver's subdivision.

**Save**----Save the changed parameters to parameter area.

### 2.5.1 Speed parameter

Press **【F2】** and select ( refer picture below )

Speed parameter setting						
Start speed : X		00250	Y	00250		
Adjust time : X		00040	Y	00040		
Max speed limit : X		05000	Y	05000		
Note	Cutter	Speed	Adjust	Control	System	Save

Means of each parameter refer left picture:


Start speed and max speed 's unit is mm/minute

time's unit is one percent second  
00040 express 0.4 second.

**The max speed limit** regulate the max speed of by-hand and G00.

### 2.5.2 Adjust parameter

Press **【F3】** and select adjust parameters ( refer picture below ) , Among these :





- 1 . Soft positive/negative-limit is system alarm when the current coordinate over the value set. If it is not used, you should set the parameter over the actual value.
- 2 . Origin value of machine tool is coordinate value relative to reference point in mechanical origin( use switch setting). If the machine tool do not set mechanical origin, you can set the origin value of machine tool as zero.
3. The reference point is defined as start point of program machining, G92 will be produced automatically when system running.
4. Reversal clearance should fill diameter when fill the value of X axis.

2.5.3

Adjust parameter settings					
Soft positive limit : X 1500.000 Z 1500.000					
Soft negative limit : X -1000.000 Z -1500.000					
Machine tool origin : X 0000.000 Z 0000.000					
Cutter	Speed	Adjus	Contr	Syste	Save

Press **【F4】** and select, refer picture below:


Control parameter settings					
Machining speed limit : 01000					
Ignition delay : 00050					
Preheat delay : 01000					
Cutting gun rising delay : 00200					
	Speed	Adjus	Contr	Syste	Save
		t	ol	m	

- 1 . **Machining speed limit** is set the max speed of G01,G02,G03. When program running, it will execute in this mode by default. When the set speed(F) low the machining speed limit, actual speed is according to F speed.

- 2 . **Ignition delay**----Keep up the electrified time of high-voltage ignition.
- 3 . **Preheat delay**----It is the preheat time when steel plate perforation, preheat time is adjustable. When preheat perforation, press **【Pause】** key, can delay automatically 150 seconds. Press **【Startup】** will stop preheating and save the actual preheat time to parameter.
- 4 . **Cutting gun rising delay**----It is used usually before G00 transfer .The cutting gun rise to suitable height in order to avoid knocking between cutting gun and steel plate.
- 5 . **Cutting gun falling delay**----Contrary to the above item, the cutting gun fall to suitable height. After transfer the G00,you should down the cutting gun before machining. Because of gravity, the time of falling is shorter than rising.
- 6 . **Perforation cutting gun rising**——Under fixed cycle of preheat perforation, cutting gun rising rapidly and perforation cutting gun rising delay. This moment open cutting oxygen and cutting gun begin falling and perforation cutting gun falling delay. Cutting gun rising before open cutting oxygen in order to avoid jamming the cutting gun’s gate when open cutting oxygen.
- 7 . **Perforation cutting gun falling**——Its usage refer the above item. Under fixed cycle of preheat perforation, it will finished after cutting gun falling and perforation cutting gun falling delay. Because of gravity, the time of falling is shorter than rising.

#### 2.5.4 System parameter

Press **【F5】** and select, refer picture below:



**Electric gear formula :**

$$N/M = \text{Micrometer thread pitch} * 1000 / (360 * \text{subdivision/Stepping angle} * \text{Transmission ratio})$$

Explaining : N—Numerator after simplified.

M—Denominator after simplified.

Micrometer thread pitch's unit : mm ;

Stepping angle unit : angel ;


Transmission =  $Z1/Z2$  = Motor's rotate speed / spindle rotate speed.

Formula can also be written:

$N / M$  = Pulse equivalent weight = Micrometer thread pitch\*1000/Pulse number of step motor that spindle rotate one circle

## 2.6 Program editing

This system program edit have two districts: Machining program and user program, refer picture below. There are battery to protect data from missing.



**Machining program edit area :** Current working program area ,only one current program. Once machining program be added from user program area to machining area(or new program), Regardless of new or modification executed in edit area and need not save program by saving means. Only when need change new program, the current program is saved to user program area by **【F3】** ,New or add new machining program **【F2】** from user program area.

**Program space:** 64K bites.

**Number of user program:** Save 64 user programs at best, but affected by the space of user program, When the user's program is long, the number of user program are saved will reduce relatively. When the user's program is short, the number of user program are not over 64, even though there have space.

**Length of machining program:** The max line is 540 that system supported.

Under main menu , press **【F3】** ,you can enter into edit function, refer the picture below:

```
001: G92 X0 Y100
002: G00 X-20
003: G01 X100 Y30
004: M03
005: G04 L100
006:M02
```

New	Add	Save	Delete	Delete line	Transfer
-----	-----	------	--------	-------------	----------

There are 6 items after enter into program edit state, function as follow:

- 1) **【F1】** – New program , Clear the area of program edit and start editing new machining program.
- 2) **【F2】** -- Call program , Call the existent program to the area of machining program edit and you can modify it.
- 3) **【F3】** -- Save the program of machining edit area to user's program area.
- 4) **【F4】** -- Delete existent program from user's program area.
- 5) **【F5】** --Delete the line of current edit program.
- 6) **【F6】** -- You can receive or send user program to computer or CNC system.

### 2.6.1 Edit

Enter into edit function, the current machining program will be displayed. You should pay attention to the several items as follow:

- 1) The faceplate keys have double kinds. One is compound key, the other is single function key. Usually press the compound key is the value of lower case, if you firstly press **【Shift】** ,then press compound key is the value of upper case, this function is effect only under program editing state.
- 2) Cursor move up and down: When cursor move up and down, the cursor will lie in the first line automatically. The cursor will move one line each press. When the cursor move out the first line of screen, if the front have program again, the screen will roll one line; When cursor move out the last line, if the last have program, the screen will roll one line backward.
- 3) Cursor move left and right: The cursor will move one character each press. When move to the first line, still press left is not effect. When move to the last, still press right is not effect.
- 4) Press **【F↓】** ,Cursor will move right to last line.
- 5) Turn page up and down: Press **【Pagup / S↑】** or **【Pagdn / S↓】** ,the screen will turn page forward or backward.

- 6) During machining program, the number is generated automatically.
- 7) Note of machining program: The note have important effect on add sub-program and transfer sentence when source program editing. When the line's first character is"—“or“。” , show this line is note.
- 8) This system's minimum resolution is 0.001mm。

### 2.6.2 New

Press **【F1】** ,select New.2

System hint: Are you continue?

If press **【Enter】** ,Clear the current editing area; if press **【Quit】** ,give up producing new program.

### 2.6.3 Call program

Press **【F2】** and select the program that be called user's program area. The system will listed the existent program's name, and the cursor will stay the current name of program. Move the cursor , you can select various program. After press **【Enter】** ,The selected program will be called into editing area; If press **【Quit】** ,it will give up the function of calling.

### 2.6.4 Save program

Press **【F3】** select save function, the system will hint:

Program name : 0001

The system display the current program name, you can modify it. If press **【Enter】** , it will save the program of machining edit area to the user's program area by the selected name. If press **【Quit】** ,it will give up the function of saving. Note: The document name is only four bits number.

### 2.6.5 Delete program

Press **【F4】** and select deleting the program of user program area. The system will listed the existent program's name, and the cursor will stay the current name of program. Move the cursor, you can select various program. After press **【Enter】** , The selected program will be deleted from user editing area; If press **【Quit】** ,it will give up the function of deleting.

### 2.6.6 Transport program

Press **【F6】** and select transport function. The system supports RS-232 communication. The program that transported is managed in machining edit area. Step as follow:

- 1 . Connect well two machines that will transport program by cable.
- 2 . Ensure the receive machine have no documents (if have, please first save it) that you want to reserve in machining edit area. Select again the function of transport—receive. The receiver should is receiving state.
- 3 . On the program transporter, Call the program that will be sent out to machining editing area, then select **Edit—Transport—Send out。**
- 4 . When transporting finished , Save the received programs.

## Chapter three Instruction system

### 3.1 Programming symbol explanation

Every action of CNC machining should run according to regulated program. Every machining program is composed of some instruction-segment, Every instruction-segment is composed of some function-word. Every function-word must start by character, followed by parameter.

**The definition of function-word :**

N	The number of instruction-segment
G	Prepare function
M	Auxiliary function
S	Principal axis
L	Cycle frequency
X	X axis (diameter) definitely coordinates
Y	Y axis definitely coordinates
U	The increment of X axis relatively current position
V	The increment of Y axis relatively current position
I	when machining arc, Value of coordinates that the center of a circle subtract the value of start point that X axis.
J	When machining arc, Value of coordinates that the center of a circle subtract the value of start point that X axis.
R	Specify arc radius
F	Specify machining speed, use for G01、 G02、 G03

**Note 1 :** Underneath explanation, Appointment as follows:

X[U]n -- It represent X or U, n represent value, but only appear once.

Y[V]n --It represent Y or V, n represent value, but only appear once too.


PPn -- Random axis combination, include one axis at least, it also can include two-axis.

**Note 2 :** Executing order, the up line will be executed first than next (except Jump and Call sub-program instruction),In the same program, M, S and T is executed first than G.

### **3.2 Coordinates system**

This system adopt standard coordinates system, that is right hand Descartes coordinates system, as follows:





### 3.3 G ( Basic prepare instruction )

#### 1) G92 reference point setting

When you set the program running, you must put the coordinate value of machining start ( reference point ) to the start of program, and set use definitely coordinates.

**Format: G92 Xn Yn**


If the content of X and Y don't follow G92, Current coordinates of X and Y be regarded as reference point. When use the origin of machining tool to locate, the content of X and Z don't follow G92.

#### 2) G00 dot moving

This instruction can carry out getting to specify position quickly. When two axis all have displacement, System will move straight from the start to destination by the most limited speed multiply magnification. When G00 exerting , it will be affected by speed magnification.

**Format : G00 X[U]n Z[W]n**

**or G00 PPn**



### 3) G01 Cutting along straight line


This instruction can carry out cutter get to straight specify position, As cutting instruction, Single axis or double axes can move along straight interpolation. the speed of process is specified by F instruction.

**Format :** G01 X[U]n Z[W]n [Fn]

or G01 PPn [Fn]

Example:G92 X0 Y0  
 G00 X200 Y95  
 G01 X80 Y235  
 (or G01 U-120 V145)  
 M02

- The current position of cutting-gun
- The anticipative position of cutting-gun




### 4) G02/G03 Arc cut

This instruction use for arc interpolation, it is divided into sequence arc G02( anticlockwise ), inverse arc 03 ( clockwise ) . For the setting of direction refer the picture below:

**Format:**G02[03] X[U]n Y[V]n In Jn [Fn] or : G02[03] X[U]n Y[V]n Rn [Fn]

G02[03]PPn In Kn [Fn] or : G02[03] PPn Rn [Fn]



- The position of current cutting-gun.
- The position of anticipative cutting-gun.

Example(G02):

```
G92 X0 Y0
G00 X40 Y50
G02 X160 V0 I60 J20
G28
M02
```

Example ( G03 ) :

```
G92 X0 Y0
G00 X40 Y50
G03 X160 V0 I60 J20
( or G03 X160 V0 R63.25 )
```

**Illustration:**

- The value of I and J is increment that relative to start point of X and Y direction center.(Center subtract start point).
- R is radius.(R is positive value, When arc $\leq 180^\circ$ , you can use R to represent radius.
- If you specified I , J, no R. If you specified R, no I and J.

**5) G04 Pause / delay instruction**

This instruction can be used for set time delay, When program run this instruction, The program will delay according to the L defined. Unit is second.

**Format: G04 Ln**

Example:G04 L2.4 ( delay 2.4 second )

When during run G04, Press **【Start】** key, it will stop delay, continue to run program that behind

G04.Press **【Quit】** key, it will stop the run of current program.

**6) G26,G27,G28 return to reference point**

Implement this instruction, Cutter can return to reference point automatically.

**Format: G26**

**X axis return to reference point**

**G27**

**Z axis return to reference point**

**G28**

**X and Z axis return to reference point simultaneously**

Example: G28 ( X and Z axis return to reference point simultaneously, equal to G00 )

### 7) G97 Jump sentence

This instruction can make program jump automatically to specified section running.

**Format: G97 Nn**

```
Example: N000 G92 X100 Y100
          N001 G00 X70 Y80
          N002 G01 W-30
          ○○○○
          N151 G28
          N152 G97 N1          ( jump to instruction that No N001 running )
          M02
```

The above program is a endless loop, usually it is used for check the stability of system and mechanism.

### 8 ) G98/G99 Call sub-program

The use of G98 and G99 need cooperating, G98 is call instruction and G99 is return instruction.

**Symbol : G98 Nn ( N is the first segment number of subprogram that will be called )**

**G99**

```
Example : N001 G92 X100 Y100
          N002 G00 X50 Y80
          N003 G98 N20          - Call first subprogram
          N004 G01 W-10
          N005 G98 N25          - Call secondly subprogram
          ○○○○
          N019 M02          - Program finished
          N020 G02 U0 V-20 R10 - The first subprogram
          N021 G03 U0 V-20 R10
          N022 G99          - The first subprogram return
          N023 *          - Two note lines, adjust the position of subprogram
          N024 *
          N025 G01 U2 V-1 - The second subprogram
          N026 G01 V-5
          N027 G98 N20 - Subprogram nesting, call subprogram one.
```

N028 G01 V-5  
 N029 G99 - Subprogram two return.

Note: Subprogram can call subprogram(named nesting), System permit subprogram that have five nesting.

### 8) G22/G80 Cycle sentence

This instruction can be used to run program cycle, G22 is the start that cycle body, and specified the cycle times L. G80 is the finished sign of cycle body. This instruction can nesting cycle, but don't allow over five. G22 and G80 make up a cycle body.

**Format:**            **G22 Ln\_            ( L is the specified times )**  
                          **Cycle body**  
                          **G80                    ( Sign of cycle body finish )**

Example: N000 G92 X100 Y100  
 N001 G00 X60 Y80  
 N002 G22 L5                    - First layer cycle starting  
 N003 G00 V50 U-25  
 N004 G22 L5                    - Twice layer cycle starting  
 N005 G01 U5 V-10  
 N006 G80                        - Twice layer cycle finish  
 N007 G80                        - First layer cycle finish  
 N008 G28  
 N009 M02

### 9) G81 Machining piece add one

This instruction can make the machining piece add one.

**Format: G81**

## 3.4 M function and configuration files

### 1) M function

M00            Program pause instruction, Press **【Start】** , program will continue running.  
 M02            Program finish instruction, program is waiting state after run this.  
 M30            Same to M02  
 M10/M11      Acetylene valve on-off,M10(On),M11(Off)  
 M12/M13      Cutting oxygen valve on-off,M12(On),M13(Off)  
 M14/M15      Cutting-gun rising on-off,M14(On),M15(Off)

M16/M17	Cutting-gun descending on-off,M16(On) , M17(Off)
M24/M25	Preheat oxygen valve on-off,M24(On) , M25(Off)
M20/M21	Ignition on-off M20(on),M21(off)
M50	<p><b>Preheat perforation fixed circle</b>, operate order as follow:</p> <ol style="list-style-type: none"> <li>1.If acetylene valve isn't opened, turn on acetylene ignition;</li> <li>2.Cutting-gun descending(Cutting-gun descending delay, refer M71) ;</li> <li>3.Open preheat oxygen valve, start preheat delay. If the time of preheat is not enough, you can press【Pause】, the preheat time will delay automatically 150 seconds.</li> </ol> <p>If preheat is ok, you can press【Start】to finish preheat delay, and the pre-heat time will be saved automatically to preheat delay parameter.</p> <ol style="list-style-type: none"> <li>4.Cutting-gun rising (perforation cutting gun rising delay)</li> <li>5.Open cutting oxygen valve, at the same time cutting-gun descending(perforation cutting-gun delay) and start to run the latter program.</li> </ol>
M51	<p>Close cutting fixed cycle, opposite to M50. Operate order as follow:</p> <ol style="list-style-type: none"> <li>1.Colse cutting oxygen valve(M13) ;</li> <li>2.Cutting-gun rising (Cutting-gun rising delay, refer M70).</li> </ol> <p>M51 is often used before G00, put up cutting-gun to shift position and avoid colliding with steel plates.</p>
M52	<b>Ignition fixed cycle</b> , operate order: open acetylene valve(M10) and high-voltage ignition(M20), delay “ignition delay”, close high-voltage ignition(M21).
M70	<b>Cutting-gun rising fixed cycle</b> , operate order: open cutting-gun rising on-off(M14),delay “cutting-gun rising delay”, close cutting-gun rising on-off(M15).
M71	<b>Cutting-gun descending fixed cycle</b> , operate order: open cutting-gun descending on-off (M16), delay “cutting-gun descending delay”, close cutting-gun descending on-off (M17).
M80	General switch, after execute M80, all outputs will be closed.
M16/M17	Control output 4# on-off,M16(on),M17(off)
M18/M19	Control output 6# on-off,M18(on),M19(off)
M22/M23	Control output 7# on-off,M22(on),M23(off)
M40/M41	Control output 9# on-off,M40(on),M41(off)
M26/M27	Control output 10# on-off,M26(on),M27(off)
M28/M29	Control output 11# on-off,M28(on),M29(off)
M32/M33	Control output 12# on-off,M32(on),M33(off)
M34/M35	Control output 13# on-off,M34(on),M35(off)
M36/M37	Control output 14# on-off,M36(on),M37(off)
M38/M39	Control output 15# on-off,M38(on),M39(off)
M42/M43	Control output 16# on-off,M42(on),M43(off)

## 2) **Output configuration files**

In order to adapt for different user's request of output form, This system adapt configuration files to confirm:

- 1 . Specified M function after G60, it will output pulse signal. At the same time D parameter will specify pulse width. If G60 is not specified M function, it will output electric level form..
- 2 . M function that behind G61 instruction is need executed after carry out the Pause instruction.

## 3) **Output configuration files sentence contents:**

### **1.G60 : Specified M instruction that followed is pulse output.**

Format: G60 Mn... Dn

**Mn** – M function( You can specify eight M function at most or none.)

**Dn** – Delay time ( uniform delay time of above specified M function ) , unit: second, default value: 0.13 second.

Example: G60 M03 M04 M05 M10 M11 M12 M08 M09 D0.23

Explain: Specified M03 M04 M05 M08 M09 M10 M11 M12. Output is pulse signal that 0.23 second.

### **2.G61 : Specified the followed M instruction be used after Pause.**

Format: G61 Mn...

**Mn** – M function ( You can specify eight M function at most or none ) .

Example: G61 M05 M12 M22 M04 M09 M78

Explain: After system execute pause operation, requiring execute M05 M12 M22 M04 M09 output. M78 express resuming automatically pause's output state when start again after pause.

## 4) **The usage of output configuration files:**

( Only execute once, if not amend the output form, it is not need to execute again. )

- 1.Enter program editing function.
- 2.Compile configuration files that include G60 and G61, named file again and save.
- 3.Entering automatic function, execute configuration files.



## Chapter Four System diagnosis

Under main function menu, Press **【F5】** and enter **System diagnosis** function, refer picture below:


Output:	M10	M12	M14	M16	M20	M18	M22
	M24						
	0	0	0	0	0	0	0
	0						
	M40	M26	M28	M32	M34	M36	M38
	M42						
	0	0	0	0	0	0	0
	0						
Input:	>X+	X-<	>Y+	Y-<	HAD	STP	PAU
	STA						
	1	1	1	1	1	1	1
	1						

System diagnosis display the opened hardware resource of current system. Under the pictudre of system diagnosis, you can check the interface that followed:


- 1 . **Output checking:** Cursor move to random position of 16 dots photo-electricity isolation output. Use “0 and 1” to change output state of electric level. 1 express set-bit, 0 express cancel. The definition of other output ports, please refer to 6.2 chapter. ( output ports definition ) .
- 2 . **Input checking:** Display the input state of current 16 dots photo-electricity isolation. ‘1’ express set-bit. ‘0’ express this port have no set-bit. The definition of other input ports, please refer to 6.1 chapter.( input ports definition).
- 3 . **Keyboard checking:** Press random key of 44 keyboard and display the value.
- 4 . **Coder checking:** Turn coder, the screen display coding angle signal cumulate value, rotate signal and checking thread No.
- 5 . **Hand-pulse generator checking:** Turn hand-pulse ,display direction electric level and the number of input pulse.

## Chapter five System inside connect


### 5.1 System inside structure picture



### 5.2 System power supply




5.3 CNC main-board



#### 5.4 Signal shifting board

J7 LCD inverter interface




## Chapter six System outside connect

### 6.1 Outside input interface

#### 1) Urgent stop / Start /Pause signal input


Urgent stop/Stop/Pause commonly use mechanical on-off, in order to avoid interfere, we usually use **normally off contact** of mechanical on-off, according to the followed picture to connect.




**Attention:** System require urgent stop, start ,pause and the logic of margin is uniform, this is all connect to normally on or normally off (in common use). After system start, it will check the state of **start bit** automatically and as control base. So, if don't connect external **start on-off**, the corresponding **start-bit** should be connected to **24V** ground (simple to connect to normally off contact) or connect none(simple to connect to normally on contact).

#### 2) Margin / origin signal input

**Margin/origin** usually use mechanical on-of or double thread magnet on-off and NPN, PNP Hall on-off. Toward use mechanical on-off or double thread magnet on-off , you can connect according to as the above item 1). If use NPN or PNP model Hall on-off, you can connect according to the picture below.





### 3 ) Definition of input ports

Signal definition	25 pin socket	Introduction
>X+	1	X+ margin, high-level is effect, if don't use, the signal connect to 24V ground.
X - <	14	X- margin, high-level is effect, if don't use, the signal connect to 24V ground.
> Y +	2	Y+ margin, high-level is effect, if don't use, the signal connect to 24V ground.
Y - <	15	Y - margin, high-level is effect, if don't use, the signal connect to 24V ground.
H A D	3	Manual/ Auto change selecting
S T P	16	External urgent stop key, high-level is effect, if don't use, the signal connect to 24V ground.
P A U	4	External pause key, high-level is effect, if don't use, the signal connect to 24V ground.
S T A	17	External start key, high-level is effect, if don't use, the signal connect to 24V ground.
X+	5	External manual control box, X+ positive control, high-level is effect, if don't use, the signal connect to 24V ground.
X -	18	External manual control box, X - positive control, high-level is effect, if don't use, the signal connect to 24V ground.
Y +	6	External manual control box, Y +positive control, high-level is effect, if don't use, the signal connect to 24V ground.


Y -	19	External manual control box, Y - positive control, high-level is effect, if don't use, the signal connect to 24V ground.
SP +	7	External manual control box's speedup control key, high-level is effect, if don't use, the signal connect to 24V ground.
SP -	20	External manual control box's speed-down control key, high-level is effect, if don't use, the signal connect to 24V ground.
UP	8	External manual control box's cutting-gun rising control key, high-level is effect, if don't use, the signal connect to 24V ground.
DOW	21	External manual control box's cutting-gun descending key, high-level is effect, if don't use, the signal connect to 24V ground.
24V	12,24	+24V/1A power source
24Vground	13,25	24V power source ground

## 6.2 Outside output interface

Explain: Control signal = 0 on-off/relay switch-on (+24V's circuit come into being loop,

low-level is effect, signal send out)

Control signal = 1 on-off/relay switch-off (+24V's circuit don't get, signal cancel)



### Output port definition (25 pins socket) ( hole )

Signal definition	Socket No	Instruction
M10/M11	1	Acetylene valve control, M10(on), M11(off)
M12/M13	14	Cutting oxygen control, M12(on), M13(off)
M14/M15	2	Cutting-gun rising control, M14(on), M15(off)




M16/M17	15	Cutting-gun descending control, M16(on), M17(off)
M20/M21	3	Ignition control, M20(on), M21(off)
M18/M19	16	Output port 6# control, M18(on), M19(off)
M22/M23	4	Output port 7# control, M22(on), M23(off)
M24/M25	17	Preheat oxygen valve control, M24(on), M25(off)
M40/M41	5	Output port 9# control, M40(on), M41(off)
M26/M27	18	Output port 10# control, M26(on), M27(off)
M28/M29	6	Output port 11# control, M28(on), M29(off)
M32/M33	19	Output port 12# control, M32(on), M33(off)
M34/M35	7	Output port 13# control, M34(on), M35(off)
M36/M37	20	Output port 14# control, M36(on), M37(off)
M38/M39	8	Output port 15# control, M38(on), M39(off)
M42/M43	21	Output port 16# control, M42(on), M43(off)
0-10V	9 , 22	0-10V Voltage output
24V	12,24	+24V / 1A Power source
24V ground	13,25	24V ground



### 6.3 Outside step-motor driver interface

Start Microstep CNC SH-2000TH


Start Microstep CNC MS serial driver



### Connect Start Microstep MS serial driver demonstration




## Connect Panasonic servo-driver demonstration



Driver signal interface definition:


Signal definition	15 pin socket
XDIR+	1
XDIR-	9
XCP+	2
XCP-	10
ZDIR+	3
ZDIR-	11
ZCP+	4
ZCP-	12

### 6.4 RS232 serial interface




RS232 interface definition:

Signal definition	9 pin socket
TXD	2
RXD	3
GND	5



9 pin socket

## Chapter seven System surface and setting dimension



Panel dimension: 270 X 170

### Appendix 1 Electronic gear fast check table

Stepping angle  $1.5 \cdot$  Transmission ratio 1:1 (  $360 \cdot$  subdivision  $\cdot$  transmission / stepping angle )

/micrometer thread pitch

Subdivisio n Screw-pitch mm)	5	10	20	40
3	5/2	5/4	5/8	5/16
4	10/3	5/3	5/6	5/12
5	25/6	25/12	25/24	25/48
6	5	15/6	5/4	5/8
8	20/3	10/3	5/3	5/6
10	25/3	25/6	25/12	25/24
12	10	5	15/6	5/4

Stepping angle  $0.75^\circ$  · Transmission ratio 1:1 (  $360 \cdot \text{subdivision} \cdot \text{transmission} / \text{stepping angle}$  )

/micrometer thread pitch

n Screw-pitch(mm)	Subdivisio	5	10	20	40
3		5/4	5/8	5/16	5/32
4		5/3	5/6	5/12	5/24
5		25/12	25/24	25/48	25/96
6		5/2	5/4	5/8	5/16
8		10/3	5/3	5/6	5/12
10		25/6	25/12	25/24	25/48
12		5	5/2	5/4	5/8

Stepping angle  $0.6^\circ$  · Transmission ratio 1:1 (  $360 \cdot \text{subdivision} \cdot \text{transmission} / \text{stepping angle}$  )

/micrometer thread pitch

n Screw-pitch (mm)	Subdivisio	5	10	20	40
3		1	1/2	1/4	1/8
4		4/3	2/3	1/3	1/6
5		5/3	5/6	5/12	5/24
6		2	1	1/2	1/4
8		8/3	4/3	2/3	1/3
10		10/3	5/3	5/6	5/12
12		4	2	1	1/2

Stepping angle  $1.8^\circ$  · Transmission ratio 1:1 (  $360 \cdot \text{subdivision} \cdot \text{transmission} / \text{stepping angle}$  ) /micrometer thread pitch

n Screw-pitch(mm)	Subdivisio	5	10	20	40
3		3	3/2	3/4	3/8
4		4	2	1	1/2
5		5	5/2	5/4	5/8
6		6	3	3/2	3/4
8		8	4	2	1
10		10	5	5/2	5/4
12		12	6	3	3/2

## Appendix 2 Error information table

Error code	Error contents
40H	'urgent stop' key press
41H	X axis positive margin
42H	X axis negative margin
43H	Y axis positive margin
44H	Y axis negative margin
45H	Software coordinates negative margin
46H	Software coordinates positive margin
01H	When programming, there are unwanted or illegal character
20H	Division overflow
21H	Arc ( G02 , G03 ) Start point or end point have error
22H	Arc ( G02 , G03 ) radius have error.
24H	Arc ( G02 , G03 ) term have error.
34H	Executing illegal operation

## Neri Machine Tools Pvt Ltd.

Plot No. 92/93, 7<sup>th</sup> Main, 3<sup>rd</sup> Phase, Peenya Industrial Area, Bangalore – 560 058 (India)

Phone: +91 80 28374885, Fax: +91 80 28397834, E-mail: sales@nerigroup.in

Website: www.nerigroup.in